



**GENUINE PARTS CATALOGUE
CATALOGUE PIECES D'ORIGINE
ORIGINAL ERSATZTEILKATALOG
CATALOGO DE PIEZAS LEGITIMAS
CATALOGO RICAMBI ORIGINALI**

This document has been printed from mye doc

MANITOU BF

Head office: 430, Rue de l'Aubinière
44150 Ancenis - FRANCE
Share capital: 39,548,949 euros
857 802 508 RCS Nantes
Tel: +33 (0)2 40 09 10 11
www.manitou.com

IMPORTANT

PARTS ORDER :

When placing an order, always state :

- Spare part ref. number
- Complete description
- Quantity
- Type of machine
- Machine serial number.
- Component identification number
(mast, jib, cab, engine, etc)

CAUTION :

Certain parts, or part assemblies illustrated in this catalogue are only supplied as options, and not with the standard machine.

SYMBOLS :

- └─▶ : From (machine, engine, date, etc.)
─▶┐ : Up to (machine, engine, date, etc.)

- □ : For (machine, engine, date, etc.)
□ □ : Except for (machine, engine, date, etc.)
◁ : See drawing

- , ■, ▲, ★, ⊗, ⊙, ⊕ : Up to } machine N°,
○, □, △, ☆, ⊗, ⊙, ⊕ : From } N° engine, cab,
transmission, etc.

This manual is for information purposes only. Any reproduction, copy, representation, recording, transfer, distribution, or other, in part or in whole, in any format is prohibited. The plans, designs, views, commentaries and instructions, even the document organization that are found in this document, are the intellectual property of MANITOU BF. Any violation of the aforementioned may lead to civil and criminal prosecution. The logos as well as the visual identity of the company are the property of MANITOU BF and may not be used without express and formal authorization. All rights are reserved.

IMPORTANT

COMMANDES DE PIECES :

Pour passer vos commandes, préciser toujours :

- N° de pièce rechange
- Désignation complète
- Quantité
- Type de machine
- N° dans la série de la machine
- N° d'identification du composant
(mât, flèche, cabine, moteur, etc.)

ATTENTION :

Certaines pièces ou montages de pièces illustrés dans ce catalogue sont livrés seulement en option et non avec la machine standard.

SYMBOLISATION :

- └─▶ : A partir de (machine, moteur, date, etc.)
─▶┐ : Jusqu'à (machine, moteur, date, etc.)

- □ : Pour (machine, moteur, etc.)
□ □ : Sauf pour (machine, moteur, etc.)
◁ : Voir planche

- , ■, ▲, ★, ⊗, ⊙, ⊕ : Jusqu'à } machine N°,
○, □, △, ☆, ⊗, ⊙, ⊕ : A partir } N° moteur, cabine,
transmission, etc.

La présente brochure n'est fournie qu'à titre consultatif, toute reproduction, copie, représentation, captation, cession, distribution, ou autre, partiellement ou en totalité, sous quelque format que ce soit est interdite. Les schémas, les dessins, les vues, les commentaires les indications, l'organisation même du document qui sont rapportés dans la présente documentation, sont la propriété intellectuelle de MANITOU BF. Toute infraction à ce qui précède est susceptible d'entraîner des condamnations civiles et pénales. Les logos ainsi que l'identité visuelle de l'entreprise sont la propriété de MANITOU BF et ne peuvent être utilisés sans autorisation expresse et formelle. Tous droits réservés.

WICHTIG

BESTELLUNG VON TEILEN :

Bei Ihrer Bestellung bitte immer folgende Daten angeben :

- Nr. des Ersatzteiles
- komplette Bezeichnung
- Menge
- Typ der Maschine
- Seriennummer der Maschine
- Identifikationsnummer des Bestandteiles
(Mast, Ausleger, Kabine, Motor, usw.)

ACHTUNG :

Bestimmte in diesem Katalog illustrierte Teile oder Montagen von Teilen werden ausschließlich als Option geliefert und nicht mit der Maschine in ihrer Standardausführung.

SYMBOLISIERUNG :

- └─▶ : Ab (Maschine, Motor, Datum, usw.)
─▶┐ : Bis (Maschine, Motor, Datum, usw.)

- □ : Bei (Maschine, Motor, Datum, usw.)
□ □ : Außer bei (Maschine, Motor, Datum, usw.)
◁ : siehe Tafel

- , ■, ▲, ★, ⊗, ⊙, ⊕ : Bis } Maschine N°,
○, □, △, ☆, ⊗, ⊙, ⊕ : Ab } Motor Nr, kabine,
Transmission, usw.

Die vorliegende Broschüre dient allein zur Beratung. Nachdruck, Fotokopieren, Vervielfältigung, Darstellung, Erfassung, Überlassung, Verbreitung oder Sonstiges (ganz oder teilweise) in jeglicher Form sind verboten. Die Entwürfe, Zeichnungen, Bilder, Darstellungen, Ansichten, Kommentare, Hinweise und der Aufbau der Druckschrift selbst, die in der vorliegenden Dokumentation enthalten sind, sind geistiges Eigentum von MANITOU BF. Alle Verstöße gegen das Vorstehende können zu straf- oder zivilrechtlicher Verfolgung führen. Die Logos und Markenzeichen sowie Unternehmens- und Produktbezeichnungen sind Eigentum von MANITOU BF und dürfen ohne ausdrückliche Genehmigung nicht verwendet werden. Alle Rechte vorbehalten.

IMPORTANTE

PEDIDOS DE PIEZAS :

Cuando efectúe sus pedidos, indique siempre :

- N° de pieza de recambio
- Designación completa
- Cantidad
- Tipo de máquina
- N° en la serie de la máquina
- N° de identificación del componente
(mástil, pluma, cabina, motor, etc.)

ATENCIÓN

Ciertas piezas o montajes de piezas ilustrados en este catálogo se suministran únicamente como opción y no con la máquina estándar.

SÍMBOLOS :

- └─▶ : A partir de (máquina, motor, fecha, etc.)
─▶ : Hasta (máquina, motor, fecha, etc.)

- □ : Para (máquina, motor, etc.)
□ □ : Salvo para (máquina, motor, etc.)
◀ : Ver la lámina

- , ■, ▲, ★, ⊗, ⊙, ⊕ : Hasta } máquina N°,
○, □, △, ☆, ⊗, ⊙, ⊕ : A partir } N° motor, cabina,
transmisión, etc.

Este folleto se ofrece a título meramente informativo y queda prohibida su reproducción, copia, representación, captación, cesión, distribución y demás, parcial o total, en el formato que sea. Los esquemas, dibujos, vistas, comentarios, indicaciones, la organización misma del documento aportado en esta documentación son propiedad intelectual de MANITOU BF. Cualquier infracción a lo antedicho puede acarrear condenas civiles y penales. Los logotipos y la identidad visual de la empresa son propiedad de MANITOU BF y no pueden utilizarse sin su autorización expresa y formal. Reservados todos los derechos.

IMPORTANTE

ORDINE DI PEZZI :

Per passare i vostri ordini, precisare sempre :

- N° pezzo di ricambio
- Descrizione completa
- Quantità
- Tipo di macchina
- N° di serie della macchina
- N° d'identificazione componente
(rampa, braccio, cabina, motore, ecc.)

ATTENZIONE :

Alcuni pezzi o montaggio di pezzi illustrati in questo catalogo vengono spediti solamente come optional e non con la macchina standard.

SIMBOLI :

- └─▶ : A partire da (macchina, motore, data, ecc.)
─▶ : Fino a (macchina, motore, data, ecc.)

- □ : Per (macchina, motore, ecc.)
□ □ : Escluso per (macchina, motore, ecc)
◀ : Vedere tavola

- , ■, ▲, ★, ⊗, ⊙, ⊕ : Fino a } macchina N°,
○, □, △, ☆, ⊗, ⊙, ⊕ : A partire da } N° motore, cabina,
trasmissione, ecc.

Il presente manuale è fornito esclusivamente a titolo di consultazione; è vietata qualsiasi riproduzione, copia, rappresentazione, acquisizione, cessione, distribuzione o altro, parziale o totale, e in qualsivoglia formato. Gli schemi, i disegni, le viste, i commenti, le indicazioni e l'organizzazione stessa del documento, riportati nella presente documentazione, sono proprietà intellettuale di MANITOU BF. Qualsiasi violazione a quanto riportato sopra è passibile di condanna civile e penale. I loghi e l'identità visiva dell'azienda sono di proprietà di MANITOU BF e non possono essere utilizzati senza previa autorizzazione espressa e formale. Tutti i diritti sono riservati.

GENERAL INSTRUCTIONS AND SAFETY NOTICE

_ADHESIVE SIGNS

12AA664 - ADHESIVE (647101)	1
12AA665 - ADHESIVE (647101)	3

FRAME - BODY

_ENGINE BONNET

9AA621 - BODY (647101)	5
9AA622 - BODY (647101)	8
9AA623 - BODY (647101)	10
9AA715 - BODY (647101)	13
9AA719 - BODY (647101)	16
9AA811 - BODY (647101)	19
9AA812 - BODY (647101)	22

_COUNTERWEIGHT

6AA647 - FRAME - COUNTERWEIGHT (647101)	24
---	----

_MUD GUARD (FENDER)

9AA620 - BODY (647101)	27
------------------------------	----

_SOUND PROOFING

9AA621 - BODY (647101)	See page 5
9AA623 - BODY (647101)	See page 10
9AA715 - BODY (647101)	See page 13
9AA719 - BODY (647101)	See page 16
9AA811 - BODY (647101)	See page 19
9AA812 - BODY (647101)	See page 22

_DRIVER CAB

8AA974 - CAB ADAPTATION (647101)	29
--	----

_TANK

4AC354 - FUEL CIRCUIT (647101)	32
--------------------------------------	----

_EXTERIOR REARVIEW MIRROR

9AA621 - BODY (647101)	See page 5
9AA715 - BODY (647101)	See page 13

_STABILIZER

6AA647 - FRAME - COUNTERWEIGHT (647101)	See page 24
---	-------------

ELECTRICITY

_Electronic unit - ECU

11CB1317 - ELECTRICITY (Details) (647101)	35
11CB1649 - ELECTRICITY (Details) (647101)	39

_CIRCUIT - HARNESS

11AA1639 - ELECTRIC CIRCUIT (647101)	42
11AA1643 - ELECTRIC CIRCUIT (647101)	45
11AA1647 - ELECTRIC CIRCUIT (647101)	47
11CB1306 - ELECTRICITY (DETAILS) (647101)	50
11CB1307 - ELECTRICITY (Details) (647101)	53
11CB1322 - ELECTRICITY (DETAILS) (647101)	57
11CB1323 - ELECTRICITY (DETAILS) (647101)	60
11CB1659 - ELECTRICITY (Details) (647101)	63
11CC312 - ELECTRICITY (Cab structure) (647101)	67

_LIGHTING - SIGNALING

11AA1639 - ELECTRIC CIRCUIT (647101)	See page 42
11CB1317 - ELECTRICITY (Details) (647101)	See page 35
11CB1322 - ELECTRICITY (DETAILS) (647101)	See page 57
11CB1323 - ELECTRICITY (DETAILS) (647101)	See page 60
11CB1649 - ELECTRICITY (Details) (647101)	See page 39

_ REEL

11CB1306 - ELECTRICITY (DETAILS) (647101)	See page 50
11CB1307 - ELECTRICITY (Details) (647101)	See page 53
11CB1659 - ELECTRICITY (Details) (647101)	See page 63

_ SWITCH

11CB1322 - ELECTRICITY (DETAILS) (647101)	See page 57
11CB1323 - ELECTRICITY (DETAILS) (647101)	See page 60
11CC312 - ELECTRICITY (Cab structure) (647101)	See page 67
6BB282 - PEDALS - LINKAGE (647101)	70
8AD361 - HEATING CIRCUIT (647101)	72

_ SAFETY SYSTEM

10EA357 - HYDRAULIC (Details) (647101)	74
11CB1306 - ELECTRICITY (DETAILS) (647101)	See page 50
11CB1307 - ELECTRICITY (Details) (647101)	See page 53
11CB1317 - ELECTRICITY (Details) (647101)	See page 35
11CB1649 - ELECTRICITY (Details) (647101)	See page 39
11CB1659 - ELECTRICITY (Details) (647101)	See page 63
11CC312 - ELECTRICITY (Cab structure) (647101)	See page 67
11CD233 - ELECTRICITY (ENGINE - TRANSMISSION) (647101)	76

_ SELECTOR - MANIPULATOR

10EA309 - HYDRAULIC (DETAILS) (647101)	78
11CB1317 - ELECTRICITY (Details) (647101)	See page 35
11CB1649 - ELECTRICITY (Details) (647101)	See page 39
11CC312 - ELECTRICITY (Cab structure) (647101)	See page 67
6BB282 - PEDALS - LINKAGE (647101)	See page 70
8AA975 - CAB ADAPTATION (647101)	80

AXLE ASSEMBLY - AXLE

_ REAR

3AA390 - WHEELS (647101)	83
3AA391 - WHEELS (647101)	85
AX2745 - REAR AXLE (647101)	87
AX2748 - REAR AXLE (647101)	89

_ FRONT

3AA390 - WHEELS (647101)	See page 83
3AA391 - WHEELS (647101)	See page 85
AX2744 - FRONT AXLE (647101)	91
AX2747 - FRONT AXLE (647101)	93

_ WHEELS

3AA390 - WHEELS (647101)	See page 83
3AA391 - WHEELS (647101)	See page 85

HYDRAULIC

_ CIRCUIT

-- ATTACHMENT

10AE1341 - HYDRAULIC (JIB CIRCUIT - ATTACHMENT) (647101)	95
10AE1355 - HYDRAULIC (Jib circuit - Attachment) (647101)	97
10AE1560 - HYDRAULIC (Boom circuit - Tilting) (647101)	99
10AE1561 - HYDRAULIC (Jib circuit - Attachment) (647101)	102

__ACUMULATOR	
10AE1365 - HYDRAULIC (Lifting circuit) (647101)	104
6BA341 - BRAKE CIRCUIT (647101)	107
6BA395 - BRAKE CIRCUIT (647101)	111
__AXLE LOCKING	
10AG307 - HYDRAULIC (Locking / Rear axle circuit) (647101)	115
__COMPENSATION	
10AE1366 - HYDRAULIC (Compensation - Jib feed circuit) (647101)	117
10AE1367 - HYDRAULIC (Compensation - Jib feed circuit) (647101)	120
__LEVELLING	
10AG304 - HYDRAULIC (STABILIZER-LEVELLING SYSTEM CIRCUIT) (647101)	123
10AG306 - HYDRAULIC (Levelling system circuit) (647101)	125
__STEERING	
10BA463 - HYDRAULIC (STEERING CIRCUIT) (647101)	127
__LIFTING	
10AE1365 - HYDRAULIC (Lifting circuit) (647101)	See page 104
__CENTRALISED GREASING	
17AA50 - LUBRIFICATION (647101)	131
__TILTING	
10AE1340 - HYDRAULIC (JIB CIRCUIT - TILTING) (647101)	133
10AE1354 - HYDRAULIC (Jib circuit - Tilting) (647101)	136
__MAIN	
10AA1032 - HYDRAULIC (PRINCIPAL CIRCUIT) (647101)	140
__COOLING SYSTEM	
4AA1211 - ENGINE - TRANSMISSION ADAPTATION (647101)	143
__EMERGENCY CIRCUIT	
10AF847 - HYDRAULIC (Emergency circuit) (647101)	146
__STABILIZER	
10AG304 - HYDRAULIC (STABILIZER-LEVELLING SYSTEM CIRCUIT) (647101)	See page 123
10AG305 - HYDRAULIC (Stabilizer circuit) (647101)	148
__TELESCOPING	
10AE1338 - HYDRAULIC (Telescope circuit) (647101)	150
10AE1339 - HYDRAULIC (TELESCOPE CIRCUIT) (647101)	152
10AE1353 - HYDRAULIC (Telescope circuit) (647101)	155
10AE1354 - HYDRAULIC (Jib circuit - Tilting) (647101)	See page 136
10AE1366 - HYDRAULIC (Compensation - Jib feed circuit) (647101)	See page 117
10AE1367 - HYDRAULIC (Compensation - Jib feed circuit) (647101)	See page 120
__FAN	
4AA1211 - ENGINE - TRANSMISSION ADAPTATION (647101)	See page 143
__DETAIL	
10AA1032 - HYDRAULIC (PRINCIPAL CIRCUIT) (647101)	See page 140
10AA1211 - HYDRAULIC (Principal circuit) (647101)	157
10AE1341 - HYDRAULIC (JIB CIRCUIT - ATTACHMENT) (647101)	See page 95
10AE1355 - HYDRAULIC (Jib circuit - Attachment) (647101)	See page 97
10AE1560 - HYDRAULIC (Boom circuit - Tilting) (647101)	See page 99
10AE1561 - HYDRAULIC (Jib circuit - Attachment) (647101)	See page 102
10BA463 - HYDRAULIC (STEERING CIRCUIT) (647101)	See page 127
10DA309 - VALVE BANK (647101)	160
10DA328 - VALVE BANK (647101)	162

10DA459 - VALVE BANK (647101)	164
10DA461 - VALVE BANK (647101)	167
10EA357 - HYDRAULIC (Details) (647101)	See page 74
2AA283 - FILTERS AND BELTS (647101)	170
AX2736 - GEAR BOX (647101)	172

_ VALVE BANK

10AA1031 - HYDRAULIC (Principal circuit) (647101)	174
10AA1032 - HYDRAULIC (PRINCIPAL CIRCUIT) (647101)	See page 140
10AA1211 - HYDRAULIC (Principal circuit) (647101)	See page 157
10DA309 - VALVE BANK (647101)	See page 160
10DA328 - VALVE BANK (647101)	See page 162
10DA459 - VALVE BANK (647101)	See page 164
10DA461 - VALVE BANK (647101)	See page 167
6BA341 - BRAKE CIRCUIT (647101)	See page 107
6BA395 - BRAKE CIRCUIT (647101)	See page 111

_ JOYSTICK

10AA1031 - HYDRAULIC (Principal circuit) (647101)	See page 174
10AA1211 - HYDRAULIC (Principal circuit) (647101)	See page 157
10EA309 - HYDRAULIC (DETAILS) (647101)	See page 78
6BB282 - PEDALS - LINKAGE (647101)	See page 70

_ PUMP

10AA1032 - HYDRAULIC (PRINCIPAL CIRCUIT) (647101)	See page 140
10AA1211 - HYDRAULIC (Principal circuit) (647101)	See page 157

_ TANK

10AA1031 - HYDRAULIC (Principal circuit) (647101)	See page 174
10AA1211 - HYDRAULIC (Principal circuit) (647101)	See page 157
10EA357 - HYDRAULIC (Details) (647101)	See page 74

_ RAM

__ AXLE LOCKING

10AG307 - HYDRAULIC (Locking / Rear axle circuit) (647101)	See page 115
10CF82 - HYDRAULIC - CYLINDER OF LOCKING REAR AXLE (647101)	177
10CF92 - HYDRAULIC - CYLINDER OF LOCKING REAR AXLE (647101)	179

__ COMPENSATION

10AE1366 - HYDRAULIC (Compensation - Jib feed circuit) (647101)	See page 117
10AE1367 - HYDRAULIC (Compensation - Jib feed circuit) (647101)	See page 120
10CB62 - HYDRAULIC (Compensation cylinder) (647101)	182
10CB78 - HYDRAULIC (Compensation cylinder) (647101)	184

__ LEVELLING

10CF91 - HYDRAULIC (Levelling system cylinder) (647101)	186
10CF93 - HYDRAULIC (Levelling system cylinder) (647101)	188
10AG306 - HYDRAULIC (Levelling system circuit) (647101)	See page 125
10CF51 - HYDRAULIC (Levelling system cylinder) (647101)	190

__ LIFTING

10AE1365 - HYDRAULIC (Lifting circuit) (647101)	See page 104
10CA297 - HYDRAULIC (Lifting cylinder) (647101)	192
10CA298 - HYDRAULIC (Lifting cylinder) (647101)	194
10CA448 - HYDRAULIC (Lifting cylinder) (647101)	196
10CA449 - HYDRAULIC (Lifting cylinder) (647101)	198

__ TILTING

10AE1340 - HYDRAULIC (JIB CIRCUIT - TILTING) (647101)	See page 133
10AE1354 - HYDRAULIC (Jib circuit - Tilting) (647101)	See page 136
10CD122 - HYDRAULIC (TILTING CYLINDER) (647101)	200

__ STABILIZER

10CF94 - HYDRAULIC (Stabilizer cylinder) (647101)	202
10AG305 - HYDRAULIC (Stabilizer circuit) (647101)	See page 148
10CF50 - HYDRAULIC (Stabilizer cylinder) (647101)	204

__TELESCOPING

10AE1338 - HYDRAULIC (Telescope circuit) (647101)	See page 150
10AE1339 - HYDRAULIC (TELESCOPE CIRCUIT) (647101)	See page 152
10AE1353 - HYDRAULIC (Telescope circuit) (647101)	See page 155
10CC131 - HYDRAULIC (Outer telescope cylinder) (647101)	206
10CC161 - HYDRAULIC (INNER TELESCOPE CYLINDER) (647101)	208
10CC171 - HYDRAULIC (Telescope cylinder) (647101)	210
10CC191 - HYDRAULIC (Outer telescope cylinder) (647101)	212
10CC193 - HYDRAULIC (Outer telescope cylinder) (647101)	216

TELESCOPIC BOOM

_ATTACHMENT

11CB1306 - ELECTRICITY (DETAILS) (647101)	See page 50
11CB1307 - ELECTRICITY (Details) (647101)	See page 53
11CB1659 - ELECTRICITY (Details) (647101)	See page 63

_DETAIL

5BA775 - BOOM (Simultaneous telescoping) (647101)	218
5BA776 - SEALING KIT ON BOOM (647101)	222
5BA784 - BOOM (Simultaneous telescoping) (647101)	224
5BA785 - SEALING KIT ON BOOM (647101)	232
5BA786 - BOOM (SIMULTANEOUS TELESCOPING) (647101)	234

_REEL

11CB1306 - ELECTRICITY (DETAILS) (647101)	See page 50
11CB1307 - ELECTRICITY (Details) (647101)	See page 53
11CB1659 - ELECTRICITY (Details) (647101)	See page 63

_FORK CARRIAGE

5BA775 - BOOM (Simultaneous telescoping) (647101)	See page 218
5BA784 - BOOM (Simultaneous telescoping) (647101)	See page 224

ENGINE

_ENGINE UNIT

2AA283 - FILTERS AND BELTS (647101)	See page 170
4AA1195 - ENGINE - TRANSMISSION ADAPTATION (647101)	238
AP2252 - ENGINE ADAPTATION (647101)	240
AP2278 - ENGINE ADAPTATION (647101)	243

_COMPLETE

AP2252 - ENGINE ADAPTATION (647101)	See page 240
AP2278 - ENGINE ADAPTATION (647101)	See page 243

_ELECTRICITY

11AA1647 - ELECTRIC CIRCUIT (647101)	See page 47
11CB1322 - ELECTRICITY (DETAILS) (647101)	See page 57
11CB1323 - ELECTRICITY (DETAILS) (647101)	See page 60
11CD233 - ELECTRICITY (ENGINE - TRANSMISSION) (647101)	See page 76

_FILTERS-BELT

2AA283 - FILTERS AND BELTS (647101)	See page 170
4AA1197 - ENGINE - TRANSMISSION ADAPTATION (647101)	245
4AA1201 - ENGINE - TRANSMISSION ADAPTATION (647101)	247
4AC354 - FUEL CIRCUIT (647101)	See page 32
AP2252 - ENGINE ADAPTATION (647101)	See page 240
AP2278 - ENGINE ADAPTATION (647101)	See page 243

_INTAKE SYSTEM - EXHAUST

11CB1322 - ELECTRICITY (DETAILS) (647101)	See page 57
11CB1323 - ELECTRICITY (DETAILS) (647101)	See page 60
4AA1197 - ENGINE - TRANSMISSION ADAPTATION (647101)	See page 245
4AA1201 - ENGINE - TRANSMISSION ADAPTATION (647101)	See page 247

_ FUEL SUPPLY SYSTEM

4AA1211 - ENGINE - TRANSMISSION ADAPTATION (647101)	See page 143
4AC354 - FUEL CIRCUIT (647101)	See page 32
AP2252 - ENGINE ADAPTATION (647101)	See page 240
AP2278 - ENGINE ADAPTATION (647101)	See page 243

_ ELECTRICAL SYSTEM

11AA1647 - ELECTRIC CIRCUIT (647101)	See page 47
11CB1322 - ELECTRICITY (DETAILS) (647101)	See page 57
11CB1323 - ELECTRICITY (DETAILS) (647101)	See page 60
11CD233 - ELECTRICITY (ENGINE - TRANSMISSION) (647101)	See page 76

_ COOLING SYSTEM

4AA1208 - ENGINE - TRANSMISSION ADAPTATION (647101)	250
4AA1209 - ENGINE - TRANSMISSION ADAPTATION (647101)	252
4AA1210 - ENGINE - TRANSMISSION ADAPTATION (647101)	254
4AA1211 - ENGINE - TRANSMISSION ADAPTATION (647101)	See page 143
4AA1221 - ENGINE - TRANSMISSION ADAPTATION (647101)	256
4AA1237 - ENGINE - TRANSMISSION ADAPTATION (647101)	258
4AA1240 - ENGINE - TRANSMISSION ADAPTATION (647101)	260

PEDALS

_ BRAKING CIRCUIT

6BA341 - BRAKE CIRCUIT (647101)	See page 107
6BA395 - BRAKE CIRCUIT (647101)	See page 111

_ BRAKE PEDAL

6BA341 - BRAKE CIRCUIT (647101)	See page 107
6BA395 - BRAKE CIRCUIT (647101)	See page 111

_ LINKAGE

6BB282 - PEDALS - LINKAGE (647101)	See page 70
------------------------------------	-------------

DRIVER CAB

_ CAB

8AD361 - HEATING CIRCUIT (647101)	See page 72
-----------------------------------	-------------

_ HEATER - AIR CONDITIONING

11AA1643 - ELECTRIC CIRCUIT (647101)	See page 45
11CC312 - ELECTRICITY (Cab structure) (647101)	See page 67
8AA975 - CAB ADAPTATION (647101)	See page 80
8AD361 - HEATING CIRCUIT (647101)	See page 72

_ ELECTRICITY

11AA1643 - ELECTRIC CIRCUIT (647101)	See page 45
11CC312 - ELECTRICITY (Cab structure) (647101)	See page 67
8AA974 - CAB ADAPTATION (647101)	See page 29
8AA975 - CAB ADAPTATION (647101)	See page 80

_ DOOR - GLASS

8AA360 - SEAT (647101)	262
8AA974 - CAB ADAPTATION (647101)	See page 29

TRANSMISSION


_ GEAR BOX

11CD233 - ELECTRICITY (ENGINE - TRANSMISSION) (647101)	See page 76
--	-------------


AX2736 - GEAR BOX (647101)	See page 172
AX2744 - FRONT AXLE (647101)	See page 91
AX2745 - REAR AXLE (647101)	See page 87
AX2747 - FRONT AXLE (647101)	See page 93
AX2748 - REAR AXLE (647101)	See page 89



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	252767	Adhesive (white)	1		MT 1440 A ST3B, MT 1840 A ST3B
2	271507	Adhesive (white)	1		MT 1440 A ST3B, MT 1840 A ST3B
3	253610	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
4	240794	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
5	301934	Adhesive	1		MT 1840 A ST3B
6	301932	Adhesive	1		MT 1440 A ST3B
7	286970	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
8	302182	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
9	24653	name plate	3		MT 1440 A ST3B, MT 1840 A ST3B
10	234805	name plate	1		MT 1440 A ST3B, MT 1840 A ST3B
11	296998	name plate	2		MT 1440 A ST3B, MT 1840 A ST3B
12	302012	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
13	288430	name plate	1		MT 1440 A ST3B, MT 1840 A ST3B
14	259398	name plate	1		MT 1440 A ST3B, MT 1840 A ST3B
15	296741	name plate	2		MT 1440 A ST3B, MT 1840 A ST3B
16	293887	name plate	1		MT 1440 A ST3B, MT 1840 A ST3B
17	234798	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
18	217826	Adhesive	2		MT 1440 A ST3B, MT 1840 A ST3B
19	275329	Adhesive	4		MT 1440 A ST3B, MT 1840 A ST3B
20	270466	Adhesive	2		MT 1440 A ST3B, MT 1840 A ST3B
21	306583	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
22	305405	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
23	261707	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
24	261718	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
25	261703	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
26	261714	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
27	302333	Adhesive (white)	2		MT 1440 A ST3B, MT 1840 A ST3B
28	307508	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
29	307749	Adhesive (white)	1		MT 1440 A ST3B, MT 1840 A ST3B
30	309207	name plate	2		MT 1440 A ST3B, MT 1840 A ST3B
31	289101	name plate	5		MT 1440 A ST3B, MT 1840 A ST3B
32	288174	Adhesive	3		MT 1440 A ST3B, MT 1840 A ST3B
33	52501046	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	261307	Card	1		MT 1440 A ST3B, MT 1840 A ST3B
2	261308	Card	1		MT 1440 A ST3B
3	296889	Card	1		MT 1840 A ST3B
4	261552	Load chart	1		MT 1440 A ST3B
5	296885	Load chart	1		MT 1840 A ST3B
6	292240	Card	1		MT 1440 A ST3B
7	292235	Card	1		MT 1840 A ST3B
8	301934	Adhesive	1		MT 1840 A ST3B
9	301932	Adhesive	1		MT 1440 A ST3B
10	291899	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
11	317209	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
12	279142	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
13	297734	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
14	290183	name plate	1		MT 1440 A ST3B, MT 1840 A ST3B
15	297393	Adhesive	1		MT 1840 A ST3B
16	239596	Plate	1		MT 1440 A ST3B, MT 1840 A ST3B
17	268491	name plate	1		MT 1440 A ST3B, MT 1840 A ST3B
18	184276	name plate	1		MT 1440 A ST3B, MT 1840 A ST3B
19	302188	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
20	218653	Identification plate	1		MT 1440 A ST3B, MT 1840 A ST3B
21	261476	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
22	275395	Card	1		MT 1440 A ST3B, MT 1840 A ST3B
23	297251	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
24	266893	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
25	306582	Adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	301294	Plate	1		MT 1440 A ST3B, MT 1840 A ST3B
2	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
3	260503	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
4	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
5	260504	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
6	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
7	260505	Rear fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
8	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
9	301290	Front bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
10	260495	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
11	259986	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
12	276218	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
13	268255	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
14	61674	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
15	276220	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
16	275028	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
17	268255	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
18	301095	Rear bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
19	275028	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
20	295014	Rear case	1		MT 1440 A ST3B, MT 1840 A ST3B
21	295016	Rear case	1		MT 1440 A ST3B, MT 1840 A ST3B
22	295977	Bracket sheat	2		MT 1440 A ST3B, MT 1840 A ST3B
23	216927	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
24	298593	Washer	6		MT 1440 A ST3B, MT 1840 A ST3B
25	259601	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
26	259601	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
27	266454	Rearview mirror bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
28	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
29	256484	Rearview mirror	1		MT 1440 A ST3B, MT 1840 A ST3B
30	276221	Lateral axle case	1		MT 1440 A ST3B, MT 1840 A ST3B
31	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
32	276224	Complete flap	1		MT 1440 A ST3B, MT 1840 A ST3B
33	276225	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
34	276228	Flap	1		MT 1440 A ST3B, MT 1840 A ST3B
35	228248	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
36	54242	Nut	6		MT 1440 A ST3B, MT 1840 A ST3B
37	228248	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
38	268255	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
39	61674	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
40	73976	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	260557	Nut	3		MT 1440 A ST3B, MT 1840 A ST3B
42	282478	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
43	300838	support	1		MT 1440 A ST3B, MT 1840 A ST3B
44	232750	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
45	296027	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
46	232750	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
47	298594	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
48	204665	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
49	305294	Rearview mirror bracket	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	301942	Complete engine bonnet	1		MT 1440 A ST3B, MT 1840 A ST3B
2	301556	Capping	1		MT 1440 A ST3B, MT 1840 A ST3B
3	184828	hinge	3		MT 1440 A ST3B, MT 1840 A ST3B
4	61975	screw	6	486639, 501310, 750461, 55661F204071, 900891166371, 418802, 54768, 453479, Q28264, 485860, 488158	MT 1440 A ST3B, MT 1840 A ST3B
5	240822	screw	9		MT 1440 A ST3B, MT 1840 A ST3B
6	260555	nut	9		MT 1440 A ST3B, MT 1840 A ST3B
7	302165	seal	2		MT 1440 A ST3B, MT 1840 A ST3B
8	302166	seal	2		MT 1440 A ST3B, MT 1840 A ST3B
9	302163	Air spring bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
10	189172	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
11	302155	Air spring	1		MT 1440 A ST3B, MT 1840 A ST3B
12	282478	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
13	302213	Locking hook	2	798233	MT 1440 A ST3B, MT 1840 A ST3B
14	189172	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
15	302135	Locking hook	2		MT 1440 A ST3B, MT 1840 A ST3B
16	184036	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
17	198004	Nut	4		MT 1440 A ST3B, MT 1840 A ST3B
18	306091	Air spring	1		MT 1440 A ST3B, MT 1840 A ST3B
19	798232	support	1		MT 1440 A ST3B, MT 1840 A ST3B
20	798233	hook	2		MT 1440 A ST3B, MT 1840 A ST3B
21	798396	Reinforcing	2		MT 1440 A ST3B, MT 1840 A ST3B
22	240822	screw	9		MT 1440 A ST3B, MT 1840 A ST3B
23	798397	Sound proofing foam	1		MT 1440 A ST3B, MT 1840 A ST3B
24	304235	knee-joint	1		MT 1440 A ST3B, MT 1840 A ST3B
25	52507295	Complete engine bonnet	1		MT 1440 A ST3B, MT 1840 A ST3B

_ENGINE BONNET




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52507390	Complete motor compartment	1	311544	MT 1440 A ST3B, MT 1840 A ST3B
2	247501	Weatherstrip	1	183649, 75821, 259254, 183652, 75341, 283659, 210405, 183182, 211797, 250822, 252539, 76217, 183837, 191578, 229172	MT 1440 A ST3B, MT 1840 A ST3B
3	720909	Weatherstrip	1	183651, 183650, 252531, 196945, 229169, 252530, 191996, 229363, 183838, 191995, 229170, 191993, 229171	MT 1440 A ST3B, MT 1840 A ST3B
4	63547	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
5	77710	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
6	271669	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
7	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
8	273063	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
9	273170	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
10	301504	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
11	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
12	299451	L.H. rear sound proofing foam	1		MT 1440 A ST3B, MT 1840 A ST3B
13	52508144	R.H. rear sound proofing foam	1	302945	MT 1440 A ST3B, MT 1840 A ST3B
14	241391	button	11	239411	MT 1440 A ST3B, MT 1840 A ST3B
15	295601	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
16	259601	Screw	8		MT 1440 A ST3B, MT 1840 A ST3B
17	297869	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
18	190427	bumper	2		MT 1440 A ST3B, MT 1840 A ST3B
19	58528	nut	2		MT 1440 A ST3B, MT 1840 A ST3B
20	300226	cable	1		MT 1440 A ST3B, MT 1840 A ST3B
21	300297	Side bonnet	1		MT 1440 A ST3B, MT 1840 A ST3B
22	168746	clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
23	7242	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
24	593698	Locker	2		MT 1440 A ST3B, MT 1840 A ST3B
25	226606	screw	4	229591	MT 1440 A ST3B, MT 1840 A ST3B
26	685568	hook	2		MT 1440 A ST3B, MT 1840 A ST3B
27	226606	screw	4	229591	MT 1440 A ST3B, MT 1840 A ST3B
28	223902	Locker	2		MT 1440 A ST3B, MT 1840 A ST3B
29	184036	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
30	184775	Nut	4	127107, 562604, 551846	MT 1440 A ST3B, MT 1840 A ST3B
31	297830	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
32	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
33	273225	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
34	273170	washer	3		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
35	273063	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
36	52507255	bonnet	1		MT 1440 A ST3B, MT 1840 A ST3B
37	52506181	lock	2		MT 1440 A ST3B, MT 1840 A ST3B
38	226606	screw	6	229591	MT 1440 A ST3B, MT 1840 A ST3B
39	184818	key	1		MT 1440 A ST3B, MT 1840 A ST3B
40	797819	Lock	2		MT 1440 A ST3B, MT 1840 A ST3B
41	306915	Sludge door	1		MT 1440 A ST3B, MT 1840 A ST3B
42	259601	Screw	5		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	301294	Plate	1		MT 1440 A ST3B, MT 1840 A ST3B
2	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
3	260503	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
4	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
5	260504	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
6	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
7	311298	Rear fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
8	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
9	301290	Front bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
10	260495	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
11	259986	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
12	276218	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
13	268255	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
14	61674	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
15	276220	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
16	275028	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
17	268255	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
18	311297	Rear bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
19	275028	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
20	295014	Rear case	1		MT 1440 A ST3B, MT 1840 A ST3B
21	295016	Rear case	1		MT 1440 A ST3B, MT 1840 A ST3B
22	295977	Bracket sheat	2		MT 1440 A ST3B, MT 1840 A ST3B
23	216927	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
24	298593	Washer	6		MT 1440 A ST3B, MT 1840 A ST3B
25	259601	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
26	259601	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
27	303904	Rearview mirror bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
28	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
29	299493	rearview kit	1		MT 1440 A ST3B, MT 1840 A ST3B
30	276221	Lateral axle case	1		MT 1440 A ST3B, MT 1840 A ST3B
31	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
32	276224	Complete flap	1		MT 1440 A ST3B, MT 1840 A ST3B
33	276225	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
34	276228	Flap	1		MT 1440 A ST3B, MT 1840 A ST3B
35	228248	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
36	54242	Nut	6		MT 1440 A ST3B, MT 1840 A ST3B
37	228248	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
38	261493	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
39	61674	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
40	73976	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	309713	Nut	3		MT 1440 A ST3B, MT 1840 A ST3B
42	54242	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
43	300838	support	1		MT 1440 A ST3B, MT 1840 A ST3B
44	232750	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
45	296027	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
46	232750	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
47	298594	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
48	204665	Nut	3		MT 1440 A ST3B, MT 1840 A ST3B
49	797820	mirror	2		MT 1440 A ST3B, MT 1840 A ST3B
50	798238	mirror	1		MT 1440 A ST3B, MT 1840 A ST3B
51	18805	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
52	61674	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
53	54242	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
54	310008	spacer	1		MT 1440 A ST3B, MT 1840 A ST3B
55	299496	Complete rearview mirror	1		MT 1440 A ST3B, MT 1840 A ST3B
56	297330	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
57	199976	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
58	259601	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
59	797820	mirror	1		MT 1440 A ST3B, MT 1840 A ST3B
60	797821	Rearview mirror bracket	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52507390	Complete motor compartment	1	311544	MT 1440 A ST3B, MT 1840 A ST3B
2	247501	Weatherstrip	1	183649, 75821, 259254, 183652, 75341, 283659, 210405, 183182, 211797, 250822, 252539, 76217, 183837, 191578, 229172	MT 1440 A ST3B, MT 1840 A ST3B
3	720909	Weatherstrip	1	183651, 183650, 252531, 196945, 229169, 252530, 191996, 229363, 183838, 191995, 229170, 191993, 229171	MT 1440 A ST3B, MT 1840 A ST3B
4	273225	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
5	273170	washer	3		MT 1440 A ST3B, MT 1840 A ST3B
6	271669	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
7	286341	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
8	273063	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
9	273170	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
10	301504	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
11	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
12	299451	L.H. rear sound proofing foam	1		MT 1440 A ST3B, MT 1840 A ST3B
13	52508144	R.H. rear sound proofing foam	1	302945	MT 1440 A ST3B, MT 1840 A ST3B
14	241391	button	11	239411	MT 1440 A ST3B, MT 1840 A ST3B
15	306915	Sludge door	1		MT 1440 A ST3B, MT 1840 A ST3B
16	286341	screw	5		MT 1440 A ST3B, MT 1840 A ST3B
17	297869	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
18	190427	bumper	2		MT 1440 A ST3B, MT 1840 A ST3B
19	58528	nut	2		MT 1440 A ST3B, MT 1840 A ST3B
20	300226	cable	1		MT 1440 A ST3B, MT 1840 A ST3B
21	311529	Side bonnet	1		MT 1440 A ST3B, MT 1840 A ST3B
22	168746	clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
23	7242	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
24	593698	Locker	2		MT 1440 A ST3B, MT 1840 A ST3B
25	226606	screw	6	229591	MT 1440 A ST3B, MT 1840 A ST3B
26	685568	hook	2		MT 1440 A ST3B, MT 1840 A ST3B
27	296364	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
28	303428	Locker	2		MT 1440 A ST3B, MT 1840 A ST3B
29	226606	screw	6	229591	MT 1440 A ST3B, MT 1840 A ST3B
30	184818	key	1		MT 1440 A ST3B, MT 1840 A ST3B
31	297830	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
32	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
33	797819	Lock	2		MT 1440 A ST3B, MT 1840 A ST3B
34	190427	bumper	1		MT 1440 A ST3B, MT 1840 A ST3B
35	310017	support	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
36	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
37	228575	Weatherstrip	2	242006, 242005, 261123, 282817, 286272	MT 1440 A ST3B, MT 1840 A ST3B
38	720909	Weatherstrip	1	183651, 183650, 252531, 196945, 229169, 252530, 191996, 229363, 183838, 191995, 229170, 191993, 229171	MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52500477	Motor compartment	1		MT 1440 A ST3B, MT 1840 A ST3B
2	247501	Weatherstrip	1	183649, 75821, 259254, 183652, 75341, 283659, 210405, 183182, 211797, 250822, 252539, 76217, 183837, 191578, 229172	MT 1440 A ST3B, MT 1840 A ST3B
3	720909	Weatherstrip	1	183651, 183650, 252531, 196945, 229169, 252530, 191996, 229363, 183838, 191995, 229170, 191993, 229171	MT 1440 A ST3B, MT 1840 A ST3B
4	273225	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
5	273170	washer	3		MT 1440 A ST3B, MT 1840 A ST3B
6	271669	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
7	286341	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
8	273063	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
9	273170	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
10	301504	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
11	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
12	319669	panel	1		MT 1440 A ST3B, MT 1840 A ST3B
13	52508144	R.H. rear sound proofing foam	1	302945	MT 1440 A ST3B, MT 1840 A ST3B
14	241391	button	11	239411	MT 1440 A ST3B, MT 1840 A ST3B
15	306915	Sludge door	1		MT 1440 A ST3B, MT 1840 A ST3B
16	286341	screw	5		MT 1440 A ST3B, MT 1840 A ST3B
17	297869	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
18	190427	bumper	2		MT 1440 A ST3B, MT 1840 A ST3B
19	58528	nut	2		MT 1440 A ST3B, MT 1840 A ST3B
20	300226	cable	1		MT 1440 A ST3B, MT 1840 A ST3B
21	52507388	Side bonnet	1	52500478	MT 1440 A ST3B, MT 1840 A ST3B
22	168746	clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
23	7242	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
24	593698	Locker	2		MT 1440 A ST3B, MT 1840 A ST3B
25	226606	screw	6	229591	MT 1440 A ST3B, MT 1840 A ST3B
26	685568	hook	2		MT 1440 A ST3B, MT 1840 A ST3B
27	226606	screw	2	229591	MT 1440 A ST3B, MT 1840 A ST3B
28	303428	Locker	2		MT 1440 A ST3B, MT 1840 A ST3B
29	226606	screw	6	229591	MT 1440 A ST3B, MT 1840 A ST3B
30	184818	key	1		MT 1440 A ST3B, MT 1840 A ST3B
31	297830	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
32	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
33	797819	Lock	2		MT 1440 A ST3B, MT 1840 A ST3B
34	190427	bumper	1		MT 1440 A ST3B, MT 1840 A ST3B
35	310017	support	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
36	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
37	228575	Weatherstrip	2	242006, 242005, 261123, 282817, 286272	MT 1440 A ST3B, MT 1840 A ST3B
38	720909	Weatherstrip	1	183651, 183650, 252531, 196945, 229169, 252530, 191996, 229363, 183838, 191995, 229170, 191993, 229171	MT 1440 A ST3B, MT 1840 A ST3B
39	296364	screw	2		MT 1440 A ST3B, MT 1840 A ST3B



16 / 06 / 14


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52507390	Complete motor compartment	1	311544	MT 1440 A ST3B, MT 1840 A ST3B
2	52507408	Weatherstrip	1		MT 1440 A ST3B, MT 1840 A ST3B
4	273225	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
5	273170	washer	3		MT 1440 A ST3B, MT 1840 A ST3B
6	271669	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
7	286341	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
8	273063	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
10	301504	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
11	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
12	319669	panel	1		MT 1440 A ST3B, MT 1840 A ST3B
13	52508144	R.H. rear sound proofing foam	1	302945	MT 1440 A ST3B, MT 1840 A ST3B
14	241391	button	11	239411	MT 1440 A ST3B, MT 1840 A ST3B
15	306915	Sludge door	1		MT 1440 A ST3B, MT 1840 A ST3B
16	286341	screw	5		MT 1440 A ST3B, MT 1840 A ST3B
17	297869	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
18	190427	bumper	2		MT 1440 A ST3B, MT 1840 A ST3B
19	58528	nut	2		MT 1440 A ST3B, MT 1840 A ST3B
20	300226	cable	1		MT 1440 A ST3B, MT 1840 A ST3B
21	52507388	Side bonnet	1	52500478	MT 1440 A ST3B, MT 1840 A ST3B
22	168746	clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
23	7242	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
24	593698	Locker	2		MT 1440 A ST3B, MT 1840 A ST3B
25	226606	screw	6	229591	MT 1440 A ST3B, MT 1840 A ST3B
26	685568	hook	2		MT 1440 A ST3B, MT 1840 A ST3B
27	226606	screw	2	229591	MT 1440 A ST3B, MT 1840 A ST3B
28	52506181	lock	2		MT 1440 A ST3B, MT 1840 A ST3B
29	226606	screw	6	229591	MT 1440 A ST3B, MT 1840 A ST3B
30	184818	key	1		MT 1440 A ST3B, MT 1840 A ST3B
31	297830	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
32	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
33	941179	lock	2		MT 1440 A ST3B, MT 1840 A ST3B
34	190427	bumper	1		MT 1440 A ST3B, MT 1840 A ST3B
35	310017	support	1		MT 1440 A ST3B, MT 1840 A ST3B
36	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
37	228575	Weatherstrip	2	242006, 242005, 261123, 282817, 286272	MT 1440 A ST3B, MT 1840 A ST3B
38	52507403	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
39	296364	screw	2		MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	299782	Frame	1		MT 1440 A ST3B, MT 1840 A ST3B
2	258628	Counterweight	1		MT 1440 A ST3B
3	258629	Counterweight	1		MT 1840 A ST3B
4	172912	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
5	183816	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
6	111680	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
7	183816	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
8	183817	nut	2		MT 1440 A ST3B, MT 1840 A ST3B
9	246590	Nut cage	2		MT 1440 A ST3B, MT 1840 A ST3B
10	258615	Towing spindle	1		MT 1440 A ST3B, MT 1840 A ST3B
11	32963	cotter pin	1		MT 1440 A ST3B, MT 1840 A ST3B
12	259386	Level indicator	1		MT 1440 A ST3B, MT 1840 A ST3B
13	57446	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
14	61674	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
15	58528	nut	2		MT 1440 A ST3B, MT 1840 A ST3B
16	259383	Level indicator	1		MT 1440 A ST3B, MT 1840 A ST3B
17	259385	Spring	1		MT 1440 A ST3B, MT 1840 A ST3B
18	259382	Guide	1		MT 1440 A ST3B, MT 1840 A ST3B
19	259602	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
20	259546	Stabilizer	2		MT 1440 A ST3B, MT 1840 A ST3B
21	292568	Articulating pin	2		MT 1440 A ST3B, MT 1840 A ST3B
22	63727	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
23	45921	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
24	51534	Straight greaser	2	455684, 49402, 133103, 127378, 130435, 188315, 470719, A517853, 43813, 138390, 501153, 127315, 90822, 137023, A4104177A	MT 1440 A ST3B, MT 1840 A ST3B
25	291063	Sole	2		MT 1440 A ST3B, MT 1840 A ST3B
26	267417	Articulating pin	2		MT 1440 A ST3B, MT 1840 A ST3B
27	189680	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
28	192213	Circlip	4		MT 1440 A ST3B, MT 1840 A ST3B
29	51534	Straight greaser	2	455684, 49402, 133103, 127378, 130435, 188315, 470719, A517853, 43813, 138390, 501153, 127315, 90822, 137023, A4104177A	MT 1440 A ST3B, MT 1840 A ST3B
30	227111	Bushing	4	211770, 780450, 487874, 658290, 551241, 478712, 705896	MT 1440 A ST3B, MT 1840 A ST3B
31	199079	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
32	273436	screw	6	278713	MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
33	295212	Wedge	1		MT 1440 A ST3B, MT 1840 A ST3B
34	300145	Weatherstrip	2		MT 1440 A ST3B, MT 1840 A ST3B
35	677524	Pin	2		MT 1440 A ST3B, MT 1840 A ST3B
36	295216	Pin	2		MT 1440 A ST3B, MT 1840 A ST3B
37	295189	Wedge	1		MT 1440 A ST3B, MT 1840 A ST3B
38	300167	Wedge bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
39	55581	Weatherstrip	2	165818, 71963, 162700, 596984, 168522, 168524, 168525, 168527, 55847, 57905, 168529, 55846, 57906, 55845, 57907, 171055, 55848, 163466, 164710, 246952, 61456, 165003, 60717, 165002, 60716, 60715, 60724, 78354, 60723, 60721, 184827, 227185, 51734, 161715, 200967, 245355, 75820, 170786, 61817, 54138, 684229, 54137, 54537, 738665, 188919, 164708, 73539, 243027, 519478, 519311, 168531, 168532	MT 1440 A ST3B, MT 1840 A ST3B
40	254215	Socket	4		MT 1440 A ST3B, MT 1840 A ST3B
41	300165	Wedge bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
42	685474	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
43	220664	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
44	52504509	Stabilizer	2		MT 1440 A ST3B, MT 1840 A ST3B

_MUD GUARD (FENDER)




19 / 03 / 12

P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	305296	R.H. fender bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
2	305299	L.H. fender bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
3	260524BIS	Fender	4	260524	MT 1440 A ST3B, MT 1840 A ST3B
4	240822	screw	8		MT 1440 A ST3B, MT 1840 A ST3B
5	282478	nut	8		MT 1440 A ST3B, MT 1840 A ST3B
6	305296	R.H. fender bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
7	305299	L.H. fender bracket	2		MT 1440 A ST3B, MT 1840 A ST3B

_DRIVER CAB



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	302217	Cab	1		MT 1440 A ST3B, MT 1840 A ST3B
2	260674	housing	1	265017, 261991	MT 1440 A ST3B, MT 1840 A ST3B
3	189172	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
4	551599	washer	4		MT 1440 A ST3B, MT 1840 A ST3B
5	260674	housing	1	265017, 261991	MT 1440 A ST3B, MT 1840 A ST3B
6	746110	lock	1		MT 1440 A ST3B, MT 1840 A ST3B
7	184818	key	1		MT 1440 A ST3B, MT 1840 A ST3B
8	264009	Rear case bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
9	259601	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
10	261957	Rear case bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
11	264380	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
12	260675	Rear case	1		MT 1440 A ST3B, MT 1840 A ST3B
13	199977	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
14	459749	Washer	3	573096, 198138	MT 1440 A ST3B, MT 1840 A ST3B
15	58630	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
16	61683	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
17	214160	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
17	312547	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
17	312548	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
18	264615	silent block	4	732790	MT 1440 A ST3B, MT 1840 A ST3B
19	208504	washer	4		MT 1440 A ST3B, MT 1840 A ST3B
20	185054	Nut	4		MT 1440 A ST3B, MT 1840 A ST3B
21	252468	Complete seat	1		MT 1440 A ST3B, MT 1840 A ST3B
22	261148	Stop	1		MT 1440 A ST3B, MT 1840 A ST3B
23	261503	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
24	254501	Seat bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
25	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
26	254177	Nut	4		MT 1440 A ST3B, MT 1840 A ST3B
27	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
28	260674	housing	1	265017, 261991	MT 1440 A ST3B, MT 1840 A ST3B
29	300973	foot board	1		MT 1440 A ST3B, MT 1840 A ST3B
30	234304	Plug	3		MT 1440 A ST3B, MT 1840 A ST3B
31	459749	Washer	1	573096, 198138	MT 1440 A ST3B, MT 1840 A ST3B
32	25714	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
33	55404	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
34	60950	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
35	261971	filter	1		MT 1440 A ST3B, MT 1840 A ST3B
36	310402	Weatherstrip	1		MT 1440 A ST3B, MT 1840 A ST3B
37	308232	Cab	1		MT 1440 A ST3B, MT 1840 A ST3B
38	299483	rearview kit	1		MT 1440 A ST3B, MT 1840 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
39	797916	mirror	1		MT 1440 A ST3B, MT 1840 A ST3B
40	459749	Washer	4	573096, 198138	MT 1440 A ST3B, MT 1840 A ST3B
41	313526	Shim	1		MT 1440 A ST3B, MT 1840 A ST3B
41	313527	Shim	1		MT 1440 A ST3B, MT 1840 A ST3B
41	316010	Wedge	1		MT 1440 A ST3B, MT 1840 A ST3B
41	52500527	Wedge	1		MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52500474	Tank	1		MT 1440 A ST3B, MT 1840 A ST3B
2	80861	Seal washer	1		MT 1440 A ST3B, MT 1840 A ST3B
3	189535	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
4	278514	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
5	286900	Sludge door	1		MT 1440 A ST3B, MT 1840 A ST3B
6	240822	screw	6		MT 1440 A ST3B, MT 1840 A ST3B
7	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
8	61675	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
9	261872	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
10	36010	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
11	60360	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
12	42366	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
13	261872	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
14	314144	Filling plug	1		MT 1440 A ST3B, MT 1840 A ST3B
15	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
16	291428	Housing	1		MT 1440 A ST3B, MT 1840 A ST3B
17	301483	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
18	301480	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
19	270225	clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
20	168758	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
21	168494	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
22	58530	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
23	300850	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
24	194287	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
25	294283	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
26	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
27	301482	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
28	301481	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
29	295360	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
30	296737	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
31	306346	Fuel pre-filter	1		MT 1440 A ST3B, MT 1840 A ST3B
32	248096	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
33	315766	Pre-filter bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
34	259601	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
35	266219	Air breather (Tank)	1		MT 1440 A ST3B, MT 1840 A ST3B
36	941	"O" ring	2	A003001872, 470768, 41624, 745792, 2742043MI, 474734, A5514102, 22237, 551470	MT 1440 A ST3B, MT 1840 A ST3B
37	295354	cable protection	1		MT 1440 A ST3B, MT 1840 A ST3B
38	270621	Trapdoor	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
39	246805	Lock	1		MT 1440 A ST3B, MT 1840 A ST3B
40	260545	Hinge	2		MT 1440 A ST3B, MT 1840 A ST3B
41	206083	screw	8		MT 1440 A ST3B, MT 1840 A ST3B
42	28988	Washer	8		MT 1440 A ST3B, MT 1840 A ST3B
43	25758	Nut	8		MT 1440 A ST3B, MT 1840 A ST3B
44	260544	Stop	2		MT 1440 A ST3B, MT 1840 A ST3B
45	184818	key	2		MT 1440 A ST3B, MT 1840 A ST3B
46	184818	key	2		MT 1440 A ST3B, MT 1840 A ST3B
47	283729	Fuel gauge	1		MT 1440 A ST3B, MT 1840 A ST3B
48	187485	Gasket	1		MT 1440 A ST3B, MT 1840 A ST3B
49	61801	Screw	6	561547	MT 1440 A ST3B, MT 1840 A ST3B
50	187294	Copper seal	7		MT 1440 A ST3B, MT 1840 A ST3B
51	58588	Screw	1	484439, 470109	MT 1440 A ST3B, MT 1840 A ST3B
52	249209	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
53	797756	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
54	895353	Pre-filter	1		MT 1440 A ST3B, MT 1840 A ST3B
55	798466	Fuel pre-filter	1		MT 1440 A ST3B, MT 1840 A ST3B
56	775856	Sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
57	306344	Fitting diesel	2		MT 1440 A ST3B, MT 1840 A ST3B
58	315397	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
59	306345	Plug	2		MT 1440 A ST3B, MT 1840 A ST3B
60	315397	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B

_Electronic unit - ECU




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	265418	Complete front headlight, UK	1	747046	MT 1440 A ST3B, MT 1840 A ST3B
2	265416	light	1	747044	MT 1440 A ST3B, MT 1840 A ST3B
3	265418	Complete front headlight, UK	1	747046	MT 1440 A ST3B, MT 1840 A ST3B
4	265416	light	1	747044	MT 1440 A ST3B, MT 1840 A ST3B
5	265417	Complete front headlight, UK	1	747045	MT 1440 A ST3B, MT 1840 A ST3B
6	265415	light	1	747038	MT 1440 A ST3B, MT 1840 A ST3B
7	265417	Complete front headlight, UK	1	747045	MT 1440 A ST3B, MT 1840 A ST3B
8	265415	light	1	747038	MT 1440 A ST3B, MT 1840 A ST3B
9	747043	Bulb	2		MT 1440 A ST3B, MT 1840 A ST3B
10	747039	Front direction lights	2		MT 1440 A ST3B, MT 1840 A ST3B
11	563881	Bulb	2	747042	MT 1440 A ST3B, MT 1840 A ST3B
12	20996	Bulb	2		MT 1440 A ST3B, MT 1840 A ST3B
13	164378	bulb	2	747041, 565462360071, 89616, 550813, 56511F203071, 565512332071, 563879, A029733, 50000063CAB, A4191555A, 2806316MI, 171560	MT 1440 A ST3B, MT 1840 A ST3B
14	300739	L.H. front headlight bracket "brown"	1		MT 1440 A ST3B, MT 1840 A ST3B
15	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
16	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
17	20125	Horn	1		MT 1440 A ST3B, MT 1840 A ST3B
18	300733	R.H. front headlight bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
19	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
20	604975	"0" ring	1	232959, 745993	MT 1440 A ST3B, MT 1840 A ST3B
21	264195	Low pressure	1		MT 1440 A ST3B, MT 1840 A ST3B
22	194048	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
23	260600	Strain-gage	2		MT 1440 A ST3B, MT 1840 A ST3B
24	265814	Screw	4	604065	MT 1440 A ST3B, MT 1840 A ST3B
25	254088	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
26	265435	Housing	1		MT 1440 A ST3B, MT 1840 A ST3B
27	60950	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
28	29469	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
29	264434	Guide	1		MT 1440 A ST3B, MT 1840 A ST3B
30	56707	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
31	61674	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
32	268521	horn	1		MT 1440 A ST3B, MT 1840 A ST3B
33	6942	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
34	254177	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
35	267706	Black box	1		MT 1440 A ST3B, MT 1840 A ST3B
36	273436	screw	4	278713	MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
37	257269	Low pressure	4		MT 1440 A ST3B, MT 1840 A ST3B
38	177588	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
39	259356	light	1	745990	MT 1440 A ST3B, MT 1840 A ST3B
40	259356	light	1	745990	MT 1440 A ST3B, MT 1840 A ST3B
41	259357	light	1	745989	MT 1440 A ST3B, MT 1840 A ST3B
42	259357	light	1	745989	MT 1440 A ST3B, MT 1840 A ST3B
43	745991	bulb	6		MT 1440 A ST3B, MT 1840 A ST3B
44	140661	Bulb	2	745992	MT 1440 A ST3B, MT 1840 A ST3B
45	174132	washer	4		MT 1440 A ST3B, MT 1840 A ST3B
46	25714	Nut	4		MT 1440 A ST3B, MT 1840 A ST3B
47	260669	housing	2		MT 1440 A ST3B, MT 1840 A ST3B
48	267479	Sheath	4		MT 1440 A ST3B, MT 1840 A ST3B
49	232750	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
50	226606	screw	8	229591	MT 1440 A ST3B, MT 1840 A ST3B
51	225746	Washer	8		MT 1440 A ST3B, MT 1840 A ST3B
52	302507	R.H. tail light bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
53	302506	L.H. tail light bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
54	294354	support	2		MT 1440 A ST3B, MT 1840 A ST3B
55	261503	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
56	299148	support	2		MT 1440 A ST3B, MT 1840 A ST3B
57	294373	plate	2		MT 1440 A ST3B, MT 1840 A ST3B
58	255143	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
59	189980	nut	4		MT 1440 A ST3B, MT 1840 A ST3B
60	61674	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
61	161008	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
62	237841	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
63	748543	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
64	264199	Remote control unit	1		MT 1440 A ST3B, MT 1840 A ST3B
65	267478	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
66	299892	Black box	1		MT 1440 A ST3B, MT 1840 A ST3B
67	273436	screw	4	278713	MT 1440 A ST3B, MT 1840 A ST3B
68	265290	Sheath	1		MT 1440 A ST3B, MT 1840 A ST3B
69	283991	Emergency stop button	1		MT 1440 A ST3B, MT 1840 A ST3B
70	746242	Push button	1		MT 1440 A ST3B, MT 1840 A ST3B
71	603366	Switch + base plate	1	508585, 609838	MT 1440 A ST3B, MT 1840 A ST3B
72	265875	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
73	305305	L.H. front headlight bracket "black"	1		MT 1440 A ST3B, MT 1840 A ST3B
74	305304	R.H. front headlight bracket "black"	1		MT 1440 A ST3B, MT 1840 A ST3B
75	61674	Washer	6		MT 1440 A ST3B, MT 1840 A ST3B
76	307248	Tail light bracket	2		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
77	307249	L.H. tail light bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
78	307250	R.H. tail light bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
79	307159	Folded sheet	2		MT 1440 A ST3B, MT 1840 A ST3B

_Electronic unit - ECU




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	265418	Complete front headlight, UK	1	747046	MT 1440 A ST3B, MT 1840 A ST3B
2	265416	light	1	747044	MT 1440 A ST3B, MT 1840 A ST3B
3	265418	Complete front headlight, UK	1	747046	MT 1440 A ST3B, MT 1840 A ST3B
4	265416	light	1	747044	MT 1440 A ST3B, MT 1840 A ST3B
5	265417	Complete front headlight, UK	1	747045	MT 1440 A ST3B, MT 1840 A ST3B
6	265415	light	1	747038	MT 1440 A ST3B, MT 1840 A ST3B
7	265417	Complete front headlight, UK	1	747045	MT 1440 A ST3B, MT 1840 A ST3B
8	265415	light	1	747038	MT 1440 A ST3B, MT 1840 A ST3B
9	747043	Bulb	2		MT 1440 A ST3B, MT 1840 A ST3B
10	747039	Front direction lights	2		MT 1440 A ST3B, MT 1840 A ST3B
11	563881	Bulb	2	747042	MT 1440 A ST3B, MT 1840 A ST3B
12	20996	Bulb	2		MT 1440 A ST3B, MT 1840 A ST3B
13	164378	bulb	2	747041, 565462360071, 89616, 550813, 56511F203071, 565512332071, 563879, A029733, 50000063CAB, A4191555A, 2806316MI, 171560	MT 1440 A ST3B, MT 1840 A ST3B
14	305305	L.H. front headlight bracket "black"	1		MT 1440 A ST3B, MT 1840 A ST3B
15	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
16	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
17	20125	Horn	1		MT 1440 A ST3B, MT 1840 A ST3B
18	305304	R.H. front headlight bracket "black"	1		MT 1440 A ST3B, MT 1840 A ST3B
19	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
20	604975	"0" ring	1	232959, 745993	MT 1440 A ST3B, MT 1840 A ST3B
21	264195	Low pressure	1		MT 1440 A ST3B, MT 1840 A ST3B
22	194048	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
23	288252	strain-gage	1		MT 1440 A ST3B, MT 1840 A ST3B
24	290321	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
25	285552	Clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
26	265435	Housing	1		MT 1440 A ST3B, MT 1840 A ST3B
27	60950	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
28	29469	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
29	264434	Guide	1		MT 1440 A ST3B, MT 1840 A ST3B
30	56707	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
31	61674	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
32	268521	horn	1		MT 1440 A ST3B, MT 1840 A ST3B
33	6942	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
34	254177	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
35	267706	Black box	1		MT 1440 A ST3B, MT 1840 A ST3B
36	273436	screw	4	278713	MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
37	257269	Low pressure	4		MT 1440 A ST3B, MT 1840 A ST3B
38	177588	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
39	259356	light	1	745990	MT 1440 A ST3B, MT 1840 A ST3B
40	259356	light	1	745990	MT 1440 A ST3B, MT 1840 A ST3B
41	259357	light	1	745989	MT 1440 A ST3B, MT 1840 A ST3B
42	259357	light	1	745989	MT 1440 A ST3B, MT 1840 A ST3B
43	745991	bulb	6		MT 1440 A ST3B, MT 1840 A ST3B
44	140661	Bulb	2	745992	MT 1440 A ST3B, MT 1840 A ST3B
45	174132	washer	4		MT 1440 A ST3B, MT 1840 A ST3B
46	25714	Nut	4		MT 1440 A ST3B, MT 1840 A ST3B
47	260669	housing	2		MT 1440 A ST3B, MT 1840 A ST3B
48	267479	Sheath	4		MT 1440 A ST3B, MT 1840 A ST3B
49	232750	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
50	226606	screw	8	229591	MT 1440 A ST3B, MT 1840 A ST3B
51	225746	Washer	8		MT 1440 A ST3B, MT 1840 A ST3B
52	307250	R.H. tail light bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
53	307249	L.H. tail light bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
54	307248	Tail light bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
55	261503	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
56	299148	support	2		MT 1440 A ST3B, MT 1840 A ST3B
57	294373	plate	2		MT 1440 A ST3B, MT 1840 A ST3B
58	255143	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
59	189980	nut	4		MT 1440 A ST3B, MT 1840 A ST3B
60	61674	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
61	161008	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
62	237841	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
63	748543	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
64	264199	Remote control unit	1		MT 1440 A ST3B, MT 1840 A ST3B
65	267478	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
66	299892	Black box	1		MT 1440 A ST3B, MT 1840 A ST3B
67	273436	screw	4	278713	MT 1440 A ST3B, MT 1840 A ST3B
68	265290	Sheath	1		MT 1440 A ST3B, MT 1840 A ST3B
69	283991	Emergency stop button	1		MT 1440 A ST3B, MT 1840 A ST3B
70	746242	Push button	1		MT 1440 A ST3B, MT 1840 A ST3B
71	603366	Switch + base plate	1	508585, 609838	MT 1440 A ST3B, MT 1840 A ST3B
72	265875	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
75	61674	Washer	6		MT 1440 A ST3B, MT 1840 A ST3B
79	307159	Folded sheet	2		MT 1440 A ST3B, MT 1840 A ST3B
80	282755	Clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
81	781595	*	1	273504	MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	301086	Main wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
2	260478	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
3	260477	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
4	161008	Screw	8		MT 1440 A ST3B, MT 1840 A ST3B
5	192310	Washer	8		MT 1440 A ST3B, MT 1840 A ST3B
6	260477	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
7	260477	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
8	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
9	260478	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
10	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
11	260478	Clamp	6		MT 1440 A ST3B, MT 1840 A ST3B
12	260475	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
13	260576	cable	1		MT 1440 A ST3B, MT 1840 A ST3B
14	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
15	254177	Nut	3		MT 1440 A ST3B, MT 1840 A ST3B
16	260472	clamp	12		MT 1440 A ST3B, MT 1840 A ST3B
17	286971	wiring	2		MT 1440 A ST3B, MT 1840 A ST3B
18	260478	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
19	257779	support	2		MT 1440 A ST3B, MT 1840 A ST3B
20	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
21	260475	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
22	21979	Clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
23	307647	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
24	260472	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
25	264868	Wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
26	286567	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
27	176926	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
28	264380	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
29	254177	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
30	238984	Clamp	3		MT 1440 A ST3B, MT 1840 A ST3B
31	25713	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
32	174132	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
33	276034	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
34	58525	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
35	29469	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
36	4240	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
37	28959	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
38	54232	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
39	58526	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
40	168491	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	168488	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
42	54284	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
43	168490	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
44	168486	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
45	220624	Screw	1	57319	MT 1440 A ST3B, MT 1840 A ST3B
46	305727	Main wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
47	306102	Connector bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
48	4240	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
49	54232	nut	2		MT 1440 A ST3B, MT 1840 A ST3B
50	261187	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
51	270248	connector	1		MT 1440 A ST3B, MT 1840 A ST3B
52	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
53	52504486	Wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
54	52504648	Shunt	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	301091	Cab wiring harness	1		MT_1840_A_ST3B, MT_1440_A_ST3B
2	254177	Nut	2		MT_1840_A_ST3B, MT_1440_A_ST3B
3	229107	plate	2		MT_1840_A_ST3B, MT_1440_A_ST3B
4	220408	Shunt	1		MT_1840_A_ST3B, MT_1440_A_ST3B
5	265485	Resistance	1		MT_1840_A_ST3B, MT_1440_A_ST3B
6	292546	Shunt	1		MT_1840_A_ST3B, MT_1440_A_ST3B
7	286567	Washer	2		MT_1840_A_ST3B, MT_1440_A_ST3B
8	299893	Instrument panel	1		MT_1840_A_ST3B, MT_1440_A_ST3B
9	305724	Cab wiring harness	1		MT_1840_A_ST3B, MT_1440_A_ST3B
10	260473	Clamp	1		MT_1840_A_ST3B, MT_1440_A_ST3B
11	261720	Resistance	1		MT_1840_A_ST3B, MT_1440_A_ST3B
12	164856	Clamp	1		MT_1840_A_ST3B, MT_1440_A_ST3B
13	52513469	Instrument panel	1		MT_1840_A_ST3B, MT_1440_A_ST3B

_CIRCUIT - HARNESS



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	301088	Engine wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
2	281807	Clip	2		MT 1440 A ST3B, MT 1840 A ST3B
3	226606	screw	2	229591	MT 1440 A ST3B, MT 1840 A ST3B
4	260569	Cable grommet	1		MT 1440 A ST3B, MT 1840 A ST3B
5	294701	Power supply terminal	1		MT 1440 A ST3B, MT 1840 A ST3B
6	232750	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
7	170884	Cap (red)	2		MT 1440 A ST3B, MT 1840 A ST3B
8	301673	Cable	1		MT 1440 A ST3B, MT 1840 A ST3B
9	42347	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
10	42325	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
11	54242	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
12	170884	Cap (red)	1		MT 1440 A ST3B, MT 1840 A ST3B
13	240822	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
14	301522	Cable	1		MT 1440 A ST3B, MT 1840 A ST3B
15	260477	clamp	3		MT 1440 A ST3B, MT 1840 A ST3B
16	58546	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
17	301335	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
18	268255	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
19	296142	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
20	177082	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
21	29481	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
22	203757	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
23	210845	Cable	1		MT 1440 A ST3B, MT 1840 A ST3B
24	301670	Cable	1		MT 1440 A ST3B, MT 1840 A ST3B
25	301671	Cable	1		MT 1440 A ST3B, MT 1840 A ST3B
26	301669	Cable	1		MT 1440 A ST3B, MT 1840 A ST3B
27	168758	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
28	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
29	61323	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
30	260473	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
31	257779	support	1		MT 1440 A ST3B, MT 1840 A ST3B
32	273436	screw	1	278713	MT 1440 A ST3B, MT 1840 A ST3B
33	162229	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
34	260478	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
35	260474	clamp	3		MT 1440 A ST3B, MT 1840 A ST3B
36	257779	support	1		MT 1440 A ST3B, MT 1840 A ST3B
37	273436	screw	1	278713	MT 1440 A ST3B, MT 1840 A ST3B
38	260473	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
39	302505	Clamp bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
40	260473	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	260475	clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
42	247814	Cable	1		MT 1440 A ST3B, MT 1840 A ST3B
43	302606	Lug	1		MT 1440 A ST3B, MT 1840 A ST3B
44	275028	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
45	305806	Engine wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
46	306131	Air temperature sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
47	297828	Box	1		MT 1440 A ST3B, MT 1840 A ST3B
48	304403	Clamp bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
49	273436	screw	2	278713	MT 1440 A ST3B, MT 1840 A ST3B
50	260477	clamp	3		MT 1440 A ST3B, MT 1840 A ST3B
51	305266	Cable bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
52	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
53	234197	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
54	260255	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
55	52507242	Engine wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
56	54242	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
57	170884	Cap (red)	1		MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	276053	Wiring harness	1		MT 1440 A ST3B
2	260639	Sensor	2		MT 1440 A ST3B
3	264826	Bracket	1		MT 1440 A ST3B
4	278713	screw	2		MT 1440 A ST3B
5	220427	Housing	1		MT 1440 A ST3B
6	278713	screw	2		MT 1440 A ST3B
7	21979	Clamp	14		MT 1440 A ST3B
8	264238	Drain trough	1		MT 1440 A ST3B
9	264237	Front drain trough	1		MT 1440 A ST3B
10	278713	screw	5		MT 1440 A ST3B
11	264272	Side drain trough	1		MT 1440 A ST3B
12	228244	Screw	3		MT 1440 A ST3B
13	189857	Washer	3		MT 1440 A ST3B
14	283759	Bracket hose reel	1		MT 1440 A ST3B
15	268255	screw	4		MT 1440 A ST3B
16	291976	Complete hose reel	1		MT 1440 A ST3B
17	261872	screw	4		MT 1440 A ST3B
18	55714	Nut	4		MT 1440 A ST3B
19	276234	Bracket	2		MT 1440 A ST3B
20	268255	screw	4		MT 1440 A ST3B
21	283778	Bracket	1		MT 1440 A ST3B
22	268255	screw	1		MT 1440 A ST3B
23	58538	Screw	1		MT 1440 A ST3B
24	242853	Bushing	1		MT 1440 A ST3B
25	61675	Washer	2		MT 1440 A ST3B
26	182211	Hose pulley	1		MT 1440 A ST3B
27	55714	Nut	1		MT 1440 A ST3B
28	276323	Guide cable	1		MT 1440 A ST3B
29	63544	Screw	1		MT 1440 A ST3B
30	61675	Washer	2		MT 1440 A ST3B
31	276324	Bushing	1		MT 1440 A ST3B
32	55714	Nut	1		MT 1440 A ST3B
33	13393	pin	1		MT 1440 A ST3B
34	283784	Connector bracket	1		MT 1440 A ST3B
35	228780	Half-clamp	2		MT 1440 A ST3B
36	168847	Protection plate	1		MT 1440 A ST3B
37	288358	Screw	2		MT 1440 A ST3B
38	25714	Nut	2		MT 1440 A ST3B
39	79533	Screw	4		MT 1440 A ST3B
40	242642	Connector base-plate	1		MT 1440 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	242643	Female connector	1		MT 1440 A ST3B
42	746710	Resistance	1		MT 1440 A ST3B
43	601249	Plug	7		MT 1440 A ST3B
44	549456	Plug	1		MT 1440 A ST3B
45	702670	Reducing	1		MT 1440 A ST3B
46	507596	Packing box	1	593528, 565533	MT 1440 A ST3B
47	748543	plate	1		MT 1440 A ST3B

_CIRCUIT - HARNESS




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	300576	Potentiometer bracket	1		MT 1840 A ST3B
2	240822	screw	2		MT 1840 A ST3B
3	288253	potentiometer	1		MT 1840 A ST3B
4	188736	Screw	2		MT 1840 A ST3B
5	261441	Rod	1		MT 1840 A ST3B
6	484702	Screw	1		MT 1840 A ST3B
7	180603	Nut	1	750482, A7204813A, 2762401MI, 603235, 485980	MT 1840 A ST3B
8	261444	Rod	1		MT 1840 A ST3B
9	210776	Bushing	2		MT 1840 A ST3B
10	459749	Washer	2	573096, 198138	MT 1840 A ST3B
11	8038	Pin	1	482336, 5152, T7004055, 133645, K449025026, T7003030, 63035, 134136, 125211, 58396, 125210, 138074, 418810, 9538103028, 471351, A506354, 853817602471	MT 1840 A ST3B
12	29481	Screw	1		MT 1840 A ST3B
13	42316	Washer	1		MT 1840 A ST3B
14	459749	Washer	2	573096, 198138	MT 1840 A ST3B
15	261445	Articulating pin	1		MT 1840 A ST3B
16	288650	Switch	1		MT 1840 A ST3B
17	268037	Screw	2		MT 1840 A ST3B
18	288755	Switch bracket	1		MT 1840 A ST3B
19	273436	screw	2	278713	MT 1840 A ST3B
20	292563	Wiring harness	1		MT 1840 A ST3B
21	297774	Half-flange	1		MT 1840 A ST3B
22	297775	Half-flange	1		MT 1840 A ST3B
23	293806	screw	2		MT 1840 A ST3B
24	298020	Clamp	1		MT 1840 A ST3B
25	295713	Protection plate	2		MT 1840 A ST3B
26	58526	Screw	1		MT 1840 A ST3B
27	162229	Nut	1		MT 1840 A ST3B
28	293621	Wiring harness	1		MT 1840 A ST3B
29	292564	Wiring harness	1		MT 1840 A ST3B
30	260472	clamp	1		MT 1840 A ST3B
31	79533	Screw	4		MT 1840 A ST3B
32	288812	Bracket	1		MT 1840 A ST3B
33	259946	screw	2		MT 1840 A ST3B
34	242642	Connector base-plate	1		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
35	242643	Female connector	1		MT 1840 A ST3B
36	601249	Plug	7		MT 1840 A ST3B
37	549456	Plug	1		MT 1840 A ST3B
38	702670	Reducing	1		MT 1840 A ST3B
39	507596	Packing box	1	593528, 565533	MT 1840 A ST3B
40	746710	Resistance	1		MT 1840 A ST3B
41	274184	Clamp	18		MT 1840 A ST3B
42	274139	Clamp	18		MT 1840 A ST3B
43	260472	clamp	2		MT 1840 A ST3B
44	260473	Clamp	1		MT 1840 A ST3B
45	260473	Clamp	1		MT 1840 A ST3B
46	288763	Drain trough	1		MT 1840 A ST3B
47	291367	Drain trough	1		MT 1840 A ST3B
48	273436	screw	5	278713	MT 1840 A ST3B
49	296629	Wiring harness	1		MT 1840 A ST3B
50	288815	Sheath	1		MT 1840 A ST3B
51	168746	clamp	4		MT 1840 A ST3B
52	168847	Protection plate	2		MT 1840 A ST3B
53	54305	Screw	2		MT 1840 A ST3B
54	264826	Bracket	2		MT 1840 A ST3B
55	273436	screw	4	278713	MT 1840 A ST3B
56	260639	Sensor	4		MT 1840 A ST3B
57	220427	Housing	2		MT 1840 A ST3B
58	273436	screw	4	278713	MT 1840 A ST3B
59	296630	Wiring harness	1		MT 1840 A ST3B
60	168487	Half-clamp	2		MT 1840 A ST3B
61	168490	Protection plate	1		MT 1840 A ST3B
62	54284	Screw	2		MT 1840 A ST3B
63	288647	Switch	2		MT 1840 A ST3B
64	268037	Screw	4		MT 1840 A ST3B
65	288755	Switch bracket	2		MT 1840 A ST3B
66	273436	screw	4	278713	MT 1840 A ST3B
67	288754	Cam	2		MT 1840 A ST3B
68	288753	Bracket	1		MT 1840 A ST3B
69	296562	Hose reel	1		MT 1840 A ST3B
70	243077	Bracket hose reel	1		MT 1840 A ST3B
71	259946	screw	4		MT 1840 A ST3B
72	259601	Screw	2		MT 1840 A ST3B
73	254177	Nut	2		MT 1840 A ST3B
74	291374	Bracket	1		MT 1840 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
75	240822	screw	2		MT 1840 A ST3B
76	173004	Half-clamp	2		MT 1840 A ST3B
77	168847	Protection plate	1		MT 1840 A ST3B
78	58526	Screw	2		MT 1840 A ST3B
79	288647	Switch	2		MT 1840 A ST3B
80	268037	Screw	4		MT 1840 A ST3B
81	288755	Switch bracket	2		MT 1840 A ST3B
82	273436	screw	4	278713	MT 1840 A ST3B
83	288783	Cam	2		MT 1840 A ST3B
84	260473	Clamp	1		MT 1840 A ST3B
85	300094	Wiring harness	1		MT 1840 A ST3B

_CIRCUIT - HARNESS



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	270261	Switch bracket	1		MT 1440 A ST3B
2	261501	Screw	2		MT 1440 A ST3B
3	29469	washer	2		MT 1440 A ST3B
4	276057	Switch	1		MT 1440 A ST3B
5	268037	Screw	2		MT 1440 A ST3B
6	270264	Sheat	1		MT 1440 A ST3B
7	261501	Screw	2		MT 1440 A ST3B
8	29469	washer	2		MT 1440 A ST3B
9	261440	Potentiometer bracket	1		MT 1440 A ST3B
10	268255	screw	2		MT 1440 A ST3B
11	748543	plate	1		MT 1440 A ST3B
12	288253	potentiometer	1		MT 1440 A ST3B
13	188736	Screw	2		MT 1440 A ST3B
14	261441	Rod	1		MT 1440 A ST3B
15	484702	Screw	1		MT 1440 A ST3B
16	485980	nut	1		MT 1440 A ST3B
17	261444	Rod	1		MT 1440 A ST3B
18	210776	Bushing	2		MT 1440 A ST3B
19	459749	Washer	2	573096, 198138	MT 1440 A ST3B
20	63035	cotter pin	1		MT 1440 A ST3B
21	29481	Screw	1		MT 1440 A ST3B
22	42316	Washer	1		MT 1440 A ST3B
23	459749	Washer	2	573096, 198138	MT 1440 A ST3B
24	261445	Articulating pin	1		MT 1440 A ST3B
25	224776	Air filter clogging switch	1		MT 1440 A ST3B
26	705222	battery lock out	1	10001945	MT 1440 A ST3B
27	259839	Fastening plate	1		MT 1440 A ST3B
28	232750	screw	2		MT 1440 A ST3B
29	283831	Battery	1		MT 1440 A ST3B
30	214774	Rubber strip	1		MT 1440 A ST3B
31	261937	bracket	1		MT 1440 A ST3B
32	232750	screw	2		MT 1440 A ST3B
33	300991	Bracket sheat	1		MT 1440 A ST3B
34	259710	screw	2		MT 1440 A ST3B
35	265015	Cable terminal	1		MT 1440 A ST3B
36	296807	Cap	1		MT 1440 A ST3B
37	313641	feeler	1		MT 1440 A ST3B
38	212298	"0" ring	1		MT 1440 A ST3B
39	554935	Revolving light	1	781618	MT 1440 A ST3B
40	466247	bulb	1		MT 1440 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	554993	Revolving light glass	1		MT 1440 A ST3B
42	255587	Clamp	1		MT 1440 A ST3B
43	259601	Screw	1		MT 1440 A ST3B
44	797024	Fuses box	1		MT 1440 A ST3B
45	795609	Packing box	1		MT 1440 A ST3B
46	795610	Nut	1		MT 1440 A ST3B
47	273978	Screw	4		MT 1440 A ST3B
48	247244	Washer	4		MT 1440 A ST3B
49	175921	Nut	4		MT 1440 A ST3B
50	301746	Modulus bracket	1		MT 1440 A ST3B
51	192041	Screw	2		MT 1440 A ST3B
52	795612	Modulus	1		MT 1440 A ST3B
53	231245	Relay	1		MT 1440 A ST3B
54	746004	Relay	1		MT 1440 A ST3B
55	795611	Modulus	1		MT 1440 A ST3B
56	720888	fuse	1		MT 1440 A ST3B
57	243480	Fuse	1		MT 1440 A ST3B
58	251178	Fuse	1		MT 1440 A ST3B
59	207007	Fuse	1		MT 1440 A ST3B
60	173491	Fuse	1		MT 1440 A ST3B
61	473080	Fuse	1		MT 1440 A ST3B
62	301765	Bracket	1		MT 1440 A ST3B
63	228363	screw	2		MT 1440 A ST3B
64	42325	Washer	2		MT 1440 A ST3B
65	226606	screw	4	229591	MT 1440 A ST3B
66	304722	Modulus bracket	1		MT 1440 A ST3B
67	306131	Air temperature sensor	1		MT 1440 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	705222	battery lock out	1	10001945	MT 1840 A ST3B
2	259839	Fastening plate	1		MT 1840 A ST3B
3	232750	screw	2		MT 1840 A ST3B
4	283831	Battery	1		MT 1840 A ST3B
5	214774	Rubber strip	1		MT 1840 A ST3B
6	261937	bracket	1		MT 1840 A ST3B
7	232750	screw	2		MT 1840 A ST3B
8	300991	Bracket sheat	1		MT 1840 A ST3B
9	259710	screw	1		MT 1840 A ST3B
10	265015	Cable terminal	1		MT 1840 A ST3B
11	296807	Cap	1		MT 1840 A ST3B
12	313641	feeler	1		MT 1840 A ST3B
13	212298	"0" ring	1		MT 1840 A ST3B
14	748543	plate	1		MT 1840 A ST3B
15	224776	Air filter clogging switch	1		MT 1840 A ST3B
16	554935	Revolving light	1	781618	MT 1840 A ST3B
17	466247	bulb	1		MT 1840 A ST3B
18	554993	Revolving light glass	1		MT 1840 A ST3B
19	797024	Fuses box	1		MT 1840 A ST3B
20	795609	Packing box	1		MT 1840 A ST3B
21	795610	Nut	1		MT 1840 A ST3B
22	273978	Screw	4		MT 1840 A ST3B
23	247244	Washer	4		MT 1840 A ST3B
24	175921	Nut	4		MT 1840 A ST3B
25	301746	Modulus bracket	1		MT 1840 A ST3B
26	192041	Screw	2		MT 1840 A ST3B
27	795612	Modulus	1		MT 1840 A ST3B
28	231245	Relay	1		MT 1840 A ST3B
29	746004	Relay	1		MT 1840 A ST3B
30	795611	Modulus	1		MT 1840 A ST3B
31	720888	fuse	0		MT 1840 A ST3B
32	243480	Fuse	0		MT 1840 A ST3B
33	251178	Fuse	0		MT 1840 A ST3B
34	207007	Fuse	0		MT 1840 A ST3B
35	173491	Fuse	0		MT 1840 A ST3B
36	473080	Fuse	0		MT 1840 A ST3B
37	301765	Bracket	1		MT 1840 A ST3B
38	228363	screw	2		MT 1840 A ST3B
39	42325	Washer	2		MT 1840 A ST3B
40	226606	screw	4	229591	MT 1840 A ST3B

Позиция	№ детали	Название	К- во	SupersededPa rtNumber	Product Type
41	304722	Modulus bracket	1		MT 1840 A ST3B
42	306131	Air temperature sensor	1		MT 1840 A ST3B

_CIRCUIT - HARNESS



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	300576	Potentiometer bracket	1		MT 1840 A ST3B
2	240822	screw	2		MT 1840 A ST3B
3	288253	potentiometer	1		MT 1840 A ST3B
4	188736	Screw	2		MT 1840 A ST3B
5	52512371	Rod	1		MT 1840 A ST3B
6	484702	Screw	1		MT 1840 A ST3B
7	180603	Nut	1	750482, A7204813A, 2762401MI, 603235, 485980	MT 1840 A ST3B
8	261444	Rod	1		MT 1840 A ST3B
9	210776	Bushing	2		MT 1840 A ST3B
10	459749	Washer	2	573096, 198138	MT 1840 A ST3B
11	8038	Pin	1	482336, 5152, T7004055, 133645, K449025026, T7003030, 63035, 134136, 125211, 58396, 125210, 138074, 418810, 9538103028, 471351, A506354, 853817602471	MT 1840 A ST3B
12	29481	Screw	1		MT 1840 A ST3B
13	42316	Washer	1		MT 1840 A ST3B
14	459749	Washer	2	573096, 198138	MT 1840 A ST3B
15	261445	Articulating pin	1		MT 1840 A ST3B
16	288650	Switch	1		MT 1840 A ST3B
17	268037	Screw	2		MT 1840 A ST3B
18	288755	Switch bracket	1		MT 1840 A ST3B
19	273436	screw	2	278713	MT 1840 A ST3B
20	52500496	Wiring harness	1		MT 1840 A ST3B
21	297774	Half-flange	1		MT 1840 A ST3B
22	297775	Half-flange	1		MT 1840 A ST3B
23	293806	screw	2		MT 1840 A ST3B
24	298020	Clamp	2		MT 1840 A ST3B
25	295713	Protection plate	1		MT 1840 A ST3B
26	58526	Screw	1		MT 1840 A ST3B
27	162229	Nut	1		MT 1840 A ST3B
28	293621	Wiring harness	1		MT 1840 A ST3B
29	292564	Wiring harness	1		MT 1840 A ST3B
30	260472	clamp	1		MT 1840 A ST3B
31	79533	Screw	4		MT 1840 A ST3B
32	288812	Bracket	1		MT 1840 A ST3B
33	259946	screw	2		MT 1840 A ST3B
34	242642	Connector base-plate	1		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
35	242643	Female connector	1		MT 1840 A ST3B
36	601249	Plug	7		MT 1840 A ST3B
37	549456	Plug	1		MT 1840 A ST3B
38	702670	Reducing	1		MT 1840 A ST3B
39	507596	Packing box	1	593528, 565533	MT 1840 A ST3B
40	746710	Resistance	1		MT 1840 A ST3B
41	274184	Clamp	18		MT 1840 A ST3B
42	274139	Clamp	18		MT 1840 A ST3B
43	260472	clamp	2		MT 1840 A ST3B
44	260473	Clamp	1		MT 1840 A ST3B
45	260473	Clamp	1		MT 1840 A ST3B
46	52500411	Drain trough	1		MT 1840 A ST3B
47	291367	Drain trough	1		MT 1840 A ST3B
48	273436	screw	5	278713	MT 1840 A ST3B
49	296629	Wiring harness	1		MT 1840 A ST3B
50	288815	Sheath	1		MT 1840 A ST3B
51	168746	clamp	4		MT 1840 A ST3B
52	168847	Protection plate	2		MT 1840 A ST3B
53	54305	Screw	2		MT 1840 A ST3B
55	303150	Plug	2		MT 1840 A ST3B
56	308447	Sensor	4		MT 1840 A ST3B
57	306956	Housing	2		MT 1840 A ST3B
59	296630	Wiring harness	1		MT 1840 A ST3B
60	168746	clamp	2		MT 1840 A ST3B
61	168847	Protection plate	1		MT 1840 A ST3B
62	54305	Screw	2		MT 1840 A ST3B
63	288647	Switch	2		MT 1840 A ST3B
64	268037	Screw	4		MT 1840 A ST3B
65	288755	Switch bracket	2		MT 1840 A ST3B
66	273436	screw	4	278713	MT 1840 A ST3B
67	288754	Cam	2		MT 1840 A ST3B
68	288753	Bracket	1		MT 1840 A ST3B
69	296562	Hose reel	1		MT 1840 A ST3B
70	243077	Bracket hose reel	1		MT 1840 A ST3B
71	259946	screw	4		MT 1840 A ST3B
72	259601	Screw	2		MT 1840 A ST3B
73	254177	Nut	2		MT 1840 A ST3B
74	291374	Bracket	1		MT 1840 A ST3B
75	240822	screw	2		MT 1840 A ST3B
76	173004	Half-clamp	2		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
77	168847	Protection plate	1		MT 1840 A ST3B
78	58526	Screw	2		MT 1840 A ST3B
79	288647	Switch	2		MT 1840 A ST3B
80	268037	Screw	4		MT 1840 A ST3B
81	288755	Switch bracket	2		MT 1840 A ST3B
82	273436	screw	4	278713	MT 1840 A ST3B
83	288783	Cam	2		MT 1840 A ST3B
84	260473	Clamp	1		MT 1840 A ST3B
85	300094	Wiring harness	1		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	264968	Emergency stop button	1		MT 1440 A ST3B, MT 1840 A ST3B
2	247077	Emergency stop button	1		MT 1440 A ST3B, MT 1840 A ST3B
3	247078	Switch + base plate	1		MT 1440 A ST3B, MT 1840 A ST3B
4	184817	switch	1		MT 1440 A ST3B, MT 1840 A ST3B
5	77522	cover	1		MT 1440 A ST3B, MT 1840 A ST3B
6	184818	key	2		MT 1440 A ST3B, MT 1840 A ST3B
7	257234	pressure switch	1		MT 1440 A ST3B, MT 1840 A ST3B
8	604975	"0" ring	1	232959, 745993	MT 1440 A ST3B, MT 1840 A ST3B
9	299893	Instrument panel	1		MT 1440 A ST3B, MT 1840 A ST3B
10	265322	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
11	260578	control	1		MT 1440 A ST3B, MT 1840 A ST3B
12	279973	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
13	260579	control	1		MT 1440 A ST3B, MT 1840 A ST3B
14	79533	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
15	192041	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
16	46668	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
17	42316	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
18	29469	washer	4		MT 1440 A ST3B, MT 1840 A ST3B
19	299263	Accelerator pedal	1		MT 1440 A ST3B, MT 1840 A ST3B
20	288358	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
21	748070	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
22	797792	Relay modulus	1		MT 1440 A ST3B, MT 1840 A ST3B
23	266680	Relay	1		MT 1440 A ST3B, MT 1840 A ST3B
24	748071	Modulus	2		MT 1440 A ST3B, MT 1840 A ST3B
25	250561	fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
26	250606	Fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
27	225184	Fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
28	797314	Modulus	1		MT 1440 A ST3B, MT 1840 A ST3B
29	225186	Fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
30	225187	Fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
31	250431	Fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
32	746158	Modulus	1		MT 1440 A ST3B, MT 1840 A ST3B
33	266377	Plate	1		MT 1440 A ST3B, MT 1840 A ST3B
34	243480	Fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
35	247075	Fuse	1		MT 1440 A ST3B, MT 1840 A ST3B
36	265723	Switch bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
37	224775	plug	4		MT 1440 A ST3B, MT 1840 A ST3B
38	280282	Movements cut out switch	1		MT 1440 A ST3B, MT 1840 A ST3B
39	747847	Lens	1		MT 1440 A ST3B, MT 1840 A ST3B
40	170836	Bulb	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	299864	Switch	1		MT 1440 A ST3B, MT 1840 A ST3B
42	796552	Lens	1		MT 1440 A ST3B, MT 1840 A ST3B
43	237370	Cigarette lighter	1		MT 1440 A ST3B, MT 1840 A ST3B
44	220408	Shunt	1		MT 1440 A ST3B, MT 1840 A ST3B
45	54242	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
46	260599	proximity switch	1		MT 1440 A ST3B, MT 1840 A ST3B
47	184036	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
48	266911	Switch assy	1		MT 1440 A ST3B, MT 1840 A ST3B
49	604829	Switch	1		MT 1440 A ST3B, MT 1840 A ST3B
50	603363	Switch + base plate	1	579041, 675473	MT 1440 A ST3B, MT 1840 A ST3B
51	746243	Switch	1		MT 1440 A ST3B, MT 1840 A ST3B
52	603363	Switch + base plate	1	579041, 675473	MT 1440 A ST3B, MT 1840 A ST3B
53	603363	Switch + base plate	2	579041, 675473	MT 1440 A ST3B, MT 1840 A ST3B
54	227321	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
55	245295	Fuse pincers	1	746159	MT 1440 A ST3B, MT 1840 A ST3B
56	245700	Relay	1		MT 1440 A ST3B, MT 1840 A ST3B
57	797315	Locker	1		MT 1440 A ST3B, MT 1840 A ST3B
58	797793	Locker	1		MT 1440 A ST3B, MT 1840 A ST3B
59	164856	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
60	52506971	Accelerator pedal bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
61	52513469	Instrument panel	1		

6 BB 282


PEDALERIE - TRINGLERIE
PEDALEN- GESTANGE
PEDALES - VARILLAS
PEDALS - LINKAGE
PEDALI - COMANDI

MT 1440 A ST3B
MT 1840 A ST3B




06 / 12 / 11
P.A.O. illus


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	261992	Gear lever	1		MT 1440 A ST3B, MT 1840 A ST3B
2	266028	Ball	1		MT 1440 A ST3B, MT 1840 A ST3B
3	551255	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
4	551256	Transmission cut-off switch	1		MT 1440 A ST3B, MT 1840 A ST3B
5	551258	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
6	551257	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
7	747053	Wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
8	29475	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
9	42231	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
10	261997	Fixing spring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	220645	Spring	1		MT 1440 A ST3B, MT 1840 A ST3B
12	261996	Fixing spring	1		MT 1440 A ST3B, MT 1840 A ST3B
13	58588	Screw	1	484439, 470109	MT 1440 A ST3B, MT 1840 A ST3B
14	194287	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
15	265806	Bellows	1		MT 1440 A ST3B, MT 1840 A ST3B
16	205275	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
17	189857	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
18	164856	Clamp	3		MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	294657	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
2	169552	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
3	233369	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
4	246891	Hose	1	264695, 277515, 280295, 297676	MT 1440 A ST3B, MT 1840 A ST3B
5	246891	Hose	1	264695, 277515, 280295, 297676	MT 1440 A ST3B, MT 1840 A ST3B
6	58533	Screw	5		MT 1440 A ST3B, MT 1840 A ST3B
7	264664	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
8	264663	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
9	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
10	168865	Half-clamp	12		MT 1440 A ST3B, MT 1840 A ST3B
11	168854	plate	6		MT 1440 A ST3B, MT 1840 A ST3B
12	58531	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
13	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
14	261969	control	1		MT 1440 A ST3B, MT 1840 A ST3B
15	746569	Wiring harness	1		MT 1440 A ST3B, MT 1840 A ST3B
16	746570	bulb	2		MT 1440 A ST3B, MT 1840 A ST3B
17	746571	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
18	746572	handle	2		MT 1440 A ST3B, MT 1840 A ST3B
19	746573	rack	1		MT 1440 A ST3B, MT 1840 A ST3B
20	746574	cable	1		MT 1440 A ST3B, MT 1840 A ST3B
21	564071	clip	1		MT 1440 A ST3B, MT 1840 A ST3B
22	260676	Heating	1		MT 1440 A ST3B, MT 1840 A ST3B
23	267932	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
24	194492	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
25	267870	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
26	304848	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
27	177637	Seal	0		MT 1440 A ST3B, MT 1840 A ST3B
28	304842	Hose	2		MT 1440 A ST3B, MT 1840 A ST3B
29	230567	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
30	60483	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
31	63351	washer	1		MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	259499	pipe union	1		MT 1440 A ST3B, MT 1840 A ST3B
2	745750	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
3	745751	o-ring	1		MT 1440 A ST3B, MT 1840 A ST3B
4	745752	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
5	745753	screw	6		MT 1440 A ST3B, MT 1840 A ST3B
6	745754	washer	6		MT 1440 A ST3B, MT 1840 A ST3B
7	289918	Complete hydraulic return oil filter	1		MT 1440 A ST3B, MT 1840 A ST3B
8	745714	Cover	1		MT 1440 A ST3B, MT 1840 A ST3B
9	745715	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
10	745716	Adjusting screw	1		MT 1440 A ST3B, MT 1840 A ST3B
11	289920	Hydraulic oil filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
12	745718	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
13	745719	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
14	745720	Low pressure	1		MT 1440 A ST3B, MT 1840 A ST3B
15	197335	Steering pump body	1		MT 1440 A ST3B, MT 1840 A ST3B
16	169586	Lamella kit	1		MT 1440 A ST3B, MT 1840 A ST3B
17	25026	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
18	305928	Complete hydraulic accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
20	746309	Hydraulic accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
21	746306	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
22	746308	Filter (hydraulic accumulator)	1		MT 1440 A ST3B, MT 1840 A ST3B
23	746307	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
24	748497	Electrovalve	1		MT 1440 A ST3B, MT 1840 A ST3B
25	746305	Solenoid	1		MT 1440 A ST3B, MT 1840 A ST3B
26	311820	Complete hydraulic return oil filter	1	289918	MT 1440 A ST3B, MT 1840 A ST3B
27	895453	Cover	1		MT 1440 A ST3B, MT 1840 A ST3B
28	745715	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
29	311821	Hydraulic oil filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
30	745718	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
31	745719	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
32	745720	Low pressure	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	797365	Pressure sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
2	797369	Oil pressure sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
3	797357	Temperature sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
4	797357	Temperature sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
5	797353	Heating plug	4		MT 1440 A ST3B, MT 1840 A ST3B
6	797370	Temperature sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
7	797366	Sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
8	745854	Oil temperature sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
9	746722	Sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746723	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
11	563821	Screw	1	551487, 746724	MT 1440 A ST3B, MT 1840 A ST3B
12	746725	Sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
13	745846	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
14	775856	Sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
15	306131	Air temperature sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
16	797364	Pressure sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
17	797623	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
18	797352	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
19	895915	Speed sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
20	797623	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
21	797625	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
22	797671	Pressure valve	1		MT 1440 A ST3B, MT 1840 A ST3B
23	797674	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
24	797623	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B

10 EA 309

HYDRAULIQUE (Détails)
HYDRAULIK (Einzelteile)
HIDRAULICO (Detalles)
HYDRAULIC (Details)
IDRAULICO (Dettaglio)

MT 625 T COMFORT Série 2-E3
MT-X 625 T COMFORT Série 2-E3
MLT 625 - 75 H Série1-E3
MLT-X 625 - 75 H Série1-E3



P.A.O. illus
18 / 05 / 11


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	290605	Remote control unit	1		MT 1440 A ST3B, MT 1840 A ST3B
2	747192	R.H. housing	1	748434	MT 1440 A ST3B, MT 1840 A ST3B
3	706143	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
4	794723	wiring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	788421	handle	1		MT 1440 A ST3B, MT 1840 A ST3B
6	706146	fairlead	1		MT 1440 A ST3B, MT 1840 A ST3B
7	794722	push button	1		MT 1440 A ST3B, MT 1840 A ST3B
8	746606	push button	2	745373	MT 1440 A ST3B, MT 1840 A ST3B
9	706147	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746320	screw	6		MT 1440 A ST3B, MT 1840 A ST3B
11	746321	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
12	746322	seal	2		MT 1440 A ST3B, MT 1840 A ST3B
13	705164	Female connector	1		MT 1440 A ST3B, MT 1840 A ST3B
14	704564	Male cable terminal	14		MT 1440 A ST3B, MT 1840 A ST3B
15	794870	Switch	1		MT 1440 A ST3B, MT 1840 A ST3B

8 AA 975

ADAPTATION CABINE
KABINE ANPASSUNG
ADAPTACION CABINA
CAB ADAPTATION
ADATTAMENTO CABINA

MT 1440 A ST3B
MT 1840 A ST3B

★ SURVANT MONTAGE
NACH MONTAGE
SEGUN MONTAJE
AS MOUNTING
SECONDO MONTAGGIO



* LIVRE AVEC CABINE
DELIVERED WITH CAB
CONSEGNARE CON CABINA

29 / 05 / 13

P.O. Iltis

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	290427	dashboard	1		MT 1440 A ST3B, MT 1840 A ST3B
2	29469	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
3	31007	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
4	189172	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
5	189857	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
6	290423	strike	4		MT 1440 A ST3B, MT 1840 A ST3B
7	290424	strike	1		MT 1440 A ST3B, MT 1840 A ST3B
8	261970	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
9	260414	Instrument panel fittings	1		MT 1440 A ST3B, MT 1840 A ST3B
10	260415	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
11	260416	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
12	194668	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
13	225746	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
14	260417	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
15	260413	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
16	745658	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
17	240822	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
18	261975	duct	1		MT 1440 A ST3B, MT 1840 A ST3B
19	267870	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
21	286593	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
22	79533	Screw	5		MT 1440 A ST3B, MT 1840 A ST3B
23	189858	Washer	5		MT 1440 A ST3B, MT 1840 A ST3B
24	287795	cable protection	1		MT 1440 A ST3B, MT 1840 A ST3B
25	214137	lock	1		MT 1440 A ST3B, MT 1840 A ST3B
26	264478	Am-rest	1		MT 1440 A ST3B, MT 1840 A ST3B
27	260557	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
28	247117	flexible dust cover	1		MT 1440 A ST3B, MT 1840 A ST3B
29	290605	Remote control unit	1		MT 1440 A ST3B, MT 1840 A ST3B
30	260604	R.H. side console	1		MT 1440 A ST3B, MT 1840 A ST3B
31	189172	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
32	189857	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
33	239337	level	1		MT 1440 A ST3B, MT 1840 A ST3B
34	61213	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
35	264818	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
36	261835	clip	4		MT 1440 A ST3B, MT 1840 A ST3B
37	261544	Load chart bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
38	226606	screw	1	229591	MT 1440 A ST3B, MT 1840 A ST3B
39	276562	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
40	264698	Cover	1		MT 1440 A ST3B, MT 1840 A ST3B
41	52521342	Foam	1	264701	MT 1440 A ST3B, MT 1840 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
42	746181	Hinge	2		MT 1440 A ST3B, MT 1840 A ST3B
43	748476	guard	1		MT 1440 A ST3B, MT 1840 A ST3B
44	747768	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
45	746627	adhesive	1		MT 1440 A ST3B, MT 1840 A ST3B
46	476831	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
47	277592	housing	1		MT 1440 A ST3B, MT 1840 A ST3B
48	603173	screw	6	549072, 272118	MT 1440 A ST3B, MT 1840 A ST3B
49	750330	nut	4		MT 1440 A ST3B, MT 1840 A ST3B
50	750327	nut	3		MT 1440 A ST3B, MT 1840 A ST3B
51	275036	plug	1		MT 1440 A ST3B, MT 1840 A ST3B

_REAR

3 AA 390

ROUES
RAD
RUEDAS
WHEELS
RUOTE

MT 1440 A ST3B



02 / 12 / 11

P.A.O. B&B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	270318	Complete wheel	4		MT 1440 A ST3B
2	273331	Tyre	1	282540	MT 1440 A ST3B
3	52500645	Wheel, stripped	1		MT 1440 A ST3B
4	60665	Valve	1	587325	MT 1440 A ST3B
5	781678	nut	32	245767, 109480	MT 1440 A ST3B

_REAR

3 AA 391

ROUES
RAD
RUEDAS
WHEELS
RUOTE

MT 1840 A ST3B



01 / 12 / 11

P.A.O. B&B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	270315	Complete wheel	4		MT 1840 A ST3B
2	273332	Tyre	1		MT 1840 A ST3B
3	52500645	Wheel, stripped	1		MT 1840 A ST3B
4	60665	Valve	1	587325	MT 1840 A ST3B
5	781678	nut	32	245767, 109480	MT 1840 A ST3B

_REAR

AX 2745

POUR ESSIEU ARRIERE
FÜR HINTERACHSE
PARA EJE TRASERO
REAR FRONT AXLE
PER ASSALE POSTERIORE


□ Type : 212 / 469
□ Ref : 259 394

JUSQU'À LA MACHINE
BIS DER MASCHINE
HASTA LA MAQUINA
UP TO MACHINE
FINO LA MACCHINA

→ N° : 908 287


ESSIEU ARRIERE
HINTERACHSE
EJE TRASERO
REAR AXLE
ASSALE POSTERIORE

MT 1440 A ST3B
MT 1840 A ST3B



05 / 04 / 12
P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	299939	Rear axle	1		MT 1440 A ST3B, MT 1840 A ST3B
2	197378	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
3	196460	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
4	781678	nut	16	245767, 109480	MT 1440 A ST3B, MT 1840 A ST3B
5	289561	Centering pin	4		MT 1440 A ST3B, MT 1840 A ST3B
6	477538	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
7	299970	Front bearing	1		MT 1440 A ST3B, MT 1840 A ST3B
8	299971	Rear bearing	1		MT 1440 A ST3B, MT 1840 A ST3B



05 / 04 / 12
P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	299939	Rear axle	1		MT 1440 A ST3B, MT 1840 A ST3B
2	197378	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
3	196460	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
4	781678	nut	16	245767, 109480	MT 1440 A ST3B, MT 1840 A ST3B

_FRONT

AX 2744

POUR ESSIEU AVANT
FÜR VORNACHSE
PARA EJE DELANTERO
FOR FRONT AXLE
PER ASSALE ANTERIORE


□ □ Type : 212 / 452
□ □ Ref : 259 395

JUSQU'À LA MACHINE
BIS DER MASCHINE
HASTA LA MAQUINA
UP TO MACHINE
FINO LA MACCHINA

→ N° : 908 287

ESSIEU AVANT
VORNACHSE
EJE DELANTERO
FRONT AXLE
ASSALE ANTERIORE

MT 1440 HA ST3B
MT 1840 HA ST3B



05 / 04 / 12
P.A.O. / l.h.s

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	299938	Front axle	1		MT 1440 A ST3B, MT 1840 A ST3B
2	197378	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
3	196460	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
4	781678	nut	16	245767, 109480	MT 1440 A ST3B, MT 1840 A ST3B
5	289561	Centering pin	4		MT 1440 A ST3B, MT 1840 A ST3B
6	477538	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
7	299970	Front bearing	1		MT 1440 A ST3B, MT 1840 A ST3B
8	299971	Rear bearing	1		MT 1440 A ST3B, MT 1840 A ST3B

_FRONT

AX 2747

POUR ESSIEU AVANT
FÜR VORNACHSE
PARA EJE DELANTERO
FOR FRONT AXLE
PER ASSALE ANTERIORE


□ □ Type : 212 / 452
□ □ Ref : 299938

A PARTIR DE LA MACHINE
AB DER MASCHINE
A PARTIR DE LA MAQUINA
FROM MACHINE
A PARTIR DA MACCHINA

→ N° : 908 288

ESSIEU AVANT
VORNACHSE
EJE DELANTERO
FRONT AXLE
ASSALE ANTERIORE

MT 1440 H ST3B
MT 1840 H ST3B



05 / 04 / 12
P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	299938	Front axle	1		MT 1440 A ST3B, MT 1840 A ST3B
2	197378	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
3	196460	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
4	781678	nut	16	245767, 109480	MT 1440 A ST3B, MT 1840 A ST3B

__ATTACHMENT

10 AE 1341

HYDRAULIQUE (Circuit flèche - Accessoires)
 HYDRAULIK (Auslegerkreis - Zubehör)
 HIDRAULICO (Circuito aguilón - Accesorios)
 HYDRAULIC (Jib circuit - Attachments)
 IDRAULICO (Cicuito bracci telescopici - accessori)


MT 1440 A ST3B

POUR FLEXIBLE ET RACCORD
 FÜR SCHLAUCH UND VERSCHRAUBUNG
 PARA FLEXIBLE Y RACOR
 FOR HOSE AND CONNECTION
 PER FLESSIBILE E RACCORDO

Ø 2 mm
 Ø 13 mm


POUR TUBE - FÜR ROHR
 PARA TUBO - FOR TUBE
 PER TUBO

Ø 16 mm
 Ø 2 mm
 Ø 13 mm




08 / 11 / 11
 P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	280952	Tube	1		MT 1440 A ST3B
2	287869	Tube	1		MT 1440 A ST3B
3	261806	Hose	1		MT 1440 A ST3B
4	219457	"O" ring	0		MT 1440 A ST3B
5	261802	Hose	2		MT 1440 A ST3B
6	280972	Connection	1		MT 1440 A ST3B
7	280835	Tube	1		MT 1440 A ST3B
8	287867	Tube	1		MT 1440 A ST3B
9	193325	Connection	2		MT 1440 A ST3B
10	261397	Connection	2		MT 1440 A ST3B
11	227321	washer	4		MT 1440 A ST3B
12	401668	Nut	2		MT 1440 A ST3B
13	261439	Coupling bracket	1		MT 1440 A ST3B
14	31051	Screw	2	484718	MT 1440 A ST3B
15	219457	"O" ring	0		MT 1440 A ST3B
16	63351	washer	2		MT 1440 A ST3B
17	261398	plug	2		MT 1440 A ST3B
18	214365	name plate	1		MT 1440 A ST3B
19	214364	name plate	1		MT 1440 A ST3B
20	193325	Connection	1		MT 1440 A ST3B
21	281914	Bushing	1		MT 1440 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	297561	Hydraulic tube	1		MT 1840 A ST3B
2	293235	Tube	1		MT 1840 A ST3B
3	293237	Tube	1		MT 1840 A ST3B
4	219457	"O" ring	1		MT 1840 A ST3B
5	293819	Hose	1		MT 1840 A ST3B
6	219457	"O" ring	1		MT 1840 A ST3B
7	293803	screw	1		MT 1840 A ST3B
8	58531	Screw	1		MT 1840 A ST3B
9	168494	Protection plate	1		MT 1840 A ST3B
10	293749	Half-clamp	2		MT 1840 A ST3B
11	290788	Hose	1		MT 1840 A ST3B
12	288604	Tube	1		MT 1840 A ST3B
13	288605	Tube	1		MT 1840 A ST3B
14	168758	Half-clamp	2		MT 1840 A ST3B
15	168494	Protection plate	1		MT 1840 A ST3B
16	61323	Screw	1		MT 1840 A ST3B
17	193325	Connection	2		MT 1840 A ST3B
18	261398	plug	2		MT 1840 A ST3B
19	261397	Connection	2		MT 1840 A ST3B
20	227321	washer	4		MT 1840 A ST3B
21	401668	Nut	2		MT 1840 A ST3B
22	288599	Coupling bracket	1		MT 1840 A ST3B
23	54951	Screw	2		MT 1840 A ST3B
24	63351	washer	2		MT 1840 A ST3B
25	289383	pulley	1		MT 1840 A ST3B
26	567420	bushing	2		MT 1840 A ST3B
27	298811	Housing	1		MT 1840 A ST3B
28	261500	Screw	4		MT 1840 A ST3B
29	260473	Clamp	2		MT 1840 A ST3B
30	214365	name plate	1		MT 1840 A ST3B
31	214364	name plate	1		MT 1840 A ST3B
32	281914	Bushing	1		MT 1840 A ST3B
33	303634	Hydraulic tube	1		MT 1840 A ST3B
34	303635	Hydraulic tube	1		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	300419	Tube assy	1		MT 1840 A ST3B
2	297562	Hydraulic tube	1		MT 1840 A ST3B
3	273436	screw	4	278713	MT 1840 A ST3B
10	293819	Hose	1		MT 1840 A ST3B
11	219457	"0" ring	1		MT 1840 A ST3B
12	289383	pulley	2		MT 1840 A ST3B
13	567420	bushing	4		MT 1840 A ST3B
14	287972	support	2		MT 1840 A ST3B
15	273112	screw	6		MT 1840 A ST3B
16	297389	support	1		MT 1840 A ST3B
17	776947	pin	1		MT 1840 A ST3B
18	55131	grease nipple	1		MT 1840 A ST3B
20	61674	Washer	2		MT 1840 A ST3B
21	8038	Pin	4	482336, 5152, T7004055, 133645, K449025026, T7003030, 63035, 134136, 125211, 58396, 125210, 138074, 418810, 9538103028, 471351, A506354, 853817602471	MT 1840 A ST3B
22	293803	screw	4		MT 1840 A ST3B
23	298846	Drain trough	1		MT 1840 A ST3B
24	295078	sliding block	3		MT 1840 A ST3B
25	261504	screw	6		MT 1840 A ST3B
26	291794	support	2		MT 1840 A ST3B
27	268255	screw	4		MT 1840 A ST3B
28	778221	spring	2		MT 1840 A ST3B
29	289294	guide	2		MT 1840 A ST3B
30	289146	spacer	2		MT 1840 A ST3B
33	194048	washer	2		MT 1840 A ST3B
34	297410	shaft	1		MT 1840 A ST3B
35	297415	roller	2		MT 1840 A ST3B
36	290788	Hose	1		MT 1840 A ST3B
37	303424	Housing	1		MT 1840 A ST3B
38	261495	Screw	4		MT 1840 A ST3B
39	29469	washer	4		MT 1840 A ST3B
40	297414	roller	4		MT 1840 A ST3B
42	297147	Half-flange	1		MT 1840 A ST3B
43	297148	Half-flange	1		MT 1840 A ST3B
44	293806	screw	2		MT 1840 A ST3B
45	297164	screw	2		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
51	168758	Half-clamp	2		MT 1840 A ST3B
52	168494	Protection plate	1		MT 1840 A ST3B
53	58530	Screw	1		MT 1840 A ST3B
54	295721	Hose	1		MT 1840 A ST3B
55	295721	Hose	1		MT 1840 A ST3B
56	193325	Connection	2		MT 1840 A ST3B
57	485396	pipe fitting	2		MT 1840 A ST3B
58	177638	Seal	1		MT 1840 A ST3B
59	229571	Balancing valve	1		MT 1840 A ST3B
60	189960	"O" ring	2		MT 1840 A ST3B
61	600907	Repair kit	1		MT 1840 A ST3B
62	42325	Washer	4		MT 1840 A ST3B
63	58531	Screw	4		MT 1840 A ST3B
64	260508	Tilting cylinder	1		MT 1840 A ST3B
65	264608	Pin	1		MT 1840 A ST3B
66	60360	Screw	1		MT 1840 A ST3B
67	45921	Washer	1		MT 1840 A ST3B
68	264606	Pin	1		MT 1840 A ST3B
69	192213	Circlip	1		MT 1840 A ST3B
71	292349	Weatherstrip	1		MT 1840 A ST3B
72	297021	Half-flange	2		MT 1840 A ST3B
73	297023	Half-flange	2		MT 1840 A ST3B
74	293806	screw	4		MT 1840 A ST3B
75	299297	Cap	1		MT 1840 A ST3B
82	293804	Screw	2		MT 1840 A ST3B
83	289295	cotter pin	2		MT 1840 A ST3B
84	5302	Pin	2		MT 1840 A ST3B
85	268255	screw	2		MT 1840 A ST3B
86	300952	Cam	1		MT 1840 A ST3B
87	303275	Hydraulic tube	1		MT 1840 A ST3B
88	303276	Hydraulic tube	1		MT 1840 A ST3B
89	41186	nut	2		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	297561	Hydraulic tube	1		MT 1840 A ST3B
4	219457	"O" ring	1		MT 1840 A ST3B
5	293819	Hose	1		MT 1840 A ST3B
6	219457	"O" ring	1		MT 1840 A ST3B
7	293803	screw	4		MT 1840 A ST3B
11	290788	Hose	1		MT 1840 A ST3B
14	168758	Half-clamp	2		MT 1840 A ST3B
15	168494	Protection plate	1		MT 1840 A ST3B
16	61323	Screw	1		MT 1840 A ST3B
17	193325	Connection	2		MT 1840 A ST3B
18	261398	plug	2		MT 1840 A ST3B
19	261397	Connection	2		MT 1840 A ST3B
20	227321	washer	4		MT 1840 A ST3B
21	401668	Nut	2		MT 1840 A ST3B
22	288599	Coupling bracket	1		MT 1840 A ST3B
23	54951	Screw	2		MT 1840 A ST3B
24	63351	washer	2		MT 1840 A ST3B
25	289383	pulley	1		MT 1840 A ST3B
26	567420	bushing	2		MT 1840 A ST3B
30	214365	name plate	1		MT 1840 A ST3B
31	214364	name plate	1		MT 1840 A ST3B
32	281914	Bushing	1		MT 1840 A ST3B
33	303634	Hydraulic tube	1		MT 1840 A ST3B
34	303635	Hydraulic tube	1		MT 1840 A ST3B

ACUMULATOR



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	74357	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
2	169372	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
3	259573	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
4	219457	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	167925	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
6	169373	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
7	290552	Balancing valve	1		MT 1440 A ST3B, MT 1840 A ST3B
8	781854	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
9	189960	"O" ring	2		MT 1440 A ST3B, MT 1840 A ST3B
10	61545	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
11	42325	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
12	281602	Lifting cylinder	1		MT 1440 A ST3B
13	281601	Lifting cylinder	1		MT 1840 A ST3B
14	267483	Articulating pin	1		MT 1440 A ST3B, MT 1840 A ST3B
15	60360	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
16	45921	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
17	267482	Articulating pin	1		MT 1440 A ST3B, MT 1840 A ST3B
18	60360	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
19	45921	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
20	167923	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
21	259571	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
22	25002	"O" ring	1	563895, 86788	MT 1440 A ST3B, MT 1840 A ST3B
23	259604	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
24	232463	Half-clamp	6		MT 1440 A ST3B, MT 1840 A ST3B
25	168854	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
26	58530	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
27	261020	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
28	261020	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
29	261348	Bracket hose	1		MT 1440 A ST3B, MT 1840 A ST3B
30	54951	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
31	63351	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
32	259543	Flange	1		MT 1440 A ST3B, MT 1840 A ST3B
33	58533	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
34	63351	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
35	210971	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
36	289379	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
37	266178	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
38	177588	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
39	284398	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
40	750539	Solenoid	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	193325	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
42	174551	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
43	169552	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
44	264435	Hydraulic accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
45	197760	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
46	203670	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
47	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
48	192386	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
49	190877	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
50	299297	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
51	189956	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
52	52504751	Lifting cylinder	1	281602, 794859	MT 1440 A ST3B
53	52504752	Lifting cylinder	1	281601, 794861	MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	268226	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
2	177636	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
3	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
4	190013	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	264725	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
6	212828	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
7	209249	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
8	271984	Master cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
9	786448	Bellows	1		MT 1440 A ST3B, MT 1840 A ST3B
10	786449	Repair kit	1		MT 1440 A ST3B, MT 1840 A ST3B
11	5818	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
12	42231	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
13	261144	pin	1		MT 1440 A ST3B, MT 1840 A ST3B
14	56354	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
15	5549	fork	1		MT 1440 A ST3B, MT 1840 A ST3B
16	4350	Pin	1		MT 1440 A ST3B, MT 1840 A ST3B
17	29437	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
18	61344	dowel	1		MT 1440 A ST3B, MT 1840 A ST3B
19	273325	pedal	1		MT 1440 A ST3B, MT 1840 A ST3B
20	172569	bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
21	190427	bumper	1		MT 1440 A ST3B, MT 1840 A ST3B
22	3212	Nut	1	58646, 132479, 9412040800, 841207600371, 206882, 454217, 485025, 43151F106071, 478567, 4292	MT 1440 A ST3B, MT 1840 A ST3B
23	5398	spring	1		MT 1440 A ST3B, MT 1840 A ST3B
24	7242	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
25	25714	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
26	7242	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
27	285334	support	1		MT 1440 A ST3B, MT 1840 A ST3B
28	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
29	261141	Articulating pin	1		MT 1440 A ST3B, MT 1840 A ST3B
30	162215	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
31	174132	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
32	217096	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
33	168850	Clamp Half HR2L 16 0/1	4		MT 1440 A ST3B, MT 1840 A ST3B
34	167155	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
35	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
36	261384	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
37	177588	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
38	203709	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
39	264052	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
40	169373	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
41	161625	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
42	168492	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
43	282223	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
44	295897	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
45	168487	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
46	168490	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
47	54284	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
48	213046	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
49	169552	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
50	261382	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
51	305971	Accumulator	1	602643	MT 1440 A ST3B, MT 1840 A ST3B
52	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
53	305928	Complete hydraulic accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
54	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
55	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
56	261481	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
57	265297	Excess flow valve	1		MT 1440 A ST3B, MT 1840 A ST3B
58	746393	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
59	168753	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
60	292071	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
61	168866	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
62	168858	collar	1		MT 1440 A ST3B, MT 1840 A ST3B
63	60950	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
64	63351	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
65	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
66	209280	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
67	191197	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
68	237907	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
69	177635	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
70	183036	Hydraulic hose	1	193953, 260468	MT 1440 A ST3B, MT 1840 A ST3B
71	227352	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
72	236147	tank	1		MT 1440 A ST3B, MT 1840 A ST3B
73	895314	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
74	602032	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
75	167981	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
76	78806	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
77	264122	Spacer	2		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
78	180603	Nut	2	750482, A7204813A, 2762401MI, 603235, 485980	MT 1440 A ST3B, MT 1840 A ST3B
79	194896	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
80	264073	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
81	247873	Hose	1	245401	MT 1440 A ST3B, MT 1840 A ST3B
82	260790	guard	1		MT 1440 A ST3B, MT 1840 A ST3B
83	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
84	197784	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
85	287255	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
86	173004	Half-clamp	6		MT 1440 A ST3B, MT 1840 A ST3B
87	168847	Protection plate	3		MT 1440 A ST3B, MT 1840 A ST3B
88	54305	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
89	264069	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
90	168486	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
91	168490	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
92	54284	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
93	190442	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
94	260463	Tube	2		MT 1440 A ST3B, MT 1840 A ST3B
95	497922	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
96	214908	Connection	4		MT 1440 A ST3B, MT 1840 A ST3B
97	264070	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
98	25714	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
99	28988	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
100	261679	Pressure test	1		MT 1440 A ST3B, MT 1840 A ST3B
101	605816	Pressure test	2		MT 1440 A ST3B, MT 1840 A ST3B
102	497922	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
103	175498	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
104	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
105	226282	Bushing	1		MT 1440 A ST3B, MT 1840 A ST3B
106	270477	Tank bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
107	29469	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
108	189172	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
109	295847	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
110	252781	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
111	295681	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
112	168492	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
113	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
114	798371	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	268226	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
2	177636	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
3	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
4	190013	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	264725	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
6	212828	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
7	209249	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
8	271984	Master cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
9	786448	Bellows	1		MT 1440 A ST3B, MT 1840 A ST3B
10	786449	Repair kit	1		MT 1440 A ST3B, MT 1840 A ST3B
11	5818	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
12	42231	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
13	261144	pin	1		MT 1440 A ST3B, MT 1840 A ST3B
14	56354	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
15	5549	fork	1		MT 1440 A ST3B, MT 1840 A ST3B
16	4350	Pin	1		MT 1440 A ST3B, MT 1840 A ST3B
17	29437	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
18	61344	dowel	1		MT 1440 A ST3B, MT 1840 A ST3B
19	305961	pedal	1		MT 1440 A ST3B, MT 1840 A ST3B
20	172569	bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
21	190427	bumper	1		MT 1440 A ST3B, MT 1840 A ST3B
22	3212	Nut	1	58646, 132479, 9412040800, 841207600371, 206882, 454217, 485025, 43151F106071, 478567, 4292	MT 1440 A ST3B, MT 1840 A ST3B
23	5398	spring	1		MT 1440 A ST3B, MT 1840 A ST3B
24	7242	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
25	25714	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
26	7242	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
27	312352	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
28	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
29	317217	Articulating pin	1		MT 1440 A ST3B, MT 1840 A ST3B
30	162215	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
31	174132	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
32	217096	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
33	168850	Clamp Half HR2L 16 0/1	4		MT 1440 A ST3B, MT 1840 A ST3B
34	167155	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
35	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
36	261384	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
37	177588	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
38	203709	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
39	264052	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
40	169373	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
41	161625	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
42	168492	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
43	282223	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
44	295897	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
45	168487	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
46	168490	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
47	54284	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
48	213046	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
49	169552	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
50	261382	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
51	305971	Accumulator	1	602643	MT 1440 A ST3B, MT 1840 A ST3B
52	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
53	305928	Complete hydraulic accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
54	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
55	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
56	261481	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
57	265297	Excess flow valve	1		MT 1440 A ST3B, MT 1840 A ST3B
58	746393	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
59	168753	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
60	292071	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
61	168866	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
62	168858	collar	1		MT 1440 A ST3B, MT 1840 A ST3B
63	60950	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
64	63351	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
65	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
66	209280	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
67	191197	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
68	237907	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
69	177635	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
70	183036	Hydraulic hose	1	193953, 260468	MT 1440 A ST3B, MT 1840 A ST3B
71	227352	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
72	236147	tank	1		MT 1440 A ST3B, MT 1840 A ST3B
73	895314	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
74	798371	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
75	167981	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
76	78806	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
77	264122	Spacer	2		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
78	180603	Nut	2	750482, A7204813A, 2762401MI, 603235, 485980	MT 1440 A ST3B, MT 1840 A ST3B
79	194896	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
80	264073	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
81	247873	Hose	1	245401	MT 1440 A ST3B, MT 1840 A ST3B
82	260790	guard	1		MT 1440 A ST3B, MT 1840 A ST3B
83	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
84	197784	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
85	287255	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
86	173004	Half-clamp	6		MT 1440 A ST3B, MT 1840 A ST3B
87	168847	Protection plate	3		MT 1440 A ST3B, MT 1840 A ST3B
88	54305	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
89	264069	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
90	168486	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
91	168490	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
92	54284	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
93	190442	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
94	260463	Tube	2		MT 1440 A ST3B, MT 1840 A ST3B
95	497922	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
96	214908	Connection	4		MT 1440 A ST3B, MT 1840 A ST3B
97	264070	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
98	25714	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
99	28988	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
100	261679	Pressure test	1		MT 1440 A ST3B, MT 1840 A ST3B
101	605816	Pressure test	2		MT 1440 A ST3B, MT 1840 A ST3B
102	497922	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
103	175498	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
104	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
106	270477	Tank bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
107	29469	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
108	189172	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
110	252781	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
111	295681	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
112	168492	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
113	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B

___AXLE LOCKING



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	266178	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
2	177588	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
3	266242	Filter	1		MT 1440 A ST3B, MT 1840 A ST3B
4	271235	Half-clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
5	168870	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
6	60950	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
7	270902	Filter bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
8	31051	Screw	2	484718	MT 1440 A ST3B, MT 1840 A ST3B
9	44025	Washer	2	4101, 484100, 485125, 480304, 550938	MT 1440 A ST3B, MT 1840 A ST3B
10	266177	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
11	219457	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
12	210971	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
13	291592	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
14	168850	Clamp Half HR2L 16 0/1	4		MT 1440 A ST3B, MT 1840 A ST3B
15	168490	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
16	54284	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
17	193325	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
18	74362	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
19	169552	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
20	294868	Cylinder of locking rear axle	2		MT 1440 A ST3B, MT 1840 A ST3B
21	259592	Bushing	4		MT 1440 A ST3B, MT 1840 A ST3B
22	242059	screw	12		MT 1440 A ST3B, MT 1840 A ST3B
23	194287	Washer	12		MT 1440 A ST3B, MT 1840 A ST3B
24	259593	Delivery port connection	2		MT 1440 A ST3B, MT 1840 A ST3B
25	168358	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
26	194048	washer	4		MT 1440 A ST3B, MT 1840 A ST3B
27	219457	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
28	311701	Cylinder of locking rear axle	2		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	174548	Connection	2		MT 1440 A ST3B
2	169373	"O" ring	1		MT 1440 A ST3B
3	259578	Hose	1		MT 1440 A ST3B
4	219457	"O" ring	1		MT 1440 A ST3B
5	259578	Hose	1		MT 1440 A ST3B
6	232463	Half-clamp	4		MT 1440 A ST3B
7	168854	plate	1		MT 1440 A ST3B
8	261020	Screw	1		MT 1440 A ST3B
9	58528	nut	1		MT 1440 A ST3B
10	170387	Half-clamp	4		MT 1440 A ST3B
11	168854	plate	1		MT 1440 A ST3B
12	261020	Screw	1		MT 1440 A ST3B
13	58528	nut	1		MT 1440 A ST3B
14	170387	Half-clamp	4		MT 1440 A ST3B
15	168854	plate	1		MT 1440 A ST3B
16	282222	Screw	1	259564	MT 1440 A ST3B
17	58528	nut	1		MT 1440 A ST3B
18	74357	pipe fitting	1		MT 1440 A ST3B
19	169372	"O" ring	1		MT 1440 A ST3B
20	261352	Hose	1		MT 1440 A ST3B
21	259636	Connection	1		MT 1440 A ST3B
22	259572	Hose	1		MT 1440 A ST3B
23	287000	Connection	2		MT 1440 A ST3B
24	194818	Hose	1		MT 1440 A ST3B
25	194818	Hose	1		MT 1440 A ST3B
26	180396	Hose	1		MT 1440 A ST3B
27	190874	"O" ring	1		MT 1440 A ST3B
28	190968	Hose	1		MT 1440 A ST3B
29	217217	Half-clamp	2		MT 1440 A ST3B
30	168494	Protection plate	1		MT 1440 A ST3B
31	61323	Screw	1		MT 1440 A ST3B
32	257899	Fastening plate	1		MT 1440 A ST3B
33	281603	Compensation cylinder	1		MT 1440 A ST3B
34	259645	Articulating pin	1		MT 1440 A ST3B
35	264500	Articulating pin	1		MT 1440 A ST3B
36	60360	Screw	2		MT 1440 A ST3B
37	45921	Washer	2		MT 1440 A ST3B
38	197233	Connection	1		MT 1440 A ST3B
39	212831	Connection	1		MT 1440 A ST3B
40	247861	Hose	1	213031	MT 1440 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	167927	Connection	2		MT 1440 A ST3B
42	169436	"O" ring	1		MT 1440 A ST3B
43	265366	Valve	1		MT 1440 A ST3B
44	264746	Valve bracket	1		MT 1440 A ST3B
45	6224	Screw	2		MT 1440 A ST3B
46	42325	Washer	2		MT 1440 A ST3B
47	171109	Hose	1		MT 1440 A ST3B
48	746721	Seal kit	1		MT 1440 A ST3B
49	167924	pipe fitting	1		MT 1440 A ST3B
50	226621	Connection	1		MT 1440 A ST3B
51	193773	Connection	1		MT 1440 A ST3B
52	190877	Seal	1		MT 1440 A ST3B
53	62179	Valve	1		MT 1440 A ST3B
54	193772	Connection	1		MT 1440 A ST3B
55	213488	hose	1		MT 1440 A ST3B
56	193325	Connection	1		MT 1440 A ST3B
57	210971	Connection	1		MT 1440 A ST3B
58	258264	Hose	1		MT 1440 A ST3B
59	168851	Half-clamp	2		MT 1440 A ST3B
60	168491	Protection plate	1		MT 1440 A ST3B
61	31007	Screw	2		MT 1440 A ST3B
62	205349	Connection	1		MT 1440 A ST3B
63	25002	"O" ring	1	563895, 86788	MT 1440 A ST3B
64	268224	Fastening lug	1		MT 1440 A ST3B
65	86506	Clamp	1		MT 1440 A ST3B
66	259601	Screw	1		MT 1440 A ST3B
67	247871	Hose	1	209635	MT 1440 A ST3B
68	52504753	Compensation cylinder	1	281603	MT 1440 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	174548	Connection	2		MT 1840 A ST3B
2	169373	"O" ring	1		MT 1840 A ST3B
3	259578	Hose	1		MT 1840 A ST3B
4	219457	"O" ring	1		MT 1840 A ST3B
5	259578	Hose	1		MT 1840 A ST3B
6	232463	Half-clamp	4		MT 1840 A ST3B
7	168854	plate	1		MT 1840 A ST3B
8	261020	Screw	1		MT 1840 A ST3B
9	58528	nut	1		MT 1840 A ST3B
10	170387	Half-clamp	4		MT 1840 A ST3B
11	168854	plate	1		MT 1840 A ST3B
12	261020	Screw	1		MT 1840 A ST3B
13	58528	nut	1		MT 1840 A ST3B
14	170387	Half-clamp	4		MT 1840 A ST3B
15	168854	plate	1		MT 1840 A ST3B
16	282222	Screw	1	259564	MT 1840 A ST3B
17	58528	nut	1		MT 1840 A ST3B
18	74357	pipe fitting	1		MT 1840 A ST3B
19	169372	"O" ring	1		MT 1840 A ST3B
20	261352	Hose	1		MT 1840 A ST3B
21	259636	Connection	1		MT 1840 A ST3B
22	259572	Hose	1		MT 1840 A ST3B
23	287000	Connection	2		MT 1840 A ST3B
24	194818	Hose	1		MT 1840 A ST3B
25	194818	Hose	1		MT 1840 A ST3B
26	180396	Hose	1		MT 1840 A ST3B
27	190874	"O" ring	1		MT 1840 A ST3B
28	190968	Hose	1		MT 1840 A ST3B
29	217217	Half-clamp	2		MT 1840 A ST3B
30	168494	Protection plate	1		MT 1840 A ST3B
31	61323	Screw	1		MT 1840 A ST3B
32	257899	Fastening plate	1		MT 1840 A ST3B
33	281603	Compensation cylinder	1		MT 1840 A ST3B
34	259645	Articulating pin	1		MT 1840 A ST3B
35	264500	Articulating pin	1		MT 1840 A ST3B
36	60360	Screw	2		MT 1840 A ST3B
37	45921	Washer	2		MT 1840 A ST3B
38	197233	Connection	1		MT 1840 A ST3B
39	212831	Connection	1		MT 1840 A ST3B
40	247861	Hose	1	213031	MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	167927	Connection	2		MT 1840 A ST3B
42	169436	"O" ring	1		MT 1840 A ST3B
43	265366	Valve	1		MT 1840 A ST3B
44	264746	Valve bracket	1		MT 1840 A ST3B
45	6224	Screw	2		MT 1840 A ST3B
46	42325	Washer	2		MT 1840 A ST3B
47	171109	Hose	1		MT 1840 A ST3B
48	746721	Seal kit	1		MT 1840 A ST3B
49	167924	pipe fitting	1		MT 1840 A ST3B
50	226621	Connection	1		MT 1840 A ST3B
51	193773	Connection	1		MT 1840 A ST3B
52	190877	Seal	1		MT 1840 A ST3B
53	62179	Valve	1		MT 1840 A ST3B
54	193772	Connection	1		MT 1840 A ST3B
55	213488	hose	1		MT 1840 A ST3B
56	193325	Connection	1		MT 1840 A ST3B
57	210971	Connection	1		MT 1840 A ST3B
58	258264	Hose	1		MT 1840 A ST3B
59	168851	Half-clamp	2		MT 1840 A ST3B
60	168491	Protection plate	1		MT 1840 A ST3B
61	31007	Screw	2		MT 1840 A ST3B
62	205349	Connection	1		MT 1840 A ST3B
63	25002	"O" ring	1	563895, 86788	MT 1840 A ST3B
64	268224	Fastening lug	1		MT 1840 A ST3B
65	86506	Clamp	1		MT 1840 A ST3B
66	259601	Screw	1		MT 1840 A ST3B
67	247871	Hose	1	209635	MT 1840 A ST3B
68	52504753	Compensation cylinder	1	281603	MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	167925	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
2	169373	"O" ring	1		MT 1840 A ST3B
2	169373	"O" ring	0		MT 1440 A ST3B
3	200671	Hose	2		MT 1440 A ST3B, MT 1840 A ST3B
4	219457	"O" ring	1		MT 1840 A ST3B
4	219457	"O" ring	0		MT 1440 A ST3B
5	193325	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
6	74362	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
7	169552	"O" ring	1		MT 1840 A ST3B
7	169552	"O" ring	0		MT 1440 A ST3B
8	174618	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
9	266306	Complete valve bank	1		MT 1440 A ST3B, MT 1840 A ST3B
10	259946	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
11	267160	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
12	169434	"O" ring	0	213859	MT 1440 A ST3B
12	169434	"O" ring	1	213859	MT 1840 A ST3B
13	248325	Hose	1	210999	MT 1440 A ST3B, MT 1840 A ST3B
14	190013	"O" ring	1		MT 1840 A ST3B
14	190013	"O" ring	0		MT 1440 A ST3B
15	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
16	202512	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
17	170387	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
18	168854	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
19	58531	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
20	268225	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
21	168854	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
22	282222	Screw	1	259564	MT 1440 A ST3B, MT 1840 A ST3B
23	254177	Nut	3		MT 1440 A ST3B, MT 1840 A ST3B
24	259534	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
25	259946	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
26	268229	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
27	277213	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
28	227088	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
29	277216	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
30	301021	Guide hose	1		MT 1440 A ST3B, MT 1840 A ST3B


10 AG 306

HYDRAULIQUE (Circuit correcteur de dévers)
 HYDRAULIK (Niveauausgleich kreis)
 HIDRAULICO (Circuito corrector de inclinación)
 HYDRAULIC (Levelling system circuit)
 IDRAULICO (Circuito livellamento)

MT 1440 A ST3B
MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	168753	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
2	169552	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
3	211706	Hose	2		MT 1440 A ST3B, MT 1840 A ST3B
4	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	217217	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
6	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
7	6224	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
8	197233	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
9	266574	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
10	169436	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	167927	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
12	266267	Balancing valve	1		MT 1440 A ST3B, MT 1840 A ST3B
13	170221	"O" ring	2		MT 1440 A ST3B, MT 1840 A ST3B
14	746657	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
15	9142	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
16	259528	Levelling system cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
17	259529	Pin	1		MT 1440 A ST3B, MT 1840 A ST3B
18	60360	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
19	45921	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
20	259530	Pin	1		MT 1440 A ST3B, MT 1840 A ST3B
21	63545	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
22	45921	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
23	311648	Levelling system cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
24	52504504	Levelling system cylinder	1	259528	MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	167924	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
2	169436	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
3	261320	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
4	219457	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
5	174204	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
6	287001	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
7	223456	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
8	184787	Seal	0		MT 1440 A ST3B, MT 1840 A ST3B
9	283146	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
10	190013	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
11	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
12	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
13	177588	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
14	197335	Steering pump body	1		MT 1440 A ST3B, MT 1840 A ST3B
15	259555	support	1		MT 1440 A ST3B, MT 1840 A ST3B
16	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
17	259602	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
18	259627	stud	1		MT 1440 A ST3B, MT 1840 A ST3B
19	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
20	206083	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
21	259618	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
22	230546	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
23	189852	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
24	169373	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
25	190887	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
26	268217	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
27	190874	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
28	268218	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
29	168494	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
30	6224	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
31	197233	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
32	405064	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
33	177637	Seal	0		MT 1440 A ST3B, MT 1840 A ST3B
34	268216	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
35	168863	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
36	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
37	168753	Connection	4		MT 1440 A ST3B, MT 1840 A ST3B
38	169552	"O" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
39	259532	Complete valve bank	1		MT 1440 A ST3B, MT 1840 A ST3B
40	198433	screw	2		MT 1440 A ST3B, MT 1840 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
42	235272	lever	1		MT 1440 A ST3B, MT 1840 A ST3B
43	181130	handle	1		MT 1440 A ST3B, MT 1840 A ST3B
44	259553	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
45	168863	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
46	168494	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
47	61323	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
48	197233	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
49	405064	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
50	259552	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
51	274240	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
52	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
53	61323	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
54	259552	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
55	197233	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
56	190887	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
57	168852	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
58	168854	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
59	58531	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
60	268226	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
61	189956	"0" ring	0		MT 1440 A ST3B, MT 1840 A ST3B
62	291617	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
63	291619	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
64	264527	steering wheel	1		MT 1440 A ST3B, MT 1840 A ST3B
65	746362	knob	1		MT 1440 A ST3B, MT 1840 A ST3B
66	746361	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
67	261191	Valve bank bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
68	202731	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
69	229564	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
70	605816	Pressure test	1		MT 1440 A ST3B, MT 1840 A ST3B
71	261322	plate	1		MT 1440 A ST3B, MT 1840 A ST3B
72	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
73	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
74	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
75	63351	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
76	259956	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
77	168492	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
78	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
79	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
80	190874	"0" ring	0		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
81	168001	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B

CENTRALISED GREASING




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	179545	Cranked greaser	4		MT 1440 A ST3B, MT 1840 A ST3B
2	42322	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
3	266120	Connection	4		MT 1440 A ST3B, MT 1840 A ST3B
4	281167	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
5	190013	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
6	168486	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
7	168490	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
8	54284	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
9	297225	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
10	168492	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
11	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
12	61323	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
13	281166	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
14	282026	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
15	217041	pipe fitting	1		MT 1440 A ST3B, MT 1840 A ST3B
16	266116	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
17	168486	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
18	168490	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
19	54284	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
20	247168	Spring	1		MT 1440 A ST3B, MT 1840 A ST3B
21	287377	Bushing	1		MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	287873	Tube	1		MT 1440 A ST3B
2	280950	Tube	1		MT 1440 A ST3B
3	168850	Clamp Half HR2L 16 0/1	8		MT 1440 A ST3B
4	168490	Protection plate	4		MT 1440 A ST3B
5	162229	Nut	4		MT 1440 A ST3B
6	29469	washer	2		MT 1440 A ST3B
7	205933	Screw	4		MT 1440 A ST3B
8	193325	Connection	1		MT 1440 A ST3B
9	7242	screw	2		MT 1440 A ST3B
10	261807	Hose	1		MT 1440 A ST3B
11	219457	"0" ring	0		MT 1440 A ST3B
12	261802	Hose	2		MT 1440 A ST3B
13	270280	Flange bracket	1		MT 1440 A ST3B
14	266728	Screw	2		MT 1440 A ST3B
15	259975	Bracket	1		MT 1440 A ST3B
16	255615	Half-clamp	1		MT 1440 A ST3B
17	255713	Screw	2		MT 1440 A ST3B
18	261292	Flange	1		MT 1440 A ST3B
19	259740	Fastening lug	1		MT 1440 A ST3B
20	167460	Screw	2		MT 1440 A ST3B
21	42316	Washer	2		MT 1440 A ST3B
22	280972	Connection	1		MT 1440 A ST3B
23	287865	Tube	1		MT 1440 A ST3B
24	280831	Tube	1		MT 1440 A ST3B
25	293747	Hose	2		MT 1440 A ST3B
26	193325	Connection	2		MT 1440 A ST3B
27	485396	pipe fitting	1		MT 1440 A ST3B
28	177638	Seal	0		MT 1440 A ST3B
29	229571	Balancing valve	1		MT 1440 A ST3B
30	189960	"0" ring	2		MT 1440 A ST3B
31	600907	Repair kit	1		MT 1440 A ST3B
32	58531	Screw	4		MT 1440 A ST3B
33	42325	Washer	4		MT 1440 A ST3B
34	260508	Tilting cylinder	1		MT 1440 A ST3B
35	264572	Pin	1		MT 1440 A ST3B
36	60360	Screw	1		MT 1440 A ST3B
37	45921	Washer	1		MT 1440 A ST3B
38	264606	Pin	1		MT 1440 A ST3B
39	192213	Circlip	1		MT 1440 A ST3B
40	219457	"0" ring	0		MT 1440 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	168758	Half-clamp	2		MT 1440 A ST3B
42	168494	Protection plate	1		MT 1440 A ST3B
43	58530	Screw	1		MT 1440 A ST3B
44	218525	Connection	1		MT 1440 A ST3B
45	894547	Plug	1	299297	MT 1440 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	293749	Half-clamp	2		MT 1840 A ST3B
2	168494	Protection plate	1		MT 1840 A ST3B
3	58531	Screw	1		MT 1840 A ST3B
4	293231	Tube	1		MT 1840 A ST3B
5	293233	Tube	1		MT 1840 A ST3B
6	168758	Half-clamp	12		MT 1840 A ST3B
7	168494	Protection plate	3		MT 1840 A ST3B
8	294283	Screw	3		MT 1840 A ST3B
9	58528	nut	3		MT 1840 A ST3B
10	293819	Hose	1		MT 1840 A ST3B
11	219457	"O" ring	1		MT 1840 A ST3B
12	289383	pulley	2		MT 1840 A ST3B
13	567420	bushing	2		MT 1840 A ST3B
14	287972	support	2		MT 1840 A ST3B
15	273112	screw	6		MT 1840 A ST3B
16	297389	support	1		MT 1840 A ST3B
17	776947	pin	1		MT 1840 A ST3B
18	55131	grease nipple	1		MT 1840 A ST3B
19	297562	Hydraulic tube	1		MT 1840 A ST3B
20	61674	Washer	2		MT 1840 A ST3B
21	8038	Pin	4	482336, 5152, T7004055, 133645, K449025026, T7003030, 63035, 134136, 125211, 58396, 125210, 138074, 418810, 9538103028, 471351, A506354, 853817602471	MT 1840 A ST3B
22	293803	screw	4		MT 1840 A ST3B
23	293661	Drain trough	1		MT 1840 A ST3B
24	259792	sliding block	3		MT 1840 A ST3B
25	261500	Screw	6		MT 1840 A ST3B
26	291794	support	2		MT 1840 A ST3B
27	268255	screw	8		MT 1840 A ST3B
28	778221	spring	2		MT 1840 A ST3B
29	289294	guide	2		MT 1840 A ST3B
30	289146	spacer	2		MT 1840 A ST3B
31	293805	Screw	2		MT 1840 A ST3B
32	54232	nut	2		MT 1840 A ST3B
33	194048	washer	2		MT 1840 A ST3B
34	297410	shaft	1		MT 1840 A ST3B
35	297415	roller	2		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
36	290788	Hose	1		MT 1840 A ST3B
37	297577	Housing	1		MT 1840 A ST3B
38	261495	Screw	4		MT 1840 A ST3B
39	29469	washer	4		MT 1840 A ST3B
40	297414	roller	4		MT 1840 A ST3B
41	297380	Tube	1		MT 1840 A ST3B
42	297147	Half-flange	1		MT 1840 A ST3B
43	297148	Half-flange	1		MT 1840 A ST3B
44	293806	screw	2		MT 1840 A ST3B
45	297164	screw	2		MT 1840 A ST3B
46	297379	Tube	1		MT 1840 A ST3B
47	459749	Washer	1	573096, 198138	MT 1840 A ST3B
48	31007	Screw	1		MT 1840 A ST3B
49	288610	Tube	1		MT 1840 A ST3B
50	288611	Tube	1		MT 1840 A ST3B
51	168758	Half-clamp	2		MT 1840 A ST3B
52	168494	Protection plate	1		MT 1840 A ST3B
53	58530	Screw	1		MT 1840 A ST3B
54	295721	Hose	1		MT 1840 A ST3B
55	295721	Hose	1		MT 1840 A ST3B
56	193325	Connection	2		MT 1840 A ST3B
57	485396	pipe fitting	2		MT 1840 A ST3B
58	177638	Seal	1		MT 1840 A ST3B
59	229571	Balancing valve	1		MT 1840 A ST3B
60	189960	"O" ring	2		MT 1840 A ST3B
61	600907	Repair kit	1		MT 1840 A ST3B
62	42325	Washer	4		MT 1840 A ST3B
63	58531	Screw	4		MT 1840 A ST3B
64	260508	Tilting cylinder	1		MT 1840 A ST3B
65	264608	Pin	1		MT 1840 A ST3B
66	60360	Screw	1		MT 1840 A ST3B
67	45921	Washer	1		MT 1840 A ST3B
68	264606	Pin	1		MT 1840 A ST3B
69	192213	Circlip	1		MT 1840 A ST3B
70	219457	"O" ring	1		MT 1840 A ST3B
71	292349	Weatherstrip	1		MT 1840 A ST3B
72	297021	Half-flange	2		MT 1840 A ST3B
73	297023	Half-flange	2		MT 1840 A ST3B
74	293806	screw	4		MT 1840 A ST3B
75	299297	Cap	1		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
76	259975	Bracket	1		MT 1840 A ST3B
77	232750	screw	2		MT 1840 A ST3B
78	168850	Clamp Half HR2L 16 0/1	8		MT 1840 A ST3B
79	168490	Protection plate	4		MT 1840 A ST3B
80	205933	Screw	4		MT 1840 A ST3B
81	162229	Nut	4		MT 1840 A ST3B
82	293804	Screw	2		MT 1840 A ST3B
83	289295	cotter pin	2		MT 1840 A ST3B
84	5302	Pin	2		MT 1840 A ST3B
85	268255	screw	2		MT 1840 A ST3B
86	300952	Cam	1		MT 1840 A ST3B
87	303275	Hydraulic tube	1		MT 1840 A ST3B
88	303276	Hydraulic tube	1		MT 1840 A ST3B
89	41186	nut	2		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	189015	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
2	169373	"O" ring	1		MT 1840 A ST3B
2	169373	"O" ring	0		MT 1440 A ST3B
3	298730	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
4	25002	"O" ring	0	563895, 86788	MT 1440 A ST3B
4	25002	"O" ring	1	563895, 86788	MT 1840 A ST3B
5	74356	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
6	169372	"O" ring	0		MT 1440 A ST3B
6	169372	"O" ring	1		MT 1840 A ST3B
7	273281	Relief valve	1		MT 1440 A ST3B, MT 1840 A ST3B
8	277216	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
9	42325	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
10	58528	nut	3		MT 1440 A ST3B, MT 1840 A ST3B
11	3212	Nut	3	58646, 132479, 9412040800, 841207600371, 206882, 454217, 485025, 43151F106071, 478567, 4292	MT 1440 A ST3B, MT 1840 A ST3B
12	286850	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
13	54951	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
14	63351	washer	2		MT 1440 A ST3B, MT 1840 A ST3B
15	746103	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
16	706929	Magnet coil	1	746104	MT 1440 A ST3B, MT 1840 A ST3B
17	260777	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
18	264724	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
19	171758	"O" ring	0	190017	MT 1440 A ST3B
19	171758	"O" ring	1	190017	MT 1840 A ST3B
20	268742	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
21	197760	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
22	177588	"O" ring	1		MT 1840 A ST3B
22	177588	"O" ring	0		MT 1440 A ST3B
23	248243	Hose	1	211709	MT 1440 A ST3B, MT 1840 A ST3B
24	190874	"O" ring	0		MT 1440 A ST3B
24	190874	"O" ring	1		MT 1840 A ST3B
25	197233	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
26	197760	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
27	74356	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
28	261199	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
29	190876	"O" ring	0		MT 1440 A ST3B
29	190876	"O" ring	1		MT 1840 A ST3B
30	217051	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
31	167926	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
32	169374	"0" ring	0		MT 1440 A ST3B
32	169374	"0" ring	1		MT 1840 A ST3B
33	283371	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
34	191698	pipe fitting	2		MT 1440 A ST3B, MT 1840 A ST3B
35	190875	Seal	0		MT 1440 A ST3B
35	190875	Seal	1		MT 1840 A ST3B
36	301202	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
37	177082	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
38	165919	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
39	220321	valve	1		MT 1440 A ST3B, MT 1840 A ST3B
40	278908	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
41	167928	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
42	247873	Hose	1	245401	MT 1440 A ST3B, MT 1840 A ST3B
43	190013	"0" ring	1		MT 1840 A ST3B
43	190013	"0" ring	0		MT 1440 A ST3B
44	497922	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
45	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
46	266242	Filter	1		MT 1440 A ST3B, MT 1840 A ST3B
47	214908	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
48	190442	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
49	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
50	605816	Pressure test	1		MT 1440 A ST3B, MT 1840 A ST3B
51	261680	Pressure test	1		MT 1440 A ST3B, MT 1840 A ST3B
52	277942	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
53	604975	"0" ring	1	232959, 745993	MT 1840 A ST3B
53	604975	"0" ring	0	232959, 745993	MT 1440 A ST3B
54	217043	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	213535	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
2	169372	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
3	300849	Tube & Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
4	190019	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	192666	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
6	300848	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
7	213535	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
8	300829	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
9	259718	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
10	177119	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
11	60483	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
12	74356	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
13	217148	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
14	25002	"O" ring	1	563895, 86788	MT 1440 A ST3B, MT 1840 A ST3B
15	184787	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
16	259523	Back pressure valve	1		MT 1440 A ST3B, MT 1840 A ST3B
17	200480	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
18	317886	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
19	195932	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
20	167923	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
21	169373	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
22	259708	motor	1		MT 1440 A ST3B, MT 1840 A ST3B
23	167925	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
24	193325	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
25	189956	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
26	271127	Hose	1	258288	MT 1440 A ST3B, MT 1840 A ST3B
27	216972	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
28	259719	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
29	168861	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
30	58531	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
31	230567	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
32	279042	fan	1		MT 1440 A ST3B, MT 1840 A ST3B
33	261913	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
34	169436	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
35	295600	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
36	202286	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
37	259709	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
38	232833	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
39	192666	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
40	218258	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	300840	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
42	259718	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
43	177119	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
44	60483	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
45	177119	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
46	190876	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
47	745749	seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
48	748485	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
49	42232	RW 10 zinguée	4		MT 1440 A ST3B, MT 1840 A ST3B
50	702579	woodruff key	1		MT 1440 A ST3B, MT 1840 A ST3B
51	706062	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
52	184672	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
53	213535	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
54	275028	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
55	304411	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
56	258273	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B

EMERGENCY CIRCUIT




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	197760	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
2	177588	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
3	211714	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
4	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	291605	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
6	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
7	286997	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
8	190013	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
9	260692	Pump manual	1		MT 1440 A ST3B, MT 1840 A ST3B
10	279722	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
11	63545	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
12	45921	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
13	167925	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
14	169373	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
15	291602	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
16	219457	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
17	245395	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
18	168494	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
19	61323	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
20	261831	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
21	236381	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
22	258118	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
23	256740	Weatherstrip	1		MT 1440 A ST3B, MT 1840 A ST3B
24	261826	Housing	1		MT 1440 A ST3B, MT 1840 A ST3B
25	63754	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
26	5309	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
27	61674	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
28	173038	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
29	175748	Back pressure valve	1		MT 1440 A ST3B, MT 1840 A ST3B
30	167932	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
31	1574	Screw	4	257488	MT 1440 A ST3B, MT 1840 A ST3B
32	307148	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	168753	Connection	4		MT 1440 A ST3B, MT 1840 A ST3B
2	169552	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
3	261319	Hose	4		MT 1440 A ST3B, MT 1840 A ST3B
4	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
5	250878	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
6	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
7	217217	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
8	168494	Protection plate	2		MT 1440 A ST3B, MT 1840 A ST3B
9	61323	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
10	259585	L.H. housing	1		MT 1440 A ST3B, MT 1840 A ST3B
11	259584	R.H. housing	1		MT 1440 A ST3B, MT 1840 A ST3B
12	5309	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
13	61674	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
14	217217	Half-clamp	4		MT 1440 A ST3B, MT 1840 A ST3B
15	261193	Bracket	2		MT 1440 A ST3B, MT 1840 A ST3B
16	6224	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
17	197233	Connection	4		MT 1440 A ST3B, MT 1840 A ST3B
18	173038	Connection	4		MT 1440 A ST3B, MT 1840 A ST3B
19	169373	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
20	259569	Balancing valve	2		MT 1440 A ST3B, MT 1840 A ST3B
21	170221	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
22	749808	seal kit	1	746112	MT 1440 A ST3B, MT 1840 A ST3B
23	276277	Housing	2		MT 1440 A ST3B, MT 1840 A ST3B
24	58531	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
25	58533	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
26	42325	Washer	8		MT 1440 A ST3B, MT 1840 A ST3B
27	259544	Stabilizer cylinder	2		MT 1440 A ST3B, MT 1840 A ST3B
28	292568	Articulating pin	2		MT 1440 A ST3B, MT 1840 A ST3B
29	63727	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
30	45921	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
31	52504511	Housing	2	276277	MT 1440 A ST3B, MT 1840 A ST3B
32	52504503	Stabilizer cylinder	2	259544	MT 1440 A ST3B, MT 1840 A ST3B

___TELESCOPING




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	74356	Connection	1		MT 1440 A ST3B
2	169372	"O" ring	1		MT 1440 A ST3B
3	259604	Connection	1		MT 1440 A ST3B
4	259589	Hose	1		MT 1440 A ST3B
5	25002	"O" ring	1	563895, 86788	MT 1440 A ST3B
6	259599	Hose	1		MT 1440 A ST3B
7	168855	Half-clamp	8		MT 1440 A ST3B
8	168854	plate	2		MT 1440 A ST3B
9	277216	Screw	2		MT 1440 A ST3B
10	58530	Screw	1		MT 1440 A ST3B
11	217043	Connection	2		MT 1440 A ST3B
12	261453	Connection	1		MT 1440 A ST3B
13	169374	"O" ring	1		MT 1440 A ST3B
14	261461	Connection	1		MT 1440 A ST3B
15	287170	Balancing valve	1		MT 1440 A ST3B
16	9047	"O" ring	2	6223, 81034, 526866, 2742042MI, 745686	MT 1440 A ST3B
17	749916	Repair kit	1		MT 1440 A ST3B
18	58538	Screw	4		MT 1440 A ST3B
19	42232	RW 10 zinguée	4		MT 1440 A ST3B
20	260651	Telescope cylinder	1		MT 1440 A ST3B
21	58608	Screw	1		MT 1440 A ST3B
22	183812	Washer	2		MT 1440 A ST3B
23	171460	Nut	1		MT 1440 A ST3B
24	260538	block	2		MT 1440 A ST3B
25	273112	screw	4		MT 1440 A ST3B
26	261346	Stop plate (Rotation)	1		MT 1440 A ST3B
27	261409	Cap	1		MT 1440 A ST3B
28	227088	Screw	1		MT 1440 A ST3B
29	58528	nut	1		MT 1440 A ST3B
30	254177	Nut	2		MT 1440 A ST3B
31	299297	Cap	1		MT 1440 A ST3B
32	52504506	Telescope cylinder	1		MT 1440 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504506	Telescope cylinder	1		MT 1440 A ST3B
2	259613	Hose	1		MT 1440 A ST3B
3	261354	Hose	1		MT 1440 A ST3B
4	25002	"O" ring	0	563895, 86788	MT 1440 A ST3B
5	168855	Half-clamp	2		MT 1440 A ST3B
6	168854	plate	1		MT 1440 A ST3B
7	58530	Screw	1		MT 1440 A ST3B
8	280936	Tube	1		MT 1440 A ST3B
9	280934	Tube	1		MT 1440 A ST3B
10	168852	Half-clamp	2		MT 1440 A ST3B
11	168854	plate	1		MT 1440 A ST3B
12	58530	Screw	1		MT 1440 A ST3B
13	280839	Tube (R.H)	1		MT 1440 A ST3B
14	280844	Tube (L.H)	1		MT 1440 A ST3B
15	255709	Screw	4		MT 1440 A ST3B
16	29468	Washer	4		MT 1440 A ST3B
17	281782	Slide block	2		MT 1440 A ST3B
18	261497	Screw	4		MT 1440 A ST3B
19	261874	Guide	2		MT 1440 A ST3B
20	29468	Washer	2		MT 1440 A ST3B
21	261504	screw	2		MT 1440 A ST3B
22	261808	Hose	2		MT 1440 A ST3B
23	190221	Connection	2		MT 1440 A ST3B
24	177638	Seal	0		MT 1440 A ST3B
25	229571	Balancing valve	1		MT 1440 A ST3B
26	189960	"O" ring	2		MT 1440 A ST3B
27	600907	Repair kit	1		MT 1440 A ST3B
28	58531	Screw	4		MT 1440 A ST3B
29	42325	Washer	4		MT 1440 A ST3B
30	283286	Telescope cylinder	1		MT 1440 A ST3B
31	52500501	Slide face	1	304501	MT 1440 A ST3B
32	259792	sliding block	2		MT 1440 A ST3B
33	261498	Screw	4		MT 1440 A ST3B
34	281782	Slide block	2		MT 1440 A ST3B
35	261497	Screw	4		MT 1440 A ST3B
36	261919	Cover plate	1		MT 1440 A ST3B
37	273811	Screw	5		MT 1440 A ST3B
38	273790	Spacer	5		MT 1440 A ST3B
39	261943	Spacer	4		MT 1440 A ST3B
40	261501	Screw	8		MT 1440 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	459749	Washer	8	573096, 198138	MT 1440 A ST3B
42	264415	Vent window	2		MT 1440 A ST3B
43	283284	Screw	1		MT 1440 A ST3B
44	276353	Concave washer	1		MT 1440 A ST3B
45	261804	Screw	4		MT 1440 A ST3B
46	194287	Washer	4		MT 1440 A ST3B
47	264445	Separator	1		MT 1440 A ST3B
48	281782	Slide block	2		MT 1440 A ST3B
49	261497	Screw	4		MT 1440 A ST3B
50	255709	Screw	2		MT 1440 A ST3B
51	208524	washer	2		MT 1440 A ST3B
52	25002	"O" ring	0	563895, 86788	MT 1440 A ST3B
53	168853	Fastening plate	1		MT 1440 A ST3B
54	168855	Half-clamp	2		MT 1440 A ST3B
55	168854	plate	1		MT 1440 A ST3B
56	284261	Screw	1		MT 1440 A ST3B
57	276354	Convexe washer	1		MT 1440 A ST3B
58	894547	Plug	1	299297	MT 1440 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	74356	Connection	1		MT 1840 A ST3B
2	169372	"O" ring	1		MT 1840 A ST3B
3	259604	Connection	1		MT 1840 A ST3B
4	291868	Hose	1		MT 1840 A ST3B
5	25002	"O" ring	1	563895, 86788	MT 1840 A ST3B
6	291868	Hose	1		MT 1840 A ST3B
7	168855	Half-clamp	4		MT 1840 A ST3B
8	277216	Screw	2		MT 1840 A ST3B
9	254177	Nut	2		MT 1840 A ST3B
10	168855	Half-clamp	2		MT 1840 A ST3B
11	168854	plate	1		MT 1840 A ST3B
12	227088	Screw	1		MT 1840 A ST3B
13	58528	nut	1		MT 1840 A ST3B
14	217043	Connection	2		MT 1840 A ST3B
15	190222	pipe fitting	2		MT 1840 A ST3B
16	190878	Seal	1		MT 1840 A ST3B
17	199263	valve	1		MT 1840 A ST3B
18	550466	Repair kit	1		MT 1840 A ST3B
19	478002	Anti-extrusion seal	2		MT 1840 A ST3B
20	9047	"O" ring	2	6223, 81034, 526866, 2742042MI, 745686	MT 1840 A ST3B
21	300930	Telescope cylinder	1		MT 1840 A ST3B
22	58608	Screw	1		MT 1840 A ST3B
23	183812	Washer	2		MT 1840 A ST3B
24	188730	Washer	2		MT 1840 A ST3B
25	171460	Nut	1		MT 1840 A ST3B
26	260538	block	2		MT 1840 A ST3B
27	273112	screw	4		MT 1840 A ST3B
28	777343	pin	1		MT 1840 A ST3B
29	26774	circlip	2		MT 1840 A ST3B
30	31003	Screw	4		MT 1840 A ST3B
31	42232	RW 10 zinguée	4		MT 1840 A ST3B
32	299297	Cap	2		MT 1840 A ST3B
33	52504508	Telescope cylinder	1		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	273810	Oil tank	1		MT 1440 A ST3B, MT 1840 A ST3B
2	80661	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
3	189535	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
4	488236	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
5	259499	pipe union	1		MT 1440 A ST3B, MT 1840 A ST3B
6	261487	Oil tank air breather	1		MT 1440 A ST3B, MT 1840 A ST3B
7	941	"0" ring	1	A003001872, 470768, 41624, 745792, 2742043MI, 474734, A5514102, 22237, 551470	MT 1440 A ST3B, MT 1840 A ST3B
8	259945	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
9	259944	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
10	259986	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
11	261872	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
12	259500	Principal circuit strainer	1		MT 1440 A ST3B, MT 1840 A ST3B
13	259579	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
14	195728	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
15	259537	Delivery port connection	1		MT 1440 A ST3B, MT 1840 A ST3B
16	566974	o-ring	1	134679, 457808, 561818	MT 1440 A ST3B, MT 1840 A ST3B
17	44807	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
18	42231	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
19	259587	Complete Pump	1		MT 1440 A ST3B, MT 1840 A ST3B
20	261617	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
21	207072	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
22	77710	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
23	268742	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
24	169373	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
25	259603	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
26	171758	"0" ring	1	190017	MT 1440 A ST3B, MT 1840 A ST3B
27	205206	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
28	169372	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
29	289918	Complete hydraulic return oil filter	1		MT 1440 A ST3B, MT 1840 A ST3B
30	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
31	224945	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
32	190879	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
33	259597	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
34	194813	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
35	259568	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
36	242746	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
37	295292	Valve bank	1		MT 1440 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
38	299791	Valve bank bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
39	259710	screw	7		MT 1440 A ST3B, MT 1840 A ST3B
40	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
41	177588	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
42	487227	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
43	190013	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
44	212060	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
45	177637	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
46	233522	Hydraulic accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
47	189956	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
48	300031	Complete valve bank	1		MT 1840 A ST3B
49	197760	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
50	248322	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
51	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
52	197233	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
53	217047	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
54	197760	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
55	296882	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
56	259601	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
57	798123	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
58	894639	Solenoid	1		MT 1440 A ST3B, MT 1840 A ST3B
59	745783	Pump (Principal circuit)	1		MT 1440 A ST3B, MT 1840 A ST3B
60	745784	Pump (Brake circuit)	1		MT 1440 A ST3B, MT 1840 A ST3B
61	746290	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
62	745786	Secondary pump	1		MT 1440 A ST3B, MT 1840 A ST3B
63	745787	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
64	748115	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
65	193901	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
66	167925	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
67	175743	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
68	287000	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
69	307853	Protection	1		MT 1440 A ST3B, MT 1840 A ST3B
70	311820	Complete hydraulic return oil filter	1	289918	MT 1440 A ST3B, MT 1840 A ST3B
71	296883	Accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
72	169372	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
73	179951	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
74	293746	Sheath	1		MT 1440 A ST3B, MT 1840 A ST3B

10 DA 309

DISTRIBUTEUR
KOMMANDOSTEUERVENTIL
DISTRIBUIDOR
VALVE BANK
DISTRIBUTORE

MLT 625 - 75 H Série1-E3
(AS 803800)




08 / 11 / 06
P.A.O. Illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	259532	Complete valve bank	1		MT 1440 A ST3B, MT 1840 A ST3B
2	746000	Spring return drive	1		MT 1440 A ST3B, MT 1840 A ST3B
3	135891	"O" ring	2	G1475648, 2742040MI, 87070, 474708, 448751, 2680204MI	MT 1440 A ST3B, MT 1840 A ST3B
4	564307	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
5	746001	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
6	474706	Complete manual drive	1		MT 1440 A ST3B, MT 1840 A ST3B
7	182024	Screw	2	485979, 749663, 474710, 882687	MT 1440 A ST3B, MT 1840 A ST3B
8	746191	Seal kit	1		MT 1840 A ST3B
8	746191	Seal kit	0		MT 1440 A ST3B

10 DA 328

DISTRIBUTEUR
KOMMANDOSTEUERVENTIL
DISTRIBUIDOR
VALVE BANK
DISTRIBUTORE

MT 1840 HA ST3B
(AS 803858)



21 / 90 / 01

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	266306	Complete valve bank	1		MT 1440 A ST3B, MT 1840 A ST3B
2	746258	Inlet member	1		MT 1440 A ST3B, MT 1840 A ST3B
3	746259	Double-acting member	1		MT 1440 A ST3B, MT 1840 A ST3B
4	746260	Double-acting member	2		MT 1440 A ST3B, MT 1840 A ST3B
5	895122	SEAL KIT	1	746272	MT 1440 A ST3B, MT 1840 A ST3B
6	746262	Fastening member	1		MT 1440 A ST3B, MT 1840 A ST3B
7	747281	Washer	3		MT 1440 A ST3B, MT 1840 A ST3B
8	895122	SEAL KIT	3	746272	MT 1440 A ST3B, MT 1840 A ST3B
9	895122	SEAL KIT	2	746272	MT 1440 A ST3B, MT 1840 A ST3B
10	895122	SEAL KIT	1	746272	MT 1440 A ST3B, MT 1840 A ST3B
11	746266	Solenoid	1	703451	MT 1440 A ST3B, MT 1840 A ST3B
12	895122	SEAL KIT	1	746272	MT 1440 A ST3B, MT 1840 A ST3B
13	746268	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
14	895122	SEAL KIT	2	746272	MT 1440 A ST3B, MT 1840 A ST3B
15	895122	SEAL KIT	2	746272	MT 1440 A ST3B, MT 1840 A ST3B
16	895122	SEAL KIT	1	746272	MT 1440 A ST3B, MT 1840 A ST3B
17	746271	Solenoid	1		MT 1440 A ST3B, MT 1840 A ST3B
18	895122	SEAL KIT	1	746272	MT 1440 A ST3B, MT 1840 A ST3B
19	746273	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B

10 DA 459


DISTRIBUTEUR
KOMMANDOSTEUERVENTIL
DISTRIBUIDOR
VALVE BANK
DISTRIBUTORE

MT-X 1440 A E3

* NEIG LIPST BEI EINER (VORBEREIT. 10)
NIGHT BEI EINER ALLEN (DIESE 1000-30)
NO ENTEN GANZES (DIESE 1000-30)
NOT ENLIPST BEI EINER (DIESE 1000-30)
NO CONGRUENTE (DIESE 1000-30)

POCHETTE DE JOINTS - DICHTUNGSATZ
JUEGO DE JUNTAS - SEAL KIT
SERIE GUARNIZIONE

POCHETTE DE JOINTS - DICHTUNGSATZ
JUEGO DE JUNTAS - SEAL KIT
SERIE GUARNIZIONE



12/10/11

P.A.O. (10)

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	295292	Valve bank	1		MT 1440 A ST3B
2	796476	Complete inlet member	1		MT 1440 A ST3B
3	796878	Complete telescope member	1		MT 1440 A ST3B
4	796879	Complete lifting member	1		MT 1440 A ST3B
5	796479	Complete tilting member	1		MT 1440 A ST3B
6	796480	Complete out put member	1		MT 1440 A ST3B
7	796481	Complete Member (Attachment)	1		MT 1440 A ST3B
8	746660	Fastening member	1		MT 1440 A ST3B
9	746661	Manual drive	4		MT 1440 A ST3B
10	192431	Seal kit	4		MT 1440 A ST3B
11	603687	Slide valve	1		MT 1440 A ST3B
12	894456	*	1	746662	MT 1440 A ST3B
13	549240	Seal kit	1		MT 1440 A ST3B
14	746663	Valve bank element	1		MT 1440 A ST3B
15	746664	Electrovalve	1		MT 1440 A ST3B
16	703367	Seal kit	1		MT 1440 A ST3B
17	746671	valve	1		MT 1440 A ST3B
18	796475	Seal kit + Tie bar	1		MT 1440 A ST3B
19	894437	*	1	746668	MT 1440 A ST3B
20	549240	Seal kit	1		MT 1440 A ST3B
21	602716	Valve	1		MT 1440 A ST3B
22	602719	Valve	1		MT 1440 A ST3B
23	746669	Slide valve	1		MT 1440 A ST3B
24	894437	*	1	746668	MT 1440 A ST3B
25	549240	Seal kit	1		MT 1440 A ST3B
26	602718	Valve	1		MT 1440 A ST3B
27	603688	Valve	1		MT 1440 A ST3B
28	746670	Slide valve	1		MT 1440 A ST3B
29	894437	*	1	746668	MT 1440 A ST3B
30	549240	Seal kit	1		MT 1440 A ST3B
31	602719	Valve	2		MT 1440 A ST3B
32	746671	valve	3		MT 1440 A ST3B
33	746672	Slide valve	1		MT 1440 A ST3B
34	746673	Electrovalve	1		MT 1440 A ST3B
36	746675	tie rod kit	1		MT 1440 A ST3B
37	5863	Screw	16		MT 1440 A ST3B
38	796473	Inlet member	1	796563	MT 1440 A ST3B
39	796473	Inlet member	1	796563	MT 1440 A ST3B
40	796471	Telescope member	1		MT 1440 A ST3B
41	796470	Double-acting member	1		MT 1440 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
42	796470	Double-acting member	1		MT 1440 A ST3B
43	796472	Out put member	1		MT 1440 A ST3B
44	796474	Member (Attachment)	1		MT 1440 A ST3B

10 DA 461


DISTRIBUTEUR
KOMMANDOSTEUERVENTIL
DISTRIBUIDOR
VALVE BANK
DISTRIBUTORE

MT 1840 HA ST3B
(AS 803858)

* NEU LIFT TREATMENT (FOR REF. 39)
NEU LIFT TREATMENT (FOR REF. 39)
NEU LIFT TREATMENT (FOR REF. 39)
NEU LIFT TREATMENT (FOR REF. 39)
NEU LIFT TREATMENT (FOR REF. 39)
NEU LIFT TREATMENT (FOR REF. 39)

POCHETTE DE JOINTS - DICHTUNGSSATZ
JUEGO DE JUNTAS - SEAL KIT
SERIE GUARNIZIONE


POCHETTE DE JOINTS - DICHTUNGSSATZ
JUEGO DE JUNTAS - SEAL KIT
SERIE GUARNIZIONE



12/10/11

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	300031	Complete valve bank	1		MT 1840 A ST3B
2	796476	Complete inlet member	1		MT 1840 A ST3B
3	796880	Complete telescope member	1		MT 1840 A ST3B
4	796879	Complete lifting member	1		MT 1840 A ST3B
5	796479	Complete tilting member	1		MT 1840 A ST3B
6	796480	Complete out put member	1		MT 1840 A ST3B
7	796481	Complete Member (Attachment)	1		MT 1840 A ST3B
8	746660	Fastening member	1		MT 1840 A ST3B
9	746661	Manual drive	4		MT 1840 A ST3B
10	192431	Seal kit	4		MT 1840 A ST3B
11	603687	Slide valve	1		MT 1840 A ST3B
12	894456	*	1	746662	MT 1840 A ST3B
13	549240	Seal kit	1		MT 1840 A ST3B
14	746663	Valve bank element	1		MT 1840 A ST3B
15	746664	Electrovalve	1		MT 1840 A ST3B
16	703367	Seal kit	1		MT 1840 A ST3B
17	746671	valve	1		MT 1840 A ST3B
18	796475	Seal kit + Tie bar	1		MT 1840 A ST3B
19	894437	*	1	746668	MT 1840 A ST3B
20	549240	Seal kit	1		MT 1840 A ST3B
21	602716	Valve	1		MT 1840 A ST3B
22	602719	Valve	1		MT 1840 A ST3B
23	746669	Slide valve	1		MT 1840 A ST3B
24	894437	*	1	746668	MT 1840 A ST3B
25	549240	Seal kit	1		MT 1840 A ST3B
26	602718	Valve	1		MT 1840 A ST3B
27	603688	Valve	1		MT 1840 A ST3B
28	746670	Slide valve	1		MT 1840 A ST3B
29	894437	*	1	746668	MT 1840 A ST3B
30	549240	Seal kit	1		MT 1840 A ST3B
31	603688	Valve	2		MT 1840 A ST3B
32	746671	valve	3		MT 1840 A ST3B
33	746672	Slide valve	1		MT 1840 A ST3B
34	746673	Electrovalve	1		MT 1840 A ST3B
36	746675	tie rod kit	1		MT 1840 A ST3B
37	5863	Screw	16		MT 1840 A ST3B
38	796473	Inlet member	1	796563	MT 1840 A ST3B
39	796473	Inlet member	1	796563	MT 1840 A ST3B
40	796471	Telescope member	1		MT 1840 A ST3B
41	796470	Double-acting member	1		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
42	796470	Double-acting member	1		MT 1840 A ST3B
43	796472	Out put member	1		MT 1840 A ST3B
44	796474	Member (Attachment)	1		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	299936	Air filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
2	299937	Security air filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
3	745750	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
4	261487	Oil tank air breather	1		MT 1440 A ST3B, MT 1840 A ST3B
5	296854	cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
6	259500	Principal circuit strainer	1		MT 1440 A ST3B, MT 1840 A ST3B
7	745878	Oil filter transmission	1		MT 1440 A ST3B, MT 1840 A ST3B
8	317039	filter	1		MT 1440 A ST3B, MT 1840 A ST3B
9	289920	Hydraulic oil filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
10	947415	belt	1		MT 1440 A ST3B, MT 1840 A ST3B
11	261971	filter	1		MT 1440 A ST3B, MT 1840 A ST3B
12	266242	Filter	2		MT 1440 A ST3B, MT 1840 A ST3B
13	299885	cartridge	1	797755, 798466	MT 1440 A ST3B, MT 1840 A ST3B
14	746106	Heating filter	1		MT 1440 A ST3B, MT 1840 A ST3B
15	746308	Filter (hydraulic accumulator)	1		MT 1440 A ST3B, MT 1840 A ST3B
16	266219	Air breather (Tank)	1		MT 1440 A ST3B, MT 1840 A ST3B
17	748115	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
18	797650	cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
19	311821	Hydraulic oil filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B

AX 2736

POUR BOITE DE VITESSES
FÜR GETRIEBEKASTEN
PARA CAJA DE VELOCIDADES
FOR GEAR BOX
PER CAMBIO
□ □ Type : 859 / 53
□ □ Ref : 278 124

BOITE DE VITESSES
GETRIEBEKASTEN
CAJA DE VELOCIDADES
GEAR BOX
CAMBIO

MT 1440 ST3B
MT 1840 ST3B




POUR FLEXIBLE ET RACCORD
FÜR SCHLAUCH UND VERSCHRAUBUNG
PARA FLEXIBLE Y RACOR
FOR HOSE AND CONNECTION
PER FLESSIBILE E RACCORDO

12 $\varnothing 2,9$ mm
 $\varnothing 23,6$ mm
14 $\varnothing 2$ mm
 $\varnothing 20$ mm


04 / 01 / 12 P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	278124	Gear box	1		MT 1440 A ST3B, MT 1840 A ST3B
2	43789	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
3	76462	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
4	177461	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
5	210790	Screw	3	21079	MT 1440 A ST3B, MT 1840 A ST3B
6	42231	Washer	14		MT 1440 A ST3B, MT 1840 A ST3B
7	62362	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
8	254928	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
9	188544	Washer	4	36102	MT 1440 A ST3B, MT 1840 A ST3B
10	561101	dowel	2		MT 1440 A ST3B, MT 1840 A ST3B
11	205206	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
12	169372	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
13	271497	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
14	171758	"O" ring	1	190017	MT 1440 A ST3B, MT 1840 A ST3B
15	260778	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
16	217044	Connection	2		MT 1440 A ST3B, MT 1840 A ST3B
17	205206	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
18	260777	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
19	260460	Complete oil filter	1		MT 1440 A ST3B, MT 1840 A ST3B
20	745878	Oil filter transmission	1		MT 1440 A ST3B, MT 1840 A ST3B
21	259602	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
22	745879	Filter head	1		MT 1440 A ST3B, MT 1840 A ST3B
23	259638	Screw	8		MT 1440 A ST3B, MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	273810	Oil tank	1		MT 1440 A ST3B, MT 1840 A ST3B
2	80661	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
3	189535	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
4	488236	plug	1		MT 1440 A ST3B, MT 1840 A ST3B
5	259499	pipe union	1		MT 1440 A ST3B, MT 1840 A ST3B
6	261487	Oil tank air breather	1		MT 1440 A ST3B, MT 1840 A ST3B
7	941	"0" ring	1	A003001872, 470768, 41624, 745792, 2742043MI, 474734, A5514102, 22237, 551470	MT 1440 A ST3B, MT 1840 A ST3B
8	259945	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
9	259944	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
10	259986	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
11	261872	screw	3		MT 1440 A ST3B, MT 1840 A ST3B
12	259500	Principal circuit strainer	1		MT 1440 A ST3B, MT 1840 A ST3B
13	259579	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
14	195728	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
15	259537	Delivery port connection	1		MT 1440 A ST3B, MT 1840 A ST3B
16	566974	o-ring	1	134679, 457808, 561818	MT 1440 A ST3B, MT 1840 A ST3B
17	44807	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
18	42231	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
19	259587	Complete Pump	1		MT 1440 A ST3B, MT 1840 A ST3B
20	261617	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
21	207072	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
22	77710	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
23	268742	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
24	169373	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
25	259603	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
26	171758	"0" ring	1	190017	MT 1440 A ST3B, MT 1840 A ST3B
27	205206	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
28	169372	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
29	289918	Complete hydraulic return oil filter	1		MT 1440 A ST3B, MT 1840 A ST3B
30	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
31	224945	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
32	190879	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
33	259597	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
34	194813	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
35	259568	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
36	242746	"0" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
37	295292	Valve bank	1		MT 1440 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
38	266173	Valve bank bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
39	259710	screw	7		MT 1440 A ST3B, MT 1840 A ST3B
40	175498	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
41	177588	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
42	487227	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
43	190013	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
44	212060	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
45	177637	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
46	233522	Hydraulic accumulator	1		MT 1440 A ST3B, MT 1840 A ST3B
47	189956	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
48	300031	Complete valve bank	1		MT 1840 A ST3B
49	197760	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
50	286331	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
51	190874	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
52	175076	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
53	219457	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
54	210971	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
55	217048	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
56	193772	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
57	190877	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
58	290461	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
59	745783	Pump (Principal circuit)	1		MT 1440 A ST3B, MT 1840 A ST3B
60	745784	Pump (Brake circuit)	1		MT 1440 A ST3B, MT 1840 A ST3B
61	746290	Valve	1		MT 1440 A ST3B, MT 1840 A ST3B
62	745786	Secondary pump	1		MT 1440 A ST3B, MT 1840 A ST3B
63	745787	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
64	748115	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
65	211716	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
66	167925	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
67	175743	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
68	307853	Protection	1		MT 1440 A ST3B, MT 1840 A ST3B
70	293746	Sheath	1		MT 1440 A ST3B, MT 1840 A ST3B





Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	294868	Cylinder of locking rear axle	2		MT 1440 A ST3B, MT 1840 A ST3B
2	746083	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	746084	Solenoid	1		MT 1440 A ST3B, MT 1840 A ST3B
4	746030	Pressure test	1		MT 1440 A ST3B, MT 1840 A ST3B
5	746086	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
6	746087	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
7	705903	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
8	579849	Wiper seal	1		MT 1440 A ST3B, MT 1840 A ST3B
9	746082	Rod	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746093	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B

10 CF 92

A PARTIR DE LA MACHINE
AB DER MASCHINE
A PARTIR DE LA MAQUINA
FROM MACHINE
A PARTIR DA MACCHINA
→ N° **928 765**

HYDRAULIQUE (Vérin blocage essieu arrière)
HYDRAULIK (Verriegelung hinterachse kreis)
HIDRAULICO (Cilindro bloqueo eje trasero)
HYDRAULIC (Cylinder of locking rear axle)
IDRAULICO (Cilindro bloccaggio ponte posteriore)

MT 1440 A ST3B
MT 1840 A ST3B




26 / 02 / 14

P.A.O. illust

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	311701	Cylinder of locking rear axle	2		MT 1440 A ST3B, MT 1840 A ST3B
2	940575	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	746084	Solenoid	1		MT 1440 A ST3B, MT 1840 A ST3B
4	746030	Pressure test	1		MT 1440 A ST3B, MT 1840 A ST3B
5	746086	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
6	746087	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
7	705903	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
8	579849	Wiper seal	1		MT 1440 A ST3B, MT 1840 A ST3B
9	746082	Rod	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746093	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B


Catalogue : 647101			Qté-Menge-Cant-Qty-Q.ta										10 CF 92										M	
1	HYDRAULIQUE - VERIN BLOCAGE ESSIEU ARRIERE HYDRAULIK - VERRIEGELUNG HINTERACHSE KREIS HIDRAULICO - CILINDRO BLOQUEO EJE TRASERO HYDRAULIC - CYLINDER OF LOCKING REAR AXLE IDRAULICO - CILINDRO BLOCCAGGIO PONTE POSTERIORE		1- MT 1440 A ST3B 11- 2- MT 1840 A ST3B 12- 3- 13- 4- 14- 5- 15- 6- 16- 7- 17- 8- 18- 9- 19- 10- 20-																					
Rep Hinw Fig Item Rif	Número Teil-Nr Numero Part-Nr	Désignation Bezeichnung Description Descrizione	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20		
1	311701	Vérin blocage essieu arrière D:70mm C:163mm Verriegelung hinterachse zylinder Cilindro bloqueo eje trasero - Cylinder of locking rear axl Cilindro bloccaggio ponte posteriore	2	2																				
2	940575	Corps de vérin - Zylinder körper Cuerpo de cilindro - Cylinder body Corpo di cilindro -	1	1																				
3	746084	Solenoïde - Solenoid Solenoid - Solenoid Solenoide -	1	1																				
4	746030	Prise de pression - Drückdose Toma de presión - Pressure test Presa pressione -	1	1																				
5	746086	Joint d'étanchéité - Dichtring Junta de estanqueidad - Seal Guarnizione di tenuta -	2	2																				
6	746087	Joint de tige - Stangendichtung Junta de vástago - Rod seal Guarnizione del stelo -	1	1																				
7	705903	Joint de tige - Stangendichtung Junta de vástago - Rod seal Guarnizione del stelo -	1	1																				
8	579849	Joint racleur - Dichtung Junta - Wiper seal Guarnizione raschiaolio -	1	1																				
9	746082	Tige - Stange Vástago - Rod Stelo -	1	1																				
10	746093	Pochette de joints - Dichtungssatz Juego de juntas - Seal kit Kit guarnizioni -	X	X																				

20/05/2014




30 / 08 / 10


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	281603	Compensation cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
2	746027	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	940569	Bushing	1		MT 1440 A ST3B, MT 1840 A ST3B
4	746030	Pressure test	2		MT 1440 A ST3B, MT 1840 A ST3B
6	746025	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	940569	Bushing	1		MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746028	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	706050	Wiper seal	1		MT 1440 A ST3B, MT 1840 A ST3B
12	706051	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	184338	"O" ring	1	136404, 569063, 563653, 401800, 587954, 508384, 107717	MT 1440 A ST3B, MT 1840 A ST3B
14	746029	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
15	746026	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
16	5045	"O" ring	1	100419, 100419BL, F46048, 600408, 31077, 448564, 34945, 569057, 19934	MT 1440 A ST3B, MT 1840 A ST3B
17	190511	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
18	549137	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
19	746031	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
20	564675	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
21	794860	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504753	Compensation cylinder	1	281603	MT 1440 A ST3B, MT 1840 A ST3B
2	746027	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	940569	Bushing	1		MT 1440 A ST3B, MT 1840 A ST3B
4	746030	Pressure test	2		MT 1440 A ST3B, MT 1840 A ST3B
6	746025	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	940569	Bushing	1		MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746028	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	706050	Wiper seal	1		MT 1440 A ST3B, MT 1840 A ST3B
12	706051	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	184338	"O" ring	1	136404, 569063, 563653, 401800, 587954, 508384, 107717	MT 1440 A ST3B, MT 1840 A ST3B
14	746029	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
15	746026	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
16	5045	"O" ring	1	100419, 100419BL, F46048, 600408, 31077, 448564, 34945, 569057, 19934	MT 1440 A ST3B, MT 1840 A ST3B
17	190511	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
18	549137	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
19	746031	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B
20	564675	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
21	794860	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	311648	Levelling system cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
2	799437	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	940574	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
4	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
5	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
6	799438	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	940573	Bushing	1	746096	MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	799439	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	564675	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
12	706051	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	706050	Wiper seal	1		MT 1440 A ST3B, MT 1840 A ST3B
14	187931	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
15	746048	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
16	746095	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
17	192271	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
18	550135	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
19	563170	Seal	2	550134	MT 1440 A ST3B, MT 1840 A ST3B
20	5094	"O" ring	1	F46007, 163047	MT 1440 A ST3B, MT 1840 A ST3B
21	746099	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504504	Levelling system cylinder	1	259528	MT 1440 A ST3B, MT 1840 A ST3B
2	799437	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	940574	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
4	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
5	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
6	799438	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	940573	Bushing	1	746096	MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	799439	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	564675	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
12	706051	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	706050	Wiper seal	1		MT 1440 A ST3B, MT 1840 A ST3B
14	187931	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
15	746048	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
16	746095	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
17	192271	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
18	550135	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
19	563170	Seal	2	550134	MT 1440 A ST3B, MT 1840 A ST3B
20	5094	"O" ring	1	F46007, 163047	MT 1440 A ST3B, MT 1840 A ST3B
21	746099	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	259528	Levelling system cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
2	746097	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	940574	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
4	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
5	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
6	746094	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	940573	Bushing	1	746096	MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746098	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	564675	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
12	706051	Rod seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	706050	Wiper seal	1		MT 1440 A ST3B, MT 1840 A ST3B
14	187931	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
15	746048	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
16	746095	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
17	192271	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
18	550135	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
19	563170	Seal	2	550134	MT 1440 A ST3B, MT 1840 A ST3B
20	5094	"O" ring	1	F46007, 163047	MT 1440 A ST3B, MT 1840 A ST3B
21	746099	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	281602	Lifting cylinder	1		MT 1440 A ST3B
2	52504751	Lifting cylinder	1	281602, 794859	MT 1440 A ST3B
3	940621	Bushing	2	748487	MT 1440 A ST3B
4	746010	Cylinder rod	1		MT 1440 A ST3B
5	940620	Bushing	2		MT 1440 A ST3B
6	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B
7	192777	Cap	1		MT 1440 A ST3B
8	746018	Fastening ring	1		MT 1440 A ST3B
9	746021	Seal	1		MT 1440 A ST3B
10	738113	Seal	2		MT 1440 A ST3B
11	746019	Seal	1		MT 1440 A ST3B
12	746020	Seal	2		MT 1440 A ST3B
13	746022	Screw	20		MT 1440 A ST3B
14	746012	Bushing	1		MT 1440 A ST3B
15	746015	Cylinder piston	1		MT 1440 A ST3B
16	192271	screw	1		MT 1440 A ST3B
17	746013	Seal	2		MT 1440 A ST3B
18	746014	Seal	1		MT 1440 A ST3B
19	5239	"O" ring	1		MT 1440 A ST3B
20	746023	Seal kit	1		MT 1440 A ST3B
21	794860	Connection	1		MT 1440 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	281601	Lifting cylinder	1		MT 1840 A ST3B
2	52504752	Lifting cylinder	1	281601, 794861	MT 1840 A ST3B
3	940621	Bushing	2	748487	MT 1840 A ST3B
4	746010	Cylinder rod	1		MT 1840 A ST3B
5	940620	Bushing	2		MT 1840 A ST3B
6	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1840 A ST3B
7	192777	Cap	1		MT 1840 A ST3B
8	746018	Fastening ring	1		MT 1840 A ST3B
9	746021	Seal	1		MT 1840 A ST3B
10	738113	Seal	2		MT 1840 A ST3B
11	746019	Seal	1		MT 1840 A ST3B
12	746020	Seal	2		MT 1840 A ST3B
13	746022	Screw	20		MT 1840 A ST3B
14	746012	Bushing	1		MT 1840 A ST3B
15	746015	Cylinder piston	1		MT 1840 A ST3B
16	192271	screw	1		MT 1840 A ST3B
17	746013	Seal	2		MT 1840 A ST3B
18	746014	Seal	1		MT 1840 A ST3B
19	5239	"O" ring	1		MT 1840 A ST3B
20	746023	Seal kit	1		MT 1840 A ST3B
21	794860	Connection	1		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504751	Lifting cylinder	1	281602, 794859	MT 1440 A ST3B
2	52504751	Lifting cylinder	1	281602, 794859	MT 1440 A ST3B
3	940621	Bushing	2	748487	MT 1440 A ST3B
4	746010	Cylinder rod	1		MT 1440 A ST3B
5	940620	Bushing	2		MT 1440 A ST3B
6	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B
7	192777	Cap	1		MT 1440 A ST3B
8	746018	Fastening ring	1		MT 1440 A ST3B
9	746021	Seal	1		MT 1440 A ST3B
10	738113	Seal	2		MT 1440 A ST3B
11	746019	Seal	1		MT 1440 A ST3B
12	746020	Seal	2		MT 1440 A ST3B
13	746022	Screw	20		MT 1440 A ST3B
14	746012	Bushing	1		MT 1440 A ST3B
15	746015	Cylinder piston	1		MT 1440 A ST3B
16	192271	screw	1		MT 1440 A ST3B
17	746013	Seal	2		MT 1440 A ST3B
18	746014	Seal	1		MT 1440 A ST3B
19	5239	"O" ring	1		MT 1440 A ST3B
20	746023	Seal kit	1		MT 1440 A ST3B
21	794860	Connection	1		MT 1440 A ST3B
22	187897	"O" ring	1		MT 1440 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504752	Lifting cylinder	1	281601, 794861	MT 1840 A ST3B
2	52504752	Lifting cylinder	1	281601, 794861	MT 1840 A ST3B
3	940621	Bushing	2	748487	MT 1840 A ST3B
4	746010	Cylinder rod	1		MT 1840 A ST3B
5	940620	Bushing	2		MT 1840 A ST3B
6	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1840 A ST3B
7	192777	Cap	1		MT 1840 A ST3B
8	746018	Fastening ring	1		MT 1840 A ST3B
9	746021	Seal	1		MT 1840 A ST3B
10	738113	Seal	2		MT 1840 A ST3B
11	746019	Seal	1		MT 1840 A ST3B
12	746020	Seal	2		MT 1840 A ST3B
13	746022	Screw	20		MT 1840 A ST3B
14	746012	Bushing	1		MT 1840 A ST3B
15	746015	Cylinder piston	1		MT 1840 A ST3B
16	192271	screw	1		MT 1840 A ST3B
17	746013	Seal	2		MT 1840 A ST3B
18	746014	Seal	1		MT 1840 A ST3B
19	5239	"O" ring	1		MT 1840 A ST3B
20	746023	Seal kit	1		MT 1840 A ST3B
21	794860	Connection	1		MT 1840 A ST3B
22	187897	"O" ring	1		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	260508	Tilting cylinder	1		MT 1440 A ST3B, MT 1840 A ST3B
2	746077	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
4	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
5	209455	ring	2		MT 1440 A ST3B, MT 1840 A ST3B
6	746076	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	209455	ring	2		MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746078	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	746079	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
12	746080	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	600741	seal	2		MT 1440 A ST3B, MT 1840 A ST3B
14	551272	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
15	731482	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
16	731478	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
17	603585	Seal	1	551265	MT 1440 A ST3B, MT 1840 A ST3B
18	731479	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
19	4040	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
20	199446	Screw	1	569039	MT 1440 A ST3B, MT 1840 A ST3B
21	746081	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504503	Stabilizer cylinder	2	259544	MT 1440 A ST3B, MT 1840 A ST3B
2	746090	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	940618	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
4	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
5	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
6	746088	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	940618	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746091	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	561593	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
12	705367	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	705368	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
14	109080	"O" ring	1	509799, 165514, 186978, 569050	MT 1440 A ST3B, MT 1840 A ST3B
15	738487	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
16	746089	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
17	199446	Screw	1	569039	MT 1440 A ST3B, MT 1840 A ST3B
18	192266	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
19	4040	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
20	746092	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	259544	Stabilizer cylinder	2		MT 1440 A ST3B, MT 1840 A ST3B
2	746090	Cylinder body	1		MT 1440 A ST3B, MT 1840 A ST3B
3	940618	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
4	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
5	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
6	746088	Cylinder rod	1		MT 1440 A ST3B, MT 1840 A ST3B
7	940618	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
8	125963	Greaser	1	D1168227, 476891, H712992R91, 129963, 138106, A517852, 487527, 2727003MI, A7021145A, 501368, 546093, 604175, D1168225	MT 1440 A ST3B, MT 1840 A ST3B
9	192777	Cap	1		MT 1440 A ST3B, MT 1840 A ST3B
10	746091	Fastening ring	1		MT 1440 A ST3B, MT 1840 A ST3B
11	561593	Seal	2		MT 1440 A ST3B, MT 1840 A ST3B
12	705367	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
13	705368	seal	1		MT 1440 A ST3B, MT 1840 A ST3B
14	109080	"O" ring	1	509799, 165514, 186978, 569050	MT 1440 A ST3B, MT 1840 A ST3B
15	738487	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
16	746089	Cylinder piston	1		MT 1440 A ST3B, MT 1840 A ST3B
17	199446	Screw	1	569039	MT 1440 A ST3B, MT 1840 A ST3B
18	192266	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
19	4040	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
20	746092	Seal kit	1		MT 1440 A ST3B, MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	260651	Telescope cylinder	1		MT 1440 A ST3B
2	702102	Cylinder piston	1		MT 1440 A ST3B
3	702077	Filter	1		MT 1440 A ST3B
4	551264	Screw	1		MT 1440 A ST3B
5	607642	Complete valve	1		MT 1440 A ST3B
6	138045	Circlip	1	108964, 549118, 474279, 139454, 127331	MT 1440 A ST3B
7	563170	Seal	2	550134	MT 1440 A ST3B
8	550135	Seal	1		MT 1440 A ST3B
9	746049	Spacer	1		MT 1440 A ST3B
10	746047	Fastening ring	1		MT 1440 A ST3B
11	604119	Seal	2	585353, 561621, 604349	MT 1440 A ST3B
12	187931	"O" ring	1		MT 1440 A ST3B
13	746048	Seal	1		MT 1440 A ST3B
14	731388	Seal	1		MT 1440 A ST3B
15	731387	Seal	1		MT 1440 A ST3B
16	746050	Washer	1		MT 1440 A ST3B
17	746052	Nut	1		MT 1440 A ST3B
18	746054	Seal kit	1		MT 1440 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	283286	Telescope cylinder	1		MT 1440 A ST3B
2	746057	Fastening ring	1		MT 1440 A ST3B
3	561593	Seal	2		MT 1440 A ST3B
4	705367	seal	1		MT 1440 A ST3B
5	705368	seal	1		MT 1440 A ST3B
6	132445	"O" ring	1	2742135MI, 512950, 187400, 449541, A003009803	MT 1440 A ST3B
7	731437	Seal	1		MT 1440 A ST3B
8	702101	Cylinder piston	1	550133, 702078	MT 1440 A ST3B
9	702077	Filter	1		MT 1440 A ST3B
10	607642	Complete valve	1		MT 1440 A ST3B
11	138045	Circlip	1	108964, 549118, 474279, 139454, 127331	MT 1440 A ST3B
12	549137	Screw	1		MT 1440 A ST3B
13	604317	Seal	2		MT 1440 A ST3B
14	549135	Seal	1		MT 1440 A ST3B
15	549128	Bushing	1	579595	MT 1440 A ST3B
16	169672	Snap ring	1		MT 1440 A ST3B
17	746058	Seal kit	1		MT 1440 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	300930	Telescope cylinder	1		MT 1840 A ST3B
2	162410	Snap ring	1		MT 1840 A ST3B
3	738089	Stop	1		MT 1840 A ST3B
4	750560	Cylinder piston	1		MT 1840 A ST3B
5	561331	"O" ring	1		MT 1840 A ST3B
6	738008	Seal	1		MT 1840 A ST3B
7	192306	Screw	1		MT 1840 A ST3B
8	796743	Fastening ring	1		MT 1840 A ST3B
9	187931	"O" ring	1		MT 1840 A ST3B
10	1195	"O" ring	1	F46066, 2742196MI, 600272, 662360	MT 1840 A ST3B
11	738092	seal	2		MT 1840 A ST3B
12	795058	Rod seal	1		MT 1840 A ST3B
13	796744	Seal	1		MT 1840 A ST3B
14	796745	Seal kit	1	750561	MT 1840 A ST3B
15	564573	Anti-extrusion seal	1		MT 1840 A ST3B




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504506	Telescope cylinder	1		MT 1440 A ST3B
2	702102	Cylinder piston	1		MT 1440 A ST3B
3	702077	Filter	1		MT 1440 A ST3B
4	551264	Screw	1		MT 1440 A ST3B
5	607642	Complete valve	1		MT 1440 A ST3B
6	138045	Circlip	1	108964, 549118, 474279, 139454, 127331	MT 1440 A ST3B
7	563170	Seal	2	550134	MT 1440 A ST3B
8	550135	Seal	1		MT 1440 A ST3B
9	746049	Spacer	1		MT 1440 A ST3B
10	746047	Fastening ring	1		MT 1440 A ST3B
11	604119	Seal	2	585353, 561621, 604349	MT 1440 A ST3B
12	187931	"O" ring	1		MT 1440 A ST3B
13	746048	Seal	1		MT 1440 A ST3B
14	731388	Seal	1		MT 1440 A ST3B
15	731387	Seal	1		MT 1440 A ST3B
16	746050	Washer	1		MT 1440 A ST3B
17	746052	Nut	1		MT 1440 A ST3B
18	746054	Seal kit	1		MT 1440 A ST3B

Catalogue : 647101			Qté-Menge-Cant-Qty-Q.ta										10 CC 191										M	
1	HYDRAULIQUE (Vérin de télescopage extérieur) HYDRAULIK (Äußere teleskopzylinder) IDRAULICO (Cilindro de telescopaje exterior) HYDRAULIC (Outer telescope cylinder) IDRAULICO (Cilindro di telescopaggio esteriore)		1- MT 1440 A ST3B 11- 2- MT 1840 A ST3B 12- 3- 13- 4- 14- 5- 15- 6- 16- 7- 17- 8- 18- 9- 19- 10- 20-																					
Rep Hinw Fig Item Rif	Numéro Teil-Nr Numero Part-Nr Part-Nr	Désignation Bezeichnung Description Descrizione	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20		
1	52504506	Vérin télesc. D:65mm C:3766mm Zusammenstroll zylinder Cilindro de telescopaje Cilindro di telescopico	1																					
2	702102	Piston de vérin Pistón de cilindro Pistone del cilindro	1																					
3	702077	Filtre Filtro Filtro	1																					
4	551264	Vis Hc, M 8- 18 zinguée Tornillo Vite	1																					
5	607642	Clapet complet Valvula completa Valvola completa	1																					
6	549118	Circlips Aro retén Anello elastico	1																					
7	563170	Joint d'étanchéité Junta de estanqueidad Guarnizione	2																					
8	550135	Joint d'étanchéité Junta de estanqueidad Guarnizione	1																					
9	746049	Entretoise Separador Distanziale	1																					
10	746047	Bague de fermeture Anillo de cierre Anello di chiusura	1																					
11	604119	Joint d'étanchéité Junta de estanqueidad Guarnizione di tenuta	2																					


20/05/2014

Catalogue : 647101				Qté-Menge-Cant-Qty-Q.ta										10 CC 191										M									
Rep Hinw Fig Item Rif	Numéro Teil-Nr Numero Part-Nr Part-Nr	Designation Bezeichnung Description Descrizione		1- MT 1440 A ST3B 11- 2- MT 1840 A ST3B 12- 3- 13- 4- 14- 5- 15- 6- 16- 7- 17- 8- 18- 9- 19- 10- 20-																													
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20										
2		HYDRAULIQUE (Várin de télescopage extérieur) HYDRAULIK (Außere teleskopzylinder) IDRAULICO (Cilindro de telescopaje exterior) HYDRAULIC (Outer telescope cylinder) IDRAULICO (Cilindro di telescopaggio esteriore)																															
12	187931	Joint torique - "O" ring Junta tórica - "O" ring Anello OR -		1																													
13	746048	Joint d'étanchéité - Dichtring Junta de estanqueidad - Seal Guarnizióne di tenuta -		1																													
14	731388	Joint d'étanchéité - Dichtring Junta de estanqueidad - Seal Guarnizióne di tenuta -		1																													
15	731387	Joint d'étanchéité - Dichtring Junta de estanqueidad - Seal Guarnizióne di tenuta -		1																													
16	746050	Rondelle - Unterlegscheibe Arandela - Washer Rondella -		1																													
17	746052	Ecrou - Mutter Tuerca - Nut Dado -		1																													
18	746054	Pochette de joints - Dichtungssatz Juego de juntas - Seal kit Kit guarnizióne -		1																													

20/05/2014



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	52504508	Telescope cylinder	1		MT 1840 A ST3B
2	162410	Snap ring	1		MT 1840 A ST3B
3	738089	Stop	1		MT 1840 A ST3B
4	750560	Cylinder piston	1		MT 1840 A ST3B
5	561331	"O" ring	1		MT 1840 A ST3B
6	738008	Seal	1		MT 1840 A ST3B
7	192306	Screw	1		MT 1840 A ST3B
8	796743	Fastening ring	1		MT 1840 A ST3B
9	187931	"O" ring	1		MT 1840 A ST3B
10	1195	"O" ring	1	F46066, 2742196MI, 600272, 662360	MT 1840 A ST3B
11	738092	seal	2		MT 1840 A ST3B
12	795058	Rod seal	1		MT 1840 A ST3B
13	796744	Seal	1		MT 1840 A ST3B
14	796745	Seal kit	1	750561	MT 1840 A ST3B
15	564573	Anti-extrusion seal	1		MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	264610	Articulating pin	1		MT 1440 A ST3B
2	58610	Screw	1		MT 1440 A ST3B
3	73202	Washer	1		MT 1440 A ST3B
4	185402	thickness	1		MT 1440 A ST3B
4	185403	thickness	1		MT 1440 A ST3B
5	284012	Boom foot with bushing	1		MT 1440 A ST3B
6	208286	Bushing	4		MT 1440 A ST3B
7	51534	Straight greaser	2	455684, 49402, 133103, 127378, 130435, 188315, 470719, A517853, 43813, 138390, 501153, 127315, 90822, 137023, A4104177A	MT 1440 A ST3B
8	277366	Slide block cage	1		MT 1440 A ST3B
9	277367	Slide block cage	1		MT 1440 A ST3B
10	277388	Slide block	1		MT 1440 A ST3B
10	277389	Slide block	1		MT 1440 A ST3B
10	277390	Slide block	1		MT 1440 A ST3B
10	277391	Slide block	1		MT 1440 A ST3B
10	277392	Slide block	1		MT 1440 A ST3B
11	253449	Slide block	1		MT 1440 A ST3B
11	253450	Slide block	1		MT 1440 A ST3B
11	253451	Slide block	1		MT 1440 A ST3B
11	261368	Slide block	1		MT 1440 A ST3B
11	261369	Slide block	1		MT 1440 A ST3B
11	266727	Slide block	1		MT 1440 A ST3B
12	277368	Slide block cage	1		MT 1440 A ST3B
13	277369	Slide block cage	1		MT 1440 A ST3B
14	277393	Slide block	1		MT 1440 A ST3B
14	277394	Slide block	1		MT 1440 A ST3B
14	277395	Slide block	1		MT 1440 A ST3B
14	277396	Slide block	1		MT 1440 A ST3B
14	277397	Slide block	1		MT 1440 A ST3B
15	267569	Fastening lug	2		MT 1440 A ST3B
16	255616	Screw	4		MT 1440 A ST3B
17	255616	Screw	2		MT 1440 A ST3B
19	277472	Intermediate boom section	1		MT 1440 A ST3B
20	277388	Slide block	1		MT 1440 A ST3B
20	277389	Slide block	1		MT 1440 A ST3B
20	277390	Slide block	1		MT 1440 A ST3B
20	277391	Slide block	1		MT 1440 A ST3B
20	277392	Slide block	1		MT 1440 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
21	253449	Slide block	1		MT 1440 A ST3B
21	253450	Slide block	1		MT 1440 A ST3B
21	253451	Slide block	1		MT 1440 A ST3B
21	261368	Slide block	1		MT 1440 A ST3B
21	261369	Slide block	1		MT 1440 A ST3B
21	266727	Slide block	1		MT 1440 A ST3B
22	260685	Fastening lug	1		MT 1440 A ST3B
23	260551	Rear sheat	1		MT 1440 A ST3B
24	255616	Screw	2		MT 1440 A ST3B
25	277366	Slide block cage	1		MT 1440 A ST3B
26	277367	Slide block cage	1		MT 1440 A ST3B
27	277388	Slide block	1		MT 1440 A ST3B
27	277389	Slide block	1		MT 1440 A ST3B
27	277390	Slide block	1		MT 1440 A ST3B
27	277391	Slide block	1		MT 1440 A ST3B
27	277392	Slide block	1		MT 1440 A ST3B
28	253449	Slide block	1		MT 1440 A ST3B
28	253450	Slide block	1		MT 1440 A ST3B
28	253451	Slide block	1		MT 1440 A ST3B
28	261368	Slide block	1		MT 1440 A ST3B
28	261369	Slide block	1		MT 1440 A ST3B
28	266727	Slide block	1		MT 1440 A ST3B
29	277368	Slide block cage	1		MT 1440 A ST3B
30	277369	Slide block cage	1		MT 1440 A ST3B
31	277393	Slide block	1		MT 1440 A ST3B
31	277394	Slide block	1		MT 1440 A ST3B
31	277395	Slide block	1		MT 1440 A ST3B
31	277396	Slide block	1		MT 1440 A ST3B
31	277397	Slide block	1		MT 1440 A ST3B
32	260689	Fastening lug	1		MT 1440 A ST3B
33	273972	Screw	3		MT 1440 A ST3B
34	255616	Screw	1		MT 1440 A ST3B
35	255616	Screw	2		MT 1440 A ST3B
36	276370	Boom head	1		MT 1440 A ST3B
37	208312	Bushing	4		MT 1440 A ST3B
38	277388	Slide block	1		MT 1440 A ST3B
38	277389	Slide block	1		MT 1440 A ST3B
38	277390	Slide block	1		MT 1440 A ST3B
38	277391	Slide block	1		MT 1440 A ST3B
38	277392	Slide block	1		MT 1440 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
39	253449	Slide block	1		MT 1440 A ST3B
39	253450	Slide block	1		MT 1440 A ST3B
39	253451	Slide block	1		MT 1440 A ST3B
39	261368	Slide block	1		MT 1440 A ST3B
39	261369	Slide block	1		MT 1440 A ST3B
39	266727	Slide block	1		MT 1440 A ST3B
40	260684	Fastening lug	2		MT 1440 A ST3B
41	264079	Rear sheat	1		MT 1440 A ST3B
42	255616	Screw	4		MT 1440 A ST3B
43	51534	Straight greaser	2	455684, 49402, 133103, 127378, 130435, 188315, 470719, A517853, 43813, 138390, 501153, 127315, 90822, 137023, A4104177A	MT 1440 A ST3B
44	261134	Housing	1		MT 1440 A ST3B
45	160552	Screw	3		MT 1440 A ST3B
46	61676	Washer	3		MT 1440 A ST3B
47	293944	Carrier	1		MT 1440 A ST3B
48	208251	Bushing	2		MT 1440 A ST3B
49	264584	Articulating pin	1		MT 1440 A ST3B
50	58610	Screw	1		MT 1440 A ST3B
51	73202	Washer	1		MT 1440 A ST3B
52	213666	Spindle	1		MT 1440 A ST3B
53	32963	cotter pin	1		MT 1440 A ST3B
54	270268	Fastening lug	1		MT 1440 A ST3B
55	255616	Screw	3		MT 1440 A ST3B
56	264246	Fastening lug	1		MT 1440 A ST3B
57	73202	Washer	1		MT 1440 A ST3B
58	284027	Washer	1		MT 1440 A ST3B
59	58610	Screw	1		MT 1440 A ST3B
60	228363	screw	2		MT 1440 A ST3B
61	44706	SCREW	4	51450	MT 1440 A ST3B

5 BA 776


KIT D'ETANCHEITE SUR FLECHE
KIT FÜR DICHTHEIT AUF AUSLEGER
KIT DE ESTANQUEIDAD SOBRE AGUILON
SEALING KIT ON BOOM
KIT PROTEZIONI SU BRACCIO

MT-X 1440 A E3



08 / 11 / 11
P.A.Q. Italia

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	261242	Brush	2		MT 1440 A ST3B
2	264076	Brush	1		MT 1440 A ST3B
3	264078	Brush	1		MT 1440 A ST3B
4	264078	Brush	1		MT 1440 A ST3B
5	264076	Brush	1		MT 1440 A ST3B
6	264075	Brush bracket	2		MT 1440 A ST3B
7	79533	Screw	12		MT 1440 A ST3B
8	79533	Screw	12		MT 1440 A ST3B
9	261235	Brush	2		MT 1440 A ST3B
10	264040	Brush	1		MT 1440 A ST3B
11	264039	Brush	1		MT 1440 A ST3B
12	264043	Brush	1		MT 1440 A ST3B
13	264042	Brush	1		MT 1440 A ST3B
14	264041	Brush bracket	2		MT 1440 A ST3B



Позиция	№ детали	Название	К-во	Superseded Part Number	Product Type
1	264610	Articulating pin	1		MT 1840 A ST3B
2	58610	Screw	1		MT 1840 A ST3B
3	73202	Washer	1		MT 1840 A ST3B
4	185402	thickness	1		MT 1840 A ST3B
4	185403	thickness	1		MT 1840 A ST3B
5	73202	Washer	1		MT 1840 A ST3B
6	284027	Washer	1		MT 1840 A ST3B
7	58610	Screw	1		MT 1840 A ST3B
8	301394	Boom foot with bushing	1		MT 1840 A ST3B
9	208286	Bushing	4		MT 1840 A ST3B
10	51534	Straight greaser	2	455684, 49402, 133103, 127378, 130435, 188315, 470719, A517853, 43813, 138390, 501153, 127315, 90822, 137023, A4104177A	MT 1840 A ST3B
11	218962	sliding block	4		MT 1840 A ST3B
12	188472	thickness	1		MT 1840 A ST3B
12	188473	thickness	1		MT 1840 A ST3B
12	218395	thickness	1		MT 1840 A ST3B
13	207524	Screw	4		MT 1840 A ST3B
14	188546	Screw	4		MT 1840 A ST3B
15	58548	Nut	8	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
16	218962	sliding block	2		MT 1840 A ST3B
17	188472	thickness	1		MT 1840 A ST3B
17	188473	thickness	1		MT 1840 A ST3B
17	218395	thickness	1		MT 1840 A ST3B
18	295717	Shim	2		MT 1840 A ST3B
19	220391	Screw	4		MT 1840 A ST3B
20	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
21	218966	Slide block	2		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	Superseded Part Number	Product Type
22	197589	dowel pin	2		MT 1840 A ST3B
23	269382	thickness	2		MT 1840 A ST3B
24	269377	bushing	2		MT 1840 A ST3B
25	196078	Screw	2		MT 1840 A ST3B
27	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
28	305227	Boom telescope I	1		MT 1840 A ST3B
29	298755	thickness	1		MT 1840 A ST3B
29	298756	Shim	1		MT 1840 A ST3B
29	298757	thickness	1		MT 1840 A ST3B
29	298758	thickness	1		MT 1840 A ST3B
32	220391	Screw	4		MT 1840 A ST3B
33	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
34	218962	sliding block	2		MT 1840 A ST3B
35	288284	sliding block	1		MT 1840 A ST3B
36	288286	Slide block (L.H.)	1		MT 1840 A ST3B
38	188546	Screw	4		MT 1840 A ST3B
39	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
40	218962	sliding block	2		MT 1840 A ST3B
41	188472	thickness	1		MT 1840 A ST3B
41	188473	thickness	1		MT 1840 A ST3B
41	218395	thickness	1		MT 1840 A ST3B
42	188546	Screw	4		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
43	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
44	218962	sliding block	4		MT 1840 A ST3B
45	188472	thickness	1		MT 1840 A ST3B
45	188473	thickness	1		MT 1840 A ST3B
45	218395	thickness	1		MT 1840 A ST3B
46	188546	Screw	4		MT 1840 A ST3B
47	207524	Screw	4		MT 1840 A ST3B
48	58548	Nut	8	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
49	218962	sliding block	2		MT 1840 A ST3B
50	188472	thickness	1		MT 1840 A ST3B
50	188473	thickness	1		MT 1840 A ST3B
50	218395	thickness	1		MT 1840 A ST3B
51	288903	thickness	2		MT 1840 A ST3B
52	196078	Screw	4		MT 1840 A ST3B
53	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
54	218966	Slide block	2		MT 1840 A ST3B
56	295722	Shim	2		MT 1840 A ST3B
57	288905	bushing	2		MT 1840 A ST3B
58	188545	Screw	2	487750	MT 1840 A ST3B
59	196078	Screw	2		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
60	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
61	293269	Boom telescope II	1		MT 1840 A ST3B
62	188472	thickness	1		MT 1840 A ST3B
62	188473	thickness	1		MT 1840 A ST3B
62	188542	thickness	1		MT 1840 A ST3B
62	218395	thickness	1		MT 1840 A ST3B
65	197589	dowel pin	4		MT 1840 A ST3B
66	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
67	218962	sliding block	2		MT 1840 A ST3B
68	218962	sliding block	2		MT 1840 A ST3B
69	188472	thickness	1		MT 1840 A ST3B
69	188473	thickness	1		MT 1840 A ST3B
69	218395	thickness	1		MT 1840 A ST3B
70	188546	Screw	4		MT 1840 A ST3B
71	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
72	218962	sliding block	2		MT 1840 A ST3B
74	288896	thickness	2		MT 1840 A ST3B
75	196078	Screw	4		MT 1840 A ST3B
76	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
77	218968	sliding block	4		MT 1840 A ST3B
78	199303	Shim	1		MT 1840 A ST3B
78	199874	Shim	1		MT 1840 A ST3B
78	219068	Shim	1		MT 1840 A ST3B
79	188546	Screw	4		MT 1840 A ST3B
80	207524	Screw	4		MT 1840 A ST3B
81	58548	Nut	8	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
82	218968	sliding block	2		MT 1840 A ST3B
83	199303	Shim	1		MT 1840 A ST3B
83	199874	Shim	1		MT 1840 A ST3B
83	219068	Shim	1		MT 1840 A ST3B
84	288891	Shim	2		MT 1840 A ST3B
85	207524	Screw	4		MT 1840 A ST3B
86	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
87	218966	Slide block	2		MT 1840 A ST3B
89	295716	Shim	2		MT 1840 A ST3B
90	288905	bushing	2		MT 1840 A ST3B
91	188545	Screw	2	487750	MT 1840 A ST3B
92	196078	Screw	2		MT 1840 A ST3B
93	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
94	296993	Boom telescope	1		MT 1840 A ST3B
95	208312	Bushing	4		MT 1840 A ST3B
96	298755	thickness	1		MT 1840 A ST3B
96	298756	Shim	1		MT 1840 A ST3B


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
96	298757	thickness	1		MT 1840 A ST3B
96	298758	thickness	1		MT 1840 A ST3B
99	1479	Screw	4		MT 1840 A ST3B
100	50150	Nut	4		MT 1840 A ST3B
101	218962	sliding block	2		MT 1840 A ST3B
102	218962	sliding block	2		MT 1840 A ST3B
103	188472	thickness	1		MT 1840 A ST3B
103	188473	thickness	1		MT 1840 A ST3B
103	218395	thickness	1		MT 1840 A ST3B
104	188546	Screw	4		MT 1840 A ST3B
105	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
106	218962	sliding block	2		MT 1840 A ST3B
108	288896	thickness	2		MT 1840 A ST3B
109	196078	Screw	2		MT 1840 A ST3B
110	58548	Nut	4	A503513, 455682, 45975, 554193, 2762140MI, T4012000, D1125801, 446203, 482312, 55345F203071, 133090, A4182438A, 133087, 455623, 4866, 471368, 130490	MT 1840 A ST3B
111	259792	sliding block	2		MT 1840 A ST3B
112	261499	screw	4		MT 1840 A ST3B
113	289255	Housing	1		MT 1840 A ST3B
114	293804	Screw	2		MT 1840 A ST3B
115	259601	Screw	2		MT 1840 A ST3B
116	295707	Carrier	1		MT 1840 A ST3B
117	208251	Bushing	2		MT 1840 A ST3B
118	264584	Articulating pin	1		MT 1840 A ST3B
119	58610	Screw	1		MT 1840 A ST3B
120	73202	Washer	1		MT 1840 A ST3B
121	213666	Spindle	1		MT 1840 A ST3B
122	32963	cotter pin	1		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
123	51534	Straight greaser	2	455684, 49402, 133103, 127378, 130435, 188315, 470719, A517853, 43813, 138390, 501153, 127315, 90822, 137023, A4104177A	MT 1840 A ST3B
125	297940	Screw	4		MT 1840 A ST3B
126	42231	Washer	4		MT 1840 A ST3B
128	297940	Screw	4		MT 1840 A ST3B
129	42231	Washer	4		MT 1840 A ST3B
130	291801	support	1		MT 1840 A ST3B
131	61676	Washer	2		MT 1840 A ST3B
132	259792	sliding block	1		MT 1840 A ST3B
133	261499	screw	2		MT 1840 A ST3B
134	220391	Screw	2		MT 1840 A ST3B
135	228363	screw	3		MT 1840 A ST3B
136	196951	screw	2		MT 1840 A ST3B
137	303825	Boom foot with bushing	1		MT 1840 A ST3B
138	303828	Boom telescope	1		MT 1840 A ST3B

5 BA 785


KIT D'ETANCHEITE SUR FLECHE
 KIT FÜR DICHTHEIT AUF AUSLEGER
 KIT DE ESTANQUEIDAD SOBRE AGUILON
 SEALING KIT ON BOOM
 KIT PROTEZIONI SU BRACCIO

MT 1840 A ST3B



26 / 06 / 14
 P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	289223	L.H. brush bracket	1		MT 1840 A ST3B
2	289224	R.H. brush bracket	1		MT 1840 A ST3B
3	289221	Lower brush bracket	1		MT 1840 A ST3B
4	259986	Nut	6		MT 1840 A ST3B
5	289222	Upper brush bracket	1		MT 1840 A ST3B
6	196951	screw	2		MT 1840 A ST3B
7	29469	washer	2		MT 1840 A ST3B
8	289236	L.H. brush	1		MT 1840 A ST3B
9	289238	R.H. brush	1		MT 1840 A ST3B
10	289239	Brush bracket	2		MT 1840 A ST3B
11	289234	Lower brush	1		MT 1840 A ST3B
12	289235	Upper brush	2		MT 1840 A ST3B
13	289251	Screw	16		MT 1840 A ST3B
15	289226	L.H. brush bracket	1		MT 1840 A ST3B
16	289227	R.H. brush bracket	1		MT 1840 A ST3B
17	289225	Lower brush bracket	1		MT 1840 A ST3B
18	259986	Nut	6		MT 1840 A ST3B
19	289242	L.H. brush	1		MT 1840 A ST3B
20	289243	R.H. brush	1		MT 1840 A ST3B
21	289245	Brush bracket	2		MT 1840 A ST3B
22	289240	Lower brush	2		MT 1840 A ST3B
23	289244	Upper brush	1		MT 1840 A ST3B
24	289251	Screw	16		MT 1840 A ST3B
25	189858	Washer	2		MT 1840 A ST3B
26	289229	L.H. brush bracket	1		MT 1840 A ST3B
27	289230	R.H. bracket	1		MT 1840 A ST3B
28	289228	Lower brush bracket	1		MT 1840 A ST3B
29	259986	Nut	6		MT 1840 A ST3B
30	289247	L.H. brush	1		MT 1840 A ST3B
31	289248	R.H. brush	1		MT 1840 A ST3B
32	289245	Brush bracket	2		MT 1840 A ST3B
33	289246	Lower brush	1		MT 1840 A ST3B
34	289249	Upper brush	2		MT 1840 A ST3B
35	289251	Screw	12		MT 1840 A ST3B
37	61676	Washer	20		MT 1840 A ST3B



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	776951	Chain	2		MT 1840 A ST3B
2	777005	tensioner	2		MT 1840 A ST3B
3	777345	pin	2		MT 1840 A ST3B
4	52071	dowel	4		MT 1840 A ST3B
5	37703	washer	24		MT 1840 A ST3B
6	290550	nut	4		MT 1840 A ST3B
7	7111	dowel	2		MT 1840 A ST3B
8	776950	roller	2	295718	MT 1840 A ST3B
9	484346	pulley	2		MT 1840 A ST3B
10	303367	pin	1	300292	MT 1840 A ST3B
11	226	Straight greaser	2		MT 1840 A ST3B
12	60360	Screw	1		MT 1840 A ST3B
13	45921	Washer	1		MT 1840 A ST3B
14	776924	Fastening plate	1		MT 1840 A ST3B
15	288301	screw	4		MT 1840 A ST3B
16	777345	pin	2		MT 1840 A ST3B
17	52071	dowel	4		MT 1840 A ST3B
18	776954	Complete chain	2		MT 1840 A ST3B
19	716700	tensioner	2		MT 1840 A ST3B
20	887007	pin	2		MT 1840 A ST3B
21	35000	dowel	4	95381F202071, 631282072071, 563449, 61343, 710417, 5731, 1085, 853817601071, 9538102020	MT 1840 A ST3B
22	777004	support	1		MT 1840 A ST3B
23	288294	screw	2		MT 1840 A ST3B
24	58573	nut	4	A4107285A, 602275, 549264, T3016000	MT 1840 A ST3B
25	61344	dowel	2		MT 1840 A ST3B
26	584801	pulley	1		MT 1840 A ST3B
27	287892	Bushing	2		MT 1840 A ST3B
28	288937	pin	1		MT 1840 A ST3B
29	293662	dowel	1		MT 1840 A ST3B
30	55131	grease nipple	1		MT 1840 A ST3B
31	63727	Screw	1		MT 1840 A ST3B
32	289324	plate	2		MT 1840 A ST3B
33	288295	screw	4		MT 1840 A ST3B
34	887007	pin	2		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
35	35000	dowel	4	95381F202071, 631282072071, 563449, 61343, 710417, 5731, 1085, 853817601071, 9538102020	MT 1840 A ST3B
36	776922	Complete chain	2		MT 1840 A ST3B
37	776937	tensioner	2		MT 1840 A ST3B
38	887007	pin	2		MT 1840 A ST3B
39	35000	dowel	4	95381F202071, 631282072071, 563449, 61343, 710417, 5731, 1085, 853817601071, 9538102020	MT 1840 A ST3B
40	288788	washer	24		MT 1840 A ST3B
41	58573	nut	4	A4107285A, 602275, 549264, T3016000	MT 1840 A ST3B
42	61344	dowel	2		MT 1840 A ST3B
43	300279	pulley	2		MT 1840 A ST3B
44	300286	bushing	2		MT 1840 A ST3B
45	303368	pin	1	300282	MT 1840 A ST3B
46	226	Straight greaser	1		MT 1840 A ST3B
47	60360	Screw	1		MT 1840 A ST3B
48	45921	Washer	1		MT 1840 A ST3B
49	296846	fork	1		MT 1840 A ST3B
50	297006	screw	4		MT 1840 A ST3B
51	887007	pin	2		MT 1840 A ST3B
52	35000	dowel	4	95381F202071, 631282072071, 563449, 61343, 710417, 5731, 1085, 853817601071, 9538102020	MT 1840 A ST3B
53	776923	Complete chain	1	609537	MT 1840 A ST3B
54	776937	tensioner	1		MT 1840 A ST3B
55	887007	pin	1		MT 1840 A ST3B
56	35000	dowel	2	95381F202071, 631282072071, 563449, 61343, 710417, 5731, 1085, 853817601071, 9538102020	MT 1840 A ST3B
57	58573	nut	2	A4107285A, 602275, 549264, T3016000	MT 1840 A ST3B
58	61344	dowel	1		MT 1840 A ST3B
59	674506	pulley	1		MT 1840 A ST3B
60	288938	pin	1		MT 1840 A ST3B
61	293662	dowel	1		MT 1840 A ST3B
62	63727	Screw	1		MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
63	289324	plate	1		MT 1840 A ST3B
64	288294	screw	2		MT 1840 A ST3B
65	887007	pin	1		MT 1840 A ST3B
66	35000	dowel	2	95381F202071, 631282072071, 563449, 61343, 710417, 5731, 1085, 853817601071, 9538102020	MT 1840 A ST3B
67	597300	spacer	4		MT 1840 A ST3B

4 AA 1195

ADAPTATION MOTEUR-TRANSMISSION
MOTOR-GETRIEBE ANPASSUNG
ADAPTACION MOTOR-TRANSMISION
ENGINE-TRANSMISSION ADAPTATION
ADATTAMENTO MOTORE - TRASMISSIONE


MT 1440 A ST3B
MT 1840 A ST3B

JUSQU'A LA MACHINE
BIS DER MASCHINE
HASTA LA MAQUINA
UP TO MACHINE
FINO LA MACCHINA

● → N°: 908 287

A PARTIR DE LA MACHINE
AB DER MASCHINE
A PARTIR DE LA MAQUINA
FROM MACHINE
A PARTIR DA MACCHINA

○ → N°: 908 288




23 / 03 / 12

P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	295432	Front engine bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
2	295436	Rear engine bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
3	160525	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
4	194287	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
5	31689	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
6	58593	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
7	194287	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
8	259278	support	4		MT 1440 A ST3B, MT 1840 A ST3B
9	177461	Screw	6		MT 1440 A ST3B, MT 1840 A ST3B
10	247575	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
11	261878	Nut	8		MT 1440 A ST3B, MT 1840 A ST3B
12	277072	Gear box bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
13	31689	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
14	194287	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
15	259274	Rod	2		MT 1440 A ST3B, MT 1840 A ST3B
16	259275	Spacer	1		MT 1440 A ST3B, MT 1840 A ST3B
17	261880	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
18	77710	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
19	261878	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
20	304608	Gear box bracket	1		MT 1440 A ST3B, MT 1840 A ST3B

_ENGINE UNIT



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	306352	Complete engine	1		MT 1440 A ST3B, MT 1840 A ST3B
2	190441	Hose	1	169258, 525596, 185710, 178382, 212947, 289854, 205612	MT 1440 A ST3B, MT 1840 A ST3B
3	525416	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
4	171090	fork	2		MT 1440 A ST3B, MT 1840 A ST3B
5	226606	screw	2	229591	MT 1440 A ST3B, MT 1840 A ST3B
6	285815	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
7	36010	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
8	302221	Lower bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
9	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
10	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
11	302224	Upper bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
12	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
13	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
14	297772	Protective housing	1		MT 1440 A ST3B, MT 1840 A ST3B
15	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
16	298593	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
17	212946	Drain plug	1		MT 1440 A ST3B, MT 1840 A ST3B
18	200814	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
19	190878	Seal	1		MT 1440 A ST3B, MT 1840 A ST3B
20	287548	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
21	219457	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
22	300174	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
23	193325	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
24	200814	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
25	266728	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
26	298456	Oil filter bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
27	63546	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
28	61676	Washer	2		MT 1440 A ST3B, MT 1840 A ST3B
29	219140	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
30	167698	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
31	193325	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
32	300172	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
33	193325	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
34	219140	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
35	257899	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
36	168758	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
37	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
38	279935	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
39	219457	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
40	296855	Oil filter engine	1		MT 1440 A ST3B, MT 1840 A ST3B
41	306349	Filter head	1		MT 1440 A ST3B, MT 1840 A ST3B
42	306273	Lower bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
43	306274	Upper bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
44	306581	Oil filter bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
45	308283	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
46	317039	filter	1		MT 1440 A ST3B, MT 1840 A ST3B
47	311180	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B

AP 2278

POUR MOTEUR
FÜR MOTOR
PARA MOTOR
FOR ENGINE
PER MOTORE


Type: JR 51746 . . . Y
Ref: 319 076

A PARTIR DE LA MACHINE
AB DER MASCHINE
A PARTIR DE LA MAQUINA
FROM MACHINE
A PARTIRE DA MACCHINA

→ N°: 931 479

ADAPTATION MOTEUR
MOTOR ANPASSUNG
ADAPTACION MOTOR
ENGINE ADAPTATION
ADATTAMENTO MOTORE

MT 1440 H ST3B
MT 1840 H ST3B



06 / 05 / 14
P.A.O. Illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	319076	Complete engine	1		MT 1440 A ST3B, MT 1840 A ST3B
2	190441	Hose	1	169258, 525596, 185710, 178382, 212947, 289854, 205612	MT 1440 A ST3B, MT 1840 A ST3B
3	525416	Connection	1		MT 1440 A ST3B, MT 1840 A ST3B
4	171090	fork	2		MT 1440 A ST3B, MT 1840 A ST3B
5	226606	screw	2	229591	MT 1440 A ST3B, MT 1840 A ST3B
6	285815	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
7	36010	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
8	306273	Lower bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
9	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
10	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
11	311180	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
12	259946	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
13	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
14	297772	Protective housing	1		MT 1440 A ST3B, MT 1840 A ST3B
15	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
16	298593	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
17	212946	Drain plug	1		MT 1440 A ST3B, MT 1840 A ST3B
18	308283	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
19	279935	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B

4 AA 1197

ADAPTATION MOTEUR-TRANSMISSION
MOTOR-GETRIEBE ANPASSUNG
ADAPTACION MOTOR-TRANSMISION
ENGINE-TRANSMISSION ADAPTATION
ADATTAMENTO MOTORE - TRASMISSIONE


MT 1440 A ST3B
MT 1840 A ST3B

JUSQU'À LA MACHINE
BIS DER MASCHINE
HASTA LA MACQUINA
UP TO MACHINE
FINO LA MACCHINA

● → N°: 908 287

A PARTIR DE LA MACHINE
AB DER MASCHINE
A PARTIR DE LA MACQUINA
FROM MACHINE
A PARTIR DA MACCHINA

○ → N°: 908 288



09 / 11 / 12

P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	293770	complete filter	1		MT 1440 A ST3B, MT 1840 A ST3B
2	299638	Air filter bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
3	268255	screw	7		MT 1440 A ST3B, MT 1840 A ST3B
4	206289	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
5	300338	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
6	232027	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
7	302167	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
8	300888	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
9	230763	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
10	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
11	796622	breather	1		MT 1440 A ST3B, MT 1840 A ST3B
12	299936	Air filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
13	299937	Security air filter cartridge	1		MT 1440 A ST3B, MT 1840 A ST3B
14	304365	Air filter bracket	1		MT 1440 A ST3B, MT 1840 A ST3B

4 AA 1201

ADAPTATION MOTEUR-TRANSMISSION
 MOTOR-GETRIEBE ANPASSUNG
 ADAPTACION MOTOR-TRANSMISION
 ENGINE-TRANSMISSION ADAPTATION
 ADATTAMENTO MOTORE -

MT 1440 H ST3B
 MT 1840 H ST3B

JUSQU'A LA MACHINE
 BIS DER MASCHINE
 HASTA LA MAQUINA
 UP TO MACHINE
 FINO LA MACCHINA


● → N°: 908 287
 ▲ → N°: 931 478

A PARTIR DE LA MACHINE
 AB DER MASCHINE
 A PARTIR DE LA MAQUINA
 FROM MACHINE
 A PARTIR DA MACCHINA

○ → N°: 908 288
 △ → N°: 931 479

■ 1er MONTAGE
 1ste MONTAGE
 1ro MONTAJE
 1st MOUNTING
 1mo

□ 2ème MONTAGE
 2te MONTAGE
 2do MONTAJE
 2nd MOUNTING
 2do MONTAGGI




06 / 05 / 14

P.A.O. illus

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	296465	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
2	297124	Pipe	1		MT 1440 A ST3B, MT 1840 A ST3B
3	296467	clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
4	308847	Filter bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
5	273225	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
6	273170	washer	4		MT 1440 A ST3B, MT 1840 A ST3B
7	286994	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
8	273112	screw	4		MT 1440 A ST3B, MT 1840 A ST3B
9	29437	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
10	55714	Nut	4		MT 1440 A ST3B, MT 1840 A ST3B
11	299703	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
12	301643	Pipe	1		MT 1440 A ST3B, MT 1840 A ST3B
13	300927	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
14	299298	spacer	1		MT 1440 A ST3B, MT 1840 A ST3B
15	259601	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
16	300085	Exhaust pipe	1		MT 1440 A ST3B, MT 1840 A ST3B
17	259601	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
18	253534	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
19	295838	Exhaust particulate filter	1		MT 1440 A ST3B, MT 1840 A ST3B
20	295860	Sensor	1		MT 1440 A ST3B, MT 1840 A ST3B
21	267870	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
22	29469	washer	1		MT 1440 A ST3B, MT 1840 A ST3B
23	162229	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
24	479218	Clamp	2	A4148547A, A005001, 479215, 820100	MT 1440 A ST3B, MT 1840 A ST3B
25	296696	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
26	296512	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
27	296697	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
28	296509	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
29	305261	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
30	305262	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
31	227352	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
32	306969	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
33	310876	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
34	308420	Half-clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
35	168494	Protection plate	1		MT 1440 A ST3B, MT 1840 A ST3B
36	58530	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
37	308770	Spacer	1		MT 1440 A ST3B, MT 1840 A ST3B
38	308766	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
39	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
40	306353	Exhaust particulate filter	1		MT 1440 A ST3B, MT 1840 A ST3B

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
41	227352	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
42	183036	Hydraulic hose	1	193953, 260468	MT 1440 A ST3B, MT 1840 A ST3B
43	308599	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
44	272321	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
45	305262	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
46	308827	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B

_COOLING SYSTEM




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	300728	Complete radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
2	300742	Radiator bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
3	279238	guard	1		MT 1440 A ST3B, MT 1840 A ST3B
4	259710	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
5	259986	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
6	275826	Rubber	4		MT 1440 A ST3B, MT 1840 A ST3B
7	271523	Spacer	2		MT 1440 A ST3B, MT 1840 A ST3B
8	275827	Bushing	2		MT 1440 A ST3B, MT 1840 A ST3B
9	271524	Fastening plate	2		MT 1440 A ST3B, MT 1840 A ST3B
10	207524	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
11	259986	Nut	1		MT 1440 A ST3B, MT 1840 A ST3B
12	259893	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
13	52509104	Grid	1	300762	MT 1440 A ST3B, MT 1840 A ST3B
14	266728	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
15	206056	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
16	305612	Complete radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
17	306301	Radiator bracket	1		MT 1440 A ST3B, MT 1840 A ST3B

4 AA 1209

ADAPTATION MOTEUR-TRANSMISSION
MOTOR-GETRIEBE ANPASSUNG
ADAPTACION MOTOR-TRANSMISION
ENGINE-TRANSMISSION ADAPTATION
ADATTAMENTO MOTORE - TRASMISSIONE


MT 1440 A ST3B
MT 1840 A ST3B



30 / 11 / 11
P.A.O. illus


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	195728	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
2	300777	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
3	232027	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
4	232027	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
5	294624	sleeve	1		MT 1440 A ST3B, MT 1840 A ST3B
6	300763	Tube	1		MT 1440 A ST3B, MT 1840 A ST3B
7	259946	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
8	195716	Clamp	1	505215, 189538, 448041, 503629, 230816, 63216	MT 1440 A ST3B, MT 1840 A ST3B
9	300774	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
10	232025	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B

_COOLING SYSTEM



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	232027	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
2	300791	Outlet hose	1		MT 1440 A ST3B, MT 1840 A ST3B
3	204170	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
4	195475	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
5	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
6	273818	Complete expansion chamber	1		MT 1440 A ST3B, MT 1840 A ST3B
7	313641	feeler	1		MT 1440 A ST3B, MT 1840 A ST3B
8	212298	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
9	228805	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
10	300880	Expansion chamber bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
11	268255	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
12	278893	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
13	274885	Shock absorber	4		MT 1440 A ST3B, MT 1840 A ST3B
14	291731	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
15	54242	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
16	272321	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
17	296779	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
18	272321	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
19	294680	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
20	282013	Fuel jet	1		MT 1440 A ST3B, MT 1840 A ST3B
21	26609	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
22	300781	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
23	232027	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
24	232025	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
25	88246	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
26	259601	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B

_COOLING SYSTEM




08 / 12 / 11

P.A.O. illus


Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	300728	Complete radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
2	797247	Radiator nozzle	1		MT 1440 A ST3B, MT 1840 A ST3B
3	797505	Weatherstrip	1		MT 1440 A ST3B, MT 1840 A ST3B
4	797213	Weatherstrip	1		MT 1440 A ST3B, MT 1840 A ST3B
5	748427	Weatherstrip	7		MT 1440 A ST3B, MT 1840 A ST3B
6	797204	Radiator (water)	1		MT 1440 A ST3B, MT 1840 A ST3B
7	748479	Drain plug	1		MT 1440 A ST3B, MT 1840 A ST3B
8	797254	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
9	795079	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
10	748421	Radiator (oil)	1		MT 1440 A ST3B, MT 1840 A ST3B
11	797255	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
12	750386	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
13	797210	Spacer	4		MT 1440 A ST3B, MT 1840 A ST3B
14	797209	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
15	797208	Washer	8		MT 1440 A ST3B, MT 1840 A ST3B
16	797211	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
17	748422	Radiator (oil)	1		MT 1440 A ST3B, MT 1840 A ST3B
18	748423	Radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
19	750386	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
20	797207	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
21	797212	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
22	797205	Radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
23	795079	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
24	797206	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
25	797211	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B

_COOLING SYSTEM



Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	305612	Complete radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
2	797247	Radiator nozzle	1		MT 1440 A ST3B, MT 1840 A ST3B
3	797505	Weatherstrip	1		MT 1440 A ST3B, MT 1840 A ST3B
4	797213	Weatherstrip	1		MT 1440 A ST3B, MT 1840 A ST3B
5	748427	Weatherstrip	7		MT 1440 A ST3B, MT 1840 A ST3B
6	797204	Radiator (water)	1		MT 1440 A ST3B, MT 1840 A ST3B
7	748479	Drain plug	1		MT 1440 A ST3B, MT 1840 A ST3B
8	797254	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
9	795079	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
10	748421	Radiator (oil)	1		MT 1440 A ST3B, MT 1840 A ST3B
11	941042	Plug	1		MT 1440 A ST3B, MT 1840 A ST3B
12	750386	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
13	797210	Spacer	4		MT 1440 A ST3B, MT 1840 A ST3B
14	797209	Washer	4		MT 1440 A ST3B, MT 1840 A ST3B
15	797208	Washer	8		MT 1440 A ST3B, MT 1840 A ST3B
16	750386	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
17	748422	Radiator (oil)	1		MT 1440 A ST3B, MT 1840 A ST3B
18	748423	Radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
19	750386	Screw	4		MT 1440 A ST3B, MT 1840 A ST3B
20	797207	Fastening lug	1		MT 1440 A ST3B, MT 1840 A ST3B
21	750386	Screw	3		MT 1440 A ST3B, MT 1840 A ST3B
22	797205	Radiator	1		MT 1440 A ST3B, MT 1840 A ST3B
23	795079	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
24	797206	Bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
25	750386	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
26	941041	Radiator bracket	1		MT 1440 A ST3B, MT 1840 A ST3B

_COOLING SYSTEM




Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	232027	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
2	300791	Outlet hose	1		MT 1440 A ST3B, MT 1840 A ST3B
3	204170	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
4	195475	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
5	259601	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
6	312541	tank	1		MT 1440 A ST3B, MT 1840 A ST3B
7	313641	feeler	1		MT 1440 A ST3B, MT 1840 A ST3B
8	212298	"O" ring	1		MT 1440 A ST3B, MT 1840 A ST3B
9	302028	Filling plug	1		MT 1440 A ST3B, MT 1840 A ST3B
10	300880	Expansion chamber bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
11	268255	screw	2		MT 1440 A ST3B, MT 1840 A ST3B
12	278893	Screw	2		MT 1440 A ST3B, MT 1840 A ST3B
13	274885	Shock absorber	4		MT 1440 A ST3B, MT 1840 A ST3B
14	291731	Fastening plate	1		MT 1440 A ST3B, MT 1840 A ST3B
15	54242	Nut	2		MT 1440 A ST3B, MT 1840 A ST3B
16	272321	Clamp	3		MT 1440 A ST3B, MT 1840 A ST3B
17	296779	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
18	272321	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
19	294680	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
20	282013	Fuel jet	1		MT 1440 A ST3B, MT 1840 A ST3B
21	204170	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
22	305611	Inlet outside	1		MT 1440 A ST3B, MT 1840 A ST3B
23	232027	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
24	232025	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
25	88246	Clamp	2		MT 1440 A ST3B, MT 1840 A ST3B
26	268255	screw	1		MT 1440 A ST3B, MT 1840 A ST3B
27	60698	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
28	58528	nut	1		MT 1440 A ST3B, MT 1840 A ST3B
29	279184	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
30	274120	Clamp	1		MT 1440 A ST3B, MT 1840 A ST3B
31	306355	Connector	1		MT 1440 A ST3B, MT 1840 A ST3B
32	63546	Screw	1		MT 1440 A ST3B, MT 1840 A ST3B
33	61678	Washer	1		MT 1440 A ST3B, MT 1840 A ST3B
34	305610	Clamp bracket	1		MT 1440 A ST3B, MT 1840 A ST3B
35	213394	Cable grommet	1		MT 1440 A ST3B, MT 1840 A ST3B
36	312541	tank	1		MT 1440 A ST3B, MT 1840 A ST3B
37	271525	Hose	1		MT 1440 A ST3B, MT 1840 A ST3B
38	313641	feeler	1		MT 1440 A ST3B, MT 1840 A ST3B
39	798775	o-ring	1		MT 1440 A ST3B, MT 1840 A ST3B
40	302028	Filling plug	1		MT 1440 A ST3B, MT 1840 A ST3B

8 AA 360

JUSQU'À LA MACHINE
BIS DER MASCHINE
HASTA LA MACQUINA
UP TO MACHINE
FINO LA MACCHINA
—S.N°: 911 407

SIEGE
SITZ
ASIENTO
SEAT
SEDILE

MT 1335 HA ST3B



08 / 04 / 05
P.A.O. Italia

Позиция	№ детали	Название	К-во	SupersededPartNumber	Product Type
1	252468	Complete seat	1		MT 1440 A ST3B, MT 1840 A ST3B
2	564011	Backrest	1		MT 1440 A ST3B, MT 1840 A ST3B
3	564012	Seat	1		MT 1440 A ST3B, MT 1840 A ST3B
4	705886	Channel with drive	1		MT 1440 A ST3B, MT 1840 A ST3B
5	564014	Handle	1		MT 1440 A ST3B, MT 1840 A ST3B
6	705887	Handle	1		MT 1440 A ST3B, MT 1840 A ST3B
7	705888	Backrest extension	1		MT 1440 A ST3B, MT 1840 A ST3B
8	705889	Housing	1		MT 1440 A ST3B, MT 1840 A ST3B
9	564018	L.H. handle	1		MT 1440 A ST3B, MT 1840 A ST3B
10	564019	R.H. handle	1		MT 1440 A ST3B, MT 1840 A ST3B
11	705890	Seat belt	1		MT 1440 A ST3B, MT 1840 A ST3B
12	564021	belt	1		MT 1440 A ST3B, MT 1840 A ST3B
13	564022	spring	1		MT 1440 A ST3B, MT 1840 A ST3B
14	564023	cover	1		MT 1440 A ST3B, MT 1840 A ST3B
15	603856	Complete handle	1	564024	MT 1440 A ST3B, MT 1840 A ST3B
16	564025	spring	2		MT 1440 A ST3B, MT 1840 A ST3B
17	564026	damper	1		MT 1440 A ST3B, MT 1840 A ST3B
18	564027	suspensor	1		MT 1440 A ST3B, MT 1840 A ST3B
19	564028	flexible dust cover	1		MT 1440 A ST3B, MT 1840 A ST3B
20	604457	junction	1		MT 1440 A ST3B, MT 1840 A ST3B
21	705891	Switch	1		MT 1440 A ST3B, MT 1840 A ST3B

