

TOYOTA INDUSTRIAL VEHICLE

PARTS CATALOG

02-2FG28,30

No.G104-2

**TOYOTA MOTOR CORPORATION
TOYODA AUTOMATIC LOOM WORKS, LTD.**

TOYOTA

FORKLIFT TRUCK

PARTS CATALOG

MODEL	2 F G
FRAME NO.	2 F G 3 0
ENGINE NO.	5 P
LIFTING HEIGHT	mm

DESCRIPTION

LPG Convertible Type
LPG Exclusive Type
Upswept Exhaust
Catalytic Muffler
Cyclone Air Cleaner Single Element

Cyclone Air Cleaner Dual Element
UL-approved Model Type GS
Oil Clutch
Fully Oil Charged Lift Cylinder

TOYOTA MOTOR CORPORATION
TOYODA AUTOMATIC LOOM WORKS, LTD.

QUICK REFERENCE INDEX

INTRODUCTION

ENGINE

FUEL SYSTEM

CHASSIS

BODY

ELECTRICAL SYSTEM

MAST

HYDRAULIC SYSTEM

G104-1 5P MTM
G104-2 5P ATM

GENERAL INFORMATION

This parts catalog has been prepared for the customers of Toyota Industrial Vehicles and this shows only the part name codes instead of parts numbers.

When ordering parts from your local Toyota dealer, please specify the complete model number of the truck, the engine number or frame number. Also it is essential that you specify the part name codes described in the pages of Illustrations and text.

The complete model number and frame number are shown in the front page of this catalog. All the columns in this quick reference index are supposed to be filled out by both the factory and your local dealer.

For the industrial vehicle with optional equipment, which is described in the lower part of the DESCRIPTION, it is imperative for you to specify optional equipment when ordering parts.

Your Toyota dealer has always been furnished with enough information to decode the correct part numbers based on your information of model number, engine number or frame number as well as part name code.

INFORMATIONS D'ORDRE GENERAL

Ce catalogue de pièces a été préparé pour les propriétaires de Véhicules Industriels Toyota. On n'y trouvera que les codes de désignation de pièces au lieu des numéros de pièces.

Pour la commande de pièces auprès de votre concessionnaire Toyota, prière de spécifier le numéro de modèle complet de l'engin, le numéro du moteur ou le numéro du châssis. Il est aussi nécessaire de spécifier les codes de désignation de pièces comme ils sont décrits dans les pages d'illustrations et dans le texte.

Le numéro de modèle complet et le numéro de châssis sont indiqués en première page de ce catalogue. Toutes les colonnes de l'index de référence rapide devraient être remplies par l'usine et par votre concessionnaire.

Pour le véhicule industriel avec équipement optionnel, décrit en bas de page sous la rubrique "DESCRIPTION", il convient de bien spécifier qu'il s'agit de cet équipement lors de commande de pièces.

Votre concessionnaire Toyota est toujours suffisamment informé pour décoder les numéros de pièces sur la base de votre information du numéro de modèle, du numéro de moteur ou de châssis, et des codes de désignation de pièces.

INFORMACION GENERAL

Este catálogo de piezas ha sido preparado para los clientes de vehículos industriales de TOYOTA, e incluye tan sólo los códigos de nombre de pieza en lugar de los números de pieza.

Cuando solicite piezas a su distribuidor local de TOYOTA especifique por favor el número de modelo completo del vehículo, el número de motor o el número de bastidor. Asimismo, es esencial que Vd. especifique los códigos de nombre de pieza descritos en las páginas de ilustraciones y de texto.

El número completo de modelo y el número de bastidor se indican en la portada de este catálogo. Se supone que todas las columnas de este índice de referencia se han rellenado, tanto por parte de la fábrica como por parte de su distribuidor local.

En lo que concierne a los vehículos industriales con equipos opcionales, que se describen en la parte baja de la DESCRIPCION, es absolutamente necesario que especifique equipos opcionales cuando solicite piezas de repuesto.

Su distribuidor local de TOYOTA posee la información necesaria para descifrar los números correctos de cada pieza a base de su información de número de modelo, número de motor o número de bastidor, así como el código de nombre de la pieza.

ALLGEMEINE INFORMATION

Dieser Teilekatalog wurde für die Benutzer von Toyota Industriefahrzeugen zusammengestellt und zeigt anstelle von Teilenummern nur die Teilennamen-Kodes.

Geben Sie bei Teilebestellungen von Ihrem Toyota-Händler am Platz bitte die vollständige Modellnummer des Fahrzeugs, die Motornummer oder Fahrgestellnummer an. Es ist auch erforderlich, daß Sie die in den Illustrationen und im Text beschriebenen Teilennamen-Kodes angeben.


Die vollständige Modellnummer und Fahrgestellnummer finden Sie auf der Vorderseite dieses Katalogs. Alle Spalten in dieser Bezugstabelle sollen sowohl vom Werk als von Ihrem Händler am Platz ausgefüllt werden.

Für Industriefahrzeuge mit Sonderausrüstung, welche im unteren Teil der BESCHREIBUNG erläutert ist, müssen Sie bei der Bestellung von Teilen unbedingt diesbezügliche Angaben machen.

Ihr Toyota-Händler verfügt stets über genügend Information, um die richtigen Teilenummern zu entschlüsseln, basiert auf Ihren Angaben zu Modellnummer, Motornummer oder Fahrgestellnummer und den Teilennamen-Kodes.

ILLUSTRATION AND PART NAME CODE TEXT PAGE COMPOSITION

Essentially, one (1) page will present both the illustration and part name code. However, when the space for text page is not enough the next page will be used in succession.



- 1 Figure number
This parts catalog has been prepared according to the figure numbers.
- 2 Figure title
A representative part name which is the major assembly part name is shown as the figure title of the illustration.
- 3 Sub title
The optional name or special specification of each illustration are indicated.
- 4 Part name code
This is a combination of figure number and codes of illustrations pertaining to each part. This is a key for your Toyota Dealer to find the correct part numbers.
- 5 Part name
As a rule, the part name is indicated for each of the part name codes.
- 6 QTY (Quantity)
The quantity column indicates the utilized pieces of part name code unit. When the utilized quantity changes according to each of the vehicles, maximum is indicated.
When the utilized quantity of the parts differs or is more than 100 pieces, quantity 99 is indicated.
- 7 Standard parts numbers
The standard parts such as the bolts, nuts, washer, etc. are described with parts numbers. When ordering these parts, specify parts numbers.

COMPOSICION DE LAS PAGINAS DE ILUSTRACIONES Y DE TEXTO DE CODIGOS DE NOMBRE DE PIEZAS


Básicamente, una (1) página incluirá tanto la ilustración como el código de nombre de la pieza.

No obstante, si el espacio no fuese suficiente, se utilizará la página siguiente.

- 1 Número de figura
Este catálogo de piezas se ha preparado de acuerdo con los números de las figuras.
- 2 Título de las figuras
Como título de las figuras de la página de ilustraciones, se incluye un nombre que sea representativo del nombre del mayor conjunto.
- 3 Subtítulo
Se indican el nombre opcional o las especificaciones especiales de cada ilustración.
- 4 Código de nombre de pieza
Se trata de una combinación de número de figura y de código de las ilustraciones correspondientes a cada pieza. Esta es la clave para que su distribuidor local de TOYOTA pueda encontrar el número de pieza correcto.
- 5 Nombre de la pieza
Como norma, se indica el nombre de cada uno de los códigos de nombre de pieza.
- 6 QTY (Cantidad)
La columna de cantidad indica el número de piezas utilizadas de cada unidad de código de nombre de pieza.
Cuando la cantidad utilizada es intercambiable entre cada uno de los vehículos, se indica el máximo.
Cuando la cantidad de piezas utilizadas pueda diferir o ser superior a 100, se indica como cantidad 99.
- 7 Números de piezas normalizadas
Las piezas corrientes, tales como pernos, tuercas, arandelas etc., se describen con número de pieza. Cuando solicite tales piezas, indique su número de pieza.

ILLUSTRATION ET COMPOSITION DU DE TEXTE DE CODE DE DESIGNATION DE PIECE

Une (1) page contiendra essentiellement une illustration et ses codes de désignation de pièce. Toutefois, lorsque l'espace réservé au texte est insuffisant, la continuation se trouvera sur la page suivante.



- **Numéro de figure**
Ce catalogue de pièces a été préparé en fonction des numéros de figures.
- **Titre de figure**
Une désignation de pièce représentative, celle d'une pièce d'un ensemble important, est indiquée comme titre de figure de l'illustration.
- **Sous-titre**
La désignation optionnelle ou les spécifications spéciales de chaque illustration sont indiquées.
- **Code de désignation de pièce**
Obtenu en combinant le numéro de figure et les codes des illustrations inhérents à chaque pièce. Ce code permettra à votre concessionnaire Toyota de trouver les numéros de pièces corrects.
- **Désignation de pièce**
La désignation de la pièce est indiquée pour chacun des codes de désignation de pièce.
- **Q'ty (quantité)**
La colonne quantité indique les pièces utilisées de l'unité de code de désignation de pièce. La quantité maximum est indiquée quand la quantité utilisée diffère pour chacun des véhicules. Quand la quantité de pièces utilisées diffère ou lorsqu'elle dépasse 100 pièces, la quantité 99 est indiquée.
- **Numéros de pièces standard**
Les pièces standard comme les boulons, les écrous, les rondelles, etc. sont décrits dans les numéros de pièces. Pour commander ces pièces, prière de spécifier les numéros de pièces.

ABBILDUNG UND TEXTSEITENAUFBAU FÜR TEILENAMEN-KODE

Grundsätzlich finden Sie auf einer (1) Seite sowohl die Abbildung als auch den Teilnamen-Kode.

Wenn für den Text jedoch nicht genügend Platz vorhanden ist, wird er auf der nächsten Seite fortgesetzt.

- **Abbildungsnummer**
Dieser Teilekatalog wurde nach Abbildungsnummern zusammengestellt.
- **Abbildungstitel**
Ein stellvertretender Teilname, welcher zugleich die Bezeichnung für die Hauptbaugruppe ist, wird als Abbildungstitel der Illustration angegeben.
- **Untertitel**
Ein zusätzlicher Name oder eine besondere Kennzeichnung werden für jede Illustration angegeben.
- **Teilnamen-Kode**
Dies ist eine Kombination von ziffern und Abbildungskodes, die jedes Teil betreffen. Es ist ein Schlüssel für Ihren Toyota-Händler, um die richtigen Teilenummern zu finden.
- **Teilname**
Grundsätzlich wird der Teilname für alle Teilnamen-Kodes angegeben.
- **QTY (Menge)**
Die Mengenspalte gibt die benutzte Stückzahl von Teilnamen-Kode-Einheiten an. Wenn die benutzte Stückzahl je nach Fahrzeug Verschieden ist, wird die Höchstmenge angegeben. Wenn die benutzte Menge 100 Stück überschreiten kann, wird als Menge 99 angegeben.
- **Standardteile-Nummern**
Die Standardteile, wie Schrauben, Muttern, Unterlegscheiben usw., sind in den Teilenummern beschrieben. Geben Sie bei Bestellung dieser Teile die Teilenummern an.

DATA PLATE & SERIAL NUMBERS

For retrieving correct part numbers, it's indispensable to know the truck model, as well as frame number (or engine number). Customers can obtain said information in the data plate on the truck or in this user parts catalog.


PLAQUE DE DONNEES TECHNIQUES & NUMEROS DE SERIE

Pour relever correctement le numéro des pièces, il est indispensable de connaître le modèle de l'engin, ainsi que le numéro du châssis (ou du moteur). Les propriétaires peuvent trouver ladite information sur la plaque de données techniques de l'engin ou dans le présent ouvrage.

Data plate
Placa de datos
Plaque de données techniques
Datenplatte

 TOYOTA LIFT TRUCK	
MODEL	
CODE NO OF SPECIAL MODEL, MODEL OF ATTACHMENT	
FRAME NO	
LIFTING HEIGHT	
CAPACITY	
WEIGHT	
PROD. YEAR	
TOYODA AUTOMATIC LOOM WORKS, LTD. KARIYA, JAPAN	

Data plate
Placa de datos
Plaque de données techniques
Datenplatte



Engine Number (Top of the cylinder head)	Numéro de moteur (sur la culasse)
Número de motor (Parte superior de la culata)	Motornummer (Oben am Zylinderkopf)
Frame Number (Top of the frame)	Numéro de châssis (haut du châssis)
Número de bastidor (Parte superior del bastidor)	Fahrgestellnummer (Oben am Fahrgestell)

PLACA DE DATOS Y NUMEROS DE SERIE

Para obtener los números de pieza correctos, es indispensable conocer el modelo del vehículo, así como el número del bastidor (o del motor). Los clientes pueden obtener dicha información por la placa de datos del vehículo o este catálogo de piezas para el usuario.

DATENPLATTE & SERIENNUMMERN

Um die richtige Teilenummer zu ermitteln, müssen unbedingt das Fahrzeugmodell sowie die Fahrgestellnummer (oder die Motornummer) bekannt sein. Kunden können diese Angaben von der Datenplatte am Fahrzeug oder in diesem Teilekatalog für Benutzer entnehmen.

FIG. INDEX








FIG. 1101  エンジン アッセンブリ Engine Assembly	FIG. 1101  ショート ブロック アッセンブリ Short Block Assembly	FIG. 1101  オーバーホール ガasket キット Overhaul Gasket Kit	FIG. 1104  シリンダ ヘッド Cylinder Head	FIG. 1105  シリンダ ブロック Cylinder Block	FIG. 1108  ギヤ カバート エンド プレート Gear Cover & End Plate	FIG. 1107  マウンティング Mounting
エンジン グループ ENGINE GROUP (1/2)						
						
FIG. 1703  エア クリーナー Air Cleaner	FIG. 1702  エキゾースト パイプ Exhaust Pipe	FIG. 1701  マニホールド Manifold	FIG. 1802  ラジエーター ファン Radiator & Fan	FIG. 1801  ウォーター ポンプ Water Pump	FIG. 1803  オイル クーラー Oil Cooler	FIG. 1802  オイル フィルター Oil Filter

FIG. INDEX

FIG.1901



イグニッション コイル & コード
Ignition Coil & Cord

FIG.1902




ディストリビューター
Distributor

FIG.1903



オルタネーター
Alternator

FIG.1904




スターター
Starter

FIG.2101



フューエルパイプ
Fuel Pipe

FIG.2103



キャブレター
Carburetor

エンジン、フューエル グループ ENGINE, FUEL GROUP (2/2)




FIG.2106



メカニカル ギバ
Mechanical Governor

FIG.2201




インジェクション ノズル
Injection Nozzle

FIG.2202



インジェクション ポンプ アセンブリ
Injection Pump Assembly

FIG.2203



インジェクション ポンプ ボディ
Injection Pump Body

FIG.2606




ベンチュリ
Venturi

FIG.2601



アクセル リンク
Accelerator Link

FIG.2303



フューエル タンク
Fuel Tank

FIG.2302




フューエル フィルター
Fuel Filter

FIG.2301



フューエル ポンプ
Fuel Pump

FIG.2215




ブースト コンペンセイター
Boost Compensator

FIG.2207



オートマチック タイマー
Automatic Timer

FIG.2206



フューエル フィード ポンプ
Fuel Feed Pump

FIG.2204



プニーマチック ギバ
Pneumatic Governor

FIG. INDEX



FIG. 2311  LPG フューエル パイプ LPG Fuel Pipe	FIG. 2312  LPG キャブレタ LPG Carburetor	FIG. 2314  LPG レギュレータ LPG Regulator	FIG. 2315  LPG フィルタ LPG Filter	FIG. 2318  LPG コンテナ LPG Container		
	LPG グループ LPG GROUP					



FIG. INDEX













FIG. 3101 (MTM) 1  クラッチ Clutch	FIG. 3107 (MTM) 2  クラッチペダル Clutch Pedal	FIG. 3105 3  クラッチブースター Clutch Booster	FIG. 3106 4  フローディバイディングバルブ Flow Dividing Valve	FIG. 3201 (ATM) 5  トルクコンバータハウジング Torqueconverter Housing	FIG. 3201 (ATM) 6  オーバーホールキット Overhaul Kit	FIG. 3202 (ATM) 7  トルクコンバータ Torqueconverter
シャングループ CHASSIS GROUP (1/2) 						FIG. 3203 (ATM) 8  トルクコンバータクラッチ Torqueconverter Clutch
FIG. 4403 21  リアホイール Rear Wheel						FIG. 3204 (ATM) 9  トルクコンバータギヤ Torqueconverter Gear
FIG. 4402 (Double) 28  フロントホイール Front Wheel						FIG. 3206 (ATM) 10  コントロールバルブ Control Valve
FIG. 4401 (Single) 19  フロントホイール Front Wheel						FIG. 3213 (ATM) 11  トルクコンバータパイピング Torqueconverter Piping
FIG. 4301 18  リアアクスル Rear Axle	FIG. 4201 17  フロントアクスルシャフト Front Axle Shaft	FIG. 4101 16  ディファレンシャル Differential	FIG. 3303 (MTM) 15  ギヤシフトフォーク Gear Shift Fork	FIG. 3302 (MTM) 14  トランスミッションギヤ Transmission Gear	FIG. 3301 (MTM) 13  トランスミッションケース Transmission Case	FIG. 3214 (ATM) 12  コントロールシャフト Control Shaft

FIG. INDEX





FIG. 4501  ステアリング ホイール Steering Wheel	FIG. 4502  ステアリング ポスト Steering Post	FIG. 4503  ハイドロスタティック バルブ Hydrostatic Valve	FIG. 4507  ドラッグ リンク トーピング Drag Link & Piping	FIG. 4508  パワー シリンダ Power Cylinder	FIG. 4601  パーキング ブレーキ Parking Brake	FIG. 4701  ブレーキ ペダル Brake Pedal
シャシ グループ CHASSIS GROUP (2/2) 						
						FIG. 4704  ブレーキ バルブ Brake Valve
						FIG. 4706  ブレーキ アクкумуляター Brake Accumulator
						FIG. 4708  アクкумуляター ポンプ Accumulator Pump
						FIG. 4714  ブレーキ パイプ Brake Pipe
						FIG. 4715  ブレーキ Brake

FIG. INDEX









FIG. 5101 1  フレーム・ウエイト Frame & Weight	FIG. 5201 2  フード Hood	FIG. 5301 3  インストルメントパネル Instrument Panel	FIG. 5308 4  ドライバースeat Driver Seat	FIG. 5401 5  ヘッドガード・アクセサリ Head Guard & Accessory	FIG. 5405 6  インジケータプレート Indicator Plate	FIG. 5501 7  スチールキャビン Steel Cabin	
ボデー エレクトリカル グループ BODY, ELECTRICAL GROUP 							FIG. 5502 8  フロントガラス Front Glass
							FIG. 5504 9  ドアロック Door Lock
							FIG. 5801 10  ワイヤリング Wiring
							FIG. 5611 11  ランプ Lamp
FIG. 5806 12  OK モニタ OK Monitor	FIG. 5805 13  デフロスタ Defroster	FIG. 5802 14  ヒーター Heater	FIG. 5801 15  ワイパーモーター・ブレード Wiper Motor & Blade	FIG. 5706 16  スピードメータ Speedometer	FIG. 5701 17  メータ・スイッチ Meter & Switch	FIG. 5612 18  ランプブラケット Lamp Bracket	

FIG. INDEX




マスト
Hant



リフト ブラケット & フォーク
Lift Bracket & Fork




Chain & Chain Wheel



リフト シリンダ
Lift Cylinder



フロント リフト シリンダ
Front Lift Cylinder




リヤ リフト シリンダ
Rear Lift Cylinder




リフト シリンダ
Lift Cylinder


マスト ハイドロリック コンポーネント グループ
MAST, HYDRAULIC COMPONENT GROUP




フロント リフト シリンダ
Front Lift Cylinder




リヤ リフト シリンダ
Rear Lift Cylinder



チルト シリンダ



オイルポンプ
Oil Pump




マストパイピング
Mast Piping




ボデー パイピング
Body Piping



Oil Control Valve Link



オイル コントロール ハルフ
Oil Control Valve



オイル ポンプ ドライブ シャフト
Oil Pump Drive Shaft

MEMO

silverhorn.co.uk



FIG. 0901
STANDARD TOOL

0901

5P

85/01

5P




0901 007

PART NAME CODE	PART NAME	QTY
0901-01	TOOL SET, STANDARD	1
0901-10	SPANNER SET	1
0901-11	PUMP ASSY, GREASE	1
0901-40	BAG, TOOL	1
0901-41	PLIERS	1
0901-42	DRIVER, SCREW	1
0901-43	WRENCH, MONKEY	1
0901-47	WRENCH, HUB NUT BOX	1
0901-48	WRENCH, SPARK PLUG	1


5P

00



1101 003

5P



SP




FIG. 1101
ENGINE ASSY


1101

5P


85/06

5P

00K



00L



1101 011

PART NAME CODE	PART NAME	QTY
1101-00	ENGINE ASSY	1
1101-00K	GASKET KIT, ENGINE O/H	1
1101-00L	GASKET KIT, ENGINE VALVE GRIND	1
1101-01	ENGINE ASSY, PARTIAL	1
1101-02	BLOCK ASSY, SHORT	1


FIG. 1104
CYLINDER HEAD

1104

5P

85/01

5P



PART NAME	PART NAME	QTY
CODE		
1104-20	HEAD SUB-ASSY, CYLINDER	1
1104-20A	BUSH, VALVE GUIDE INTAKE	4
1104-20B	BUSH, VALVE GUIDE EXHAUST	4
1104-20C	BOLT (FOR CYLINDER HEAD SET)	18
1104-21	COVER SUB-ASSY, CYLINDER HEAD	1
1104-21B	WASHER, SEAL (FOR CYLINDER HEAD COVER)	3
1104-30	CAP SUB-ASSY, OIL FILLER	1
1104-40	GASKET, CYLINDER HEAD	1
1104-41	GASKET, CYLINDER HEAD COVER	1
1104-42	GASKET, CYLINDER HEAD REAR PLATE	1
1104-43A	PLUG, TIGHT, NO.1	6
1104-AA	PLATE, CAUTION	1
1104-AC	DEFLECTOR, NO.1	1
1104-AE	TUBE	4
1104-AF	PLATE, HEAD REAR	1

1104 300


FIG. 1105
CYLINDER BLOCK

1105

5P

85/01

5P



PART NAME CODE	PART NAME	QTY
1105-20	BLOCK SUB-ASSY, CYLINDER	1
1105-21	PAN SUB-ASSY, OIL	1
1105-21A	PLUG (FOR OIL PAN DRAIN)	1
1105-21B	GASKET (FOR OIL PAN DRAIN PLUG)	1
1105-30	GAGE SUB-ASSY, OIL LEVEL	1
1105-40	GASKET, OIL PAN	1
1105-41	GUIDE, OIL LEVEL GAGE	1
1105-43A	PLUG, TIGHT, NO.1	3
1105-43B	PLUG, TIGHT, NO.2	3
1105-43C	PLUG, TIGHT, NO.3	2
1105-44	COVER, VALVE PUSH ROD	1
1105-44A	GASKET, VALVE PUSH ROD COVER	1
1105-AA	SUPPORT, OIL LEVEL GAGE GUIDE	1
1105-AB	PIN, STRAIGHT	1
1105-AC	COCK SUB-ASSY, DRAIN	1
1105-AD	PLUG, DRAIN COCK	1
1105-AE	PIN, STRAIGHT	4
1105-AG	PLUG, W/HEAD TAPER SCREW	5
1105-AH	PIN, RING	10
1105-AI	BOLT	10
1105-AJ	PLUG, STRAIGHT	1
1105-AK	GASKET	1
1105-AD	PLUG	1
1105-AP	GASKET	1

1106

85/01

[illegible]

PART NAME	PART NAME	QTY
CODE		
1106-10	FLANGE ASSY, HYDRAULIC PUMP	1
1106-10B	RING, O, HYDRAULIC PUMP FLANGE	1
1106-20	COVER SUB-ASSY, TIMING GEAR (OR CHAIN)	1
1106-20A	SEAL, OIL (FOR TIMING GEAR COVER)	1
1106-22	HOUSING SUB-ASSY, DISTRIBUTOR	1
1106-22A	GASKET, DISTRIBUTOR HOUSING	1
1106-23	CASE SUB-ASSY, TIMING GEAR	1
1106-41	GASKET, TIMING GEAR (OR CHAIN) COVER	1
1106-42	GASKET, FRONT END PLATE	1
1106-45	GASKET, REAR OIL SEAL RETAINER	1
1106-46	RETAINER, REAR OIL SEAL	1
1106-46A	SEAL, ENGINE REAR OIL	1
1106-48	GEAR, PUMP DRIVE	1
1106-48A	BEARING, PUMP DRIVE GEAR, NO.1	1
1106-48B	BEARING, PUMP DRIVE GEAR, NO.2	1
1106-AA	PIN, STRAIGHT	2
1106-AB	RING, SHAFT SNAP	1
1106-AD	HANGER, ENGINE	1
1106-AE	CLAMP	2
1106-AF	PIN, STRAIGHT	4
1106-AG	ELBOW	1
1106-AH	BOLT, STUD	3



FIG. 1107
MOUNTING

1107


5P

85/06

5P



RADIATOR



1107.001C

PART NAME CODE	PART NAME	QTY
1107-30	SUPPORT SUB-ASSY. ENGINE BRACKET, RH	1
1107-31	SUPPORT SUB-ASSY. ENGINE BRACKET, LH	1
1107-40	BRACKET, ENGINE MOUNTING, FR, RH	1
1107-41	BRACKET, ENGINE MOUNTING, FR, LH	1
1107-43	INSULATOR, ENGINE MOUNTING, FR	2
1107-AA	WASHER, PLATE	2
1107-BF	BOLT, W/WASHER	8

1201

SP


PART NAME |

PART NAME

| QTY

CODE

1201-21	1 VALVE SUB-ASSY, VENTILATION	1
1201-40	HOSE, VENTILATION, NO.1	1
1201-41	HOSE, VENTILATION, NO.2	1
1201-42	HOSE, VENTILATION, NO.3	1
1201-44	HOSE, VENTILATION, NO.4	1
1201-AB	3-WAY	1
1201-AC	CLAMP	1



1701 Q13


FIG. 1301
CRANKSHAFT & PISTON

1301

5P

85/06

5P



PART NAME	PART NAME	QTY
CODE		
1301-20	ROD SUB-ASSY. CONNECTING	4
1301-20A	BUSH. CONNECTING ROD	4
1301-20B	BOLT. CONNECTING ROD	8
1301-20C	NUT. HEXAGON (FOR CONNECTING ROD)	8
1301-21	PISTON SUB-ASSY. W/PIN	4
1301-21A	RING. HOLE SNAP (FOR PISTON PIN)	8
1301-30	BEARING SET. CONNECTING ROD	1
1301-31	BEARING SET. CRANKSHAFT	1
1301-32	RING SET. PISTON	1
1301-34	WASHER SET. CRANKSHAFT THRUST	1
1301-40	CRANKSHAFT	1
1301-41	PULLEY. CRANKSHAFT	1
1301-41A	KEY. CRANKSHAFT (FOR PULLEY SET)	1
1301-42	GEAR OR SPROCKET. CRANKSHAFT TIMING	1
1301-42A	KEY. CRANKSHAFT (FOR TIMING GEAR SET)	1
1301-AC	BOLT	1

1301-001

1302

85/01

[illegible]

1302 307C

1302-60A BOLT (FOR IDLE GEAR THRUST PLATE) 2

1302-AA SCREW 2

1302-AB WASHER, SPRING 2

1302-AC KEY 1

1302-AD BOLT, W/WASHER 1

1302-AE COLLAR 1



1302-AJ SPACER 1

1302-AK PLATE, THRUST 1

1302-AL KEY, WOODRUFF 1

1302-BX BOLT, W/WASHER 2

SP



1501 016

PART NAME CODE	PART NAME	QTY
1501-01	PUMP ASSY, OIL	1
1501-20	STRAINER SUB-ASSY, OIL	1
1501-41	VALVE, OIL PUMP RELIEF	1
1501-42	GEAR, OIL PUMP DRIVE SHAFT	1
1501-43	SHAFT, OIL PUMP	1
1501-44	GEAR, OIL PUMP DRIVE	1
1501-45	GEAR, OIL PUMP DRIVEN	1
1501-46	COVER, OIL PUMP	1
1501-49	SPRING, OIL PUMP RELIEF VALVE	1
1501-AA	PLUG, OIL PUMP RELIEF VALVE	1
1501-AE	PIN, STRAIGHT	1
1501-AF	KEY, OIL PUMP DRIVEN SHAFT	1
1501-AG	RING, SHAFT SNAP	1


FIG. 1502
OIL FILTER

1502

5P

85/01

5P



1502 077

PART NAME

CODE

PART NAME


QTY

1502-20	ELEMENT SUB-ASSY, OIL FILTER	1
1502-40	BRACKET, OIL FILTER	1
1502-41	PIPE, OIL, NO.1	1
1502-42	PIPE, OIL, NO.2	1
1502-45	GASKET, OIL FILTER	1
1502-AA	UNION	2
1502-AL	GASKET	2
1502-AT	BOLT, UNION	1

1601

85/01

PART NAME	PART NAME	QTY
CODE		
14001-01	PUMP ASSY, WATER	1
14001-10	COVER ASSY, WATER PUMP	1
14001-30	SEAL SET, WATER PUMP	1
14001-40	COVER, WATER PUMP	1
14001-61	ROTOR, WATER PUMP	1
14001-61A	BEARING, WATER PUMP, NO.1	1
14001-63	SEAT, WATER PUMP PULLEY	1
14001-64	GASKET, WATER PUMP	1
14001-65	GASKET, WATER PUMP COVER	1
14001-66	PULLEY, FAN	1
14001-AA	BOLT, STUD	6
14001-AC	NUT	6
14001-AD	PLUG, W/HEAD TAPER SCREW	1
14001-AE	UNION	1



1601 015

FIG. 1603
RADIATOR & WATER OUTLET


1603

5P


85/06

5P

5P (LOW NOISE)



1603 026B



1603 117A


RADIATOR & WATER OUTLET

1603

5P

85/06

SP.-ATH (DELUXE CABIN)



PART NAME	PART NAME	QTY
CODE		
1603-01	RADIATOR ASSY	1
1603-01B	PLUG, DRAIN COCK	1
1603-01C	PACKING (FOR RADIATOR DRAIN COCK)	1
1603-10	TANK ASSY, RADIATOR RESERVE	1
1603-11	SCREEN SUB-ASSY, RADIATOR	1
1603-30	CAP SUB-ASSY, RADIATOR	1
1603-40	HOUSING, WATER OUTLET	1
1603-41	FAN	1
1603-41A	BELT, V	1
1603-42	GASKET, WATER OUTLET HOUSING	1
1603-43	OUTLET, WATER	1
1603-43A	THERMOSTAT	1
1603-44	GASKET, WATER OUTLET	1
1603-45	HOSE, WATER BY-PASS	1
1603-45A	CLAMP, HOSE (FOR WATER BY-PASS HOSE)	4
1603-46	HOSE, RADIATOR, INLET	1
1603-46A	CLAMP, HOSE (FOR RADIATOR INLET)	2
1603-47	HOSE, RADIATOR, OUTLET	1
1603-47A	CLAMP, HOSE (FOR RADIATOR OUTLET)	1
1603-48	SHROUD, FAN, NO.1	1
1603-52	SPACER, FAN PULLEY	1
1603-53	PLATE, RUBBER (FOR RADIATOR)	4
1603-54	RUBBER, MOUNTING (FOR RADIATOR)	2
1603-55	BAR, FAN BELT ADJUSTING	1
1603-AA	BRACKET, RESERVE TANK	1
1603-AD	CAP SUB-ASSY	1
1603-AP	BOLT, FAN	4
1603-AV	SPACER, FAN PULLEY	1
1603-BO	BOLT	2
1603-EV	FORM, SIDE, RH	1
1603-EW	FORM, SIDE, LH	1
1603-EX	FORM, UPPER, NO.1	1

1603 115A


FIG. 1701
MANIFOLD

1701

5P

85/01

5P



1701 003C

PART NAME	PART NAME	QTY
CODE		
1701-40	MANIFOLD, INTAKE	1
1701-41	MANIFOLD, EXHAUST	1
1701-44	GASKET, EXHAUST MANIFOLD, NO.1	2
1701-45	GASKET, EXHAUST MANIFOLD, NO.2	1
1701-47	GASKET, INTAKE MANIFOLD, NO.1	2
1701-49	PLATE, WATER STOPPER	1
1701-49A	GASKET, WATER STOPPER PLATE	1
1701-AA	BOLT, STUD	2
1701-AB	INSULATOR, EXHAUST	6
1701-AD	BOLT, STUD	6
1701-AE	NUT	2
1701-AF	BOLT, STUD	2
1701-AH	BOLT, STUD	2
1701-AJ	UNION	1
1701-AK	ELBOW	1
1701-AL	ELBOW	1
1701-AM	BOLT, STUD	2
1701-BX	BOLT	3
1701-CC	NUT	4
1701-CF	WASHER, PLATE	6

FIG. 1702
EXHAUST PIPE & MUFFLER

1702


5P

85/01


5P

5P+ATH (DELUXE CABIN)


(2J, 5P)




(2JT)






(5P, UL-GS)




(2J, 2JT, 5P)




(5P, UL-GS)



(B)



1702-184



1702-184

FIG. 1702
EXHAUST PIPE & MUFFLER

1702


5P

85/01


5P (CATALYTIC)

5P (LOW NOISE)



(2J)




(B)




(2J, B)




(5P, ULCS)




(5P)





(5P, ULCS)



(5P)



1702 158




1702 146

1702


85/01

PART NAME	PART NAME	QTY
CODE		
1702-01	MUFFLER ASSY	1
1702-02	MUFFLER ASSY, CATALYTIC	1
1702-20	PIPE SUB-ASSY, EXHAUST, NO.1	1
1702-22	PIPE SUB-ASSY, TAIL	1
1702-22A	RUBBER, MOUNTING	2
1702-23	PIPE, MUFFLER, MIDDLE	1
1702-40	GASKET, EXHAUST PIPE	1
1702-41	PELLET	1
1702-42	INSULATOR, MUFFLER MOUNTING	1-
1702-AA	NUT, HEXAGON	2
1702-AB	BRACKET, CLAMP	1
1702-AC	BOLT, U	1
1702-AD	WASHER, PLATE	4-
1702-AJ	CLAMP, PIPE	2
1702-AD	BRACKET, TAIL PIPE, UPR	1
1702-AP	BRACKET, TAIL PIPE, LWR	1
1702-BQ	BOLT, W/WASHER	1
1702-CF	INSULATOR	1




1702-0378


5P (CYCLONE SINGLE, CYCLONE DOUBLE) 16-INCH




(2J, 5P)



(2J, 5P)




(2J)




5P (SNORKEL)


(6" DOUBLE)





(2J, 5P)




(2J)




(2JT)



(5P)




(B)




5P (ALL WEATHER)

(6" SINGLE)


02




(8308-) 2J1 (JPSWEPT..EXPORT)




(2, 5P)




(2JT)




(13)




(2J)



(5P)



(B)



1/31 213

{6" SINGLE}




Diagram of a fuel line assembly. The assembly consists of a main curved pipe (47) with two O-rings (47A) at the connection points. A smaller pipe (41) is connected to the main pipe. The assembly is secured with a clamp (91611-40E20) and a nut (94110-40800).

Diagram illustrating the rear suspension assembly components:

- 49: Rear suspension arm
- 47A: Rear suspension arm bush
- 41: Rear suspension arm
- 47: Rear suspension arm bush
- 91811-40820: Rear suspension arm
- 94110-40800: Rear suspension arm

Diagram illustrating the assembly of the front suspension arm (42). The assembly includes a lower control arm (42) and a ball joint (42A). The ball joint is secured with a nut (94110-40600) and a washer (94512-00600). The control arm is secured with a pin (CP) and a bush (BZ). An inset shows the ball joint (42A) and bush (42B) being assembled onto the control arm (42).

Diagram of the front suspension assembly showing the lower control arm and its components. The components are labeled with part numbers and callouts:

- 94110-40800: Upper ball joint
- 94512-00600: Upper ball joint nut
- 92122-40620: Upper ball joint cap
- 91611-40618: Lower ball joint
- 94812-10600: Lower ball joint nut
- 42: Lower control arm
- 42A: Lower control arm bush



FIG-1703
AIR CLEANER

1703

5P

85/01

SP..ATM (DELUXE CABIN)



PART NAME	PART NAME	QTY
CODE		
1703-01	CLEANER ASSY, AIR	1
1703-02	CLEANER ASSY, CYCLONE AIR	1
1703-20A	ELEMENT SUB-ASSY, AIR CLEANER	1
1703-20B	ELEMENT SUB-ASSY, CYCLONE AIR CLEANER	1
1703-20C	ELEMENT SUB-ASSY, CYCLONE AIR CLEANER, INNER	1
1703-20D	ELEMENT SUB-ASSY, CYCLONE AIR CLEANER, OUTER	1
1703-23	CASE SUB-ASSY, AIR CLEANER	1
1703-24	CAP SUB-ASSY, AIR CLEANER	1
1703-26	CUP, DUST	1
1703-26A	GASKET, AIR CLEANER CASE	1
1703-27	WING, CYCLONE	1
1703-27A	GASKET, FILTER ELEMENT	1
1703-41	PIPE, AIR CLEANER	1
1703-42	CONNECTOR, AIR CLEANER	1
1703-42A	GASKET, AIR CLEANER CONNECTOR	1-2
1703-43	HOSE, AIR CLEANER, INLET	1
1703-43A	CLAMP (FOR AIR CLEANER INLET HOSE)	2
1703-44	HOSE, AIR CLEANER, OUTLET NO.1	1
1703-44A	CLAMP (FOR AIR CLEANER OUTLET NO.1 HOSE)	1-2
1703-47	HOSE, AIR CLEANER, OUTLET NO.2	1
1703-48	PIPE, AIR CLEANER (FOR INLET)	1
1703-AB	PLATE, CAUTION	1
1703-AC	BAND SUB-ASSY	1
1703-AD	GUIDE, CLEANER BRACKET	1
1703-AE	LINK, CLEANER, RH	1
1703-AF	LINK, CLEANER, LH	1
1703-AG	SPIN, W/HOLE	4
1703-AH	SUPPORT, CLEANER LINK	1
1703-AI	BAFFLE, SCARP	1
1703-AJ	BOLT & GASKET ASSY	1
1703-AK	CLAMP ASSY	1
1703-AL	INDICATOR	1
1703-AP	BOLT, STUD	2
1703-AU	BRACKET SUB-ASSY, CLEANER	1
1703-AZ	BRACKET SUB-ASSY, STOPPER	1
1703-BI	CAP ASSY	1
1703-BN	BOLT, STUD	1
1703-BO	NUT, WING	1
1703-BP	WASHER, SEAL	1
1703-BQ	BAND	1
1703-BR	BRACKET SUB-ASSY, CLEANER	1
1703-BX	BOLT, WING	2
1703-CN	BRACKET SUB-ASSY, SWING	1
1703-CO	PLATE, LINK	2

1703-189


FIG. 1901
IGNITION CDIL & SPARK PLUG

1901

5P

85/06


5P



PART CODE	PART NAME	QTY
1901-01	BATTERY ASSY	1
1901-20	COIL ASSY, W/IGNITER	1
1901-21	IGNITER ASSY	1
1901-22	RESISTOR ASSY	1
1901-23	DIODE ASSY	1
1901-30	CORD SET, COIL & PLUG, W/RESISTIVE	1
1901-30A	CORD, COIL RESISTIVE	1
1901-30B	CORD, SPARK PLUG RESISTIVE, NO.1	1
1901-30C	CORD, SPARK PLUG RESISTIVE, NO.2	2
1901-30D	CORD, SPARK PLUG RESISTIVE, NO.3	1
1901-31	CABLE SUB-ASSY, BATTERY TO STARTER	1
1901-32	CASE SUB-ASSY, BATTERY	1
1901-41	PLUG, SPARK	4
1901-43	CAP, BATTERY, NO.1	1
1901-49	CABLE, BATTERY EARTH	1
1901-50	STRAP, BOND	1
1901-AB	BOLT	2
1901-AD	BRACKET SUB-ASSY	1
1901-AE	PLATE, CORD CLAMP SUPPORT	1
1901-AF	CLAMP	1
1901-AM	CLAMP	1
1901-BS	CAP, TERMINAL	4
1901-BU	CLAMP	2
1901-DT	CAP, TERMINAL	1
1901-DU	BAND	1

1901 050A

5P



PART NAME	PART NAME	QTY
CODE		
1902-01	DISTRIBUTOR ASSY	1
1902-10	ADVANCER ASSY, VACUUM	1
1902-20	ROTOR SUB-ASSY, DISTRIBUTOR	1
1902-21	SHAFT AND GOVERNOR SUB-ASSY	1
1902-30	CAP SUB-ASSY, DISTRIBUTOR	1
1902-30A	PACKING, DUST PROOF (FOR DISTRIBUTOR CAP)	1
1902-41	CAP, ADJUSTER	1
1902-43	COVER, DUST PROOF	1
1902-44	GEAR, SPIRAL	1
1902-45	WEIGHT, GOVERNOR	2
1902-46	TERMINAL, DISTRIBUTOR	1
1902-47	PLATE, BREAKER	1
1902-49	RING, DISTRIBUTOR HOUSING O	1
1902-50	GENERATOR, SIGNAL	1
1902-AA	SPRING, GOVERNOR, A	1
1902-AB	SPRING, GOVERNOR, B	1
1902-AC	SHAFT & PLATE, GOVERNOR	1
1902-AL	CLAMP, DISTRIBUTOR	1
1902-AN	WASHER	1
1902-AR	CAP	1
1902-AV	PLATE, HOLDER	2
1902-AW	CLAMP SUB-ASSY, CAP	2

1902-0115

1903

85/01

5P (HI-CAPACITY)





FIG. 1903
ALTERNATOR

1903

5P

85/01

5P (UL-GS)



PART NAME	PART NAME	QTY
CODE		
1903-01	ALTERNATOR ASSY	1
1903-02	ROTOR ASSY, ALTERNATOR	1
1903-02A	BEARING (FOR ALTERNATOR ROTOR)	1
1903-03	STATOR ASSY, ALTERNATOR	1
1903-10	HOLDER ASSY, ALTERNATOR BRUSH	1
1903-11	FRAME ASSY, RECTIFIER END	1
1903-12	FRAME ASSY, DRIVE END	1
1903-12A	BEARING (FOR ALTERNATOR DRIVE END FRAME)	1
1903-12B	FELT (FOR ALTERNATOR DRIVE END FRAME)	1
1903-15	RECTIFIER ASSY, W/BRUSH	1
1903-40	PULLEY, ALTERNATOR	1
1903-41	FAN, ALTERNATOR	1
1903-42	COVER, REAR END	1
1903-43	BRUSH, ALTERNATOR	2
1903-44	SPRING, BRUSH	2
1903-45	HOLDER, W/RECTIFIER	1
1903-46	HOLDER, W/RECTIFIER POSITIVE	1
1903-47	HOLDER, W/RECTIFIER NEGATIVE	1
1903-AA	COLLAR, STEEL	1
1903-AB	RING, SPACER	1
1903-AC	RING, SNAP	1
1903-AF	BUSHING	1
1903-AQ	FRAME, RECTIFIER END	1
1903-AI	SLIPRING SUB-ASSY	1

1903-002

PART NAME CODE	PART NAME	QTY
1904-01	STARTER ASSY	1
1904-01A	GASKET (FOR STARTER HOUSING)	1
1904-02	ARMATURE ASSY, STARTER	1
1904-02A	BEARING, ARMATURE, NO.1	1
1904-02B	BEARING, ARMATURE, NO.2	1
1904-03	YOE ASSY, STARTER	1
1904-04	HOUSING ASSY, STARTER DRIVE	1
1904-05	FRAME ASSY, COMMUTATOR END	1
1904-06	SWITCH ASSY, MAGNET	1
1904-06A	PACKING, RUBBER (FOR STARTER YOKE)	2
1904-06B	PACKING (FOR MAGNET SWITCH END COVER)	1
1904-10	HOLDER ASSY, STARTER BRUSH	1
1904-20	CLUTCH SUB-ASSY, STARTER	1
1904-20A	RING, O (FOR STARTER CLUTCH)	1
1904-21	PINION SUB-ASSY, STARTER	1
1904-22	CHIP SUB-ASSY, CONTACT	1
1904-40	BRUSH, STARTER	1
1904-42	ROLLER, STARTER IDLE GEAR CLUTCH	5
1904-43	RETAINER, STARTER IDLE GEAR	1
1904-44	GEAR, STARTER IDLE	1
1904-45	SPRING, STARTER BRUSH	4
1904-47	SPRING, STARTER MAGNET SWITCH RETURN	1
1904-50	GEAR, STARTER PINION	1
1904-AD	WIRE, LEAD	1
1904-AE	BOLT	2
1904-AH	PLUNGER SUB-ASSY, CONTACTOR	1
1904-AV	SCREW, W/WASHER	2
1904-AW	RING, O	2
1904-CZ	BOLT, STUD	2
1904-DK	SCREW, W/RING, O	2


FIG. 2101
FUEL PIPE

2101

5P

85/01

5P




PART NAME CODE	PART NAME	QTY
2101-20	PIPE SUB-ASSY. CARBURETOR FUEL	1
2101-21	PIPE SUB-ASSY. FILTER TO PUMP	1
2101-41	HOSE, DISTRIBUTOR VACUUM	1
2101-AA	CLIP	1

2101 002



5P

5P




01K (INCL. 1)

01L (INCL. 1)



2103-003




2103-004

PART NAME CODE	PART NAME	QTY
2103-01	CARBURETOR ASSY	1
2103-01K	CARBURETOR KIT	1
2103-01L	GASKET KIT, CARBURETOR	1
2103-30	SHAFT SUB-ASSY, CHOKE	1
2103-31	JET SUB-ASSY, SLOW	1
2103-32	FLOAT SUB-ASSY	1
2103-35	STRAINER SUB-ASSY	1
2103-40	HORN, AIR	1
2103-41	LEVER, THROTTLE	1
2103-42	LEVER, 1ST IDLE ADJUSTING	1
2103-43	SCREW, IDLE ADJUSTING	1
2103-44	JET, 1ST MAIN	1
2103-46	SHAFT, 1ST THROTTLE	1
2103-48	ROD, LIFTER	1
2103-49	GASKET, CARBURETOR	1
2103-50	VALVE, CHOKE	1
2103-51	VALVE, THROTTLE	1
2103-AA	SCREW, CHOKE VALVE SET	2
2103-AC	SCREW	3
2103-AD	SPRING, CHOKE VALVE RELIEF	1
2103-AE	RING, SNAP	6
2103-AF	CONNECTOR, 1ST IDLE	1
2103-AG	SCREW, SMALL VENTURI SET	1
2103-AH	GASKET, VENTURI	2
2103-AI	VENTURI, SMALL	1
2103-AJ	SCREW, SET	2
2103-AL	SPRING, THROTTLE BACK	1
2103-AM	SCREW, THROTTLE ADJUSTING	1
2103-AN	SPRING, IDLE ADJUSTING SCREW	1
2103-AD	PLUG, MAIN PASSAGE	1
2103-AP	GASKET, INLET STRAINER	1
2103-AQ	GASKET, AIR HORN	1
2103-AR	VALVE SUB-ASSY, NEEDLE	1
2103-AS	VALVE, POWER	1
2103-AT	SPRING, PUMP DUMPING	1
2103-AU	LINK, PUMP	1
2103-AV	RETAINER, BALL CHECK	1
2103-AW	BALL, STEEL	1
2103-AX	PIN, FLOAT LEVER	1
2103-AY	SHIM, 1ST THROTTLE SHAFT	99
2103-AZ	PLUG, NUT	1
2103-BA	GASKET, PASSAGE PLUG	1
2103-BB	SHIM	2
2103-BC	NUT, THROTTLE LEVER SET	2
2103-BD	WASHER, SPRING	2
2103-BE	COLLAR	1
2103-BF	LEVER	1
2103-BG	SCREW, VALVE SET	1
2103-BH	SPRING, IDLE ADJUSTING	1
2103-BI	CAP, IDLE LIMIT	1
2103-BJ	SUPPORT, BACK SPRING	1
2103-BK	LINK, CONNECTING	1
2103-BL	LEVER	1
2103-BM	SCREW	1
2103-BN	RING, RETAINER	1
2103-BO	LEVER, ACCELERATOR	1
2103-BP	SHIM	1
2103-BQ	SHIM	2
2103-BR	COLLAR	1

2106


85/01

PART NAME	PART NAME	QTY
2106-10	ROD ASSY, GOVERNOR CONNECTING	1
2106-20	CASE SUB-ASSY, GOVERNOR	1
2106-30	COVER SUB-ASSY, FLYWEIGHT	1
2106-40	LEVER, GOVERNOR, NO.1	1
2106-41	LEVER, GOVERNOR, NO.2	1
2106-41A	BUSHING (FOR GOVERNOR LEVER)	2
2106-42	LEVER, FLYWEIGHT	1
2106-43	CASE, FLYWEIGHT	1
2106-44	SHAFT, GOVERNOR	1
2106-44A	SEAL, OIL (FOR GOVERNOR SHAFT)	1
2106-44B	BEARING (FOR GOVERNOR SHAFT)	2
2106-45	GASKET, GOVERNOR	1
2106-46	TENSIONER, SPRING	1
2106-47	BRACKET, SPRING	1
2106-AA	PLATE, FLYWEIGHT	1
2106-AB	BALL	6
2106-AC	GASKET	1
2106-AD	PLUG, W/HEAD STRAIGHT	1
2106-AE	PLUG, EXPANSION	1
2106-AF	SPRING, TORSION	1
2106-AG	SPRING, TENSION	1



2108-001

5P



PART NAME		
CODE	PART NAME	QTY
2301-01	PUMP ASSY, FUEL	1
2301-42	GASKET, FUEL PUMP	2
2301-43	INSULATOR, FUEL PUMP	1
2301-AA	SCREW	5
2301-AB	SPRING, ROCKER ARM	1
2301-AD	PIN, STRAIGHT	1


FIG. 2302
FUEL FILTER

2302

SP

85/01

SP



2302-003

PART NAME CODE	PART NAME	QTY
2302-02	FILTER ASSY, FUEL (ELEMENT NO SERVICE TYPE)	1

2303

85/01

· 821 ·

946:11 01E0:1

AF

5475 41510

AF.

17804 JG3.

• •

12903

—

1.

—

1

1

() 3

CA

91 GS:

天

43

وہ

2307 6' 2

Exploded view diagram of a fuel pump assembly. The diagram shows the following components and their labels:

- Top Left:** A fuel line with a filter and a pump housing.
- Top Right:** A bolt labeled **54511 01E03**, a washer labeled **AF**, and a nut labeled **54515 41B30**. Below them is a label **AE**.
- Middle Left:** A bracket labeled **17004 4503** holding a bolt labeled **42** and a washer labeled **10**.
- Middle Right:** A bracket labeled **17003** holding a bolt labeled **42** and a washer labeled **10**. Below them is a label **AE**.
- Bottom Left:** A bracket labeled **20F** holding a bolt labeled **20A**.
- Bottom Center:** A bracket labeled **10L 65** holding a bolt labeled **10** and a nut labeled **10A**.
- Bottom Right:** A bracket labeled **21** holding a bolt labeled **21A**.

2308 612

5P (CONVERTIBLE)





FIG. 2311
LPG FUEL PIPE

2311

SP

85/06

SP (EXCLUSIVE)



2311-0424


PART NAME CODE	PART NAME	QTY
2311-02	ADAPTOR ASSY	1
2311-10	VALVE ASSY, SOLENOID, LPG	1
2311-11	CONNECTION ASSY, HIGH PRESSURE, LPG	1
2311-12	VALVE ASSY, SERVICE	1
2311-13	SWITCH ASSY, LPG	1
2311-14	SWITCH ASSY, OIL PRESSURE (FOR LPG)	1
2311-15	RELAY ASSY (FOR LPG)	1
2311-16	VALVE ASSY, SOLENOID, GASOLINE	1
2311-17	VALVE ASSY, RELIEF, LPG	1
2311-18	COUPLING ASSY, LPG	1
2311-30	SLEEVE SUB-ASSY, VALVE JOINT	1
2311-31	HOSE SUB-ASSY, (CONTAINER TO FILTER)	1
2311-33	PIPE SUB-ASSY, FUEL (VALVE TO REGULATOR)	1
2311-34	PIPE SUB-ASSY, FUEL, NO.1 (FOR GASOLINE)	1
2311-35	PIPE SUB-ASSY, FUEL, NO.2 (FOR GASOLINE)	1
2311-40	WRENCH, LPG HOSE	1
2311-41	PACKING, TANK VALVE JOINT	1
2311-42	HOSE, FUEL MAIN (REGULATOR TO CARBURETOR)	1
2311-43	HOSE, FUEL SLOW (REGULATOR TO CARBURETOR)	1
2311-45	HOSE, WATER, NO.1	1
2311-46	HOSE, WATER, NO.2	1-2
2311-47	HOSE, VACUUM	1
2311-AA	NUT, HEXAGON	1
2311-AB	NUT, UNION	1
2311-AC	GROMMET	1
2311-AD	CLAMP	1
2311-AF	UNION	1
2311-AG	BRACKET, REGULATOR	1
2311-AH	CLAMP	1
2311-AI	LABEL	1
2311-AJ	JOINT, WATER HOSE	1
2311-AK	ELBOW	1
2311-AL	CLAMP	1
2311-AM	SCREW	1
2311-AN	UNION	1
2311-AD	HOLDER	1
2311-AQ	CLAMP	2
2311-AR	CLAMP	1
2311-AS	STAY SUB-ASSY	1
2311-AT	HARNES, WIRE	1
2311-AU	HARNES	1
2311-AV	JOINT	1
2311-AY	UNION	2
2311-AZ	CORD, L.P.G SWITCH	1
2311-BA	UNION	1
2311-BB	UNION	1
2311-BE	PLUG, PLATE	1
2311-BF	GASKET, FUEL PLUG	1
2311-BG	COVER, FUEL TANK	1
2311-BH	CAP, FUEL	1
2311-BI	BRACKET, SPRING	1
2311-BJ	CLAMP	2
2311-BK	ELBOW	1
2311-BL	NUT	1
2311-BM	WASHER	1
2311-BN	BRACKET	1
2311-BO	FITTING	1
2311-BP	3-WAY SUB-ASSY	2
2311-BR	NUT	1
2311-BS	SCREW	1
2311-CE	CONNECTOR	2
2311-CF	CONNECTOR	1
2311-CG	CLAMP	1
2311-CH	CLAMP	1

PART NAME CODE	PART NAME	QTY
2311-CR	BOOT	1


2312

85/01

PART NAME	PART NAME	QTY
CODE		
2312-01	CARBURETOR ASSY, LPG	1
2312-10	VALVE ASSY, SOLENOID	1
2312-10A	RING, O (FOR SOLENOID VALVE)	1
2312-10B	GASKET (FOR SOLENOID VALVE)	1
2312-43	VALVE, POWER	1
2312-48	LEVER, THROTTLE	1
2312-49	HORN, AIR	1
2312-49A	GASKET, AIR HORN	1
2312-50	SCREW, THROTTLE ADJUST	1
2312-AC	SPRING, THROTTLE BACK	1
2312-AD	COLLAR	1
2312-AE	SPRING, IDLE ADJUST SCREW	1
2312-AF	WASHER, LOCK	1
2312-AG	NUT, THROTTLE LEVEL SET	1
2312-AL	UNION	1
2312-AM	SHIM	90
2312-AD	NUT, POWER JET	1
2312-AP	SCREW, POWER JET	1
2312-AQ	BRACKET	1
2312-AR	LEVER	1
2312-AS	LINK	1
2312-AT	SHIM, THROTTLE	1
2312-AU	PLUG	3
2312-AW	SCREW	2
2312-AX	RING, SNAP	2
2312-AY	SCREW	1
2312-BB	SCREW	1
2312-BC	COLLAR	1
2312-BD	RING, RETAINER	1
2312-BE	SHIM	2
2312-BF	WASHER, PLATE	1
2312-BG	LEVER, ACCELERATOR	1
2312-BH	HARNES	1



5P (CONVERTIBLE, EXCLUSIVE)



PART NAME	PART NAME	QTY
CODE		
2314-01	REGULATOR ASSY, LPQ	1
2314-01K	DIAPHRAGM O/H KIT	1
2314-20	COVER SUB-ASSY, 1ST REGULATOR	1
2314-21	COVER SUB-ASSY, 2ND REGULATOR	1
2314-22	DIAPHRAGM SUB-ASSY, 1ST	1
2314-23	DIAPHRAGM SUB-ASSY, VACUUM LOCK	1
2314-24	DIAPHRAGM SUB-ASSY, 2ND REGULATOR	1
2314-30	VALVE SUB-ASSY, 1ST	1
2314-30K	VALVE O/H KIT	1
2314-32	LEVER SUB-ASSY, 2ND VALVE	1
2314-43	VALVE, ELASTIC FACE	1
2314-45	SPRING, 1ST REGULATOR	2
2314-46	COCK, DRAIN	1
2314-AA	UNION	1
2314-AF	SCREW, IDLE ADJUST	1
2314-AH	SPRING, IDLE ADJUST SCREW	1
2314-AI	UNION	1
2314-AK	SEAT, 2ND VALVE	1
2314-AL	SPRING, 2ND REGULATOR	1
2314-AM	RETAINER, WIRE SUPPORT	1
2314-AN	WASHER, WAVE	1
2314-AO	RING, SNAP	1
2314-AP	SCREW	7
2314-AR	UNION	2
2314-AT	SEAT, 1ST VALVE	1
2314-AV	UNION	1
2314-AW	SPRING, VACUUM LOCK DIAPHRAGM	1
2314-AX	LEVER, 1ST VALVE	1
2314-AY	RING	2
2314-AZ	RING, D	2
2314-BA	SCREW	2
2314-BB	GUIDE, SPRING	4
2314-BC	SCREW	1
2314-BD	NUT	1
2314-BE	WASHER	1
2314-BF	RING, O	2
2314-BG	COVER	1
2314-BH	SHELL	1
2314-BI	SCREW	4
2314-BJ	WASHER	1
2314-BK	PLUG	1
2314-BL	GASKET	1
2314-BM	DIAPHRAGM	1
2314-BZ	BOLT, UNION	1
2314-CA	UNION	1
2314-CB	GASKET	1


FIG. 2315
LPG FILTER

2315

5P

85/01

5P (CONVERTIBLE, EXCLUSIVE)



2315 007B

PART NAME	PART NAME	QTY
CODE		
2315-01	FILTER ASSY, LPG	1
2315-01K	ELEMENT KIT	1
2315-40	BODY, FILTER	1
2315-42	ELEMENT, FILTER	1
2315-AB	BOLT SUB-ASSY, STUD	1
2315-AC	GASKET	2
2315-AD	UNION	1
2315-AE	PLATE, ELEMENT	1
2315-AF	GASKET	1
2315-AG	NUT, SET	1
2315-AI	LABEL	1

2316




85/01

5P (CONVERTIBLE+CANADA) (EXCLUSIVE+UL)

Diagram of the IITA STD1 interface unit. It shows a physical device with several connection points labeled with numbers and text. The labels include:

- 95381-03615 (top left)
- 94812-10800 (top center)
- 21 (top center, below 94812-10800)
- AC (top left, below 95381-03615)
- 20 (bottom left)
- 30 (bottom right)
- 31 (bottom right, below 30)
- 94110-40800 (bottom right, below 31)

 The diagram shows a power cord connected to the AC input and various signal or data lines connected to the numbered terminals.



2316-000

FIG. 2316
LPG CONTAINER & BRACKET

2316

5P

85/01

PART NAME	PART NAME	QTY
CODE		
12316-01	CONTAINER ASSY, LPG	1
12316-20	BRACKET SUB-ASSY, LPG CONTAINER	1
12316-21	BAND SUB-ASSY	2
12316-30	HOOK SUB-ASSY	2
12316-32	ROD SUB-ASSY, BRACKET SET	2
12316-AB	PIN	2
12316-AC	PIN	1
12316-AD	SHAFT	1
12316-AE	PIN	1
12316-AF	SPRING	1
12316-AG	CLAMP SUB-ASSY	2
12316-AH	CLEVIS	2
12316-AI	PIN	2
12316-AJ	KNOB SUB-ASSY	1
12316-AK	PIN, SPRING	1
12316-AL	PIN, STOPPER	1
12316-AM	STOPPER SUB-ASSY	1
12316-AN	PIN, SPRING	1
12316-AD	STOPPER, LOWER	1
12316-AP	PIN, SPRING	1
12316-AQ	SPRING	1
12316-AR	PLATE, CUSHION	1
12316-A5	CLAMP	1- 2
12316-AU	CLAMP	1
12316-AV	CLAMP	1
2316 AW	WASHER, PLATE	1


FIG. 2601
ACCELERATOR LINK

2601

SP

85/01

SP



PART NAME CODE	PART NAME	QTY
2601-10	WIRE ASSY, ACCELERATOR FLEXIBLE	1
2601-11	WIRE ASSY, CHOKE	1
2601-20	PEDAL SUB-ASSY, ACCELERATOR	1
2601-20A	BUSH (FOR ACCELERATOR PEDAL)	2
2601-30	ARM SUB-ASSY, ACCELERATOR LINK, NO.1	1
2601-30A	BUSH (FOR ACCELERATOR LINK ARM)	3
2601-31	BRACKET SUB-ASSY, ACCELERATOR WIRE, NO.1	1
2601-33	BRACKET SUB-ASSY, ACCELERATOR ARM, NO.1	1
2601-34	ARM SUB-ASSY, ACCELERATOR LINK, NO.2	1
2601-37	BRACKET SUB-ASSY, ACCELERATOR WIRE, NO.2	1
2601-41	SPRING, TORSION, NO.1	1
2601-42	ROD, ACCELERATOR PEDAL	1
2601-43	PAD, PEDAL	1
2601-45	ROD, ACCELERATOR, NO.1	1
2601-47	END, CONNECTING ROD, NO.1	2
2601-51	BRACKET, PEDAL	1
2601-62	SPRING, TORSION, NO.2	1
2601-AB	PIN, W/HOLE	1
2601-AC	PIN	1
2601-AD	CLAMP	2
2601-AQ	SHAFT, ACCELERATOR LINK	1
2601-AK	CLAMP, ACCELERATOR WIRE	2
2601-AN	BOLT	2
2601-EG	BOLT	1

MEMO

silverhorn.co.uk

FIG. 3201
TORQUE CONVERTER HOUSING


3201

ATM

85/01

ATM (EXPORT) (1/2)

01K (INCL. )
03K (INCL. )



3201 Q14A


FIG. 3201
TORQUE CONVERTER HOUSING

3201

ATM

85/01

ATM (EXPORT) (2/2)



02/11 0056

FIG. 3201
TORQUECONVERTER HOUSING


3201

ATM

85/01

PART NAME CODE	PART NAME	QTY
3201-00	TRANSMISSION ASSY, AUTOMATIC, W/DIFFERENTIAL	1
3201-01K	TRANSMISSION O/H KIT, AUTOMATIC	1
3201-03K	TRANSMISSION O/H KIT (FOR TORQUECONVERTER)	1
3201-20	CASE SUB-ASSY, TORQUECONVERTER, NO.1	1
3201-22	CASE SUB-ASSY, TRANSMISSION	1
3201-23	CASE SUB-ASSY, SERVO, NO.1	1
3201-23B	RING, O (FOR SERVO CASE)	1
3201-30	GAGE SUB-ASSY, OIL LEVEL	1
3201-42	PLATE, TORQUECONVERTER END	1
3201-44	BREATHER, AIR	1
3201-45B	PLUG, DRAIN	1- 2
3201-45C	GASKET (FOR DRAIN PLUG)	1- 2
3201-49	COVER, TORQUECONVERTER CASE	1
3201-AA	COVER, COOLING AIR	1
3201-AB	RING, O	1
3201-AC	HANGER	2
3201-AD	PLUG	1
3201-AE	PLUG, W/HEAD STRAIGHT SCREW	1
3201-AF	GASKET	1
3201-AG	RING, O	1
3201-AH	PLUG, TAPER SCREW	1
3201-AI	PIN, STRAIGHT	2
3201-AJ	BOLT, STUD	10
3201-AM	BOLT, STUD	1
3201-AN	PLATE, LOCK	1
3201-AQ	MAGNET	1
3201-AP	RING, O	1
3201-AQ	RING, O	1
3201-AR	PIN, STRAIGHT	2
3201-AS	PLATE, COVER	1
3201-80	BOLT, DIFFERENTIAL CARRIER CAP	4
3201-8F	RING, O	2
3201-BL	ADAPTER, AIR BREATHER	1
3201-BM	PLATE	3
3201-BP	BOLT	1
3201-BQ	WASHER, SPRING	1
3201-BR	RING, O	3
3201-BT	RING, O	2
3201-BU	BOLT	3
3201-BV	BOLT	1
3201-BW	WASHER, SEAL	1
3201-CC	BOLT	4
3201-DJ	BOLT	2-12

ATM (EXPORT)



3709 3047

PART NAME CODE	PART NAME	QTY
3202-01	TORQUE CONVERTER ASSY	1
3202-01K	TORQUE CONVERTER O/H KIT	1
3202-11	PUMP ASSY, OIL	1
3202-12	STATOR ASSY	1
3202-14	IMPELLER ASSY, PUMP	1
3202-15	ROLLER SET (FOR STATOR)	1
3202-20	GEAR SUB-ASSY, DRIVE PLATE & RING	1
3202-21	RUNNER SUB-ASSY, TURBINE	1
3202-22	SHAFT SUB-ASSY, STATOR	1
3202-22A	PACKING (FOR STATOR SHAFT)	1
3202-23	GEAR SUB-ASSY, OIL PUMP DRIVE	1
3202-24	GEAR SUB-ASSY, OIL PUMP DRIVEN	1
3202-25	IMPELLER SUB-ASSY, PUMP	1
3202-25A	RING, O (FOR PUMP IMPELLER)	1
3202-27	PLATE SUB-ASSY, FLEXIBLE	1
3202-28	COVER SUB-ASSY, DRIVE (DISC SUB-ASSY)	1
3202-28A	BEARING (FOR DRIVE COVER)	1
3202-30	CASE SUB-ASSY, OIL PUMP	1
3202-30A	RING, O (FOR OIL PUMP CASE)	1
3202-31	EXTENSION SUB-ASSY, PUMP IMPELLER (BOSS)	1
3202-31A	BEARING, PUMP IMPELLER EXTENSION	1
3202-31B	RING, O (FOR PUMP IMPELLER EXTENSION)	1
3202-31C	RING, SEAL (FOR PUMP IMPELLER EXTENSION)	1
3202-41	PIECE, CENTER (BOSS, PILOT)	1
3202-43	SHAFT, TURBINE (SHAFT, INPUT)	1
3202-43A	BEARING, TURBINE SHAFT	1
3202-43B	RING, SEAL (FOR TURBINE SHAFT)	1-2
3202-43C	RING, SHAFT SNAP (FOR TURBINE SHAFT BEARING)	1
3202-43E	RING, HOLE SNAP (FOR TURBINE SHAFT BEARING)	1
3202-45	HUB (FACE, INNER)	1
3202-45A	BEARING, THRUST (FOR HUB)	1
3202-45B	WASHER, THRUST, NO.1 (FOR HUB)	1-2
3202-45G	COLLAR (FOR HUB)	1
3202-52	ROLLER (FOR STATOR)	8
3202-53	SPRING (FOR STATOR)	8
3202-54	CAP, SPRING (FOR STATOR)	8
3202-AA	RING, O	1
3202-AB	RING, SHAFT SNAP	1
3202-AC	WASHER, TURBINE, FRONT	1
3202-AD	NUT	20
3202-AH	BOLT	20-24
3202-AI	RING, HOLE SNAP	1
3202-AJ	RING, HOLE	2
3202-AL	BOLT	6
3202-AM	SEAL, TYPE D OIL	1
3202-AQ	PLATE, THRUST	2
3202-AR	BOLT	6
3202-AS	SPACER, DRIVE PLATE	1
3202-AT	SUPPORT, CENTERING	1
3202-AU	WASHER, PLATE	24
3202-AV	WASHER, TOOTHED	12
3202-AW	PLUG, TAPER	2
3202-AX	SEAL, OIL	1
3202-AY	SPACER	1
3202-BA	SHIM	1
3202-BB	PLATE, LOCK	4
3202-BC	WASHER, THRUST	1
3202-BE	SPACER	1
3202-BH	BOLT, STUD	8
3202-BI	NUT	8
3202-BL	BOLT	10

3203

85/01

This diagram shows an exploded view of a mechanical assembly. The main components are labeled as follows:

- Top Section:** Includes a large cylindrical housing (20) with a flange (22) and a central shaft (24). A smaller component (24A) is shown near the housing. A large gear (46) is shown at the top right.
- Bottom Section:** Includes a large gear (42A) with a central shaft (51). A smaller gear (45) is shown below it. A component (45B) is shown near the gear (45).
- Other Components:** A component (46C) is shown near the large gear (46). A component (46D) is shown near the bottom gear (45).
- Assembly Details:** A circular inset shows a cross-section of a component (45) with a central hole and a flange. A component (45A) is shown near the bottom gear (45).

3203 007C

FIG. 3203
TORQUE CONVERTER CLUTCH

3203

ATM

85/01

PART NAME CODE	PART NAME	QTY
3203-10	DRUM ASSY, CLUTCH, NO.1	1
3203-20	DRUM SUB-ASSY, CLUTCH, NO.1	1
3203-20A	RING, SEAL (FOR CLUTCH DRUM)	2
3203-22	PISTON SUB-ASSY, CLUTCH, NO.1	2
3203-22A	RING, PISTON (FOR CLUTCH PISTON)	2
3203-24	SHAFT SUB-ASSY, CLUTCH, NO.1	1
3203-24A	RING, SEAL (FOR CLUTCH SHAFT)	3
3203-24D	BEARING, NO.1 (FOR NO.1 CLUTCH SHAFT)	1
3203-40	DISC, CLUTCH	10
3203-41	PLATE, CLUTCH	8-10
3203-42	PLATE, CLUTCH PRESSURE	2
3203-42A	RING, HOLE SNAP (FOR CLUTCH PRESSURE PLATE)	2
3203-43	SPRING, CLUTCH RETURN	2
3203-44	COLLAR, SERVO	1
3203-45	GEAR, CLUTCH (FORWARD)	1
3203-45B	COLLAR (FOR FORWARD CLUTCH GEAR)	1
3203-45C	WASHER, THRUST (FOR FORWARD CLUTCH GEAR)	1
3203-46	GEAR, CLUTCH (REVERSE)	1
3203-46C	WASHER, THRUST, NO.1 (FOR REVERSE GEAR)	1
3203-46D	WASHER, THRUST, NO.2 (FOR REVERSE GEAR)	1
3203-50	PLATE, CLUTCH CAMBER	2
3203-51	PLATE, CLUTCH BACKING	2
3203-AC	RING, SHAFT SNAP	2
3203-AD	BALL	2
3203-AE	PLUG, STRAIGHT	2
3203-AG	WASHER, WAVE	1
3203-AH	RING, SHAFT SNAP	1-2
3203-AJ	RETAINER, SPRING	2
3203-AM	CAP, MAIN SHAFT	1
3203-AN	RING, O	1
3203-AD	RING, HOLE SNAP	1
3203-AP	PIN, SPRING	2
3203-AQ	SPACER	2
3203-A6	RING, SNAP	1
3203-AT	SPACER	1
3203-AZ	GEAR SET, FORWARD	1


FIG. 3204
TORQUE CONVERTER GEAR

3204

ATM

85/01

ATM (EXPORT)



PART NAME	PART NAME	QTY
CODE		
3204-43	SHAFT, IDLE	1
3204-44	GEAR, IDLE, NO.1	1
3204-44A	BEARING (FOR IDLE GEAR)	2
3204-46	GEAR, OUTPUT, NO.1	1
3204-49	GEAR, IDLE, NO.2	1
3204-AA	LOCK, SHAFT	1
3204-AB	WASHER	2
3204-AC	SPACER, IDLER SHAFT	1
3204-AK	SPACER	1
3204-AL	RING, SNAP	2
3204-AM	SPACER, SEAL	2
3204-AN	RING, O	2

3204 OCT

FIG. 3206
CONTROL VALVE

3206


ATM

85/01



ATM (EXPORT)

ATM (EXPORT)

01K --- (INCL. ●)



3206-008



3206-0108

FIG. 3206
CONTROL VALVE

3206

ATM

85/01

PART NAME	PART NAME	QTY
CODE		
3206-01	COVER & VALVE ASSY, TRANSMISSION	1
3206-01K	COVER O/H KIT, TRANSMISSION	1
3206-10	COVER ASSY, CONTROL VALVE SMALL UPPER	1
3206-11	VALVE ASSY, CONTROL, W/REGULATOR VALVE	1
3206-20	COVER SUB-ASSY, UPPER	1
3206-20A	PLUG, BREATHER	1
3206-20B	GASKET (FOR BREATHER PLUG)	1
3206-30	BODY SUB-ASSY, ORIFICE VALVE	1
3206-31	VALVE SUB-ASSY, INCHING	1
3206-40	PACKING, TRANSMISSION COVER	1
3206-41	PACKING, CONTROL VALVE BODY	2
3206-44	VALVE, INCHING	1
3206-44C	SEAL, OIL (FOR INCHING VALVE)	1
3206-45	VALVE, SELECTOR	1
3206-45A	SEAL, OIL (FOR SELECTOR VALVE)	1
3206-46	VALVE, CHANGE	1
3206-47	VALVE, MODULATOR	1
3206-48	PISTON, MODULATOR	1
3206-49	VALVE, ORIFICE	1
3206-50	VALVE, REGULATOR	1
3206-51	PISTON, ACCUMULATOR	1
3206-52	RETAINER, SPRING (FOR REGULATOR VALVE)	1
3206-54	ROD, INCHING	1
3206-55	SPRING, COMPRESSION (FOR INCHING VALVE)	1
3206-AA	LEVER, SHIFT	1
3206-AB	WASHER, PLATE	2
3206-AC	PIN, LEVER LOCK	2
3206-AD	SEAL, OIL	2
3206-AE	BUSH	2
3206-AF	LEVER, INCHING	1
3206-AG	PLUG	1-2
3206-AH	NIPPLE	1
3206-AI	GASKET	1
3206-AJ	PLUG, STRAIGHT	2
3206-AK	WASHER, PLATE	2
3206-AL	LEVER SUB-ASSY, INCHING CAM	1
3206-AM	PLATE, ADJUST SHIFT	2
3206-AN	LEVER SUB-ASSY, SHIFT CAM	1
3206-AO	PLUG, STRAIGHT	2
3206-AP	STOPPER, CHANGE VALVE	1
3206-AQ	PIN, SPRING	1-2
3206-AS	SPRING, MODULATOR OUTER	1
3206-AT	RING, SNAP	1
3206-AU	SPRING, ORIFICE VALVE	1
3206-AV	SPRING, REGULATOR VALVE	1
3206-AW	SPRING, INCHING VALVE	1
3206-AX	IBALL, STEEL	1-2
3206-AY	SPRING	1-2
3206-AZ	PLATE, HOLDER SPRING	1
3206-BA	PLATE, OIL SEPARATOR	1
3206-BB	BODY, CONTROL VALVE	1
3206-BG	RING, O	2
3206-BJ	PLUG, TAPER	1
3206-BM	PLUG, TAPER	3
3206-BN	PLUG, TAPER	4
3206-BR	BOLT, LOCK	2
3206-BX	PLUG	1
3206-BY	PACKING	1
3206-CC	NUT	1
3206-CE	PACKING	1
3206-CI	PACKING	1
3206-CJ	PLUG	1
3206-CL	LEVER, SELECTOR	1
3206-CS	PACKING	2

PART NAME	PART NAME	QTY
CODE		
3206-CT	RING, O	1
3206-CU	NUT	2
3206-CV	BOLT, ADJUST	2
3206-CW	PACKING	2
3206-CX	PLUG	2
3206-CY	PLUG	9
3206-DA	PLATE, SUB	1
3206-DB	PACKING, SUB PLATE	1
3206-DC	BOLT	8
3206-DD	BOLT	10
3206-DE	BOLT	2
3206-DF	SPRING, REGULATOR, OUTER	1
3206-DG	SPRING, REGULATOR, INNER	1
3206-DH	WASHER, THRUST	1
3206-DI	SPRING, ACCUMULATOR, INNER	1
3206-DJ	SPRING, ACCUMULATOR, OUTER	1
3206-DK	ORIFICE	1
3206-DL	PIN, STOPPER	1
3206-DM	BOLT, STOP	1
3206-DN	RING, SNAP	1-2
3206-DO	STOPPER, INCHING SPRING	1
3206-DP	ROD, SPRING STOPPER	1
3206-DQ	PLATE, VALVE HOLDER	1
3206-DR	PLATE, CONTROL VALVE BODY	1
3206-DS	PACKING	1
3206-DT	COVER	1
3206-DU	BOLT	3
3206-DW	SPRING, INCHING	1
3206-DX	PISTON, INCHING	1
3206-DY	PLUG	1
3206-DZ	WASHER, THRUST	1
3206-EN	BODY, ORIFICE VALVE	1

FIG. 3213
TORQUE CONVERTER PIPING

3213

ATM




85/06

2JT-ATM (EXPORT)

2JT-5P-ATM (EXPORT)



3213 014C



3213-011B

PART NAME	PART NAME	QTY
CODE		
3213-10	FILTER ASSY, OIL	1
3213-30	STRAINER SUB-ASSY, OIL (SCREEN)	1
3213-41	HOSE, LOW PRESSURE, NO.1 (FOR OIL COOLER)	1
3213-41A	CLAMP, NO.1 (FOR OIL COOLER HOSE)	2- 4
3213-AC	ELBDW	2
3213-AG	RING, O	1
3213-AJ	PACKING	4
3213-AK	UNION	1- 4
3213-AL	BOLT, UNION	2
3213-AQ	PIPE ASSY	1
3213-AR	PIPE ASSY	1
3213-AS	PIPE ASSY	1
3213-AV	BOLT, UNION	1- 3
3213-AW	BOLT, UNION	1
3213-AX	BOLT	1
3213-BA	CLAMP, HOSE	1
3213-BB	UNION	1
3213-BC	PIPE SUB-ASSY, OIL COOLER	1
3213-BE	BOLT	4

ATM (LH LEVER)

ATM (RH LEVER)





FIG. 3214
CONTROL SHAFT

3214

ATM

85/01

PART NAME CODE	PART NAME	QTY
3214-10	END ASSY, CONNECTING ROD, NO.1	1
3214-11	END ASSY, CONNECTING ROD, NO.2	1
3214-20	SHAFT SUB-ASSY, CONTROL	1
3214-21	LINK SUB-ASSY, CONTROL SHAFT	1
3214-30	PIN SUB-ASSY, LINK	1
3214-40	LEVER, CONTROL	1
3214-41	ROD, FORWARD & REVERSE CHANGE, NO.1	1
3214-42	KNOB, SHIFT LEVER	1
3214-44	ROD, FORWARD & REVERSE CHANGE, NO.2	1
3214-AA	PIN, SPRING	1
3214-AB	BUSHING, SOLID	2
3214-AD	NUT	1
3214-AE	PLATE, CHANGE LEVER CENTER	1
3214-AF	BUSHING, SOLID	1
3214-AG	BRACKET, CHANGE LEVER	1


FIG. 4101
DIFFERENTIAL

4101

ATM

85/01

ATM (DOMESTIC)



4101-008

FIG. 4101
DIFFERENTIAL


4101

ATM

85/01

ATM (EXPORT)

EXHAUST (EXPORT) CONTROL



4101 009

PART NAME	PART NAME	QTY
CODE		
4101-02	CASE ASSY, DIFFERENTIAL	1
4101-10	RING GEAR & PINION SET, DIFFERENTIAL	1
4101-10A	BEARING, DRIVE PINION	2
4101-10B	BEARING, DRIVE PINION PILOT	1
4101-10C	NUT, LOCK	1
4101-10D	SHIM, BEARING PRELOAD ADJUST	99
4101-20	CASE SUB-ASSY, DIFFERENTIAL	1
4101-20A	NUT, ADJUSTING	2
4101-20B	BEARING, DIFFERENTIAL CASE	2
4101-21	CARRIER SUB-ASSY, DIFFERENTIAL	1
4101-21A	RING, O (FOR DIFFERENTIAL CARRIER)	1
4101-40	HOUSING, DIFFERENTIAL	1
4101-40B	RING, O (FOR DIFFERENTIAL HOUSING)	1
4101-40C	PLUG, BREATHER (FOR DIFFERENTIAL HOUSING)	1
4101-44	PLUG (FOR INPUT SHAFT)	1
4101-44A	PACKING (FOR INPUT SHAFT PLUG)	1
4101-46	GEAR, SIDE	2
4101-46A	WASHER, SIDE GEAR THRUST	2
4101-47	SPIDER	1
4101-48	PINION	4
4101-48A	WASHER, PINION THRUST	4
4101-49	PLUG, DRAIN	1
4101-49A	GASKET, DRAIN PLUG	1
4101-50	RETAINER, DRIVE PINION BEARING	1
4101-50B	RING, O (FOR BEARING RETAINER)	1
4101-50C	SEAL, OIL (FOR BEARING RETAINER)	1
4101-50D	SHIM, DIFFERENTIAL DRIVE PINION BEARING	99
4101-54	CAP, RING GEAR THRUST SCREW	1
4101-55	BOLT, RING GEAR SET	12
4101-AB	BOLT	12
4101-AC	SCREW, RING GEAR THRUST	1
4101-AD	NUT	1
4101-AF	LOCK, ADJUSTING	2
4101-AG	PLUG, W/HEAD STRAIGHT SCREW	1
4101-AH	GASKET	1
4101-AI	PLUG	1
4101-AJ	GASKET	1
4101-AK	BOLT	2
4101-AL	BOLT	4
4101-AN	RING, O	1
4101-AO	SPACER, BEARING	1
4101-AP	WASHER, SEAL	6
4101-AR	PIN, KNOCK	2
4101-AS	BOLT	2-10
4101-AT	WASHER, SPRING	13



FIG. 4201
FRONT AXLE SHAFT

4201

ATM

B5/01

ATM



PART NAME

CODE

PART NAME


QTY

4201-40	SHAFT, FRONT AXLE	2
4201-40A	WASHER, CORN	16
4201-40B	WASHER, SPRING (FOR FRONT AXLE SHAFT)	16
4201-40C	SEAL, OIL (FOR FRONT AXLE SHAFT)	2
4201-40D	GASKET, FRONT AXLE SHAFT	2
4201-41	HUB, FRONT AXLE	2
4201-41A	SEAL, OIL (FOR FRONT AXLE HUB)	2
4201-41B	BEARING, NO.1 (FOR FRONT AXLE HUB)	2
4201-41C	BEARING, NO.2 (FOR FRONT AXLE HUB)	2
4201-41D	NUT, BEARING LOCK	2
4201-41E	BOLT, HUB	12
4201-41F	BOLT, STUD (FOR FRONT AXLE SHAFT)	12
4201-41G	NUT, HUB	12
4201-41H	BOLT, DOUBLE WHEEL STOP	12
4201-42	DRUM, BRAKE	2
4201-43	BRACKET, FRONT AXLE, RH	1
4201-43A	NUT, BRAKE SET SELF	16
4201-43B	RING, O (FOR FRONT AXLE BRACKET)	2
4201-44	BRACKET, FRONT AXLE, LH	1
4201-49	PLATE, LOCK NUT	2
4201-53	HOUSING, FRONT AXLE	2
4201-53A	RING, O (FOR FRONT AXLE HOUSING)	2
4201-AA	BOLT	4
4201-AB	BOLT, BRACKET SET	4
4201-AC	BOLT, STUD BRAKE SET	16
4201-AD	WASHER, CD SPRING	16
4201-AE	BOLT	2
4201-AG	SPACER SUB-ASSY, DISK WHEEL	2
4201-AH	WASHER, CD SPRING	12
4201-AJ	BOLT	16

4301

85/01

PART NAME	PART NAME	QTY
CODE		
4301-01	AXLE ASSY, RR	1
4301-10	END ASSY, TIE-ROD, NO.1	2
4301-10A	NUT, CASTLE (FOR TIE-ROD END)	4
4301-10B	NUT (RM THREADS)	2
4301-10C	PIN, COTTER (FOR TIE-ROD END)	4
4301-11	END ASSY, TIE-ROD, NO.2	2
4301-11B	NUT (LM THREADS)	2
4301-13K	TIE-ROD KIT	2
4301-20	BEAM SUB-ASSY, REAR AXLE	1
4301-20A	BUSH, REAR AXLE BEAM	2
4301-20B	SHIM, REAR AXLE BEAM	1
4301-23	BELLCRANK SUB-ASSY, STEERING	1
4301-23A	BEARING (FOR STEERING BELLCRANK)	2
4301-23B	SEAL, OIL (FOR STEERING BELLCRANK)	2
4301-23K	SEAL KIT, BELLCRANK PIN	1
4301-40	KNUCKLE, STEERING, RM	1
4301-41	KNUCKLE, STEERING, LH	1
4301-42	PIN, STEERING KNUCKLE KING	2
4301-42A	BEARING, STEERING KNUCKLE THRUST	2
4301-42B	SEAL, OIL, NO.1	4
4301-42C	BEARING, NEEDLE	2
4301-42D	SHIM, STEERING KNUCKLE	2
4301-42E	SEAL, OIL, NO.2	2
4301-42K	SEAL KIT, KING PIN	2
4301-63	PIN, KING PIN LOCK	2
4301-64	HUB, REAR AXLE	2
4301-64A	BEARING, INNER	2
4301-64B	BEARING, OUTER	2
4301-64C	BOLT, HUB	12
4301-64D	NUT, HUB	12
4301-64E	PIN, REAR AXLE COTTER	2
4301-64F	SEAL, OIL (FOR REAR AXLE HUB)	2
4301-64G	NUT, CASTLE (FOR REAR AXLE HUB)	2
4301-65	CAP, REAR AXLE HUB	2
4301-67	TIE-ROD	2
4301-68	PIN, BELLCRANK	1
4301-58	BOOT, TIE-ROD END	4
4301-58A	RING (FOR TIE-ROD END BOOT)	4
4301-AA	BOLT	2
4301-AB	FITTING, GREASE	4
4301-AC	FITTING, GREASE	3
4301-AD	WASHER, CLAW	2
4301-AE	SHIM	1
4301-AF	PLATE, STOPPER	1
4301-EU	NUT	2
4301-EV	WASHER, SPRING	2



4401

85701

PART NAME	CODE
-----------	------

PART NAME

QTY




FIG. 4402
FRONT WHEEL & TIRE (DOUBLE)

4402



ATM

85/01

ATM (DOUBLE)



(2-PIECE RING)



4402-004

PART NAME CODE	PART NAME	QTY
4402-02	WHEEL ASSY, INNER	2
4402-03	WHEEL ASSY, OUTER	2
4402-13	TIRE ASSY	4
4402-14	CHAIN ASSY, TIRE	1
4402-21	WHEEL SUB-ASSY, DISC, INNER	2
4402-22	WHEEL SUB-ASSY, DISC, OUTER	2
4402-40	BAND, CHAIN	1
4402-41	EXTENSION, WHEEL TUBE VALVE	2
4402-AB	RING, LOCK	4
4402-AE	TUBE SUB-ASSY	4
4402-AF	FLAP	4
4402-AG	RING, SIDE	4

FIG. 4403
REAR WHEEL & TIRE


4403

ATM


85/01

ATM

(DIVIDED RIM)



(S DE RING RIM)



4403 001

PART NAME

CODE

PART NAME

QTY

4403-01	WHEEL ASSY	2
4403-13	TIRE ASSY	2
4403-20	WHEEL SUB-ASSY, DISC	2
4403-20A	BOLT, DISC WHEEL SET	12
4403-20B	NUT, WHEEL SET	12
4403-20C	WASHER, WHEEL SET	12
4403-AA	FLANGE, SIDE	2
4403-AB	RING, LOCK	4
4403-AC	BAND, BEND SHEET	2
4403-AE	TUBE SUB-ASSY	2
4403-AF	FLAP	2


FIG. 4501
STEERING WHEEL

4501

ATM

85/01

ATM



PART NAME CODE	PART NAME	QTY
4501-01	WHEEL ASSY, STEERING	1
4501-10	KNOB ASSY, STEERING WHEEL	1
4501-30	KNOB SUB-ASSY, STEERING WHEEL	1
4501-40	BUTTON, HORN	1
4501-42	PLATE, HORN CONTACT	1
4501-43	SEAT, HORN CONTACT	1
4501-44	SPRING, HORN	1
4501-45	PLATE, LEAD	1
4501-AA	SCREW	1
4501-AB	WASHER	3
4501-AC	SCREW	2
4501-AD	CAP, STEERING WHEEL	1
4501-AE	BOLT, STEERING WHEEL KNOB SET	1
4501-AK	RING, HORN CONTACT NO.1	1

4501 D2 6A

ATM [1/2]

RJ+2JT+ATM [2/21]





FIG. 4502
STEERING POST


4502

ATM


85/01

5P..ATM (2/2)


2J..5P..ATM (DELUXE CABIN) (1/1)



4502 0118



Refer to
FIG. 4503



4502 104A

PART NAME	PART NAME	QTY
CODE		
4502-01	POST ASSY, STEERING	1
4502-10	GEAR ASSY, STEERING	1
4502-10K	GEAR O/H KIT, STEERING	1
4502-11	BALL SCREW SET	1
4502-11A	BEARING, NO.1 (FOR BALL SCREW SET)	1
4502-11B	BEARING, NO.2 (FOR BALL SCREW SET)	1
4502-11C	BEARING, THRUST (FOR BALL SCREW SET)	2
4502-12	BODY ASSY, VALVE	1
4502-20	JACKET SUB-ASSY, MAST	1
4502-21	BOX SUB-ASSY, STEERING GEAR	1
4502-21B	BEARING, NO.1 (FOR SECTOR SHAFT)	1
4502-21C	SEAL, OIL (FOR SECTOR SHAFT)	1
4502-30	COVER SUB-ASSY, SIDE	1
4502-30C	RING, O (FOR SIDE COVER)	1
4502-30D	BEARING, NO.2 (FOR SECTOR SHAFT)	1
4502-31	VALVE SET, RELIEF	1
4502-32	INSULATOR SUB-ASSY, W/COLUMN BUSH	1
4502-33	BODY SET, VALVE	1
4502-33A	RING, O (FOR VALVE BODY SET)	1
4502-40	SHAFT, SECTOR	1
4502-41	BRACKET, STEERING	1
4502-43	SHAFT, STEERING MAIN	1
4502-43A	BEARING (FOR STEERING MAIN SHAFT)	1
4502-43B	RING, SHAFT SNAP (FOR STEERING MAIN SHAFT)	1
4502-43C	RING, HOLE SNAP (FOR MAIN SHAFT BEARING)	1
4502-45	COVER, TOP	1
4502-45A	RING, O (FOR TOP COVER)	1
4502-46	COVER, END	1
4502-46C	RING, O (FOR END COVER)	1
4502-49	GROMMET, STEERING COLUMN (INSULATOR)	1
4502-AB	BOLT	7
4502-AD	GROMMET	1
4502-AE	STAY SUB-ASSY, STEERING	1
4502-AF	CLAMP	1
4502-AG	CLAMP, STEERING COLUMN, LOWER	2
4502-AK	BOLT, STUD	4
4502-AL	PLUG, OIL	1
4502-AM	BOLT, ADJUSTING	1
4502-AN	PLATE, ADJUSTING	1
4502-AD	BOLT	4
4502-AP	NUT	1
4502-AS	SEAL, OIL	1
4502-AT	COLLAR	1
4502-AU	RING, SNAP	1
4502-AV	PACKING	1
4502-AW	NUT	1
4502-AY	NUT, LOCK	1
4502-BA	RING, SNAP	1
4502-BB	SEAT	8
4502-BC	SPRING	4
4502-BE	RING, O	1
4502-BH	PLATE	2
4502-BI	RING, SNAP	1
4502-BJ	PLUG	1
4502-BK	SPRING	1
4502-BR	BOOT, MAST JACKET	1
4502-BT	JACKET	1


FIG. 4503
HYDROSTATIC STEERING VALVE

4503

ATM

85/01

2J.SP..ATM (DELUXE CABIN)



PART NAME	PART NAME	QTY
CODE		
4503-01	VALVE ASSY. HYDROSTATIC STEERING	1
4503-01K	VALVE O/H KIT, HYDROSTATIC STEERING	1
4503-AA	PIN, STRAIGHT	1
4503-AB	SPRING, CENTERING	6
4503-AC	SPRING	1
4503-AD	BALL, STEEL	1
4503-AE	SEAT	1
4503-AF	PLUG	1
4503-AG	RING, O	1
4503-AH	PLATE, MOUNTING	1
4503-AJ	PACKING, Y	1
4503-AK	RING, O	1
4503-AL	CAGE	1
4503-AM	RACE, SIDE	2
4503-AN	BEARING, NEEDLE	1
4503-AO	BOLT, SOCKET	4
4503-AP	PLATE, SIDE	1
4503-AR	RING, O	3
4503-AS	CAP, END	1
4503-AT	BOLT	7
4503-AU	GASKET	7
4503-AV	VALVE ASSY. RELIEF	1
4503-AY	NIPPLE	4
4503-BA	RETAINER	1
4503-BB	SPRING	1
4503-BC	VALVE	1
4503-BD	SHIM	99
4503-BE	SPRING	1
4503-BF	RING, O	1
4503-BG	PLUG	1
4503-BI	PLUG	1
4503-BJ	BOLT, SOCKET	2
4503-BK	RING, O	4
4503-BL	BALL, STEEL	1
4503-BT	VALVE ASSY. CHECK	1


FIG. 4507
DRAG LINK & STEERING PIPING

4507

ATM

85/01

ATM



4507 0061


FIG. 4507
DRAG LINK & STEERING PIPING

4507

ATM

85/01

2J, 5P., ATM (DELUXE CABIN)




PART NAME	PART NAME	QTY
CODE		
4507-10	END ASSY, DRAG LINK	2
4507-10A	NUT, CASTLE (FOR DRAG LINK END)	2
4507-11	END ASSY, POWER CYLINDER	2
4507-11A	NUT, CASTLE (FOR POWER CYLINDER END)	2
4507-13K	ROD KIT, DRAG LINK	1
4507-30	PIPE SUB-ASSY, NO.1 (STEERING TO CYLINDER)	1
4507-31	PIPE SUB-ASSY, NO.2 (STEERING TO CYLINDER)	1
4507-40	ROD, DRAG LINK, NO.1	1
4507-41	ARM, PITMAN	1
4507-42	HOSE, POWER CYLINDER, NO.1	1
4507-43	HOSE, POWER CYLINDER, NO.2	1
4507-44	END, POWER CYLINDER	1
4507-49	HOSE, POWER CYLINDER, NO.3	1
4507-50	HOSE, POWER CYLINDER, NO.4	1
4507-69	BOOT (FOR END)	2
4507-69A	RING (FOR END BOOT)	2
4507-AA	CLAMP, END	2
4507-AB	CLAMP, PIPE	1
4507-AC	CLAMP, END	2
4507-AD	BOLT	4
4507-AE	BRACKET SUB-ASSY, POWER CYLINDER	1
4507-AF	BOLT	1
4507-AG	GUARD SUB-ASSY, CYLINDER	1
4507-BR	CLAMP, PIPE	1
4507-CQ	BRACKET SUB-ASSY, PIPE CLAMP	1
4507-OB	BOLT	2
4507-OC	NUT	2
4507-OD	WASHER, SPRING	2
4507-DE	BOLT	1
4507-DF	BOLT	2
4507-DG	NUT	2
4507-DH	WASHER, SPRING	2


4507 077

ATM

2J, 5P, ATM (DELUXE CABIN)



4508 004A



4508 031A

FIG. 4508
STEERING POWER CYLINDER

4508

ATM

85/01

PART NAME CODE	PART NAME	QTY
4508-01	CYLINDER ASSY, POWER	1
4508-01K	PACKING KIT, POWER CYLINDER	1
4508-20	CYLINDER SUB-ASSY, POWER	1
4508-40	ROD, PISTON	1
4508-40A	NUT, SELF LOCK (FOR PISTON)	1
4508-41	PISTON	1
4508-42	RING, PISTON	1
4508-43	GUIDE, ROD	1
4508-AA	BUSHING	1
4508-AB	RING, SNAP	1
4508-AC	SEAL, DUST	1
4508-AD	RING, O	1
4508-A1	COLLAR, REAR COVER	1
4508-AJ	SEAT	2
4508-AK	RING, SNAP	1
4508-AL	PACKING, U	1
4508-AM	RING, BACK UP	1
4508-AQ	RING, O	1


FIG. 4601
PARKING BRAKE

4601

ATM

85/01

ATM



4601 0010

PART NAME CODE	PART NAME	QTY
4601-10	HANDLE ASSY, PARKING BRAKE	1
4601-24	CABLE SUB-ASSY, PARKING BRAKE, NO.1	1
4601-25	CABLE SUB-ASSY, PARKING BRAKE, NO.2	1
4601-29	LEVER SUB-ASSY, INTERMEDIATE	1
4601-29A	SPRING, TENSION (FOR INTERMEDIATE LEVER)	1
4601-AA	CLIP	2
4601-AC	SPACER	1
4601-AD	BUSHING, NYLON	1
4601-AE	BAR SUB-ASSY, EQUALIZER	1
4601-AF	PIN, W/HOLE	1
4601-AG	PULLEY	1
4601-AH	CLAMP, WIRE SET	1
4601-AI	CLAMP	1
4601-AJ	GROMMET	1
4601-AK	PLATE, GROMMET	1
4601-AR	BOLT	2
4601-BW	BOLT	2
4601-BY	NUT	2
4601-BZ	BOLT	2
4601-CA	WASHER, SPRING	2
4601-ED	TUBE	1

4701

85/01

CODE	PART NAME	QTY
4701-10	END ASSY, INCHING ROD, NO.1	1
4701-11	END ASSY, INCHING ROD, NO.2	1
4701-20	PEDAL SUB-ASSY, BRAKE	1
4701-20A	BUSH (FOR BRAKE PEDAL)	1
4701-21	LINK SUB-ASSY, BRAKE, NO.1	1
4701-21A	BUSH (FOR BRAKE LINK)	4
4701-22	BRACKET SUB-ASSY, BRAKE PEDAL	1
4701-23	LINK SUB-ASSY, BRAKE, NO.2	1
4701-27	ROD SUB-ASSY, INCHING	1
4701-28	LINK SUB-ASSY, INCHING	1
4701-28A	BUSH (FOR INCHING LINK)	2
4701-40	PAD, PEDAL	1
4701-43	SPRING, TORSION (FOR PEDAL RETURN)	1
4701-44	ROD, INCHING	1
4701-45	BRACKET, BRAKE PEDAL	2
4701-46	LINK, BRAKE, NO.1	4
4701-AA	SPACER	2
4701-AC	BRACKET, LINK	1
4701-AE	SPACER	1
4701-AF	NUT	1
4701-AI	PIN, W/HOLE	4
4701-AJ	PIN, W/HOLE	2
4701-AK	PIN, W/HOLE	3
4701-CV	BOLT	6
4701-EL	BOLT	1




FIG. 4704
BRAKE VALVE

4704

ATM

85/01

ATM



PART NAME CODE	PART NAME	QTY
4704-01	VALVE ASSY, BRAKE	1
4704-01K	VALVE O/H KIT, BRAKE	1
4704-20	PISTON SUB-ASSY, INPUT	1
4704-30	VALVE SUB-ASSY, CLOSED	1
4704-41	BOOT	1
4704-43	ROD, PUSH	1
4704-44	CUP, CYLINDER	1
4704-45	PISTON, REACTION	1
4704-46	GUIDE, REACTION PISTON	1
4704-47	SEAT, UNION	2
4704-48	SPOOL, BRAKE VALVE	1
4704-49	CLEVIS	1
4704-50	RETAINER, SPRING	1
4704-AA	SPRING, COMPRESSION	1
4704-AB	WASHER, PLATE	1
4704-AC	RING, SNAP	1
4704-AD	NUT	2
4704-AE	PLUG, HOLE	1
4704-AF	RING, O	1
4704-AG	RING, O	1
4704-AH	SPRING, VALVE RETURN	1
4704-AI	RING, O	1
4704-AJ	RING, BACK UP	1
4704-AK	RING, O	1
4704-AL	RING, O	1



FIG. 4706
BRAKE ACCUMULATOR

4706

ATM

85/01

ATM



PART NAME	PART NAME	QTY
CODE		
4706-01	ACCUMULATOR ASSY	1
4706-10	VALVE ASSY, CHECK	1
4706-10A	RING, O (FOR CHECK VALVE)	1
4706-20	ACCUMULATOR SUB-ASSY	1
4706-21	PISTON SUB-ASSY	1
4706-21A	RING, O (FOR PISTON)	1
4706-21B	RING, BACK UP (FOR PISTON)	1
4706-41	COVER, BODY	1
4706-41A	RING, O (FOR BODY COVER)	1
4706-41B	RING, BACK UP (FOR BODY COVER)	1
4706-42	ROD, STROKE SWITCH	1
4706-AA	RING, O	1
4706-AB	BRACKET, ACCUMULATOR, RR	1
4706-AD	BOLT	2
4706-AI	BOLT	7


FIG. 4708
ACCUMULATOR PUMP

4708

ATM

85/01

ATM (ELECTRIC ACCUMULATOR)



PART NAME CODE	PART NAME	QTY
4708-01	PUMP ASSY, PLUNGER, W/MOTOR	1
4708-10	MOTOR ASSY, PUMP	1
4708-11	RELAY ASSY	1
4708-12	VALVE ASSY, PUMP	1
4708-20	HARNES SUB-ASSY, BRAKE PUMP	1
4708-21	SHAFT SUB-ASSY, PUMP	1
4708-22	CYLINDER SUB-ASSY, PUMP	1
4708-30	BRACKET SUB-ASSY, OIL CHARGE PUMP	1
4708-40	BODY, PLUNGER PUMP	1
4708-41	SPRING, COMPRESSION, NO-1	1
4708-42	SPRING, COMPRESSION, NO-2	1
4708-4A	WASHER, WAVE	1
4708-4B	HOLDER, SEAL	1
4708-4C	SEAL, OIL	1
4708-4D	RING, O	1
4708-4E	RING, SNAP	1
4708-4F	RETAINER, SPRING	1
4708-4G	RING, O	1
4708-4H	RING, O	1
4708-4I	FILTER, PUMP	1
4708-4J	PLUG, HOLE	1
4708-4K	RING, O	1
4708-4M	PLUG	1
4708-4N	BOLT	5

4708 001A

FIG. 4714
BRAKE PIPE


4714

ATM

85/01

ATM

ATM (ALL WEATHER)



4714 001

4714 C 3A

FIG. 4714
BRAKE PIPE



4714

ATM

85/01

ATM (ALL WEATHER-ELECTRIC ACCUMULATOR)

ATM (ELECTRIC ACCUMULATOR)



4714-018A

4714-018A


FIG. 4714
BRAKE PIPE

4714

ATM

85/01

2J.5P..ATM (DELUXE CABIN)




4714:079A

PART NAME CODE	PART NAME	QTY
4714-17	SWITCH ASSY. ACCUMULATOR PUMP MOTOR	1
4714-22	PIPE SUB-ASSY. BRAKE, RH NO.1	1
4714-23	PIPE SUB-ASSY. BRAKE, LH NO.1	1
4714-24	PIPE SUB-ASSY. BRAKE, RH NO.2	1
4714-25	PIPE SUB-ASSY. BRAKE, LH NO.2	1
4714-29	PIPE SUB-ASSY. VALVE TO VALVE, NO.1	1
4714-31	PIPE SUB-ASSY. VALVE TO STEERING	1
4714-32	PIPE SUB-ASSY. RETURN, NO.1 (VALVE TO TANK)	1
4714-33	PIPE SUB-ASSY. RETURN, NO.2 (VALVE TO TANK)	1
4714-36	PIPE SUB-ASSY. ACCUMULATOR TO VALVE, NO.1	1
4714-37	PIPE SUB-ASSY. ACCUMULATOR TO VALVE, NO.2	1
4714-38	PIPE SUB-ASSY. RETURN (ACCUMULATOR TO TANK)	1
4714-58	PIPE SUB-ASSY. PUMP TO ACCUMULATOR	1
4714-59	PIPE SUB-ASSY. 4-WAY TO PUMP	1
4714-60	HOSE, HIGH PRESSURE (FOR BRAKE MAIN)	2
4714-61	HOSE, LOW PRESSURE (ACCUMULATOR TO TANK)	1
4714-61A	CLAMP (FOR ACCUMULATOR TO TANK HOSE)	2
4714-71	HOSE, VALVE TO VALVE	1
4714-72	HOSE, VALVE TO STEERING	1
4714-AC	PLUG	1- 2
4714-AE	3-WAY SUB-ASSY	1
4714-AG	CLAMP	1
4714-AJ	CLAMP	1
4714-AK	4-WAY SUB-ASSY. BRAKE	1
4714-AM	4-WAY SUB-ASSY	1
4714-AP	CLAMP	1

4715


85/01



PART NAME	PART NAME	QTY
CODE		
4715-01	BRAKE ASSY, RH	1
4715-02	BRAKE ASSY, LH	1
4715-10	CYLINDER ASSY, WHEEL	2
4715-10-K	CYLINDER O/H KIT, WHEEL	2
4715-20	SHOE SUB-ASSY (FOR FRONT OR UPPER)	2
4715-21	SHOE SUB-ASSY (FOR REAR OR LOWER)	2
4715-22	PLATE SUB-ASSY, BACKING, RH	1
4715-23	PLATE SUB-ASSY, BACKING, LH	1
4715-30	SCREW SUB-ASSY, ADJUSTING, RH	1
4715-31	SCREW SUB-ASSY, ADJUSTING, LH	1
4715-33	CABLE & FITTING SUB-ASSY	2
4715-34	CUP SUB-ASSY, PISTON	2
4715-40	BOOT, WHEEL CYLINDER	4
4715-41	CUP, WHEEL CYLINDER PISTON	4
4715-42	LEVER, AUTOMATIC ADJUSTMENT, RH	1
4715-43	LEVER, AUTOMATIC ADJUSTMENT, LH	1
4715-44	GUIDE, CABLE	2
4715-45	SPRING, SHOE HOLD DOWN	8
4715-46	CUP, SHOE HOLD DOWN	16
4715-47	SPRING, ADJUSTER	2
4715-48	PIN, SHOE HOLD DOWN	8
4715-49	ROD, PUSH	4
4715-51	SPRING, ANCHOR TO SHOE	4
4715-52	COVER, ADJUSTING HOLE	2
4715-53	RING, PARKING LEVER RETAINING	2
4715-AD	PLATE, SHOE GUIDE	2
4715-AE	WASHER, SPRING	2
4715-AF	LEVER SUB-ASSY, PARKING	1
4715-AG	STRUT, LEVER	1
4715-AH	RING, SNAP	2
4715-AJ	SPRING, STRUT TO SHOE	2
4715-AK	CAP, BLEEDER SCREW	2
4715-AL	SCREW, BLEEDER	2
4715-AN	SPRING, WHEEL CYLINDER	2

ATM (1/2)


ATM (ALL WEATHER)



5101-102A

5101-024C

SP. AIR FLOW NOISE) (2/2)



141 094H

493

PART NAME CODE	PART NAME	QTY
5101-30	DRAW-BAR SUB-ASSY	1
5101-31	COVER SUB-ASSY, RADIATOR	1
5101-34	GUARD SUB-ASSY, MUD, RH	1
5101-35	GUARD SUB-ASSY, MUD, LH	1
5101-AA	GUARD, MUD, FRONT	2
5101-AB	BOLT	4
5101-AC	WASHER, WAVE	4
5101-AD	HOSE, LOW PRESSURE	2
5101-AE	CLAMP SUB-ASSY	2
5101-AF	BOLT, HEXAGON	1
5101-AG	WASHER, PLATE	1
5101-AH	BRACKET SUB-ASSY, RADIATOR COVER	1
5101-AI	SPONGE	1
5101-AJ	MUD	1
5101-AK	HOOK SUB-ASSY, WEIGHT	2
5101-AL	NUT, CASTLE	2
5101-AM	WASHER, PLATE	4
5101-AN	WRENCH, WEIGHT BOLT BOX	1
5101-AD	HANDLE, WEIGHT BOLT BOX WRENCH	1
5101-AU	COVER SUB-ASSY, UNDER	1
5101-BZ	GROMMET	1
5101-CL	BLOCK, WINDSHIELD REST	1
5101-DM	COVER SUB-ASSY, REAR	1
5101-DN	COVER SUB-ASSY, RADIATOR CAP	1
5101-EK	RUBBER	1
5101-ED	BRACKET SUB-ASSY (FOR RADIATOR)	1
5101-EV	BOLT, W/WASHER	4
5101-GG	PLATE, RUBBER	1
5101-HU	FORM, RADIATOR COVER	1
5101-HV	NUT, WING	1
5101-IB	FORM, RADIATOR CAP	1
5101-ID	SEAL, RUBBER	1
5101-JL	BRACKET	1
5101-JQ	FORM, WEIGHT, UPR	1
5101-JR	FORM, WEIGHT, SIDE	1-2
5101-JS	FORM, WEIGHT, LWR	1
5101-JT	PLATE, RUBBER	1
5101-JV	FORM, REAR COVER	1
5101-JV	SEAL	1
5101-KC	PLATE, UNDER	1

FIG. 5201
HOOD & HINGE




5201

ATM

85/01

ATM

ATM (ALL WEATHER)






5201 001E


5201 002

2U-5P-ATM (DELUXE CABIN) (EXPORT)

5P-ATM (LOW NOISE)



5201 0055



5201-0544

PART NAME CODE	PART NAME	QTY
5201-10	STAY ASSY, ENGINE (OR BATTERY) HOOD	1
5201-20	HOOD SUB-ASSY, ENGINE (OR BATTERY)	1
5201-20A	SEAL, ENGINE (OR BATTERY) HOOD	1
5201-30	HINGE SUB-ASSY, ENGINE (OR BATTERY) HOOD	1
5201-32	CATCH SUB-ASSY (FOR HOOD)	1
5201-33	STAY SUB-ASSY, ENGINE (OR BATTERY) HOOD	1
5201-40	RUBBER, CUSHION (FOR HOOD)	2
5201-53	HINGE ASSY, HOOD, RH	1
5201-54	HINGE ASSY, HOOD, LH	1
5201-AA	STAY SUB-ASSY, ENGINE HOOD	1
5201-AB	PIN, W/HOLE	1
5201-AC	WASHER, PLATE	1
5201-AD	SCREW, W/TOOTHED WASHER	8
5201-AE	HOOK, HOOD LOCK	1
5201-AF	PLUG, HOLE	4
5201-AG	PLUG, HOLE	2-4
5201-AH	PLATE, HEAT INSULATOR	1
5201-AI	CLIP	1
5201-AS	HINGE SUB-ASSY, HOOD, RH	1
5201-AT	HINGE SUB-ASSY, HOOD, LH	1
5201-AU	INSULATOR	2
5201-BW	SCREW	8
5201-FP	BUSH	4
5201-GS	SHIM	99
5201-HM	WASHER, PLATE	1
5201-HN	WASHER, PLATE	2
5201-HT	PLATE SUB-ASSY, STOPPER	1
5201-IB	PIN, HINGE	2
5201-JD	SEAL	1
5201-JP	SEAL	1
5201-LF	FDRM, ENGINE HOOD	1
5201-LG	SEAL, RUBBER	2
5201-LH	RUBBER	2
5201-LI	SEAL, ENGINE HOOD	1
5201-LJ	FDRM, ENGINE HOOD	1-2
5201-LK	FDRM	1
5201-LL	SHEET, ENGINE HOOD	1
5201-LM	FDRM	1
5201-LN	SEAL, ENGINE HOOD, RR	1
5201-LO	RUBBER, ENGINE HOOD, LOWER	1

FIG. 5301
INSTRUMENT PANEL & FLOOR

5301



ATM

85/01


ATM (1/2)

ATH (ALL WEATHER) (1/2)

(FLOOR TYPE)



5301 050



5301 011

5301

85/01

2J, 5P, *ATM (DELUXE CABIN) [EXPORT, *1/2]



FIG. 5301
INSTRUMENT PANEL & FLOOR




5301

ATM

85/01

2J, 5P..ATM (DELUXE CABIN) (EXPORT..2/2)

5P..ATM (LOW NOISE) (2/2)



5301 106

5301-104

PART NAME	PART NAME	QTY
CODE		
5301-20	PANEL SUB-ASSY, INSTRUMENT	1
5301-23	PROTECTOR SUB-ASSY, FR	1
5301-24	BODY SUB-ASSY	1
5301-30	TOE-BOARD SUB-ASSY, NO.1	1
5301-31	TOE-BOARD SUB-ASSY, NO.2	1
5301-34	CLAMP SUB-ASSY, PAPER	1
5301-72	MAT, FRONT TOE-BOARD	1
5301-73	MAT, REAR TOE-BOARD	1
5301-AA	SCREW	4
5301-AC	PLUG	1
5301-AD	PLUG	1
5301-AE	PLUG	1
5301-AF	WASHER, PLATE	2
5301-AG	SAFETY WALK	1
5301-AK	EDGE, RH	1
5301-AL	EDGE, LH	1
5301-AM	SPRING	1
5301-AN	RUBBER, REAR TOE-BOARD	1
5301-AD	SAFETY WALK	1
5301-AP	PLUG, HOLE	2
5301-AQ	WALK, SAFETY	1
5301-AR	RUBBER, BODY SEAL	1
5301-AS	COVER, TILT CYLINDER SIDE	1
5301-AT	RUBBER, TOE-BOARD SIDE	1
5301-AU	SEAL	2
5301-AV	BRACKET SUB-ASSY, TOE-BOARD REAR	1
5301-AW	CUSHION	8
5301-AX	CUSHION, FRONT	2
5301-AV	RUBBER, CUSHION	2
5301-AZ	CUSHION, REAR	2
5301-BA	SEAL, TILT CYLINDER COVER	1
5301-BB	PLATE, RUBBER SET, REAR	1
5301-BC	RUBBER, TOE-BOARD COVER	1
5301-BD	BRACKET SUB-ASSY, TOE-BOARD	1
5301-BE	RUBBER, TOE-BOARD, UPPER	1
5301-BF	RUBBER, TOE-BOARD, REAR	1
5301-BG	SEAL, RUBBER	1
5301-BI	PLATE, RUBBER SET, FRONT	1
5301-BK	RUBBER, TOE-BOARD, LOWER	1
5301-BL	RUBBER, BRACKET	1
5301-BM	SEAL, RUBBER NO.2	1
5301-BN	SEAL, RUBBER NO.3	1
5301-BO	PAD	1
5301-BR	PAD	2
5301-CK	COVER, OIL	1
5301-CU	RUBBER	1
5301-ED	PLUG	3
5301-EG	PLATE, RUBBER	1
5301-FE	BOLT	2
5301-FN	PLATE	2
5301-GD	INSULATOR	4
5301-LJ	IMAT	1
5301-LK	IMAT	1
5301-LL	IMAT	1
5301-LM	IMAT	1
5301-LN	SEAL	1
5301-LO	IMAT	1
5301-LP	FORM, REAR TOE-BOARD	1
5301-LQ	FORM, FRONT TOE-BOARD	1
5301-L5	FORM, REAR TOE-BOARD	1
5301-LT	RUBBER, TOE-BOARD, FRONT	1
5301-LU	RUBBER, TILT COVER	1
5301-LV	RUBBER, TOE-BOARD, UPPER	1
5301-LW	FORM, SEAT STAND	1

PART NAME	PART NAME	QTY
CODE		
5301-LX	INSULATOR, CAB MOUNTING, UPR	4
5301-LY	PIPE	4

FIG. 5308
DRIVER SEAT


5308

ATM


85/01

ATM

ATM (W/ABSORBER)



5308-001




5308-006A


5308-001-1116

ATM (BUCKET SEAT)

ATH (TURN SEAT)



- ① 94512-12800
- ② 94512-40800
- ③ 94110-40800



5308 001

5308 002


FIG. 5308
DRIVER SEAT

5308

ATM

85/01

ATM (TURN SEAT)



PART NAME	PART NAME	QTY
CODE		
5308-01	SEAT ASSY	1
5308-10	CUSHION ASSY	1
5308-11	TRACK ASSY	1
5308-12	TRACK ASSY, SEAT OUTER, RH	1
5308-13	TRACK ASSY, SEAT OUTER, LH	1
5308-20	SEAT SUB-ASSY, BACK	1
5308-40	FRAME, BACK SEAT	2
5308-AA	RUBBER, VIBRATION ISOLATOR	2
5308-AB	BRACKET, NUMBER PLATE	1
5308-AC	NUT, CAP	2
5308-AD	WIRE	2
5308-AE	WASHER	2
5308-AF	SPRING, TENSION, BACK SEAT	2
5308-AG	LINK	2
5308-AH	PIN	4
5308-AJ	COIL, SPRING	2
5308-AK	E-RING	4
5308-AL	PIN, NO.2	2
5308-AM	SHOCK ABSORBER	1
5308-AN	PIN, NO.3	2
5308-AD	BUSHING	2
5308-AP	ADJUSTER, ROD	1
5308-AQ	RUBBER, SEAT CUSHION	1
5308-AR	HOOK, SEAT CUSHION	10
5308-AY	PIN	1
5308-BB	CUSHION	1
5308-BC	NUT, STOPPER	1
5308-BD	BOLT, W/WASHER	4
5308-BE	RING	1
5308-BF	PLATE SUB-ASSY, TURN SEAT, UPPER	1
5308-BG	BEARING	1
5308-BH	PLATE SUB-ASSY, TURN SEAT, LOWER	1
5308-BI	PLATE	1
5308-BJ	LEVER SUB-ASSY, TURN SEAT	1
5308-BK	SPRING	1
5308-BL	SUPPORT SUB-ASSY, LEVER	1
5308-BM	ROD	1
5308-BN	PIN, SPRING	1
5308-BO	SPRING	1
5308-BP	PIN, SPRING	1
5308-BQ	COLLAR	1
5308-BR	PLATE, CAUTION	1
5308-BS	BUSH, NYLON	2
5308-BT	PIN, COTTER	2


FIG. 5401
HEAD GUARD & ACCESSORY

5401

ATM

85/01

ATM



PART NAME	PART NAME	QTY
CODE		
5401-10	CLOCK ASSY	1
5401-30	SHEET SUB-ASSY, HEAD GUARD	1
5401-31	MIRROR SUB-ASSY, BACK	2
5401-32	BRACKET SUB-ASSY, BACK MIRROR	1
5401-40	REFLECTOR	1
5401-50	HARNESS SUB-ASSY, CLOCK	1
5401-AA	BRACKET SUB-ASSY, LICENCE PLATE	1
5401-AB	WIRE	1
5401-AC	BOLT, HEAD W/HOLE HEXAGON	1
5401-AD	SEAL, ROD	1
5401-AE	PLUG, HOLE	2
5401-AG	CUSHION, RUBBER	2
5401-AH	GROMMET	1
5401-AI	CUSHION, SEAT	2
5401-BX	GUARD, RR COMBINATION LAMP	2

5401 26RB


FIG. 5405
INDICATOR PLATE

5405

ATM

85/06

ATM




PART NAME	PART NAME	QTY
CODE		
5405-AA	PLATE, CAUTION	2
5405-AC	PLATE, CAUTION	2
5405-AD	PLATE, CAUTION	1
5405-AF	PLATE, SHIFT LEVER INDICATOR	1
5405-AG	PLATE, LOAD INDICATOR	1
5405-AH	PLATE, LIFT INDICATOR	1
5405-AI	PLATE, TILT INDICATOR	1
5405-AJ	PLATE, CAUTION	1
5405-AK	PLATE, INDICATOR	1
5405-AL	TOYOTA MARK	1-2
5405-AM	PLATE, SERVICE INDICATOR	1
5405-AN	PLATE, INDICATOR	1
5405-AD	PLATE, INDICATOR	1
5405-AP	STRIP	2
5405-AQ	PLATE, CAPACITY INDICATOR	2
5405-AR	PLATE, CAUTION	1
5405-AS	PLATE, INDICATOR	1
5405-AT	PLATE, CAUTION	1
5405-AU	RIVET	4
5405-AX	PLATE, DISCONNECT SWITCH INDICATOR	1
5405-BC	MARK, UL	2
5405-BW	MARK, SYMBOL	2
5405-BX	PLATE, INDICATOR	1
5405-CC	PLATE, CAUTION	1
5405-CM	MARK, TURBO	2
5405-CN	PLATE, INDICATOR	1
5405-DE	PLATE, INDICATOR	1
5405-EL	MARK, TOYOTA	1

5405 011E

5501

85/01

ATM (ALL WEATHER)



NSQ 1 002

FIG. 5501
STEEL CABIN


5501

ATM

85/01

2J,SP.,ATM (DELUXE CABIN) (EXPORT..1/2)

2J,SP.,ATM (DELUXE CABIN) (EXPORT..2/2)



5501-024B

5501 C25

PART NAME	PART NAME	QTY
CODE		
5501-10	WINDOW ASSY, DOOR, RH	1
5501-11	WINDOW ASSY, DOOR, LH	1
5501-15	HINGE ASSY, DOOR	2
5501-20	WINDOW SUB-ASSY, FR, FIXED	1
5501-21	WINDOW SUB-ASSY, RR, FIXED	1
5501-22	WINDOW SUB-ASSY, UPR, FIXED	1
5501-25	DOOR SUB-ASSY, RH	1
5501-26	DOOR SUB-ASSY, LH	1
5501-39	BOARD, DOOR TRIM, LWR	1
5501-40	BOARD, DOOR TRIM, FR, RH	1
5501-41	BOARD, DOOR TRIM, FR, LH	1
5501-42	BOARD, DOOR TRIM, RR, RH	1
5501-43	BOARD, DOOR TRIM, RR, LH	1
5501-60	BOARD, DOOR TRIM, UPR	1
5501-AA	SCREW	10
5501-AB	SEAL, RUBBER	4
5501-AC	SEAL, RUBBER	9
5501-AD	HINGE SUB-ASSY, NO.1	4
5501-AE	HINGE SUB-ASSY, NO.2	4
5501-AF	PIN, HINGE	4
5501-AG	BUSHING	8
5501-AH	BELT, DOOR STOPPER	2
5501-AI	BRACKET, BELT	2
5501-AJ	CLIP	26
5501-AK	BOARD, ROOF TRIM	1
5501-AL	BOARD, ROOF TRIM	1
5501-AM	CLIP	5
5501-AN	PLATE, ROOF TRIM BOARD SET	1
5501-AD	WEATHER STRIP, DOOR, RH	1
5501-AP	WEATHER STRIP, DOOR, LH	1
5501-AT	FRAME SUB-ASSY, FRONT FIXED WINDOW	2
5501-AU	WEDGE, RUBBER	2
5501-AV	GLASS, FRONT FIXED	1
5501-AW	FRAME SUB-ASSY, REAR FIXED WINDOW	1
5501-AX	WEDGE, RUBBER	1
5501-AY	GLASS, REAR FIXED	1
5501-AZ	FRAME SUB-ASSY, UPPER FIXED WINDOW	1
5501-BA	WEDGE, RUBBER	1
5501-BB	GLASS, UPPER FIXED	1
5501-BC	FRAME SUB-ASSY, SIDE WINDOW	1
5501-BD	FRAME SUB-ASSY, INNER, FRONT	1
5501-BE	FRAME SUB-ASSY, INNER	2
5501-BF	FRAME, SIDE WINDOW, UPPER	1
5501-BG	WEATHER STRIP, OUTER	2
5501-BH	WEATHER STRIP, INNER	2
5501-BI	WEDGE, RUBBER	2
5501-BJ	CATCH HANDLE ASSY, SIDE WINDOW	2
5501-BK	BRACKET, SIDE WINDOW, INNER, SIDE	4
5501-BL	BRACKET, CATCH	4
5501-BM	BRACKET, SIDE WINDOW, SIDE	4
5501-BN	SPACER, SIDE WINDOW, FRONT SIDE	2
5501-BO	GLASS, DOOR FIXED WINDOW	1
5501-BP	GLASS, DOOR SLIDE WINDOW	1
5501-CC	WEATHERSTRIP	2
5501-CM	RUBBER, CUSHION	2
5501-EZ	PLATE	2
5501-FA	SPACER	2
5501-FB	SPONGE	1
5501-FC	BOARD, RR PROTECTOR TRIM, NO.1	1
5501-FD	BOARD, RR PROTECTOR TRIM, NO.2	1
5501-FE	BOARD, RR PROTECTOR TRIM, NO.3	1
5501-FF	BOARD, RR PILLAR	1
5501-FG	BOARD, STAY	1
5501-FH	RECEPTACLE ASSY, RR	1

PART NAME	PART NAME	QTY
CODE		
5501-FI	SCREW	6
5501-FI	BRACKET, BELT	2
5501-FM	PIN, DOOR STOPPER	2


FIG. 5502
CANVAS CABIN & FRONT GLASS

5502

ATM

85/01

ATM (FRONT GLASS)




PART NAME	PART NAME	QTY
CODE		
5502-02	PANEL ASSY, FRONT GLASS	1
5502-20	PANEL SUB-ASSY, FRONT GLASS	1
5502-40	GLASS, WINDSHIELD	1
5502-50	WEATHER STRIP	1
5502-AB	SEAL, RUBBER	1
5502-AD	RUBBER, WINDSHIELD	2
5502-AV	BOLT, W/WASHER	11
5502-CR	PLUG, HOLE	1

5502.003 6

5504

85/01

2J,5P.-ATM (DELUXE CABIN) (EXPORT)




5504 013A

PART NAME CODE	PART NAME	QTY
5504-10	LOCK ASSY, DOOR, RH	1
5504-11	LOCK ASSY, DOOR, LH	1
5504-12	HANDLE ASSY, FRONT DOOR OUTSIDE, RH	1
5504-13	HANDLE ASSY, FRONT DOOR OUTSIDE, LH	1
5504-14	HANDLE ASSY, DOOR INSIDE	2
5504-19	CYLINDER & KEY SET, DOOR LOCK, LH	1
5504-20	LINK SUB-ASSY, DOOR W/ROD, RH	1
5504-21	LINK SUB-ASSY, DOOR W/ROD, LH	1
5504-30	GRIP SUB-ASSY, ASSIST	2
5504-40	STRIKER, DOOR LOCK, RH	1
5504-41	STRIKER, DOOR LOCK, LH	1
5504-AA	CASE, DOOR INSIDE HANDLE	2
5504-AB	SCREW	2
5504-AC	PLUG, ASSIST GRIP	4
5504-AD	SCREW, W/WASHER	4
5504-AE	BUSHING	2
5504-AF	JOINT, ADJUSTING	2
5504-AG	BUSHING	1
5504-AH	SHIM, DOOR LOCK STRIKER	4
5504-AK	CLAMP	1
5504-BO	KNOB	1
5504-BI	PAD	1
5504-BJ	SNAP	1
5504-BL	BUSH	2
5504-BT	LINK SUB-ASSY, DOOR LOCK	1
5504-BU	BOSS SUB-ASSY, DOOR LOCK LINK	1
5504-BV	ROD, DOOR LOCK, RH	1
5504-BW	ROD, DOOR LOCK, LH	1

5601

85/01


(DELUXE CABIN)



PART NAME	PART NAME	QTY
5601-10	HARNNESS ASSY, WIRING	1
5601-20	HARNNESS SUB-ASSY, MAIN	1
5601-21	HARNNESS SUB-ASSY, PANEL	1
5601-22	HARNNESS SUB-ASSY, RR	1
5601-27	HARNNESS, RR	2
5601-40	FUSE	2
5601-41	RESISTOR	1
5601-44	CORD, HEAD LAMP	2
5601-AA	CORD, OIL PRESSURE	1
5601-AB	CORD, WATER TEMPERATURE	1
5601-AC	CORD, TORCON HEAT GAGE	1
5601-AE	HARNNESS, WIRE	1
5601-AF	CLAMP	1
5601-AH	GROMMET	4
5601-AI	TUBE	3
5601-AJ	WIRE, LAMP BRACKET EARTH	2
5601-AK	COLLAR	4
5601-AL	WASHER, RUBBER	4
5601-AM	CLAMP	6
5601-AN	CORD, WORKING LAMP	1
5601-AQ	COVER, WIRING HARNNESS	1
5601-AP	CORD, SPEEDMETER	1
5601-AQ	CORD, SPEEDMETER	1
5601-AR	CORD, SPEEDMETER	1
5601-AS	BOLT, W/WASHER	2
5601-AT	PLATE SUB-ASSY	1
5601-AU	SPONGE	2
5601-AV	GROMMET	1
5601-AW	SEAL, HARNNESS HOLE	1
5601-AX	PLATE, HARNNESS HOLE	1
5601-AY	GROMMET	1
5601-AZ	CORD, LICENCE LAMP	1
5601-BA	CLAMP	1
5601-BB	CLIP	1
5601-BC	CLAMP	6
5601-BE	CLAMP	1
5601-BG	CLAMP	1
5601-BJ	CLAMP	2
5601-BK	GROMMET	1
5601-BL	FUSE BLOCK ASSY	1
5601-BM	BRACKET SUB-ASSY, FUSE BLOCK	1
5601-BN	FUSIBLE, LINK	1
5601-BD	COVER, FUSE BLOCK	1
5601-BR	HARNNESS, OIL PRESSURE	1
5601-BS	HARNNESS, FUEL CUT	1
5601-CB	HARNNESS SUB-ASSY, AIR CLEANER	1
5601-CD	HOLDER, FUSE	1
5601-CZ	CASE SUB-ASSY	2
5601-DA	CORD, AMMETER	2
5601-ED	CORD, DOOR SWITCH	2
5601-EP	GROMMET	1
5601-EQ	WASHER, RUBBER	2
5601-EU	CORD, HOUR METER	1

5501 009C

ATM



(DELUXE CABIN)
(ALL WEATHER CAB)


















FIG. 5611
LAMP

5611

ATM

B5/01

PART NAME	PART NAME	QTY
CODE		
5611-01	LAMP ASSY. HEAD	2
5611-01A	UNIT, SEALORFAM (FOR HEAD LAMP)	2
5611-02	LAMP ASSY. WORKING	1
5611-02A	UNIT, SEALORFAM (FOR WORKING LAMP)	1
5611-03	LAMP ASSY. FLASHER	2
5611-03A	BULB (FOR FLASHER LAMP)	2
5611-03B	LENS (FOR FLASHER LAMP)	2
5611-04	LAMP ASSY. REAR COMBINATION	2
5611-04A	BULB (FOR REAR COMBINATION LAMP)	2
5611-04B	LENS (FOR REAR COMBINATION LAMP)	2
5611-05	LAMP ASSY. LICENCE	1
5611-05A	BULB (FOR LICENCE LAMP)	1
5611-05B	LENS (FOR LICENCE LAMP)	1
5611-07	LAMP ASSY. CLEARANCE	2
5611-07A	BULB (FOR CLEARANCE LAMP)	2
5611-07B	LENS (FOR CLEARANCE LAMP)	2
5611-20	LAMP ASSY. ACCUMULATOR PILOT	1
5611-23	LAMP ASSY. OIL PRESSURE PILOT	1
5611-24	LAMP ASSY. CHARGE WARNING	1
5611-25	LAMP ASSY. WORKING PILOT	1
5611-26	LAMP ASSY. COMBINATION PILOT	1
5611-26A	BULB (FOR COMBINATION PILOT LAMP)	2
5611-33	LAMP ASSY. PILOT (FOR SEDIMENTER)	1
5611-34	LAMP ASSY. PILOT (FOR AIR CLEANER)	1
5611-39	LAMP ASSY. PILOT (FOR GLOW)	1
5611-41	LAMP ASSY. ROOM	1
5611-AA	RING	2
5611-AB	SCREW	2
5611-AC	SPRING, SET	6
5611-AD	SPACER	2
5611-AE	SPRING, SET	2
5611-AF	CORD, HEAD LAMP	2
5611-AG	BOLT	2
5611-AI	SCREW	4
5611-AK	PACKING	4
5611-AL	SCREW	4
5611-AM	SCREW	2
5611-AN	SCREW, TAP	2
5611-AO	PACKING	1
5611-AP	GASKET	1
5611-AQ	HOUSING	1
5611-AR	SCREW	2
5611-CE	SCREW	4
5611-CH	SPACER	1


FIG. 5612
LAMP BRACKET

5612


ATM

85/01

ATM




(ALL WEATHER CAB)



(L.P.G.)

(UL)



5612-001C

PART NAME CODE	PART NAME	QTY
5612-AA	PROTECTOR SUB-ASSY, HEAD LAMP	1
5612-AB	BRACKET SUB-ASSY, HEAD LAMP	1
5612-AC	BRACKET, BACK LAMP	1
5612-AE	COVER, CLEARANCE LAMP	2
5612-AF	GUARD, COMBINATION	2
5612-AG	BRACKET, FLASHER LAMP	1
5612-AH	BRACKET, REAR LAMP	1- 2


FIG. 5701
METER & SWITCH

5701

ATM

85/01

ATM



PART NAME

CODE

PART NAME

QTY

5701-01	REGULATOR ASSY, GENERATOR	1
5701-02	RELAY ASSY, STARTER	1
5701-03	RELAY ASSY, GLOW PLUG	1
5701-05	RELAY ASSY, FLASHER	1
5701-07	UNIT ASSY, FUEL	1
5701-09	BUZZER ASSY, ACCUMULATOR INDICATOR	1
5701-10	HORN ASSY	1
5701-11	BUZZER ASSY, BACK	1
5701-13	SWITCH ASSY, TURN SIGNAL	1
5701-13A	SWITCH ASSY, MICRO (FOR TURN SIGNAL SWITCH)	2
5701-14	SWITCH ASSY, LIGHT CONTROL	1
5701-15	SWITCH ASSY, IGNITION STARTER	1
5701-17	SWITCH ASSY, NEUTRAL SAFETY	1
5701-17A	GASKET (FOR NEUTRAL SAFETY SWITCH)	1
5701-18	SWITCH ASSY, HORN	1
5701-18A	CONTACT, HORN	1
5701-19	SWITCH ASSY, BACK-UP LAMP	1
5701-20	GAGE ASSY, FUEL	1
5701-21	GAGE ASSY, WATER TEMPERATURE (ENGINE)	1
5701-22	GAGE ASSY, TEMPERATURE (TORCON)	1
5701-23	GAGE ASSY, OIL PRESSURE (ENGINE)	1
5701-24	METER ASSY, HOUR	1
5701-29	GAGE ASSY, OIL PRESSURE SENDER (ENGINE)	1
5701-30	GAGE ASSY, WATER TEMPERATURE SENDER (ENGINE)	1
5701-31	GAGE ASSY, TEMPERATURE SENDER (TORCON)	1
5701-32	SWITCH ASSY, OIL PRESSURE (ENGINE)	1
5701-33	SWITCH ASSY, STOP LAMP	1
5701-35	SWITCH ASSY, ACCUMULATOR PILOT	1
5701-36	SWITCH ASSY, DISCONNECT	1
5701-46	SWITCH ASSY, VACUUM (FOR AIR CLEANER)	1
5701-51	TIMER, PREHEATING	1
5701-77	SWITCH ASSY, COURTESY LAMP	2
5701-AA	BRACKET SUB-ASSY, HORN	1
5701-AB	BUSHING	1
5701-AC	PLATE, BACK UP LAMP SWITCH	1
5701-AD	CLAMP, BACK UP LAMP SWITCH	1
5701-AE	NUT, HEXAGON	1
5701-AF	HARNESS ASSY	1
5701-AG	BODY, SWITCH	1
5701-AH	HOLDER, HORN POINT	1
5701-AI	SPRING, HORN CONTACT	1
5701-AJ	COVER	1
5701-AK	LOCKING BLOCK	1
5701-AL	COVER, RUBBER	1
5701-AM	HARNESS ASSY	1
5701-AN	ACTUATOR	2
5701-AO	PLATE, SWITCH	1

FIG. 5706
SPEEDOMETER & SPEED ALARM




5706

ATM

85/01

ATM (SPEEDOMETER)

ATM (SPEED ALARM)



5706-001

5706-002

FIG. 5706
SPEEDOMETER & SPEED ALARM

5706

ATM

85/01

PART NAME CODE	PART NAME	QTY
5706-10	SPEEDOMETER ASSY	1
5706-13	PICK-UP ASSY, SPEEDOMETER	1
5706-13A	GASKET (FOR SPEEDOMETER PICK-UP)	1
5706-14	BOX ASSY, SPEED ALARM	1
5706-15	RELAY ASSY	1
5706-20	HARNESS SUB-ASSY, SPEED ALARM	1
5706-AA	BRACKET, SPEEDMETER	1
5706-AB	BRACKET SUB-ASSY, SPEED ALARM	1
5706-AC	CLAMP	1
5706-AD	PLATE, SPEED INDICATOR	1


FIG. 5801
WIPER MOTOR & BLADE

5801

ATM

85/06

ZJ, 5P., ATM (DELUXE CABIN) (EXPORT)



PART NAME

CODE

PART NAME

QTY


5801-10	MOTOR ASSY, WIPER	1
5801-11	SWITCH ASSY, WIPER	1
5801-12	RELAY ASSY (FOR WIPER)	1
5801-13	WASHER ASSY, WINDSHIELD	1
5801-14	LINK ASSY, WIPER	1
5801-15	SWITCH ASSY, WIPER	1
5801-30	BLADE SUB-ASSY, WIPER	1
5801-31	ARM SUB-ASSY, WIPER	1
5801-AA	HARNESSE, WIPER	1
5801-AB	COVER, WIPER	1
5801-AC	ADAPTOR, NOZZLE	1
5801-AC	HOSE	1
5801-AF	BRACKET SUB-ASSY, WASHER TANK	1
5801-AG	COVER, WIND SHIELD WASHER TANK	1
5801-AH	NUT	1
5801-AI	WASHER	1
5801-AJ	CAP, SEAL	1
5801-AK	NUT, CAP	1
5801-AM	TANK ASSY, WASHER	1
5801-AN	NOZZLE ASSY, WASHER	1
5801-AD	CORD, WASHER	1
5801-AP	HARNESSE, WASHER	1
5801-AZ	NUT	1
5801-BA	WASHER, CUP	1
5801-BB	GROMMET	1
5801-BD	BRACKET, WIPER MOTOR	1
5801-BE	BRACKET SUB-ASSY, SWITCH	1

5801 030A


5802

85/01

ATM (ALL WEATHER)



{5P}



5002-QAN


FIG. 5802
HEATER

5802


ATM

85/01


2J.SP..ATM (DELUXE CABIN) (EXPORT)



(21)



(5P)



740/01

PART NAME	PART NAME	QTY
CODE		
5802-01	HEATER & ACCESSORY ASSY	1
5802-02	HEATER ASSY	1
5802-10	MOTOR ASSY	1
5802-11	SWITCH ASSY, HEATER	1
5802-20	UNIT SUB-ASSY, RADIATOR	1
5802-30	BODY SUB-ASSY, TILT	1
5802-40	HOSE, NO. 1	1
5802-41	HOSE, NO. 2	1
5802-42	HOSE, NO. 3	1-2
5802-43	HOSE, NO. 4	1
5802-44	HOSE, NO. 5	1
5802-46	PIPE, NO. 1	1
5802-47	PIPE, NO. 2	1
5802-48	PIPE, NO. 3	1
5802-AA	CLAMP	2-8
5802-AB	CLAMP	1-2
5802-AC	CLAMP	1
5802-AD	JOINT	1
5802-AE	JOINT	1
5802-AG	BUSHING	1-4
5802-AH	BAND	1
5802-AI	BUSHING	1-3
5802-AJ	CLAMP	1
5802-AK	PROTECTOR	2
5802-AL	PLATE, CAUTION	1
5802-AM	3-WAY	1
5802-AN	ELBOW	1
5802-AO	BRACKET SUB-ASSY, PIPE	1
5802-AP	HARNES SUB-ASSY, HEATER	1
5802-AQ	COVER, HEATER	1
5802-AR	BOLT	2
5802-AS	WASHER, WAVE	2
5802-AT	COVER, PIPE	1
5802-AU	VENT, HEATER	1
5802-AV	COVER, WATER PIPE	1
5802-AW	GROMMET	1
5802-AX	GUIDE, WATER PIPE	1
5802-AY	CLAMP	1
5802-AZ	ORNAMENT, CONTROL	1
5802-BA	GROMMET	1
5802-BB	COVER	1
5802-BC	SEAL	1
5802-BU	COVER, EDGE	1
5802-CG	CLAMP	1
5802-CR	RUBBER	1
5802-DA	SPONGE	1
5802-DI	TUBE, SPIRAL	1
5802-DJ	PIPE SUB-ASSY, WATER	1
5802-DK	COVER SUB-ASSY, HEATER	1
5802-DL	SCREW	2
5802-DM	RUBBER, HEATER PIPE	1


FIG. 5805
DEFROSTER

5805

ATM



85/01

ATM (ALL WEATHER)




PART NAME	
CODE	PART NAME
5805-20	DUCT SUB-ASSY, AIR
5805-21	BOX SUB-ASSY, DEFROSTER
5805-40	HOSE, DEFROSTER
5805-AA	ORNAMENT, CONTROL
5805-AB	CLAMP
5805-AC	WASHER, PLATE
	QTY
	1
	1
	1
	1
	2
	4

ATM (OK MONITOR)



(2)T. ALL WEATHER



PART NAME	PART NAME	QTY
CODE		
5806-02	OK MONITOR ASSY	1
5806-02A	BULB (FOR OK MONITOR)	6
5806-02B	LENS (FOR OK MONITOR)	1
5806-02C	GLASS (FOR OK MONITOR)	1
5806-11	SWITCH ASSY, VACUUM	1
5806-12	SWITCH ASSY, COURTESY LAMP (FOR PARKING)	1
5806-13	SWITCH ASSY, FUEL LEVEL	1
5806-13A	RING, D (FOR FUEL LEVEL SWITCH)	1
5806-14	SWITCH ASSY, LEVEL WARNING (FOR BATTERY)	1
5806-15	SWITCH ASSY, LEVEL WARNING (FOR BRAKE)	1
5806-30	HARNESS SUB-ASSY, MONITOR	1
5806-31	HARNESS SUB-ASSY, AIR CLEANER	1
5806-40	BRACKET SUB-ASSY, OK MONITOR	1
5806-41	STRAINER, MASTER CYLINDER RESERVOIR	1
5806-AA	HOOD	1
5806-AB	CASE	1
5806-AC	PLATE SUB-ASSY	1
5806-AD	SOCKET	6
5806-AE	PACKING	1
5806-AF	CASE, LOWER	1
5806-AG	BUSH	1
5806-AH	KNOB	1
5806-AI	SCREW, TAPPING	1
5806-AJ	SCREW, TAPPING	2

MEMO

silverhorn.co.uk

MEMO

Silverhorn.CO.UK


MEMO

Silverhorn.co.uk










6101

85/01

PART NAME	PART NAME	QTY
CODE		
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	2
6101-AG	PIN, SPRING	1
6101-AK	STOPPER, REAR CYLINDER	1
6101-BH	CAP, MAST SUPPORT	2





5101 0280




F (LOW NOISE)

(W/RUBBER)



(W/RUBBER)



PART NAME	PART NAME	QTY
CODE		
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4
6301-AB	PLATE, SIDE	2
6301-AG	BOLT	4


FIG. 6302
CHAIN & CHAIN WHEEL

6302

F

85/01

F



PART NAME	PART NAME	QTY
CODE		
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21A	NUT, CHAIN ADJUST (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO. 1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2
6302-AJ	SPACER	2

6302 025


FIG. 6505
FRONT LIFT CYLINDER

6505

F

85/01

F



PART NAME CODE	PART NAME	QTY
6505-01	CYLINDER ASSY, LIFT	1
6505-01K	CYLINDER D/H KIT, LIFT	1
6505-20	CYLINDER SUB-ASSY, LIFT	1
6505-21	ROD SUB-ASSY, LIFT CYLINDER	1
6505-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6505-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6505-AA	SEAL, DUST	1
6505-AB	RING, O	1
6505-AC	RING, BACK UP	1
6505-AD	RING, O	1
6505-AE	RING, BACK UP	1
6505-AF	PACKING, U	1
6505-AH	BUSHING	1
6505-AI	PLUG	1

6505-001


FIG. 6506
REAR LIFT CYLINDER

6506

F

85/01

F



6506 001

PART NAME	CODE	PART NAME	QTY
6506-01	CYLINDER ASSY., LIFT		1
6506-01K	CYLINDER O/H KIT, LIFT		1
6506-10	VALVE ASSY., FLOW REGULATOR		1
6506-20	CYLINDER SUB-ASSY., LIFT		1
6506-21	ROD SUB-ASSY., LIFT CYLINDER		1
6506-30	GUIDE SUB-ASSY., CYLINDER ROD		1
6506-40	PISTON, LIFT CYLINDER		1
6506-42	SLEEVE, LIFT CYLINDER ROD GUIDE		1
6506-AA	SEAL, DUST		1
6506-AB	RING, BACK UP		1
6506-AC	PACKING, U		1
6506-AD	RING, O		1
6506-AE	RING, BACK UP		1
6506-AF	RING, O		1
6506-AG	SPACER, LIFT CYLINDER		1
6506-AH	RING, SPACER		1
6506-AI	RING, WEAR		1
6506-AJ	RING, SHAFT SNAP		1
6506-AK	PLUG		1
6506-AL	RING, O		1

F (TABLE OF TILT RANGE)

テイルト角度表
TABLE OF TILT RANGE

生産期間 PROD DATE	型式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DISCRIPTION	テイルト角 TILT RANGE
7804-8002	V	SINGLE	H3000-H3700		60 - 120
7804-8002	V	SINGLE	H4000-H5000		60 - 60
7804-8002	V	DOUBLE	H3000-H4500		60 - 120
7804-8002	V	DOUBLE	H5000		60 - 60
8002	V	SINGLE	H2000-H3700		60 - 120
8002	V	SINGLE	H4000-H5000		60 - 60
8002-8205	V	DOUBLE	H2000-H3700		60 - 120
8002-8205	V	DOUBLE	H4000-H5000		60 - 60
8205	V	DOUBLE	H2000-H4500		60 - 120
8205	V	DOUBLE	H5000		60 - 60
8002	V		H2000-H2500	ALL WEATHER CAB	60 - 60
7804	M, F	SINGLE	H2000-H3700		60 - 120
7804	M, F	SINGLE	H4000-H5000		60 - 60
7804	M, F	DOUBLE	H2000-H4500		60 - 120
7804	M, F	DOUBLE	H5000		60 - 60
7804	M, F		H2000	ALL WEATHER CAB	60 - 60
7804	F		H2500-H5000	ALL WEATHER CAB	60 - 100
7804	FV		H2000-H3700		60 - 120
7804	FV	SINGLE	H4000-H5000		60 - 60
7804-8205	FV	DOUBLE	H2000-H3700		60 - 120
7804-8205	FV	DOUBLE	H4000-H5000		60 - 60
8205	FV	DOUBLE	H2000-H4500		60 - 120
8205	FV	DOUBLE	H5000		60 - 60
7804	FV		H2000-H2500	ALL WEATHER CAB	60 - 60
7804	FSV, FS		H3700-H4700	DOMESTIC	60 - 60
7804	FSV, FS		H5000-H6000	DOMESTIC	30 - 60
7804	FSV, FS		H3700-H6000	EXPORT	60 - 60
8205	SV	SINGLE	H3000-H3700		60 - 120
8205	SV	SINGLE	H4000		60 - 60
8205	SV	DOUBLE	H3000-H4000		60 - 120
8407	F		H2500-H5000	DELUXE CABIN	60 - 100
8407	F, M		H2000	DELUXE CABIN	60 - 60
8407	FV, V, SV		H2000-H2500	DELUXE CABIN	60 - 60
8407	FV, M, SV, V	SINGLE	H4000-H5000	DELUXE CABIN	60 - 60
8407	FV, M, SV, V	DOUBLE	H5000	DELUXE CABIN	60 - 60

6511-007A


FIG. 6511
TILT CYLINDER

6511

F

85/01

F



PART NAME

PART NAME

QTY

CODE

6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	2
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AK	SHIM, TILT CONTROL	99
6511-AL	SPACER, TILT CONTROL	2
6511-AM	RING, O	4
6511-AN	COLLAR	4
6511-BN	WASHER, PLATE	2


6701-6701
OIL PUMP

6701

F

85/01


F



6701-0084

PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-44A	PACKING, OIL PUMP	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4- 8
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2

F



F (3-WAY)





FIG. 6705
OIL CONTROL VALVE

6705

F

85/01

F (4-WAY)



6705 251

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, INLET, NO.2	1
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AO	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	4
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AW	SPRING, COMPRESSION	1
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BK	VALVE, CHECK	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	3
6705-DW	PLUG	1
6705-GN	BOLT, W/WASHER	4

FIG. 6709
OIL CONTROL VALVE LINK


6709

F

85/01

F

F (3-WAY)



6709 116H

6709 12P


6709 OIL CONTROL VALVE LINK

6709

F

85/01


F (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-32	ROD SUB-ASSY	1
6709-33	ROD SUB-ASSY	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	SCOT, CONTROL VALVE LINK, NO.1	2
6709-49	SCOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AW	BOLT	4
6709-BZ	WASHER, PLATE	2

6709-008A

F



PART NAME	PART NAME	QTY
CODE		
6801-10	FILTER ASSY, SUCTION	1
6801-11	FLANGE, RETURN	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	4
6801-46	FITTING (FOR LIFT CYLINDER)	1
6801-55	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-76	INSULATOR SUB-ASSY, BODY MOUNTING	1
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AD	BOLT	1
6801-AE	RING, O	1
6801-AF	FLANGE, SPLIT	1
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	1
6801-AJ	BRACKET, HIGH PRESSURE HOSE	1
6801-AK	CLAMP	1
6801-AL	COVER	1
6801-40	RING, O	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-BH	CAP, OIL CLUTCH PIPE	1
6801-BI	CLAMP, HOSE	1
6801-BP	CLAMP	1
6801-BZ	PLATE	1
6801-FE	BOLT	1
6801-FF	WASHER	1
6801-FV	SUPPORT SUB-ASSY, OIL FILTER	1
6801-HK	BOLT	1
6801-HL	BOLT	1
6801-HM	WASHER	1
6801-HN	WASHER	1
6801-HO	NUT	1


FIG. 6802
MAST PIPING

6802

F

85/01

F



PART NAME CODE	PART NAME	QTY
6802-30	PIPE SUB-ASSY. NO.1 (FRONT LIFT)	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT)	2
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AB	FITTING	1
6802-AC	RING, O	1

6802 001


MEMO

silverhorn.co.uk

6101


85/01

PART NAME	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-22	MAST SUB-ASSY, MIDDLE	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-31	STRIP SUB-ASSY, MIDDLE MAST	2
6101-31A	SHIM, MIDDLE MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-42	ROLLER, LIFT (FOR MIDDLE MAST UPPER)	2
6101-42A	SHIM, LIFT ROLLER (FOR MIDDLE MAST UPPER)	99
6101-43	ROLLER, LIFT (FOR MIDDLE MAST LOWER)	2
6101-43A	SHIM, LIFT ROLLER (FOR MIDDLE MAST LOWER)	99
6101-AF	COVER, ROLLER	2
6101-AG	PIN, SPRING	1
6101-AK	STOPPER, REAR CYLINDER	1
6101-AL	TOP, LIFT CYLINDER	1
6101-BH	CAP, MAST SUPPORT	2








4164-001-1E22

FS



(L/BACKREST)



6301 004C

FIG. 6301.



6301

FS


85/06

F5 (LOW NOISE)

(W/RUBBER)




(W/RUBBER)



PART NAME	PART NAME	QTY
CODE		
6301-03	BRACKET ASSY, LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	2
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4
6301-AB	PLATE, SIDE	2
6301-AQ	BOLT	4

FS



PART NAME	PART NAME	QTY
CODE		
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21A	NUT, CHAIN ADJUST (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-22	CHAIN SUB-ASSY (REAR)	2
6302-22K	BOLT KIT, CHAIN ANCHOR, NO.1 (REAR)	2
6302-22L	BOLT KIT, CHAIN ANCHOR, NO.2 (REAR)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-42	WHEEL, CHAIN (REAR)	2
6302-42A	RING, SHAFT SNAP (FOR CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2
6302-AI	SPACER	2
6302-AK	PLATE, CHAIN ANCHOR	2
6302-AL	COVER, CHAIN WHEEL	4
6302-AQ	BOLT	2


FIG. 6505
FRONT LIFT CYLINDER

6505

FS

85/01

FS



PART NAME CODE	PART NAME	QTY
6505-01	CYLINDER ASSY, LIFT	1
6505-01K	CYLINDER O/H KIT, LIFT	1
6505-20	CYLINDER SUB-ASSY, LIFT	1
6505-21	ROD SUB-ASSY, LIFT CYLINDER	1
6505-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6505-42	BLEEVE, LIFT CYLINDER ROD GUIDE	1
6505-AA	SEAL, DUST	1
6505-AB	RING, O	1
6505-AC	RING, BACK UP	1
6505-AD	RING, O	1
6505-AE	RING, BACK UP	1
6505-AF	PACKING, U	1
6505-A1	PLUG	1

6505 003


FIG. 6506
REAR LIFT CYLINDER

6506

FS

85/01

FS



6506 002

PART NAME

CODE

PART NAME

QTY

6506-01	CYLINDER ASSY, LIFT	1
6506-01K	CYLINDER O/H KIT, LIFT	1
6506-10	VALVE ASSY, FLOW REGULATOR	1
6506-20	CYLINDER SUB-ASSY, LIFT	1
6506-21	ROD SUB-ASSY, LIFT CYLINDER	1
6506-30	GUIDE SUB-ASSY, CYLINDER ROD	1
6506-40	PISTON, LIFT CYLINDER	1
6506-41	COVER, LIFT CYLINDER	1
6506-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6506-AA	SEAL, DUST	1
6506-AC	PACKING, U	1
6506-AF	RING, O	1
6506-AG	SPACER, LIFT CYLINDER	1
6506-AM	RING, WEAR	1
6506-AL	RING, O	1
6506-AM	RING, STOPPER	1
6506-AN	RING, BACK UP	1
6506-AD	PACKING	1
6506-AP	RING, BACK UP	1
6506-AQ	RING, O	1
6506-AR	RING, SHAFT SNAP	1

FS (TABLE OF TILT RANGE)

テイルト角度表
TABLE OF TILT RANGE

生産期間 PROD DATE	型 式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DISCRIPTION	テイルト角 TILT RANGE
7804-8002	V	SINGLE	H3000-H3700		60 - 120
7804-8002	V	SINGLE	H4000-H6000		60 - 80
7804-8002	V	DOUBLE	H3000-H4500		60 - 120
7804-8002	V	DOUBLE	H5000		60 - 60
8002	V	SINGLE	H2000-H3700		60 - 120
8002	V	SINGLE	H4000-H5000		60 - 60
8002-8205	V	DOUBLE	H2000-H3700		60 - 120
8002-8205	V	DOUBLE	H4000-H5000		60 - 60
8205	V	DOUBLE	H2000-H4500		60 - 120
8205	V	DOUBLE	H5000		60 - 60
8002	V		H2000-H2500	ALL WEATHER CAB	60 - 80
7804	M, F	SINGLE	H2000-H3700		60 - 120
7804	M, F	SINGLE	H4000-H5000		60 - 60
7804	M, F	DOUBLE	H2000-H4500		60 - 120
7804	M, F	DOUBLE	H5000		60 - 60
7804	M, F		H2000	ALL WEATHER CAB	60 - 60
7804	F		H2500-H5000	ALL WEATHER CAB	60 - 100
7804	FV		H2000-H3700		60 - 120
7804	FV	SINGLE	H4000-H6000		60 - 60
7804-8205	FV	DOUBLE	H2000-H3700		60 - 120
7804-8205	FV	DOUBLE	H4000-H5000		60 - 60
8205	FV	DOUBLE	H2000-H4500		60 - 120
8205	FV	DOUBLE	H5000		60 - 60
7804	FV		H2000-H2500	ALL WEATHER CAB	60 - 60
7804	FSV, FS		H3700-H4700	DOMESTIC	60 - 60
7804	FSV, FS		H5000-H6000	DOMESTIC	30 - 80
7804	FSV, FS		H3700-H6000	EXPORT	60 - 80
8205	SV	SINGLE	H3000-H3700		60 - 120
8205	SV	SINGLE	H4000		60 - 60
8205	SV	DOUBLE	H3000-H4000		60 - 120
8407	F		H2500-H5000	DELUXE CABIN	60 - 100
8407	F, M		H2000	DELUXE CABIN	60 - 60
8407	FV, V, SV		H2000-H2500	DELUXE CABIN	60 - 60
8407	FV, M, SV, V	SINGLE	H4000-H5000	DELUXE CABIN	60 - 60
8407	FV, M, SV, V	DOUBLE	H5000	DELUXE CABIN	60 - 60

8011 007A


FIG. 6511
TILT CYLINDER

6511

FS

85/01

FS



PART NAME	PART NAME	QTY
CODE		
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/M KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	2
6511-5A	RING, HOLE SNAP	2
6511-5B	SEAL, DUST	2
6511-5C	RING, BACK UP	2
6511-5D	RING, O	2
6511-5E	RING, BACK UP	2
6511-5F	PACKING, U	2
6511-5G	PLATE, STOPPER	2
6511-5H	RING, HOLE SNAP	2
6511-5I	RING, O	2
6511-5J	PACKING, U	2
6511-5K	SHIM, TILT CONTROL	99
6511-5L	RING, O	4
6511-5M	COLLAR	4
6511-5N	SPACER, TILT CONTROL	2
6511-5P	WASHER, PLATE	2


FIG-6701
OIL PUMP

6701

FS

85/01

FS



PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-44A	PACKING, OIL PUMP	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4-81
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-A1	BOLT	2

6701-005A


FIG. 6705
OIL CONTROL VALVE

6705

FS

85/01

FS



JUL 1971


FIG. 6705
OIL CONTROL VALVE

6705

FS

85/01

FS (4-WAY)




8104-261

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, INLET, NO.2	1
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AD	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	4
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AW	SPRING, COMPRESSION	1
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BK	VALVE, CHECK	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BD	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	3
6705-DW	PLUG	1
6705-GN	BOLT, W/WASHER	4

FS

FS (3-WAY)



6709 125

6709 115B


FIG. 6709
OIL CONTROL VALVE LINK

6709

FS

85/01

FS (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-32	ROD SUB-ASSY	1
6709-33	ROD SUB-ASSY	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AW	BOLT	4
6709-B2	WASHER, PLATE	2

6709-098A

6801

85/01

PART NAME

PART NAME

| QTY





FIG. 6802
MAST PIPING

6802

FS

85/01

FS



PART NAME CODE	PART NAME	QTY
6802-20	PULLEY SUB-ASSY, HOSE GUIDE, NO.1	1
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFT)	1
6802-40	HOSE, HIGH PRESSURE (FRONT LIFT PULLEY)	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AA	PIN, HOSE GUIDE PULLEY	1
6802-AC	RING, O	1
6802-AD	COLLAR	1
6802-AE	STOPPER SUB-ASSY, HIGH PRESSURE HOSE	1

6802 012

MEMO

silverhorn.co.uk


FIG. 6101
MAST

6101

FSV

85/01

FSV



PART NAME	PART NAME	QTY
CODE		
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-22	MAST SUB-ASSY, MIDDLE	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-31	STRIP SUB-ASSY, MIDDLE MAST	2
6101-31A	SHIM, MIDDLE MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-42	ROLLER, LIFT (FOR MIDDLE MAST UPPER)	2
6101-43	ROLLER, LIFT (FOR MIDDLE MAST LOWER)	2
6101-55	STOPPER SUB-ASSY (FOR MIDDLE MAST)	1
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	2
6101-AH	BOLT	6
6101-AJ	SHIM, STOPPER	99
6101-BF	CUSHION, MAST	2
6101-BH	CAP, MAST SUPPORT	2

6301

85/06

Exploded view diagram of a mechanical assembly. Components are labeled with alphanumeric codes: 40B, 40, 43A, 41, 41A, 42, 47A, 40S, 40, AA, and 4. A small rectangular component is labeled 4. A small circular component is labeled 40B. A larger circular component is labeled 40. A component with a central pin is labeled 43A. A component with a central pin and a flange is labeled 41. A component with a central pin and a flange is labeled 41A. A component with a central pin and a flange is labeled 42. A component with a central pin and a flange is labeled 47A. A component with a central pin and a flange is labeled 40S. A component with a central pin and a flange is labeled 40. A component with a central pin and a flange is labeled AA. A component with a central pin and a flange is labeled 4.

The diagram illustrates the assembly of the rear suspension system. It shows the rear axle being positioned between two shock absorbers. The shock absorbers are connected to the chassis via upper control arms and lower control arms. The rear axle is also connected to the chassis via a rear cross member. The diagram includes various components such as the rear axle, shock absorbers, control arms, and springs.

FIG. 6301
LIFT BRACKET & FORK



6301

FSV


85/06

FSV (LOW NOISE)

(W/RUBBER)



(W/RUBBER)



PART NAME	PART NAME	QTY
CODE		
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	4
6301-43	SHAFT, SIDE ROLLER	2
6301-44	HOLDER, SIDE ROLLER SHAFT	4
6301-44A	SHIM (FOR SHAFT HOLDER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4
6301-AB	PLATE, SIDE	2
6301-AG	BOLT	4

6301 159


FIG. 6302
CHAIN & CHAIN WHEEL

6302

FSV

85/01

FSV



6302 027A

PART NAME		
CODE	PART NAME	QTY
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-22	CHAIN SUB-ASSY (REAR)	2
6302-22K	BOLT KIT, CHAIN ANCHOR, NO.1 (REAR)	2
6302-22L	BOLT KIT, CHAIN ANCHOR, NO.2 (REAR)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-42	WHEEL, CHAIN (REAR)	2
6302-42A	RING, SHAFT SNAP (FOR CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2


FIG. 6502
FRONT LIFT CYLINDER

6502

FSV

85/01

FSV



PART NAME	PART NAME	QTY
CODE		
6502-01	CYLINDER ASSY, LIFT	1
6502-01K	CYLINDER O/H KIT, LIFT	1
6502-11	VALVE ASSY, SAFETY DOWN	1
6502-20	CYLINDER SUB-ASSY, LIFT	1
6502-21	ROD SUB-ASSY, LIFT CYLINDER	1
6502-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6502-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6502-AA	BUSHING	1
6502-AB	RING, D	1
6502-AC	RING, BACK UP	1
6502-AD	PACKING, U	1
6502-AE	RING, BACK UP	1
6502-AF	SEAL, DUST	1
6502-AG	RING, D	1
6502-AH	PLUG	1
6502-AI	RING, D	1
6502-AL	BOLT	2

6502-0018



FIG. 6503
REAR LIFT CYLINDER

6503

FSV

85/01

FSV



6503 010R

PART NAME CODE	PART NAME	QTY
6503-01	CYLINDER ASSY, LIFT, RH	1
6503-01K	CYLINDER O/H KIT, LIFT, RH	1
6503-02	CYLINDER ASSY, LIFT, LH	1
6503-02K	CYLINDER O/H KIT, LIFT, LH	1
6503-11	VALVE ASSY, SAFETY DOWN	1
6503-20	CYLINDER SUB-ASSY, LIFT, RH	1
6503-21	CYLINDER SUB-ASSY, LIFT, LH	1
6503-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6503-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6503-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6503-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH	1
6503-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6503-AA	RING, WEAR	2
6503-AB	PACKING, U	2
6503-AE	PACKING, U	2
6503-AF	RING, O	2
6503-AG	SEAL, DUST	2
6503-AH	RING, O	1
6503-AI	SHIM	2
6503-AK	BRACKET SUB ASSY, LIFT CYLINDER	2
6503-AL	BUSHING	4
6503-AM	SPACER	2
6503-AN	SHIM	2
6503-AP	PLUG	2
6503-AQ	RING, BACK UP	2
6503-BB	BOLT	2


FSV (TABLE OF TILT RANGE)

テイルト角度表
TABLE OF TILT RANGE

生産期間 PROD DATE	型 式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DIScription	テイルト角 TILT RANGE
7804-8002	V	SINGLE	H3000-H3700		80 - 120
7804-8002	V	SINGLE	H4000-H6000		80 - 60
7804-8002	V	DOUBLE	H3000-H4500		80 - 120
7804-8002	V	DOUBLE	H5000		80 - 60
8002	V	SINGLE	H2000-H3700		60 - 120
8002	V	SINGLE	H4000-H5000		80 - 60
8002-8205	V	DOUBLE	H2000-H3700		80 - 120
8002-8205	V	DOUBLE	H4000-H5000		80 - 80
8205	V	DOUBLE	H2000-H4500		80 - 120
8205	V	DOUBLE	H5000		80 - 60
8002	V		H2000-H2500	ALL WEATHER CAB	80 - 60
7804	M, F	SINGLE	H2000-H3700		80 - 120
7804	M, F	SINGLE	H4000-H5000		80 - 60
7804	M, F	DOUBLE	H2000-H4500		80 - 120
7804	M, F	DOUBLE	H5000		80 - 60
7804	M, F		H2000	ALL WEATHER CAB	80 - 60
7804	F		H2500-H5000	ALL WEATHER CAB	80 - 100
7804	FV		H2000-H3700		80 - 120
7804	FV	SINGLE	H4000-H5000		80 - 60
7804-8205	FV	DOUBLE	H2000-H3700		80 - 120
7804-8205	FV	DOUBLE	H4000-H5000		80 - 80
8205	FV	DOUBLE	H2000-H4500		80 - 120
8205	FV	DOUBLE	H5000		80 - 60
7804	FV		H2000-H2500	ALL WEATHER CAB	80 - 60
7804	FSV, FS		H3700-H4700	DOMESTIC	80 - 60
7804	FSV, FS		H5000-H6000	DOMESTIC	80 - 60
7804	FSV, FS		H3700-H6000	EXPORT	80 - 60
8205	SV	SINGLE	H3000-H3700		80 - 120
8205	SV	SINGLE	H4000		80 - 60
8205	SV	DOUBLE	H3000-H4000		80 - 120
8407	F		H2500-H5000	DELUXE CABIN	80 - 100
8407	F, M		H2000	DELUXE CABIN	80 - 60
8407	FV, V, SV		H2000-H2500	DELUXE CABIN	80 - 60
8407	FV, M, SV, V	SINGLE	H4000-H5000	DELUXE CABIN	80 - 60
8407	FV, M, SV, V	DOUBLE	H5000	DELUXE CABIN	80 - 60

8511 007A

FSV



PART NAME	PART NAME	QTY
CODE		
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	2
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AK	SHIM, TILT CONTROL	99
6511-AM	RING, O	4
6511-AN	COLLAR	4
6511-AQ	SPACER, TILT CONTROL	2
6511-BN	WASHER, PLATE	2


FIG. 6701
OIL PUMP

6701

FSV

85/01

FSV




6701.005A

PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-44A	PACKING, OIL PUMP	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2




6705

85/01



6715 191

FSV (3-WAY)



FSV (4-WAY)




FIG. 6705
OIL CONTROL VALVE

6705

FSV


85/01

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, INLET, NO.2	1
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AO	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	4
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AW	SPRING, COMPRESSION	1
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BK	VALVE, CHECK	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	3
6705-DW	PLUG	1
6705-GN	BOLT, W/WASHER	4

6709

85/01

FSV 13-WAY



4.779 126

5709 1168


6709-6709 CONTROL VALVE LINK

6709

FSV

85/01

FSV (4-WAY)




PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-32	ROD SUB-ASSY	1
6709-33	ROD SUB-ASSY	1
6709-40	KNOB, DIL CONTROL VALVE LEVER	2
6709-41	PIN, DIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AW	BOLT	4
6709-B2	WASHER, PLATE	2


6709-088A

FSV


1/804 7/812:




V.S.V. 7/812




(HDC7 1 12




(LOW NOISE)
(DELUXE CASH)




(F.V)




(FSV)




(R)




94120-40800



(OIL FUEL)



94612-10800



94512-00800

94110-40800

94512-01000

94512-01100

94512-01200

94512-01300

94512-01400

94512-01500

94512-01600

94512-01700

94512-01800

94512-01900

94512-02000

94512-02100

94512-02200

94512-02300

94512-02400

94512-02500

94512-02600

94512-02700

94512-02800

94512-02900

94512-03000

94512-03100

94512-03200

94512-03300

94512-03400

94512-03500

94512-03600

94512-03700

94512-03800

94512-03900

94512-04000

94512-04100

94512-04200

94512-04300

94512-04400

94512-04500

94512-04600

94512-04700

94512-04800

94512-04900

94512-05000

94512-05100

94512-05200

94512-05300

94512-05400

94512-05500

94512-05600

94512-05700

94512-05800

94512-05900

94512-06000

94512-06100

94512-06200

94512-06300

94512-06400

94512-06500

94512-06600

94512-06700

94512-06800

94512-06900

94512-07000

94512-07100

94512-07200

94512-07300

94512-07400

94512-07500

94512-07600

94512-07700

94512-07800

94512-07900

94512-08000

94512-08100

94512-08200

94512-08300

94512-08400

94512-08500

94512-08600

94512-08700

94512-08800

94512-08900

94512-09000

94512-09100

94512-09200

94512-09300

94512-09400

94512-09500

94512-09600

94512-09700

94512-09800

94512-09900

94512-10000

94512-10100

94512-10200

94512-10300

94512-10400

94512-10500

94512-10600

94512-10700

94512-10800

94512-10900

94512-11000

94512-11100

94512-11200

94512-11300

94512-11400

94512-11500

94512-11600

94512-11700

94512-11800

94512-11900

94512-12000

94512-12100

94512-12200

94512-12300

94512-12400

94512-12500

94512-12600

94512-12700

94512-12800

94512-12900

94512-13000

94512-13100

94512-13200

94512-13300

94512-13400

94512-13500

94512-13600

94512-13700

94512-13800

94512-13900

94512-14000

94512-14100

94512-14200

94512-14300

94512-14400

94512-14500

94512-14600

94512-14700

94512-14800

94512-14900

94512-15000

94512-15100

94512-15200

94512-15300

94512-15400

94512-15500

94512-15600

94512-15700

94512-15800

94512-15900

94512-16000

94512-16100

94512-16200

94512-16300

94512-16400

94512-16500

94512-16600

94512-16700

94512-16800

94512-16900

94512-17000

94512-17100

94512-17200

94512-17300

94512-17400

94512-17500

94512-17600

94512-17700

94512-17800

94512-17900

94512-18000

94512-18100

94512-18200

94512-18300

94512-18400

94512-18500

94512-18600

94512-18700

94512-18800

94512-18900

94512-19000

94512-19100

94512-19200

94512-19300

94512-19400

94512-19500

94512-19600

94512-19700

94512-19800

94512-19900

94512-20000

94512-20100

94512-20200

94512-20300

94512-20400

94512-20500

94512-20600

94512-20700

94512-20800

94512-20900

94512-21000

94512-21100

94512-21200

94512-21300

94512-21400

94512-21500

94512-21600

94512-21700

94512-21800

94512-21900

94512-22000

94512-22100

945

PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-12	VALVE ASSY, FLOW REGULATOR	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT)	2
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	4
6801-46	FITTING (FOR LIFT CYLINDER)	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	2
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE)	4
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK)	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE)	2
6801-74	INSULATOR SUB-ASSY, BODY MOUNTING	1
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE	4
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AD	BOLT	4
6801-AE	RING, O	1
6801-AF	FLANGE, SPLIT	1
6801-AG	CLAMP	1
6801-AH	IBRACKET SUB-ASSY, TILT HOSE	1
6801-AJ	IBRACKET, HIGH PRESSURE HOSE	1
6801-AK	CLAMP	1
6801-AL	COVER	1
6801-AD	RING, O	1
6801-AP	PIPE	1
6801-AR	FITTING	1
6801-AS	FITTING	1
6801-AT	FITTING	1
6801-AU	RING, O	3
6801-AV	RING, O	2
6801-AW	ELBOW SUB-ASSY, 3-WAY	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-AZ	SPRING, COMPRESSION	1
6801-BA	PLUG	1
6801-BB	SPRING, COMPRESSION	1
6801-BC	BALL, STEEL	1
6801-BD	RING, O	1
6801-BH	CAP, OIL CLUTCH PIPE	1
6801-BI	CLAMP, HOSE	1
6801-BP	CLAMP	1
6801-BZ	PLATE	1
6801-FE	BOLT	1

PART NAME CODE	PART NAME	QTY
6801-FF	WASHER	1
6801-FV	SUPPORT SUB-ASSY, OIL FILTER	1
6801-HK	BOLT	1
6801-HL	BOLT	1
6801-HM	WASHER	1
6801-HN	WASHER	1
6801-HO	NUT	1


FIG. 6802
MAST PIPING

6802

FSV

85/01

FSV



6802-013A

PART NAME CODE	PART NAME	QTY
6802-20	PULLEY SUB-ASSY, HOSE GUIDE, NO.1	1
6802-25	BRACKET SUB-ASSY, GUIDE PULLEY	1
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFT)	1
6802-31	PIPE SUB-ASSY, NO.2 (FRONT LIFT)	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT)	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AA	PIN, HOSE GUIDE PULLEY	1
6802-AC	RING, O	1
6802-AD	COLLAR	1
6802-AH	CLAMP	1


FIG. 6101
MAST

6101

FV

85/01


FV




6101 030A

PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-53	CUSHION, MAST (FOR INNER MAST)	2
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	2
6101-AH	BOLT	8
6101-AI	STOPPER	2
6101-AJ	SHIM, STOPPER	99
6101-BH	CAP, MAST SUPPORT	2


FV




(L/BACKREST)




FV




M



V(7904-8205)



V(8205-)



6301-0040

LIFT BRACKET & FORK


6301

FV



85/06

FV (LOW NOISE)

(W/RUBBER)



(W/RUBBER)



PART NAME	PART NAME	QTY
CODE		
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	4
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	4
6301-43	SHAFT, SIDE ROLLER	2
6301-44	HOLDER, SIDE ROLLER SHAFT	4
6301-44A	SHIM (FOR SHAFT HOLDER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4
6301-AB	PLATE, SIDE	2
6301-AG	BOLT	4


FIG. 6302
CHAIN & CHAIN WHEEL

6302

FV

85/01

FV



6302 02/04

PART NAME	PART NAME	QTY
CODE		
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21A	NUT, CHAIN ADJUST (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2


FIG. 6502
FRONT LIFT CYLINDER

6502

FV

85/01

FV



PART NAME	PART NAME	QTY
CODE		
6502-01	CYLINDER ASSY, LIFT	1
6502-01K	CYLINDER O/H KIT, LIFT	1
6502-11	VALVE ASSY, SAFETY DOWN	1
6502-20	CYLINDER SUB-ASSY, LIFT	1
6502-21	ROD SUB-ASSY, LIFT CYLINDER	1
6502-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6502-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6502-AA	BUSHING	1
6502-AB	RING, O	1
6502-AC	RING, BACK UP	1
6502-AD	PACKING, U	1
6502-AE	RING, BACK UP	1
6502-AF	SEAL, DUST	1
6502-AG	RING, O	1
6502-AH	PLUG	1
6502-AI	RING, O	1

6502 000

6503

85/01

PART NAME

, QTY

6503-01	CYLINDER ASSY, LIFT RH	1
6503-01K	CYLINDER O/H KIT, LIFT, RH	1
6503-02	CYLINDER ASSY, LIFT, LH	1
6503-02K	CYLINDER O/H KIT, LIFT, LH	1
6503-11	VALVE ASSY, SAFETY DOWN	1
6503-20	CYLINDER SUB-ASSY, LIFT, RH	1
6503-21	CYLINDER SUB-ASSY, LIFT, LH	1
6503-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6503-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6503-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6503-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH	1
6503-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6503-AA	RING, WEAR	2
6503-AD	RING, O	2
6503-AE	PACKING, O	2
6503-AF	RING, O	2
6503-AG	SEAL, DUST	2
6503-AH	RING, O	1
6503-AI	SHIM	2
6503-AK	BACKET SUB-ASSY, LIFT CYLINDER	1
6503-AL	BUSHING	4
6503-AM	SPACER	2
6503-AN	SHIM	2
6503-AP	PLUG	2



612

6164-001-1253

FV (TABLE OF TILT RANGE)

テイルト角度表
TABLE OF TILT RANGE

生産期間 PROD DATE	型 式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DISCRIPTION	テイルト角 TILT RANGE
7804-8002	V	SINGLE	H3000-H3700		8D - 12D
7804-8002	V	SINGLE	H4000-H6000		6D - 8D
7804-8002	V	DOUBLE	H3000-H4500		6D - 12D
7804-8002	V	DOUBLE	H5000		8D - 8D
8002	V	SINGLE	H2000-H3700		6D - 12D
8002	V	SINGLE	H4000-H5000		8D - 8D
8002-8205	V	DOUBLE	H2000-H3700		6D - 12D
8002-8205	V	DOUBLE	H4000-H5000		6D - 6D
8205	V	DOUBLE	H2000-H4500		6D - 12D
8205	V	DOUBLE	H5000		6D - 6D
8002	V		H2000-H2500	ALL WEATHER CAB	6D - 6D
7804	M, F	SINGLE	H2000-H3700		6D - 12D
7804	M, F	SINGLE	H4000-H5000		6D - 6D
7804	M, F	DOUBLE	H2000-H4500		6D - 12D
7804	M, F	DOUBLE	H5000		6D - 6D
7801	M, F		H2000	ALL WEATHER CAB	6D - 6D
7804	F		H2500-H5000	ALL WEATHER CAB	6D - 10D
7804	FV		H2000-H3700		6D - 12D
7804	FV	SINGLE	H4000-H5000		6D - 6D
7804-8205	FV	DOUBLE	H2000-H3700		6D - 12D
7804-8205	FV	DOUBLE	H4000-H5000		6D - 6D
8205	FV	DOUBLE	H2000-H4500		6D - 12D
8205	FV	DOUBLE	H5000		6D - 6D
7804	FV		H2000-H2500	ALL WEATHER CAB	6D - 6D
7804	FSV, FS		H3700-H4700	DOMESTIC	6D - 6D
7804	FSV, FS		H5000-H8000	DOMESTIC	3D - 6D
7804	FSV, FS		H3700-H8000	EXPORT	6D - 6D
8205	SV	SINGLE	H3000-H3700		8D - 12D
8205	SV	SINGLE	H4000		6D - 6D
8205	SV	DOUBLE	H3000-H4000		6D - 12D
8407	F		H2500-H5000	DELUXE CABIN	6D - 10D
8407	F, M		H2000	DELUXE CABIN	6D - 6D
8407	FV, V, SV		H2000-H2500	DELUXE CABIN	8D - 8D
8407	FV, M, SV, V	SINGLE	H4000-H5000	DELUXE CABIN	6D - 6D
8407	FV, M, SV, V	DOUBLE	H5000	DELUXE CABIN	6D - 6D

6511-0074

651 1

85/01

PART NAME	PART NAME	QTY
CODE		
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-61	COVER, TILT CYLINDER	2
6511-62	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-64	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	2
6511-AA	RING, HOLE SNAP	7
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	7
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	7
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	7
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AK	SHIM, TILT CONTROL	99
6511-AM	RING, O	4
6511-AN	COLLAR	2
6511-BN	WASHER, PLATE	2





FIG-6701
OIL PUMP

6701

FV

85/01

FV



6701-005A

PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-44A	PACKING, OIL PUMP	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2


FIG. 6705
OIL CONTROL VALVE

6705

FV


85/01

FV




6705 121

FV (3-WAY)



FV (4-WAY)



PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, INLET, NO.2	1
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AD	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	4
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AW	SPRING, COMPRESSION	1
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BK	VALVE, CHECK	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BQ	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	3
6705-DW	PLUG	1
6705-GN	BOLT, W/WASHER	4

6709

85/01

FV (3-WAY)



6202 726


FIG. 6709
OIL CONTROL VALVE LINK

6709

FV

85/01


FV (4-WAY)




PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-32	ROD SUB-ASSY	1
6709-33	ROD SUB-ASSY	1
6709-40	KNOW, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AW	BOLT	4
6709-BZ	WASHER, PLATE	2

6706 006A


FV





V.SV 17B12 1



ROOM 2 17



(LOW NOISE)
(DELUXE CABIN)



9161-40872


94120-40800—

44512 00800


(OH FULL)




(FV)




{FSV}



(13)




94612 10890 1.3



PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-12	VALVE ASSY, FLOW REGULATOR	1
6801-13A	PLUG (FOR OIL TANK DRAIN)	1
6801-13B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT)	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	4
6801-46	FITTING (FOR LIFT CYLINDER)	1
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-74	INSULATOR SUB-ASSY, BODY MOUNTING	1
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AD	BOLT	4
6801-AE	RING, O	1
6801-AF	FLANGE, SPLIT	1
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	1
6801-AJ	BRACKET, HIGH PRESSURE HOSE	1
6801-AK	CLAMP	1
6801-AL	COVER	1
6801-AD	RING, O	1
6801-AR	FITTING	1
6801-AS	FITTING	1
6801-AT	FITTING	1
6801-AV	RING, O	4
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-AZ	SPRING, COMPRESSION	1
6801-BA	PLUG	1
6801-BB	SPRING, COMPRESSION	1
6801-BC	BALL, STEEL	1
6801-BD	RING, O	1
6801-BH	CAP, OIL CLUTCH PIPE	1
6801-BI	CLAMP, HOSE	1
6801-BP	CLAMP	1
6801-BZ	PLATE	1
6801-FE	BOLT	1
6801-FF	WASHER	1
6801-FV	SUPPORT SUB-ASSY, OIL FILTER	1
6801-HK	BOLT	1
6801-HL	BOLT	1
6801-HM	WASHER	1
6801-HN	WASHER	1
6801-HO	NUT	1

FV




PART NAME		
CODE	PART NAME	QTY
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFT)	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT)	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AB	FITTING	1
6802-AC	RING, Ø	1

6101


85401

PART NAME	PART NAME	QTY
CODE		
6101-20	MAST SUB-ASSY. OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY. INNER	1
6101-30	STRIP SUB-ASSY. OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-53	CUSHION, MAST (FOR INNER MAST)	2
6101-AA	PIN, SPRING	2
6101-AB	GUIDE, CHAIN WHEEL SUPPORT	2
6101-AC	STOPPER, INNER MAST	2
6101-AD	FITTING, GREASE	2
6101-AE	BOLT, STOPPER	2
6101-AF	COVER, ROLLER	2
6101-BH	CAP, MAST SUPPORT	2




8101-031A


M




(L/BACKREST)




EV




M




F5




F5V



V (7904-8205)



V (8205-)



6301 OM47

IFT BRACKET & FORK



6301

M


85/06

M (LOW NOISE)

(W/RUBBER)



(W/RUBBER)



PART NAME	PART NAME	QTY
CODE		
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4

6302

85/01

QTY

2

22

2

2

2

2

1

2


2

2

2

2

7



1722 0311

FIG. 6504
LIFT CYLINDER


6504

M

85/01

M

01



6504-001

PART NAME	PART NAME	QTY
CODE		
6504-01	CYLINDER ASSY, LIFT	1
6504-01K	CYLINDER O/H KIT, LIFT	1
6504-10	VALVE ASSY, FLOW REGULATOR	1
6504-20	CYLINDER SUB-ASSY, LIFT	1
6504-21	ROD SUB-ASSY, LIFT CYLINDER PISTON	1
6504-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6504-40	PISTON, LIFT CYLINDER	1
6504-41	COVER, LIFT CYLINDER	1
6504-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6504-44	SPACER, LIFT CYLINDER	1
6504-47	RING, STOPPER	1
6504-48	RING, WEAR	1
6504-49	RING, BACK UP	1
6504-50	PACKING, U	1
6504-51	RING, BACK UP	1
6504-52	RING, O	1
6504-53	RING, SHAFT SNAP	1
6504-54	SEAL, DUST	1
6504-55	PACKING, U	1
6504-56	RING, O	1
6504-57	RING, O	1
6504-58	RING, O	1
6504-59	RING, O	1
6504-60	RING, O	1
6504-61	RING, O	1
6504-62	RING, O	1
6504-63	RING, O	1
6504-64	RING, O	1
6504-65	RING, O	1
6504-66	RING, O	1
6504-67	RING, O	1
6504-68	RING, O	1
6504-69	RING, O	1
6504-70	RING, O	1
6504-71	RING, O	1
6504-72	RING, O	1
6504-73	RING, O	1
6504-74	RING, O	1
6504-75	RING, O	1
6504-76	RING, O	1
6504-77	RING, O	1
6504-78	RING, O	1
6504-79	RING, O	1
6504-80	RING, O	1
6504-81	RING, O	1
6504-82	RING, O	1
6504-83	RING, O	1
6504-84	RING, O	1
6504-85	RING, O	1
6504-86	RING, O	1
6504-87	RING, O	1
6504-88	RING, O	1
6504-89	RING, O	1
6504-90	RING, O	1
6504-91	RING, O	1
6504-92	RING, O	1
6504-93	RING, O	1
6504-94	RING, O	1
6504-95	RING, O	1
6504-96	RING, O	1
6504-97	RING, O	1
6504-98	RING, O	1
6504-99	RING, O	1
6504-100	RING, O	1

6511

85/01

PART NAME	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	2
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AK	SHIM, TILT CONTROL	99
6511-AL	SPACER, TILT CONTROL	2
6511-AM	RING, O	4
6511-AN	COLLAR	4
6511-BN	WASHER, PLATE	2





FIG. 6701
OIL PUMP

6701

M

85/01

M



5/01 005A

PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, ND.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-44A	PACKING, OIL PUMP	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4- 8
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-A1	BOLT	2

6705

M






FIG. 6705
DIL CONTROL VALVE

6705

M

85/01

M (3-WAY)



6705 250

PART NAME	PART NAME	QTY
CODE		
6705-D1	VALVE ASSY, OIL CONTROL	1
6705-D1K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, INLET, NO.2	1
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AD	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	4
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AW	SPRING, COMPRESSION	1
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, DRIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BK	VALVE, CHECK	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	3
6705-DW	PLUG	1
6705-GN	BOLT, W/WASHER	4

M (3-WAY)




FIG. 6709
OIL CONTROL VALVE LINK

6709

M

85/01

M (4-WAY)




6709-098A

PART NAME	PART NAME	QTY
CODE		
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-32	ROD SUB-ASSY	1
6709-33	ROD SUB-ASSY	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	7
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AW	BOLT	4
6709-BZ	WASHER, PLATE	2

6801

85/01

PART NAME	PART NAME	QTY
CODE		
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	2
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	4
6801-46	FITTING (FOR LIFT CYLINDER)	1
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	1
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE)	2
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-74	INSULATOR SUB-ASSY, BODY MOUNTING	1
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE	2
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AD	BOLT	4
6801-AE	RING, O	1
6801-AF	FLANGE, SPLIT	1
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	1
6801-AJ	BRACKET, HIGH PRESSURE HOSE	1
6801-AK	CLAMP	1
6801-AL	COVER	1
6801-AD	RING, O	1
6801-AW	ELBOW SUB-ASSY, 3-WAY	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-BH	CAP, OIL CLUTCH PIPE	1
6801-BI	CLAMP, HOSE	1
6801-BP	CLAMP	1
6801-BZ	PLATE	1
6801-FE	BOLT	1
6801-FF	WASHER	1
6801-FV	SUPPORT SUB-ASSY, OIL FILTER	1
6801-HK	BOLT	1
6801-HL	BOLT	1
6801-HM	WASHER	1
6801-HN	WASHER	1
6801-HO	NUT	1



MEMO

Silverhorn.co.uk


FIG. 6101
MAST

6101

SV

85/01


SV



8101-034A

PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-53	CUSHION, MAST (FOR INNER MAST)	2
6101-AC	STOPPER, INNER MAST	2
6101-AD	FITTING, GREASE	2
6101-BH	CAP, MAST SUPPORT	2

SV



(L/BACKREST)











FIG 6301 LIFT BRACKET & FORK



6301

SV


85/06

SV (LOW NOISE)

(W/RUBBER)



(W/RUBBER)



PART NAME	PART NAME	QTY
CODE		
6301-03	BRACKET ASSY, LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-52	ROLLER, SIDE, NO-2	2
6301-52C	RING, SHAFT SNAP (FOR SIDE ROLLER)	4
6301-53	PIN, SIDE ROLLER	2
6301-53A	SHIM (FOR SIDE ROLLER PIN)	99

6301 159


FIG. 6302
CHAIN & CHAIN WHEEL

6302

SV

85/01

SV



PART NAME

PART NAME


QTY

CODE

6302-20	CHAIN SUB-ASSY	2
6302-20A	NUT, CHAIN ADJUST	2
6302-20L	BOLT KIT, CHAIN ANCHOR, ND-2	2
6302-20M	BOLT KIT, CHAIN EYE	2
6302-30	BEAM SUB-ASSY, CHAIN	1
6302-30A	BUSHING	2
6302-31	PIN SUB-ASSY, CHAIN WHEEL	1
6302-40	WHEEL, CHAIN	2
6302-AC	CLAMP, CHAIN ANCHOR BOLT	2
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AF	PIN, SPRING	2
6302-AP	COLLAR, CHAIN WHEEL	4

6302 C3/A

5v



PART NAME	PART NAME	QTY
CODE		
6501-01	CYLINDER ASSY, LIFT, RH	1
6501-01K	CYLINDER O/H KIT, LIFT, RH	1
6501-02	CYLINDER ASSY, LIFT, LH	1
6501-02K	CYLINDER O/H KIT, LIFT, LH	1
6501-11	VALVE ASSY, SAFETY DOWN	1
6501-20	CYLINDER SUB-ASSY, LIFT, RH	1
6501-21	CYLINDER SUB-ASSY, LIFT, LH	1
6501-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6501-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6501-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6501-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6501-AA	RING, WEAR	2
6501-AB	PACKING, U	2
6501-AC	RING, BACK UP	2
6501-AE	PACKING, U	2
6501-AF	RING, O	2
6501-AG	SEAL, DUST	2
6501-AH	RING, O	1
6501-AI	SHIM	99
6501-AK	BRACKET SUB-ASSY, LIFT CYLINDER	2
6501-AL	BUSHING	4
6501-AM	SPACER	2
6501-AN	SHIM	99


SV (TABLE OF TILT RANGE)

テイルト角度表
TABLE OF TILT RANGE

生産期間 PROD DATE	型 式 MODELS	タイ ン TYRE	揚 高 LIFTING HEIGHT	備 考 DISCRIPTION	テイルト角 TILT RANGE
7804-8002	V	SINGLE	H3000-H3700		6D-12D
7804-8002	V	SINGLE	H4000-H5000		6D-6D
7804-8002	V	DOUBLE	H3000-H4500		6D-12D
7804-8002	V	DOUBLE	H5000		6D-6D
8002	V	SINGLE	H2000-H3700		6D-12D
8002	V	SINGLE	H4000-H5000		6D-6D
8002-8205	V	DOUBLE	H2000-H3700		6D-12D
8002-8205	V	DOUBLE	H4000-H5000		6D-6D
8205	V	DOUBLE	H2000-H4500		6D-12D
8205	V	DOUBLE	H5000		6D-6D
8002	V		H2000-H2500	ALL WEATHER CAB	6D-6D
7804	M, F	SINGLE	H2000-H3700		6D-12D
7804	M, F	SINGLE	H4000-H5000		6D-6D
7804	M, F	DOUBLE	H2000-H4500		6D-12D
7804	M, F	DOUBLE	H5000		6D-6D
7804	M, F		H2000	ALL WEATHER CAB	6D-6D
7804	F		H2500-H5000	ALL WEATHER CAB	6D-10D
7804	FV		H2000-H3700		6D-12D
7804	FV	SINGLE	H4000-H5000		6D-6D
7804-8205	FV	DOUBLE	H2000-H3700		6D-12D
7804-8205	FV	DOUBLE	H4000-H5000		6D-6D
8205	FV	DOUBLE	H2000-H4500		6D-12D
8205	FV	DOUBLE	H5000		6D-6D
7804	FV		H2000-H2500	ALL WEATHER CAB	6D-6D
7804	FSV, FS		H3700-H4700	DOMESTIC	6D-6D
7804	FSV, FS		H5000-H6000	DOMESTIC	3D-6D
7804	FSV, FS		H3700-H5000	EXPORT	6D-6D
8205	SV	SINGLE	H3000-H3700		6D-12D
8205	SV	SINGLE	H4000		6D-6D
8205	SV	DOUBLE	H3000-H4000		6D-12D
8407	F		H2500-H5000	DELUXE CABIN	6D-10D
8407	F, M		H2000	DELUXE CABIN	6D-6D
8407	FV, V, SV		H2000-H2500	DELUXE CABIN	6D-6D
8407	FV, M, SV, V	SINGLE	H4000-H5000	DELUXE CABIN	6D-6D
8407	FV, M, SV, V	DOUBLE	H5000	DELUXE CABIN	6D-6D

6511-007A

SV



PART NAME CODE	PART NAME	QTY
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	2
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AK	SHIM, TILT CONTROL	99
6511-AM	RING, O	4
6511-AN	COLLAR	4
6511-BN	WASHER, PLATE	2


FIG. 6701
PUMP

6701

SV

85/01

SV



6701 005A

PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-44A	PACKING, OIL PUMP	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4- 8
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2




FIG. 6705
OIL CONTROL VALVE

6705

SV

85/01

SV (3-WAY)



SV (4-WAY)




FIG. 6705
OIL CONTROL VALVE

6705

SV

85/01

PART NAME	PART NAME	QTY
CODE		
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/R KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, INLET, NO.2	1
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AO	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	4
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AW	SPRING, COMPRESSION	1
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BK	VALVE, CHECK	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	3
6705-DW	PLUG	1
6705-GN	BOLT, W/WASHER	4


FIG. 6709
OIL CONTROL VALVE LINK

6709

SV

85/01

SV (4-WAY)




PART NAME	PART NAME	QTY
CODE		
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-32	ROD SUB-ASSY	1
6709-33	ROD SUB-ASSY	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-42	BOOT, CONTROL VALVE LINK, NO.1	2
6709-43	BOOT, CONTROL VALVE LINK, NO.2	2
6709-44	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AW	BOLT	4
6709-BZ	WASHER, PLATE	2


6709-4WRA

SV


(7804-7812)




V, SV (7812-)




(8002-) 12




(LOW NOISE)
(DELUXE CABIN)





(FV)




(FSV)



(B)



(OIL FULL)



6801-010F

PART NAME	PART NAME	QTY
CODE		
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	WASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LEFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LEFT)	2
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	4
6801-46	FITTING (FOR LIFT CYLINDER)	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	2
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE)	4
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK)	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE)	2
6801-74	INSULATOR SUB-ASSY, BODY MOUNTING	1
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AD	BOLT	4
6801-AE	RING, O	1
6801-AF	FLANGE, SPLIT	1
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	2
6801-AJ	BRACKET, HIGH PRESSURE HOSE	1
6801-AK	CLAMP	1
6801-AL	COVER	1
6801-AD	RING, O	1
6801-AP	PIPE	1
6801-A5	FITTING	1
6801-AT	FITTING	1
6801-AV	RING, O	2
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-BH	CAP, OIL CLUTCH PIPE	1
6801-B1	CLAMP, HOSE	1
6801-BP	CLAMP	1
6801-BZ	PLATE	1
6801-FE	BOLT	1
6801-FF	WASHER	1
6801-FV	SUPPORT SUB-ASSY, OIL FILTER	1
6801-HK	BOLT	1
6801-HL	BOLT	1
6801-HM	WASHER	1
6801-HN	WASHER	1
6801-HO	NUT	1


FIG 6101
MAST

6101

V


85/01

V




PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	1
6101-AH	BOLT	4
6101-BH	CAP, MAST SUPPORT	2


V




(L/RACKRIST)




FV



M



V(79C4-8205)



V(8205-)




FIG. 6301
LIFT BRACKET & FORK




6301

V

85/06

V (LOW NOISE)

(W/RUBBER)



PART NAME	PART NAME	QTY
CODE		
6301-03	BRACKET ASSY. LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY. LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-52	ROLLER, SIDE, NO.2	2
6301-52C	RING, SHAFT SNAP (FOR SIDE ROLLER)	4
6301-53	PIN, SIDE ROLLER	2
6301-53A	SHIM (FOR SIDE ROLLER PIN)	99
6301-AA	COVER, LIFT BRACKET ROLLER	2
6301-AH	COVER, LIFT BRACKET, SIDE ROLLER	2
6301-AD	BOLT	4
6301-BJ	RUBBER, BACKREST	1
6301-BK	RUBBER, FORK	2

8301-169

6302

3

Y



PART NAME	PART NAME	QTY
CODE		
6302-20	CHAIN SUB-ASSY	2
6302-20K	BDLT KIT, CHAIN ANCHOR, NO.1	2
6302-20L	BDLT KIT, CHAIN ANCHOR, NO.2	2
6302-40	WHEEL, CHAIN	2
6302-40A	RING, SHAFT SNAP (FOR CHAIN WHEEL)	2
6302-AD	NUT, HEXAGON	4
6302-AH	COVER, CHAIN WHEEL	2
6302-AR	NUT, LOCK	2

6501

85/01

Y

6104-001-1211

V [TABLE OF TILT RANGE]

テイルト角度表
TABLE OF TILT RANGE

生産期間 PROD DATE	型 式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DISCRIPTION	チルト角 TILT RANGE
7804-8002	V	SINGLE	H3000-H3700		6D - 12D
7804-8002	V	SINGLE	H4000-H5000		6D - 6D
7804-8002	V	DOUBLF	H3000-H4500		6D - 12D
7804-8002	V	DOUBLF	H5000		6D - 6D
8002	V	SINGLE	H2000-H3700		6D - 12D
8002	V	SINGLE	H4000-H5000		6D - 6D
8002-8205	V	DOUBLE	H2000-H3700		6D - 12D
8002-8205	V	DOUBLE	H4000-H5000		6D - 6D
8205	V	DOUBLE	H2000-H4500		6D - 12D
8205	V	DOUBLE	H5000		6D - 6D
8002	V		H2000-H2500	ALL WEATHER CAB	6D - 6D
7804	M, F	SINGLE	H2000-H3700		6D - 12D
7804	M, F	SINGLE	H4000-H5000		6D - 6D
7804	M, F	DOUBLE	H2000-H4500		6D - 12D
7804	M, F	DOUBLE	H5000		6D - 6D
7804	M, F		H2000	ALL WEATHER CAB	6D - 6D
7804	F		H2500-H5000	ALL WEATHER CAB	6D - 10D
7804	FV		H2000-H3700		6D - 12D
7804	FV	SINGLE	H4000-H5000		6D - 6D
7804-8205	FV	DOUBLE	H2000-H3700		6D - 12D
7804-8205	FV	DOUBLE	H4000-H5000		6D - 6D
8205	FV	DOUBLE	H2000-H4500		6D - 12D
8205	FV	DOUBLE	H5000		6D - 6D
7804	FV		H2000-H2500	ALL WEATHER CAB	6D - 6D
7804	FSV, FS		H3700-H4700	DOMESTIC	6D - 6D
7804	FSV, FS		H5000-H6000	DOMESTIC	3D - 6D
7804	FSV, FS		H3700-H6000	EXPORT	6D - 6D
8205	SV	SINGLE	H3000-H3700		6D - 12D
8205	SV	SINGLE	H4000		6D - 6D
8205	SV	DOUBLE	H3000-H4000		6D - 12D
8407	F		H2500-H5000	DELUXE CABIN	6D - 10D
8407	F, M		H2000	DELUXE CABIN	6D - 6D
8407	FV, V, SV		H2000-H2500	DELUXE CABIN	6D - 6D
8407	FV, M, SV, V	SINGLE	H4000-H5000	DELUXE CABIN	6D - 6D
8407	FV, M, SV, V	DOUBLE	H5000	DELUXE CABIN	6D - 6D

6511-007A

6511

85/01





FIG. 6701
OIL PUMP

6701

V


85/01

V




6701 005A

PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-44A	PACKING, OIL PUMP	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2



V (3-WAY)



V (4-WAY)




FIG. 6705
OIL CONTROL VALVE

6705

V

85/01

PART NAME	PART NAME	QTY
CODE		
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, INLET, NO.2	1
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AQ	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	4
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AW	SPRING, COMPRESSION	1
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BK	VALVE, CHECK	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	3
6705-DW	PLUG	1
6705-GN	BOLT, W/WASHER	4


FIG-6709
OIL CONTROL VALVE LINK

6709

V

85/01

V (4-WAY)



PART NAME

CODE

PART NAME


QTY

6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-32	ROD SUB-ASSY	1
6709-33	ROD SUB-ASSY	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AW	BOLT	4
6709-BZ	WASHER, PLATE	2


6709 098

V


(7804-7812)




V,SV (7812-)




(8002-) 12




(LOW NOISE)
(DELUXE CABIN)




(FV)



(FSV)



(B)



(OIL FULL)



PART NAME	PART NAME	QTY
CODE		
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-12	VALVE ASSY, FLOW REGULATOR	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT)	2
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	4
6801-46	FITTING (FOR LIFT CYLINDER)	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	4
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE)	4
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK)	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE)	2
6801-74	INSULATOR SUB-ASSY, BODY MOUNTING	1
6801-AA	RAND, LIFT CYLINDER OVERFLOW HOSE	1
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AD	BOLT	8
6801-AE	RING, O	1
6801-AF	FLANGE, SPLIT	1
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	2
6801-AJ	BRACKET, HIGH PRESSURE HOSE	1
6801-AK	CLAMP	1
6801-AL	COVER	1
6801-AD	RING, O	1
6801-AP	PIPE	1
6801-AS	FITTING	1
6801-AT	FITTING	1
6801-AV	RING, O	2
6801-AW	ELBOW SUB ASSY, 3-WAY	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-AZ	SPRING, COMPRESSION	1
6801-BA	PLUG	1
6801-BB	SPRING, COMPRESSION	1
6801-BC	BALL, STEEL	1
6801-BD	RING, O	1
6801-BH	CAP, OIL CLUTCH PIPE	1
6801-BI	CLAMP, HOSE	1
6801-BP	CLAMP	1
6801-BZ	PLATE	1
6801-FE	BOLT	1
6801-FF	WASHER	1

PART NAME	PART NAME	QTY
CODE		
6801-FV	SUPPORT SUB-ASSY, OIL FILTER	1
6801-HK	BOLT	1
6801-HL	BOLT	1
6801-HM	WASHER	1
6801-HN	WASHER	1
6801-HD	NUT	1