

TOYOTA INDUSTRIAL VEHICLE

PARTS CATALOG

**4FB/30-4FB20,25
4FBJ/30-4FBJ20,25
No.G203-1**

**TOYOTA MOTOR CORPORATION
TOYODA AUTOMATIC LOOM WORKS, LTD.**

TOYOTA

FORKLIFT TRUCK

PARTS CATALOG

MODEL	4 F B
FRAME NO.	4 F B 2 5
LIFTING HEIGHT	mm

DESCRIPTION

Cold Storage Model Type 45S	
Fully Oil Charged Lift Cylinder	

TOYOTA MOTOR CORPORATION
TOYODA AUTOMATIC LOOM WORKS, LTD.

QUICK REFERENCE INDEX

INTRODUCTION

ELECTRICAL SYSTEM

CHASSIS

BODY

ELECTRICAL SYSTEM

MAST

HYDRAULIC SYSTEM

G203-1

GENERAL INFORMATION

This parts catalog has been prepared for the customers of Toyota Industrial Vehicles and this shows only the part name codes instead of parts numbers.

When ordering parts from your local Toyota dealer, please specify the complete model number of the truck, the engine number or frame number. Also it is essential that you specify the part name codes described in the pages of illustrations and text.

The complete model number and frame number are shown in the front page of this catalog. All the columns in this quick reference index are supposed to be filled out by both the factory and your local dealer.

For the industrial vehicle with optional equipment, which is described in the lower part of the DESCRIPTION, it is imperative for you to specify optional equipment when ordering parts.

Your Toyota dealer has always been furnished with enough information to decode the correct part numbers based on your information of model number, engine number or frame number as well as part name code.

INFORMATIONS D'ORDRE GENERAL

Ce catalogue de pièces a été préparé pour les propriétaires de Véhicules Industriels Toyota. On n'y trouvera que les codes de désignation de pièces au lieu des numéros de pièces.

Pour la commande de pièces auprès de votre concessionnaire Toyota, prière de spécifier le numéro de modèle complet de l'engin, le numéro du moteur ou le numéro du châssis. Il est aussi nécessaire de spécifier les codes de désignation de pièces comme ils sont décrits dans les pages d'illustrations et dans le texte.

Le numéro de modèle complet et le numéro de châssis sont indiqués en première page de ce catalogue. Toutes les colonnes de l'index de référence rapide devraient être remplies par l'usine et par votre concessionnaire.

Pour le véhicule industriel avec équipement optionnel, décrit en bas de page sous la rubrique "DESCRIPTION", il convient de bien spécifier qu'il s'agit de cet équipement lors de commande de pièces.

Votre concessionnaire Toyota est toujours suffisamment informé pour décoder les numéros de pièces sur la base de votre information du numéro de modèle, du numéro de moteur ou de châssis, et des codes de désignation de pièces.

INFORMACION GENERAL

Este catálogo de piezas ha sido preparado para los clientes de vehículos industriales de TOYOTA, e incluye tan sólo los códigos de nombre de pieza en lugar de los números de pieza.

Cuando solicite piezas a su distribuidor local de TOYOTA especifique por favor el número de modelo completo del vehículo, el número de motor o el número de bastidor. Asimismo, es esencial que Vd. especifique los códigos de nombre de pieza descritos en las páginas de ilustraciones y de texto.

El número completo de modelo y el número de bastidor se indican en la portada de este catálogo. Se supone que todas las columnas de este índice de referencia se han rellenado, tanto por parte de la fábrica como por parte de su distribuidor local.

En lo que concierne a los vehículos industriales con equipos opcionales, que se describen en la parte baja de la DESCRIPCION, es absolutamente necesario que especifique equipos opcionales cuando solicite piezas de repuesto.

Su distribuidor local de TOYOTA posee la información necesaria para descifrar los números correctos de cada pieza a base de su información de número de modelo, número de motor o número de bastidor, así como el código de nombre de la pieza.

ALLGEMEINE INFORMATION

Dieser Teilekatalog wurde für die Benutzer von Toyota Industriefahrzeugen zusammengestellt und zeigt anstelle von Teilenummern nur die Teilennamen-Kodes.

Geben Sie bei Teilebestellungen von Ihrem Toyota-Händler am Platz bitte die vollständige Modellnummer des Fahrzeugs, die Motornummer oder Fahrgestellnummer an. Es ist auch erforderlich, daß Sie die in den Illustrationen und im Text beschriebenen Teilennamen-Kodes angeben.


Die vollständige Modellnummer und Fahrgestellnummer finden Sie auf der Vorderseite dieses Katalogs. Alle Spalten in dieser Bezugstabelle sollen sowohl vom Werk als von Ihrem Händler am Platz ausgefüllt werden.

Für Industriefahrzeuge mit Sonderausrüstung, welche im unteren Teil der BESCHREIBUNG erläutert ist, müssen Sie bei der Bestellung von Teilen unbedingt diesbezügliche Angaben machen.

Ihr Toyota-Händler verfügt stets über genügend Information, um die richtigen Teilenummern zu entschlüsseln, basiert auf Ihren Angaben zu Modellnummer, Motornummer oder Fahrgestellnummer und den Teilennamen-Kodes.

ILLUSTRATION AND PART NAME CODE TEXT PAGE COMPOSITION

Essentially, one (1) page will present both the illustration and part name code. However, when the space for text page is not enough the next page will be used in succession.



- Figure number**
This parts catalog has been prepared according to the figure numbers.
- Figure title**
A representative part name which is the major assembly part name is shown as the figure title of the illustration.
- Sub title**
The optional name or special specification of each illustration are indicated.
- Part name code**
This is a combination of figure number and codes of illustrations pertaining to each part. This is a key for your Toyota dealer to find the correct part numbers.
- Part name**
As a rule, the part name is indicated for each of the part name codes.
- QTY (Quantity)**
The quantity column indicates the utilized pieces of part name code unit. When the utilized quantity changes according to each of the vehicles, maximum is indicated. When the utilized quantity of the parts differs or is more than 100 pieces, quantity 99 is indicated.
- Standard parts numbers**
The standard parts such as the bolts, nuts, washer, etc. are described with parts numbers. When ordering these parts, specify parts numbers.

COMPOSICION DE LAS PAGINAS DE ILUSTRACIONES Y DE TEXTO DE CODIGOS DE NOMBRE DE PIEZAS


Básicamente, una (1) página incluirá tanto la ilustración como el código de nombre de la pieza.

No obstante, si el espacio no fuese suficiente, se utilizará la página siguiente.

- Número de figura**
Este catálogo de piezas se ha preparado de acuerdo con los números de las figuras.
- Título de las figuras**
Como título de las figuras de la página de ilustraciones, se incluye un nombre que sea representativo del nombre del mayor conjunto.
- Subtítulo**
Se indican el nombre opcional o las especificaciones especiales de cada ilustración.
- Código de nombre de pieza**
Se trata de una combinación de número de figura y de código de las ilustraciones correspondientes a cada pieza. Esta es la clave para que su distribuidor local de TOYOTA pueda encontrar el número de pieza correcto.
- Nombre de la pieza**
Como norma, se indica el nombre de cada uno de los códigos de nombre de pieza.
- QTY (Cantidad)**
La columna de cantidad indica el número de piezas utilizadas de cada unidad de código de nombre de pieza. Cuando la cantidad utilizada es intercambiable entre cada uno de los vehículos, se indica el máximo. Cuando la cantidad de piezas utilizadas pueda diferir o ser superior a 100, se indica como cantidad 99.
- Números de piezas normalizadas**
Las piezas corrientes, tales como pernos, tuercas, arandelas etc., se describen con número de pieza. Cuando solicite tales piezas, indique su número de pieza.

ILLUSTRATION ET COMPOSITION DU DE TEXTE DE CODE DE DESIGNATION DE PIECE

Une (1) page contiendra essentiellement une illustration et ses codes de désignation de pièce. Toutefois, lorsque l'espace réservé au texte est insuffisant, la continuation se trouvera sur la page suivante.



- 1 Numéro de figure
Ce catalogue de pièces a été préparé en fonction des numéros de figures.
- 2 Titre de figure
Une désignation de pièce représentative, celle d'une pièce d'un ensemble important, est indiquée comme titre de figure de l'illustration.
- 3 Sous-titre
La désignation optionnelle ou les spécifications spéciales de chaque illustration sont indiquées.
- 4 Code de désignation de pièce
Obtenu en combinant le numéro de figure et les codes des illustrations inhérents à chaque pièce. Ce code permettra à votre concessionnaire Toyota de trouver les numéros de pièces corrects.
- 5 Désignation de pièce
La désignation de la pièce est indiquée pour chacun des codes de désignation de pièce.
- 6 Q'ty (quantité)
La colonne quantité indique les pièces utilisées de l'unité de code de désignation de pièce. La quantité maximum est indiquée quand la quantité utilisée diffère pour chacun des véhicules. Quand la quantité de pièces utilisées diffère ou lorsqu'elle dépasse 100 pièces, la quantité 99 est indiquée.
- 7 Numéros de pièces standard
Les pièces standard comme les boulons, les écrous, les rondelles, etc. sont décrits dans les numéros de pièces. Pour commander ces pièces, prière de spécifier les numéros de pièces.

ABBILDUNG UND TEXTSEITENAUFBAU FÜR TEILENAMEN-KODE

Grundsätzlich finden Sie auf einer (1) Seite sowohl die Abbildung als auch den Teilnamen-Kode.
Wenn für den Text jedoch nicht genügend Platz vorhanden ist, wird er auf der nächsten Seite fortgesetzt.

- 1 Abbildungsnummer
Dieser Teilekatalog wurde nach Abbildungsnummern zusammengestellt.
- 2 Abbildungstitel
Ein stellvertretender Teilname, welcher zugleich die Bezeichnung für die Hauptbaugruppe ist, wird als Abbildungstitel der Illustration angegeben.
- 3 Untertitel
Ein zusätzlicher Name oder eine besondere Kennzeichnung werden für jede Illustration angegeben.
- 4 Teilnamen Kode
Dies ist eine Kombination von ziffern und Abbildungskodes, die jedes Teil betreffen. Es ist ein Schlüssel für Ihren Toyota-Händler, um die richtigen Teilenummern zu finden.
- 5 Teilname
Grundsätzlich wird der Teilname für alle Teilnamen-Kodes angegeben.
- 6 QTY (Menge)
Die Mengenspalte gibt die benutzte Stückzahl von Teilnamen-Kode-Einheiten an.
Wenn die benutzte Stückzahl je nach Fahrzeug Verschieden ist, wird die Höchstmenge angegeben.
Wenn die benutzte Menge 100 Stück überschreiten kann, wird als Menge 99 angegeben.
- 7 Standardteile-Nummern
Die Standardteile, wie Schrauben, Muttern, Unterlegscheiben usw., sind in den Teilenummern beschrieben. Geben Sie bei Bestellung dieser Teile die Teilenummern an.

DATA PLATE & SERIAL NUMBERS

For retrieving correct part numbers, it's indispensable to know the truck model, as well as frame number (or engine number).
Customers can obtain said information in the data plate on the truck or in this user parts catalog.

PLAQUE DE DONNEES TECHNIQUES & NUMEROS DE SERIE

Pour relever correctement le numéro des pièces, il est indispensable de connaître le modèle de l'engin, ainsi que le numéro du châssis (ou du moteur).
Les propriétaires peuvent trouver ladite information sur la plaque de données techniques de l'engin ou dans le présent ouvrage.

PLACA DE DATOS Y NUMEROS DE SERIE

Para obtener los números de pieza correctos, es indispensable conocer el modelo del vehículo, así como el número del bastidor (o del motor).
Los clientes pueden obtener dicha información por la placa de datos del vehículo o este catálogo de piezas para el usuario.


DATENPLATTE & SERIENNUMMERN

Um die richtige Teilenummer zu ermitteln, müssen unbedingt das Fahrzeugmodell sowie die Fahrgestellnummer (oder die Motornummer) bekannt sein.
Kunden können diese Angaben von der Datenplatte am Fahrzeug oder in diesem Teilekatalog für Benutzer entnehmen.

Data plate
Placa de datos
Plaque de données techniques
Datenplatte

 TOYOTA LIFT TRUCK	
MODEL	
CODE NO. OF SPECIAL MODEL MODEL OF ATTACHMENT	
VOLTAGE	
FRAME NO.	
LIFTING HEIGHT	
CAPACITY	
WEIGHT	
PROD. YEAR	
TOYODA AUTOMATIC LOOM WORKS. LTD. KARIYA JAPAN	

Data plate
Placa de datos
Plaque de données techniques
Datenplatte







Frame Number
(Top of the frame)
Número de bastidor
(Parte superior del bastidor)

Numéro de châssis
(haut du châssis)
Fahrgestellnummer
(Oben am Fahrgestell)

ILLUSTRATED INDEX
INDEX ILLUSTRÉ
ILLUSTRIRTES INHALTSVERZEICHNIS
INDICE ILLUSTRADO









FIG. INDEX

FIG. 1401  Drive Motor	FIG. 1402  Pump Drive Motor	FIG. 1403  P/S Pump Drive Motor	FIG. 2401  Control Panel	FIG. 2402  Contactor Panel	FIG. 2403  Contactor Assy	FIG. 2413  Circuit Breaker
ELECTRICAL GROUP 						

V.0000-052








C203-1

FIG. INDEX

 FIG. 3305 Gear Case & Gear	 FIG. 3310 Change Lever	 FIG. 4101 Differential	 FIG. 4201 Front Axle Shaft	 FIG. 4301 Rear Axle & Tie-Rod	 FIG. 4401 Front Wheel & Tire	 FIG. 4402 Front Wheel & Tire (Double)
CHASSIS GROUP 						
 FIG. 4403 Rear Wheel & Tire						
 FIG. 4501 Steering Wheel						
 FIG. 4502 Steering Post						
 FIG. 4507 Draglink & Steering Piping						
 FIG. 4715 Drum Brake	 FIG. 4714 Brake Pipe	 FIG. 4702 Brake Master Cylinder	 FIG. 4701 Brake Pedal	 FIG. 4801 Parking Brake	 FIG. 4510 Steering Oil Pump	 FIG. 4508 Steering Power Cylinder

ILLUSTRATED INDEX
INDEX ILLUSTRÉ
ILLUSTRIRTES INHALTSVERZEICHNIS
INDICE ILLUSTRADO

FIG. INDEX

FIG. 5101  Frame & Weight	FIG. 5201  Hood & Hinge	FIG. 5301  Instrument Panel & Floor	FIG. 5308  Driver Seat	FIG. 5401  Head Guard & Accessory	FIG. 5405  Indicator Plate	FIG. 5502  Canvas Cabin & Front Glass
BODY, ELECTRICAL GROUP 						
 Wiring & Clamp						
 Lamp						
 Lamp Bracket						
 Meter & Switch						
 Wiper Motor & Blade						 Speedo Meter & Speed Alarm

Y-0000 064

G203-3

FIG. INDEX










FIG. 6101  Mast	FIG. 6301  Lift Bracket & Fork	FIG. 6302  Chain & Chain Wheel	FIG. 6501 (SV, V)  Lift Cylinder	FIG. 6502 (FV, FSV)  Front Lift Cylinder	FIG. 6503 (FV, FSV)  Rear Lift Cylinder	FIG. 6504 (M)  Lift Cylinder
MAST, HYDRAULIC COMPONENT GROUP 						
						FIG. 6505 (F, FS)  Front Lift Cylinder
						FIG. 6506 (F, FS)  Rear Lift Cylinder
						FIG. 6511  Tilt Cylinder
						FIG. 6701  Oil Pump
			FIG. 6802  Mast Piping	FIG. 6801  Body Piping	FIG. 6709  Oil Control Valve Link	FIG. 6705  Oil Control Valve

FIG. 0901
STANDARD TOOL

0901

MAIN

87/10



0901-010

PART NAME	PART NAME	QTY
CODE		
0901-01	TOOL SET, STANDARD	1
0901-10	SPANNER SET	1
0901-11	PUMP ASSY, GREASE	1
0901-12	METER ASSY, HYDRAULIC SAILING	1
0901-40	BAG, TOOL	1
0901-41	PLIERS	1
0901-42	DRIVER, SCREW	1
0901-43	WRENCH, MONKEY	1
0901-45	ROD, THERMOMETER	1
0901-46	FUSE	1
0901-47	WRENCH, HUB NUT BOX	1

G203-001E

FIG-1401
DRIVE MOTOR


1401

MAIN


87/10

DPR

STM



1401-007A



1401-006C

G203-001


1401-007A

1401-006C 0128

1401

87/10

PART NAME	PART NAME	QTY
CODE		
1401-01	MOTOR ASSY. DRIVE	1
1401-01A	BEARING, DRIVE MOTOR, NO.1	1
1401-01B	BEARING, DRIVE MOTOR, NO.2	1
1401-01C	SHIM	99
1401-10	YOKE ASSY	1
1401-11	HOLDER ASSY. BRUSH	4
1401-12	ARMATURE ASSY. DRIVE	1
1401-16A	BOLT, STUD (TERMINAL)	1 - 3
1401-40	BRUSH, DRIVE MOTOR	4
1401-41	BRACKET, NO.1	1
1401-41A	SEAL, OIL (FOR BRACKET)	1
1401-42	BRACKET, NO.2	1
1401-43	COVER, MOTOR	1
1401-44	COVER, BRUSH	1
1401-45	BRACKET, DRIVE MOTOR MOUNTING, NO.1	1
1401-46	BRACKET, DRIVE MOTOR MOUNTING, NO.2	1
1401-50	RUBBER, CUSHION (FOR MOTOR MOUNTING)	2
1401-AC	INSULATOR	8
1401-AD	WASHER, PLATE	8
1401-AE	WASHER, SPRING	8
1401-AF	NUT	8
1401-AG	WASHER, PLATE	4-12
1401-AO	PLATE, CUSHION RUBBER	1
1401-AS	WASHER, WAVE	1




G203-002E

1402

87/10

STM




1402-024A

G203-001

1402

87/10

PART NAME	PART NAME	QTY
CODE		
1402-01	MOTOR ASSY, PUMP	1
1402-01A	BEARING, PUMP MOTOR, NO.1	1
1402-01B	BEARING, PUMP MOTOR, NO.2	1
1402-10	YOKE ASSY, PUMP MOTOR	1
1402-11	HOLDER ASSY, PUMP MOTOR	4
1402-12	ARMATURE ASSY, PUMP MOTOR	1
1402-16A	BOLT, STUD (TERMINAL)	2
1402-35	INSULATOR SUB-ASSY, MOTOR MOUNTING	4
1402-40	BRUSH, PUMP MOTOR	4
1402-41	BRACKET, NO.1	1
1402-42	BRACKET, NO.2	1
1402-43	COVER, MOTOR	1
1402-44	COVER, BRUSH	1
1402-45	BRACKET, PUMP MOTOR MOUNTING	1
1402-48	PLATE, PUMP MOTOR SET	1
1402-AB	INSULATOR	4
1402-AD	WASHER, SPRING	4
1402-AE	NUT	4
1402-AN	WASHER, PLATE	8
1402-AQ	BOLT	4
1402-AR	WASHER, SPRING	8
1402-AS	NUT	8
1402-AT	NUT	1



1402-025

G203-002E

FIG. 1403


1403

MAIN


87/10

20.25 (FDR NO P/B MOTOR)

20,25 (HIGH P. P/\$) [FOR MEIDEN P/\$ MOTOR]



1403-023



1403-022

G203-001


FIG. 1403
POWER STEERING PUMP DRIVE MOTOR

1403

MAIN

87/10

J20, J25 (FOR MEIDEN P/S MOTOR)




1403 022


PART NAME	PART NAME	QTY
CODE		
1403-01	MOTOR ASSY, POWER STEERING	1
1403-01A	BEARING, POWER STEERING MOTOR	2
1403-10	YOKE ASSY, POWER STEERING MOTOR	1
1403-11	HOLDER ASSY, BRUSH	1
1403-12	ARMATURE ASSY, POWER STEERING	2- 4
1403-15	FRAME ASSY, COMMUTATOR	1
1403-16A	BOLT, STUD (TERMINAL)	1
1403-30	BRACKET SUB-ASSY, MOTOR MOUNTING	1
1403-31	INSULATOR SUB-ASSY, BODY MOUNTING	3
1403-40	BRUSH, POWER STEERING MOTOR	2- 4
1403-41	BRACKET, NO.1	1
1403-42	BRACKET, NO.2	1
1403-44	COVER, BRUSH	1
1403-45	SPRING, POWER STEERING MOTOR BRUSH	2
1403-AA	BOLT	2
1403-AB	INSULATOR	4
1403-AC	BOLT	3
1403-AD	WASHER, SPRING	3
1403-AE	NUT	4
1403-AF	FRINGER	1
1403-AG	WASHER, PLATE	4
1403-AH	WASHER, PLATE	4
1403-AI	WASHER, SPRING	4
1403-AT	CLAMP	1
1403-BB	BOLT, W/WASHER	1

G203-002E

2401

87/10





2401-094

G203-002

FIG. 2401
CONTROL PANEL


2401

MAIN

87/10

(SCR HANDLING)

01



2401-093

G203-003

FIG. 2401
CONTROL PANEL

2401

MAIN

87/10

PART NAME	PART NAME	QTY
CODE		
2401-01	PANEL ASSY, DRIVE CONTROL	1
2401-03	PANEL ASSY, RESISTOR	1
2401-26	SENSOR ASSY, CURRENT	1
2401-27	BOARD ASSY	1
2401-28	BOARD ASSY	1
2401-40	THYRISTOR, MAIN	1
2401-48	DIODE	1
2401-74	WIRING SUB-ASSY, CONTROL	1
2401-77	TRANSISTOR	1
2401-83	HEATSINK, TMP	1
2401-89	CONDENSER	1
2401-96	DIODE	1
2401-98	BDDT	1
2401-AK	VARI-OHM ASSY	1
2401-AL	KNOB	1
2401-BA	INSULATOR	4
2401-BL	BOLT	4
2401-BM	WASHER, SPRING	4
2401-BN	WASHER, PLATE	4
2401-BU	BRACKET SUB-ASSY, CAPACITOR	1
2401-BV	BRACKET SUB-ASSY	1
2401-BY	BRACKET SUB-ASSY, TERMINAL	2
2401-CC	PLATE	1
2401-DC	SPACER, NO.1	2
2401-DD	SPACER, NO.2	1
2401-DJ	WIRING, NO.1	1
2401-DK	WIRING, NO.2	1
2401-DL	WIRING, NO.3	1
2401-DS	TERMINAL BLOCK, FUSE	1- 2
2401-DV	GROMMET	4-10
2401-DW	SHEET	1
2401-DZ	COVER	1
2401-EA	BUSH	1
2401-EC	TERMINAL	1
2401-ED	NUT	6- 9
2401-EN	SHEET	1
2401-ES	WASHER, SPRING	6
2401-ET	WASHER, PLATE	9-15
2401-EU	BAND	1
2401-EW	STAY SUB-ASSY	1
2401-EZ	PLATE, TERMINAL NUMBER	1
2401-FT	RESISTOR	1- 6
2401-GL	WIRING SUB-ASSY	1
2401-GH	BAR	1- 2
2401-GN	GROMMET	3
2401-GR	BOLT	2
2401-GZ	BAR	1
2401-HA	BAR	1
2401-HW	BRACKET SUB-ASSY	1
2401-JA	BAR	1
2401-JB	BAR	1
2401-JM	SCREW	4- 6
2401-JD	SCREW	4
2401-JQ	SCREW	4
2401-JT	WASHER, SPRING	4
2401-JU	WASHER, PLATE	4
2401-JV	SCREW	12
2401-KE	SCREW	10
2401-KL	BOLT, STUD	1
2401-KT	PLATE	1
2401-KU	CASE SUB-ASSY	1
2401-KV	BASE	1
2401-KW	BLOCK, TERMINAL FUSE	1
2401-KX	BASE SUB-ASSY	1

PART NAME	PART NAME	QTY
CODE		
2401-KY	BOLT, W/WASHER	2
2401-KZ	BOLT, W/WASHER	2- 4
2401-LA	BASE	1
2401-LB	NUT	4
2401-LC	WASHER, PLATE	8
2401-LD	WASHER, SPRING	4


G203-004E

FIG. 2402
CONTACTOR PANEL

2402

MAIN

87/10



G203-001

FIG. 2402
CONTACTOR PANEL


2402

MAIN

87/10

(SCR HANDLING)

01



2402-076

G203-002

FIG. 2402
CONTACTOR PANEL

2402

MAIN

87/10

PART NAME	PART NAME	QTY
CODE		
2402-01	PANEL ASSY, CONTACTOR	1
2402-40	DIODE	3
2402-41	FUSE (F1)	1
2402-42	FUSE (F2)	1
2402-47	TRANSISTOR	1
2402-53	RESISTOR	1
2402-58	HEATSINK	1
2402-59	HEATSINK	1
2402-60	SENSOR ASSY, CURRENT	1
2402-61	HARNES SUB-ASSY	1
2402-BK	HOLDER, TERMINAL	1- 2
2402-BQ	SCREW	8
2402-BX	GROMMET	17
2402-BY	PLATE, TERMINAL NUMBER	1
2402-CF	WASHER, PLATE	5
2402-CG	WASHER, SPRING	5
2402-CN	COVER	1
2402-CP	TERMINAL	3
2402-CS	SCREW	5
2402-CY	BAR	2
2402-CZ	BOLT	6
2402-DA	BAR	1
2402-DH	BAR	1
2402-DI	BAR	1
2402-DJ	BAR	1
2402-DP	SHEET	1- 2
2402-DQ	BAR	1
2402-DR	BAR	1
2402-DS	BAR	1
2402-DT	BAR	1
2402-EA	INSULATOR	5
2402-EM	PLATE	1
2402-EW	BUSHING	1
2402-EX	BUSHING	1
2402-FD	BAR	1
2402-FE	SHEET	1
2402-FF	SHEET	1
2402-FG	SHEET	1
2402-FH	BASE	1
2402-FJ	BRACKET SUB-ASSY, TERMINAL	1
2402-FK	BOLT	1
2402-FL	BOLT	3
2402-FM	NUT	12-14
2402-FN	WASHER, PLATE	18-24
2402-FD	WASHER, SPRING	12-13
2402-FP	BAR	2
2402-FQ	BAR	2
2402-FR	WASHER, SPRING	8
2402-FS	WASHER, PLATE	5
2402-FU	BRACKET SUB-ASSY	1
2402-FV	CASE SUB-ASSY	1
2402-FW	BRACKET SUB-ASSY	1
2402-FX	SCREW	13
2402-FY	SCREW	2
2402-FZ	SCREW	8-10
2402-GA	BOLT, W/WASHER	2
2402-GB	BRACKET SUB-ASSY	1
2402-GC	SCREW	2
2402-GD	SPACER	1
2402-GE	BOLT, STUD	1

G203-003E

FIG. 2403
CONTACTOR ASSY


2403

MAIN


87/10

[DRIVE]

[SHORT]



2403-061




2403-063


G203-001

[PUMP]

(SCR HANDLING) (PUMPI



2403-057



24033-D62

G203-002

FIG. 2403
CONTACTOR ASSY



2403

MAIN

87/10

20.25 (FOR ND P/S MOTOR)

20.25 (HIGH P. P/S) (FOR HEIDEN P/S MOTOR)



2403-007A

2403 006

G203-003

2403 006

2403 007A 0141

FIG. 2403
CONTACTOR ASSY


2403

MAIN


87/10

20.25 (HIGH P. P/S) (FOR MEIDEN P/S MOTOR)

J20. J25 (FOR MEIDEN P/S MOTOR)



2403 D15



2403 D07A

G203-004


FIG. 2403
CONTACTOR ASSY

2403

MAIN

87/10




J20, J25 (FOR MEIDEN P/S MOTOR)



2403-016

PART NAME	PART NAME	QTY
CODE		
2403-09	CONTACTOR ASSY, POWER STEERING, LARGE	1
2403-10	CONTACTOR ASSY, DRIVE	2
2403-11	CONTACTOR ASSY, SHORT	1
2403-12	CONTACTOR ASSY, PUMP	1
2403-13	CONTACTOR ASSY, POWER STEERING	1
2403-22	CONTACT SUB-ASSY, PUMP MOVING	1
2403-23	CONTACT SUB-ASSY, POWER STEERING MOVING	1
2403-25	COIL SUB-ASSY	1- 4
2403-40	CONTACT, DRIVE FIXED, NO.1	2
2403-41	CONTACT, DRIVE FIXED, NO.2	2
2403-42	CONTACT, SHORT FIXED	2
2403-43	CONTACT, PUMP FIXED	1
2403-44	CONTACT, POWER STEERING FIXED	1
2403-45	BLOCK, CONTACT (FOR PUMP CONTACTOR)	1
2403-46	DIODE	1
2403-47	FUSE (F3)	1
2403-49	CONTACT, PUMP FIXED, NO.2	1
2403-52	CONTACT, MOVING	1- 2
2403-53	CONTACT, STATIONARY	1
2403-56	IFRAME	1- 4
2403-AF	ISPRING, NO.1	1- 4
2403-AG	ISPRING, NO.2	1- 4
2403-AI	ISWITCH, MICRO	1
2403-AJ	IBARRIER, NO.1	1
2403-AK	IBARRIER, NO.2	1
2403-AL	IINSULATOR	1
2403-AP	IGUIDE, PLUNGER	1
2403-AQ	IFRAME	1
2403-AS	IBASE	1
2403-AT	IBAR	1
2403-AU	IBAR	1
2403-AV	IHOLDER, TERMINAL	1
2403-AY	INUT	2- 6
2403-AZ	IWASHER, SPRING	3- 8
2403-BA	IWASHER, PLATE	3-12
2403-BG	IWIRE, LEAD	1
2403-BJ	ISUPPORT	1- 4
2403-BL	ISCREW	1-12
2403-BD	ISCREW	1- 4
2403-BP	IPIN	1- 4
2403-CB	PLUNGER, MOVING	1
2403-CI	CLIP, FUSE	2
2403-CJ	PIPE	1
2403-CM	ISUPPORT	1- 4
2403-CN	ICORE, MOVING	1- 4
2403-CD	ICORE, FIXED	1- 4
2403-CP	IMAGNET	2- 8
2403-CQ	IBOLT	1- 4
2403-CR	ISPACER	1- 4
2403-CS	ICAP	2- 8
2403-CT	IPIN	1- 4
2403-CU	CONNECTOR	1- 4
2403-CV	TAB	2- 8

G203-005E



G203-001


FIG. 2413
CIRCUIT BREAKER

2413

MAIN

87/10

(CIRCUIT BREAKER)



2413-001

PART NAME	PART NAME	QTY
CODE		
2413-01	BREAKER ASSY, CIRCUIT	1
2413-10	BOARD ASSY, CIRCUIT	1
2413-20	BASE SUB-ASSY, BREAKER	1
2413-40	RESISTOR	1
2413-AA	TERMINAL BLOCK, FUSE	1
2413-AB	NUT	4
2413-AC	WASHER, SPRING	4
2413-AD	WASHER, PLATE	8
2413-AE	SPACER	2
2413-AF	COVER	1
2413-AG	PLATE, TERMINAL NUMBER (N1)	1
2413-AH	PLATE, TERMINAL NUMBER (N0)	1

G203-001E

FIG. 2501
BATTERY






2501

MAIN


87/10

20.25 (G.S..CENTRAL FILLING)

20.25 (YUA5A)





2501-130





91611 40840



AC (LONG)



2501 033



G203-002

FIG. 2501
BATTERY





2501

MAIN

87/10

20.25 (YUASA, CENTRAL FILLING)

20 (SHIN-KOBE)




2501-008


G203-003

J20, J25 (G.S.)

J20, J25 (G.S.-CENTRAL FILLING)



2501-030



2501 13:

G203-004

FIG. 2501
BATTERY



2501

MAIN



87/10

J20, J25 (YUASA)

J20, J25 (YUASA..CENTRAL FILLING)



2501-031




2501-032

G203-005

2501

87/10

PART NAME	PART NAME	QTY
CODE		
2501-01	BATTERY ASSY, W/CASE	1
2501-10	PLUG ASSY, VENT	1-24
2501-11	SENSOR ASSY, LEVEL	1
2501-13	PLUG ASSY, VENT, A	8-16
2501-14	PLUG ASSY, VENT, B	4-8
2501-15	PLUG ASSY, VENT, C	4-8
2501-20	CASE SUB-ASSY, BATTERY	1
2501-30	LEVER SUB-ASSY, EMERGENCY	1
2501-40	KNOB, EMERGENCY LEVER	1
2501-41	PLUG, BATTERY	1
2501-AA	COVER, TERMINAL, LH	1-14
2501-AB	COVER, TERMINAL, RH	1-16
2501-AC	COVER, TERMINAL	2-32
2501-AD	PLUG, VENT	17-23
2501-AE	CAP	17-24
2501-AF	PACKING	17-23
2501-AG	FLOAT	17-24
2501-AH	BRACKET	1
2501-AN	CAP	1
2501-AD	PACKING	1
2501-AP	FLOAT	1
2501-AQ	FLOAT, ROD SUPPORT	23
2501-AR	PLUG, VENT	1
2501-AS	ALARM	1
2501-AU	BRACKET SUB-ASSY, EMERGENCY LEVER	1
2501-AV	BUSHING	2
2501-AW	SPRING, TORSION	1
2501-AX	RUBBER, BATTERY CABLE	1
2501-AY	PLATE SUB-ASSY, BATTERY RUBBER	1
2501-AZ	BUSHING	2
2501-BA	STOPPER SUB-ASSY, BATTERY CASE	1
2501-BB	SPRING, BATTERY STOPPER	1
2501-BG	TUBE	1-2
2501-BI	TANK	1
2501-BJ	METER ASSY, HYDRO SAILING	1
2501-BK	HANGER, BATTERY CASE, FRONT	1
2501-BL	STAY SUB-ASSY, BATTERY CASE, NO.2	1
2501-BM	TURNBUCKLE	1
2501-BN	NUT	1
2501-BO	HANGER	2
2501-BP	RUBBER, CUSHION	7-8
2501-BT	RING	48
2501-BU	PIPE	1-2
2501-BV	PIPE, INLET	1



7501-012

G203-006E


FIG. 2511
BATTERY MOUNT CHARGER

2511


MAIN

87/10

STM.-20 [440AH/SHR]



STM.-20,25 [480-560AH/SHR]



G203-001

FIG. 2511
BATTERY MOUNT CHARGER

2511

MAIN

87/10

PART NAME CODE	PART NAME	QTY
2511-01	CHARGER ASSY, BATTERY	1
2511-02	TRANSFORMER ASSY	1
2511-10	TIMER ASSY	1
2511-14	SWITCH ASSY, MAGNET	1
2511-20	TRANSFORMER SUB-ASSY	1
2511-31	PLUG SUB-ASSY	1
2511-33	CABLE SUB-ASSY, CHARGER	1
2511-34	SWITCH SUB-ASSY, MAGNET	1
2511-35	RELAY SUB-ASSY, THERMAL	1
2511-41	ELEMENT, SILICON, FORWARD	3
2511-42	ELEMENT, SILICON, REVERSE	3
2511-47	FUSE	1
2511-BM	BRACKET, CHARGER	1
2511-BN	BOLT, W/WASHER	4
2511-CA	WIRING, NO. 1	3
2511-CB	WIRING, NO. 2	1
2511-CC	WIRING, NO. 3	1
2511-CD	WIRING, NO. 4	1
2511-CE	WIRING, NO. 5	1
2511-CF	PLATE	1
2511-CG	SHEET	1
2511-CD	RUBBER	1
2511-CP	HARNESS SUB-ASSY	1

G203-002E

FIG.2512
BATTERY SEPARATE CHARGER


2512

MAIN




87/10

(G.S.)

(YUASA)



2512-0578



2512-0655

G203-001

FIG. 2512
BATTERY SEPARATE CHARGER

2512

MAIN

87/10

PART NAME CODE	PART NAME	QTY
2512-01	CHARGER ASSY, BATTERY SEPARATE	1
2512-13	CABLE ASSY, CHARGER (DC)	1
2512-14	SWITCH ASSY, MAGNET	1
2512-18	DVT ASSY	1
2512-20	TRANSFORMER SUB-ASSY	1
2512-21	BVT ASSY	1
2512-34	SWITCH SUB-ASSY, MAGNET	1
2512-35	RELAY SUB-ASSY, THERMAL	1
2512-40	HANDLE	1
2512-41	ELEMENT, SILICON, FORWARD	3
2512-42	ELEMENT, SILICON, REVERSE	3
2512-43	SUB-TRANSFORMER, CHARGER	1
2512-44	PLUG	1
2512-46	CABLE (AC)	1
2512-47	FUSE	1
2512-AC	TERMINAL	1- 4
2512-AD	METER ASSY, AMPERE	1
2512-AE	SHUNT	1
2512-AG	RUBBER	4
2512-AI	AMMETER	1
2512-AJ	SHUNT	1
2512-AK	CABLE	1
2512-AL	CABLE	1- 2
2512-AR	RESISTOR	1



G203-002E

FIG. 2611
ACCELERATOR

2611

MAIN

87/10



2611-061

2611-010

G203-001

FIG. 2611
ACCELERATOR

2611

MAIN

87/10

PART NAME CODE	PART NAME	QTY
2611-10	SWITCH ASSY, ACCELERATOR (PEDAL TYPE)	1
2611-40	VARI-OHM	1
2611-41	PEDAL, ACCELERATOR	1
2611-42	ARM, ACCELERATOR LINK	1
2611-43	ROD, ACCELERATOR PEDAL	1
2611-44	SWITCH, MICRO	1
2611-47	PAD, PEDAL	1
2611-48	ROD, ACCELERATOR LINK	1
2611-49	BOOT	1
2611-50	END, CONNECTING ROD, NO.1	1
2611-51	END, CONNECTING ROD, NO.2	1
2611-52	SPRING, TENSION, NO.1	2
2611-AA	BUSHING	2
2611-AB	BUSHING	2
2611-AI	PIN, SPRING	1
2611-AK	BUSHING	1
2611-AL	BUSHING	2
2611-AR	SUPPORT	1
2611-BB	SCREW	4
2611-BK	BRACKET, PEDAL	1
2611-BL	PIN, W/WASHER	1
2611-BM	ROLLER, ACCELERATOR LINK	1
2611-BN	BOLT	1
2611-BO	NUT	1
2611-BP	HOLDER	1
2611-BQ	GEAR	1
2611-BR	GEAR, ACCELERATOR	1
2611-B6	LEVER, SWITCH	1
2611-BT	COLLAR	1
2611-BU	SPACER	1
2611-BV	PLUG	1
2611-BX	RING, SNAP	1


G203-002E

FIG. 3305
GEAR CASE & GEAR

3305

MAIN

87/10



PART NAME	PART NAME	QTY
CODE		
3305-01	CASE ASSY, GEAR	1
3305-20	CASE SUB-ASSY, GEAR	1
3305-20A	GASKET, GEAR CASE	1
3305-40	GEAR, OUTPUT	1
3305-41	GEAR, DRIVE	1
3305-41A	BEARING (FOR DRIVE GEAR)	1
3305-AA	BOLT	4
3305-AB	WIRE	2
3305-AL	SHIM	99

G203-001E

FIG. 3310
CHANGE LEVER



3310

MAIN

87/10

20,25

J20, J25



G203-001

FIG. 3310
CHANGE LEVER

3310

MAIN

87/10

PART NAME CODE	PART NAME	QTY
3310-01	SWITCH ASSY, DIRECTION	1
3310-10	SHAFT ASSY, DIRECTION SWITCH	1
3310-10A	BUSH, NO.1 (FOR DIRECTION SWITCH SHAFT)	1
3310-10B	BUSH, NO.2 (FOR DIRECTION SWITCH SHAFT)	1
3310-10C	BUSH, NO.3 (FOR DIRECTION SWITCH SHAFT)	2
3310-21	CAM SUB-ASSY, DIRECTION SWITCH	1
3310-32	ARM SUB-ASSY, DIRECTION	1
3310-40	LEVER	1
3310-41	CAM	1
3310-43	SWITCH, MICRO, NO.1	3- 4
3310-44	SWITCH, MICRO, NO.2	3
3310-45	KNOB	1
3310-46	BOOT (FOR CONTROL SHAFT)	1
3310-47	SHAFT, DIRECTION SWITCH, LWR	1
3310-50	HOUSING, ROLLER	1
3310-51	ROLLER	1
3310-52	SPRING, COMPRESSION	1
3310-53	KILLER, SPARK	1
3310-AB	PLUG	1
3310-AC	TAB	1
3310-AE	BOOT	1
3310-AF	SPRING, PIN STOPPER	1
3310-AG	ROLLER, NEEDLE	1
3310-AH	STAY, DIRECTION SWITCH BRACKET	1
3310-AI	BRACKET SUB-ASSY, DIRECTION SWITCH	1
3310-AJ	PIN, SPRING	1
3310-AK	PLATE	7
3310-AL	NUT, PLATE	3
3310-AM	PLATE, CHANGE LEVER	1
3310-AN	PLATE, INDICATOR	1
3310-AD	SCREW	2
3310-AP	PIN, SPRING	1
3310-AQ	SCREW	4
3310-AR	SCREW	2
3310-AS	SWITCH, MICRO	1
3310-AT	LEVER, HORN	1
3310-AU	BOSS, LEVER	1
3310-AX	SCREW SET, SWITCH	1
3310-AY	BOLT, STUD	1
3310-AZ	GROMMET	1
3310-BA	COVER	1
3310-BB	PLATE, NO.1	1
3310-BC	PLATE, NO.2	1
3310-BD	CLIP	1

G203-002E




FIG. 4101
DIFFERENTIAL

4101

MAIN

87/10

PART NAME CODE	PART NAME	QTY
4101-02	CASE ASSY, DIFFERENTIAL	1
4101-10	RING GEAR & PINION SET, DIFFERENTIAL	1
4101-10A	BEARING, DRIVE PINION	2
4101-10B	BEARING, DRIVE PINION PILOT	1
4101-10C	NUT, LOCK	1
4101-10D	SHIM, BEARING PRELOAD ADJUST	99
4101-20	CASE SUB-ASSY, DIFFERENTIAL	1
4101-20A	NUT, ADJUSTING	2
4101-20B	BEARING, DIFFERENTIAL CASE	2
4101-40	HOUSING, DIFFERENTIAL	1
4101-40B	RING, O (FOR DIFFERENTIAL HOUSING)	1
4101-40C	PLUG, BREATHER (FOR DIFFERENTIAL HOUSING)	1
4101-44	PLUG (FOR INPUT SHAFT)	1
4101-44A	PACKING (FOR INPUT SHAFT PLUG)	1
4101-46	GEAR, SIDE	2
4101-46A	WASHER, SIDE GEAR THRUST	2
4101-47	SPIDER	1
4101-48	PINION	4
4101-48A	WASHER, PINION THRUST	4
4101-49	PLUG, DRAIN	1
4101-49A	GASKET, DRAIN PLUG	1
4101-50	RETAINER, DRIVE PINION BEARING	1
4101-50D	SHIM, DIFFERENTIAL DRIVE PINION BEARING	99
4101-54	CAP, RING GEAR THRUST SCREW	1
4101-55	BOLT, RING GEAR SET	12
4101-AB	BOLT	16
4101-AC	SCREW, RING GEAR THRUST	1
4101-AD	NUT	1
4101-AF	LOCK, ADJUSTING	2
4101-AG	PLUG, W/HEAD STRAIGHT SCREW	1
4101-AH	GASKET	1
4101-AI	PLUG	1
4101-AJ	GASKET	1
4101-AK	BOLT	2
4101-AL	BOLT	4
4101-AD	SPACER, BEARING	1


G203-002E

FIG. 4201
FRONT AXLE SHAFT

4201

MAIN

87/10



PART NAME CODE	PART NAME	QTY
4201-40	SHAFT, FRONT AXLE	2
4201-40C	SEAL, OIL (FOR FRONT AXLE SHAFT)	2
4201-40D	GASKET, FRONT AXLE SHAFT	2
4201-41	HUB, FRONT AXLE	2
4201-41A	SEAL, OIL (FOR FRONT AXLE HUB)	2
4201-41B	BEARING, NO.1 (FOR FRONT AXLE HUB)	4
4201-41D	NUT, BEARING LOCK	2
4201-41E	BOLT, HUB	12
4201-41G	NUT, HUB	12
4201-41H	BOLT, DOUBLE WHEEL STOP	12
4201-42	DRUM, BRAKE	2
4201-43	BRACKET, FRONT AXLE, RH	1
4201-43A	NUT, BRAKE SET SELF	12
4201-43B	RING, O (FOR FRONT AXLE BRACKET)	2
4201-44	BRACKET, FRONT AXLE, LH	1
4201-49	PLATE, LOCK NUT	2
4201-53	HOUSING, FRONT AXLE	2
4201-53A	RING, O (FOR FRONT AXLE HOUSING)	2
4201-AA	BOLT	4
4201-AB	BOLT, BRACKET SET	4
4201-AC	BOLT, STUD BRAKE SET	12
4201-AD	WASHER, CD SPRING	12
4201-AE	BOLT	2
4201-AJ	BOLT	16
4201-AP	NUT	12


G203-001E

FIG. 4301
REAR AXLE & TIE-ROD

4301

MAIN

87/10



4301-0058

PART NAME	PART NAME	QTY
CODE		
4301-01	AXLE ASSY, RR	1
4301-10	END ASSY, TIE-ROD, NO.1	2
4301-10A	NUT, CASTLE (FOR TIE-ROD END)	4
4301-10B	NUT (RH THREADS)	2
4301-10C	PIN, COTTER (FOR TIE-ROD END)	4
4301-11	END ASSY, TIE-ROD, NO.2	2
4301-11B	NUT (LH THREADS)	2
4301-13K	TIE-ROD KIT	2
4301-20	BEAM SUB-ASSY, REAR AXLE	1
4301-20A	BUSH, REAR AXLE BEAM	2
4301-20B	SHIM, REAR AXLE BEAM	1
4301-23	BELLCRANK SUB-ASSY, STEERING	1
4301-23A	BEARING (FOR STEERING BELLCRANK)	2
4301-23B	SEAL, OIL (FOR STEERING BELLCRANK)	2
4301-23K	SEAL KIT, BELLCRANK PIN	1
4301-40	KNUCKLE, STEERING, RH	1
4301-41	KNUCKLE, STEERING, LH	1
4301-42	PIN, STEERING KNUCKLE KING	2
4301-42A	BEARING, STEERING KNUCKLE THRUST	2
4301-42B	SEAL, OIL, NO.1	4
4301-42C	BEARING, NEEDLE	4
4301-42D	SHIM, STEERING KNUCKLE	2
4301-42E	SEAL, OIL, NO.2	2
4301-42K	SEAL KIT, KING PIN	2
4301-43	PIN, KING PIN LOCK	2
4301-44	HUB, REAR AXLE	2
4301-44A	BEARING, INNER	2
4301-44B	BEARING, OUTER	2
4301-44C	BOLT, HUB	10-12
4301-44D	NUT, HUB	10-12
4301-44E	PIN, REAR AXLE COTTER	2
4301-44F	SEAL, OIL (FOR REAR AXLE HUB)	2
4301-44G	NUT, CASTLE (FOR REAR AXLE HUB)	2
4301-45	CAP, REAR AXLE HUB	2
4301-47	TIE-ROD	2
4301-48	PIN, BELLCRANK	1
4301-AA	BOLT	2
4301-AB	FITTING, GREASE	4
4301-AC	FITTING, GREASE	2
4301-AD	WASHER, CLAW	2
4301-AE	SHIM	2
4301-AF	PLATE, STOPPER	1

G203-001E




FIG-4401
FRONT WHEEL & TIRE(SINGLE)

4401

MAIN

87/10

(SINGLE)



4401-009

PART NAME	PART NAME	QTY
CODE		
4401-01	WHEEL ASSY	2
4401-13	TIRE ASSY	2
4401-14	CHAIN ASSY, TIRE	1
4401-20	WHEEL SUB-ASSY, DISC	2
4401-40	BAND, CHAIN	1
4401-AA	FLANGE, SIDE	2
4401-AB	RING, LOCK	2
4401-AC	BAND, BEND SHEET	2
4401-AE	TUBE SUB-ASSY	2
4401-AF	FLAP	2

G203-001E



FIG. 4402
FRONT WHEEL & TIRE (DOUBLE)

4402

MAIN

87/10

(DOUBLE)



PART NAME	PART NAME	QTY
CODE		
4402-02	WHEEL ASSY, INNER	2
4402-03	WHEEL ASSY, OUTER	2
4402-13	TIRE ASSY	4
4402-21	WHEEL SUB-ASSY, DISC, INNER	2
4402-22	WHEEL SUB-ASSY, DISC, OUTER	2
4402-41	EXTENSION, WHEEL TUBE VALVE	2
4402-AA	FLANGE, SIDE	4
4402-AB	RING, LOCK	4
4402-AC	BAND, BEND SHEET	4
4402-AE	TUBE SUB-ASSY	4
4402-AF	FLAP	4

G203-001E


FIG-4403
REAR WHEEL & TIRE

4403


MAIN

87/10

(DIVIDED RIM)



(SIDE RING RIM)



4403 009

PART NAME CODE	PART NAME	QTY
4403-01	WHEEL ASSY	2
4403-13	TIRE ASSY	2
4403-20	WHEEL SUB-ASSY, DISC	2
4403-20A	BOLT, DISC WHEEL SET	10
4403-20B	NUT, WHEEL SET	10
4403-20C	WASHER, WHEEL SET	10
4403-AA	IFLANGE, SIDE	2
4403-AB	IRING, LOCK	2
4403-AE	ITUBE SUB-ASSY	2
4403-AF	IFLAP	2

G203-001E

4403 008


0154

FIG. 4501
STEERING WHEEL

4501

MAIN

87/10



PART NAME	PART NAME	QTY
CODE		
4501-01	WHEEL ASSY, STEERING	1
4501-10	KNOB ASSY, STEERING WHEEL	1
4501-30	KNOB SUB-ASSY, STEERING WHEEL	1
4501-40	BUTTON, HORN	1
4501-42	PLATE, HORN CONTACT	1
4501-43	SEAT, HORN CONTACT	1
4501-44	SPRING, HORN	1
4501-45	PLATE, LEAD	1
4501-AA	SCREW	1
4501-AB	WASHER	3
4501-AC	SCREW	3
4501-AD	CAP, STEERING WHEEL	1
4501-AE	BOLT, STEERING WHEEL KNOB SET	1
4501-AF	BRACKET, STEERING WHEEL KNOB	1
4501-AG	SEAT, STEERING WHEEL KNOB BRACKET	1
4501-AH	SEAT, STEERING WHEEL KNOB BRACKET	1
4501-AI	SEAT, WHEEL KNOB SET PLATE	1
4501-AJ	PLATE, STEERING WHEEL KNOB SET	1
4501-AK	RING, HORN CONTACT NO.1	1
4501-AN	SPRING, LEAD	1
4501-AU	RING, HORN CONTACT NO.2	1
4501-AV	SCREW	3

4501-004

G203-001E

FIG. 4502
STEERING POST


4502

MAIN



87/10

{1/2}

[2/2]



10K - - - (INCL.)



4502-0180

G203-001

FIG. 4502
STEERING POST

4502

MAIN

87/10

PART NAME	PART NAME	QTY
CODE		
4502-01	POST ASSY, STEERING	1
4502-10	GEAR ASSY, STEERING	1
4502-10K	GEAR O/H KIT, STEERING	1
4502-11	BALL SCREW SET	1
4502-11A	BEARING, NO.1 (FOR BALL SCREW SET)	1
4502-11B	BEARING, NO.2 (FOR BALL SCREW SET)	1
4502-11C	BEARING, THRUST (FOR BALL SCREW SET)	2
4502-12	BODY ASSY, VALVE	1
4502-20	JACKET SUB-ASSY, MAST	1
4502-21	BOX SUB-ASSY, STEERING GEAR	1
4502-21B	BEARING, NO.1 (FOR SECTOR SHAFT)	1
4502-21C	SEAL, OIL (FOR SECTOR SHAFT)	1
4502-30	COVER SUB-ASSY, SIDE	1
4502-30A	BUSH, SECTOR SHAFT, NO.2	1
4502-30C	RING, O (FOR SIDE COVER)	1
4502-31	VALVE SET, RELIEF	1
4502-33	BODY SET, VALVE	1
4502-33A	RING, O (FOR VALVE BODY SET)	1
4502-40	SHAFT, SECTOR	1
4502-44	PISTON, BALANCE	1
4502-45	COVER, TOP	1
4502-45A	RING, O (FOR TOP COVER)	1
4502-46	COVER, END	1
4502-46C	RING, O (FOR END COVER)	1
4502-49	GROMMET, STEERING COLUMN (INSULATOR)	1
4502-AA	WASHER, SPRING	10
4502-AB	BOLT	4
4502-AE	STAY SUB-ASSY, STEERING	1
4502-AF	CLAMP	1
4502-AG	CLAMP, STEERING COLUMN, LOWER	1
4502-AK	BOLT, STUD	4
4502-AL	PLUG, OIL	1
4502-AM	BOLT, ADJUSTING	1
4502-AN	PLATE, ADJUSTING	99
4502-AD	BOLT	4
4502-AP	NUT	1
4502-AS	SEAL, OIL	1
4502-AT	COLLAR	1
4502-AU	RING, SNAP	1
4502-AV	PACKING	2
4502-AW	NUT	1
4502-AX	NUT	1
4502-AY	NUT, LOCK	1
4502-AZ	BOLT	3
4502-BA	RING, SNAP	1
4502-BB	SEAT	8
4502-BC	SPRING	4
4502-BD	STOPPER, BALANCE PISTON	1
4502-BE	RING, O	1
4502-BG	SPRING, BALANCE PISTON	1

G203-002E

FIG. 4507
DRAG LINK & STEERING PIPING


4507

MAIN


87/10

20.25

J20, J25



4507-0000



4507-0091

G203-001

FIG. 4507
DRAG LINK & STEERING PIPING

4507

MAIN

87/10

PART NAME CODE	PART NAME	QTY
4507-10	END ASSY, DRAG LINK	2
4507-10A	NUT, CASTLE (FOR DRAG LINK END)	2
4507-11	END ASSY, POWER CYLINDER	2
4507-11A	NUT, CASTLE (FOR POWER CYLINDER END)	2
4507-30	PIPE SUB-ASSY, NO.1 (STEERING TO CYLINDER)	1
4507-31	PIPE SUB-ASSY, NO.2 (STEERING TO CYLINDER)	1
4507-32	PIPE SUB-ASSY (PUMP TO STEERING)	1
4507-40	ROD, DRAG LINK, NO.1	1
4507-41	ARM, PITMAN	1
4507-42	HOSE, POWER CYLINDER, NO.1	1
4507-43	HOSE, POWER CYLINDER, NO.2	1
4507-44	END, POWER CYLINDER	1
4507-45	HOSE, POWER STEERING PUMP SUCTION	1
4507-46	HOSE, HIGH PRESSURE (PUMP TO STEERING)	1
4507-AA	CLAMP, END	2
4507-AB	CLAMP, PIPE	1
4507-AC	CLAMP, END	2
4507-AD	BOLT	2
4507-AF	BOLT	2
4507-AQ	CLAMP	2
4507-AS	FITTING	1
4507-AT	FITTING	1
4507-AU	RING, O	2
4507-BB	CLAMP	1
4507-BD	WASHER, SPRING	2
4507-BE	NUT	2
4507-BF	WASHER, SPRING	2
4507-BG	NUT	2
4507-BH	BOLT	1
4507-BI	WASHER	1
4507-BJ	CLAMP	1
4507-BK	PLATE	1


G203-002E

FIG. 4508
STEERING POWER CYLINDER

4508

MAIN

87/10




4508-041A

PART NAME	PART NAME	QTY
CODE		
4508-01	CYLINDER ASSY, POWER	1
4508-01K	PACKING KIT, POWER CYLINDER	1
4508-20	CYLINDER SUB-ASSY, POWER	1
4508-40	ROD, PISTON	1
4508-40A	NUT, SELF LOCK (FOR PISTON)	1
4508-41	PISTON	1
4508-42	RING, PISTON	2
4508-43	GUIDE, ROD	1
4508-45	BOOT, CYLINDER	1
4508-AA	BUSH	1
4508-AB	RING, SNAP	1
4508-AC	SEAL, DUST	1
4508-AD	RING, O	1
4508-AI	COLLAR, REAR COVER	1
4508-AJ	SEAT	2
4508-AM	RING, SNAP	1
4508-AL	PACKING, U	1
4508-AM	RING, BACK UP	1
4508-BE	WIRE	1
4508-BX	PLUG	2
4508-CA	BALL	2
4508-CB	RING, O	2

G203-001E

4510

87/10




0177

FIG. 4601
PARKING BRAKE

4601

MAIN

87/10



4601 008A

PART NAME	PART NAME	QTY
CODE		
4601-10	HANDLE ASSY, PARKING BRAKE	1
4601-25	CABLE SUB-ASSY, PARKING BRAKE, NO.2	1
4601-29	LEVER SUB-ASSY, INTERMEDIATE	1
4601-AE	BAR SUB-ASSY, EQUALIZER	1
4601-AF	PIN, W/HOLE	1
4601-AG	PULLEY	1
4601-AH	CLAMP, WIRE SET	1
4601-AI	CLAMP	1
4601-AL	PIN, W/HOLE	1
4601-AP	BUSH	1
4601-AQ	RING, SNAP	1
4601-AR	BOLT	2
4601-AS	WASHER, SPRING	2



G203-001E

FIG. 4701
BRAKE PEDAL

4701

MAIN

87/10



4701-113

PART NAME CODE	PART NAME	QTY
4701-20	PEDAL SUB-ASSY, BRAKE	1
4701-20A	BUSH (FOR BRAKE PEDAL)	2
4701-22	BRACKET SUB-ASSY, BRAKE PEDAL	1
4701-40	PAD, PEDAL	1- 2
4701-47	SPRING, TENSION (FOR PEDAL RETURN)	1
4701-AA	SPACER	1
4701-AB	BOLT	1
4701-AG	BOLT, ADJUST	1
4701-AQ	BOLT	4
4701-AR	WASHER, SPRING	4


G203-001E

FIG. 4702
BRAKE MASTER CYLINDER

4702

MAIN

87/10



4702-043A

PART NAME	PART NAME	QTY
CODE		
4702-01	CYLINDER ASSY, MASTER	1
4702-01K	CYLINDER O/H KIT, MASTER	1
4702-10	PISTON SUB-ASSY, MASTER CYLINDER	1
4702-11	RESERVOIR SET, MASTER CYLINDER	1
4702-14	VALVE ASSY	1
4702-31	BRACKET SUB-ASSY, RESERVOIR	1
4702-40	ROD, PUSH	1
4702-42	BOOT	1
4702-43	HOSE, RESERVOIR	1
4702-45	CAP, RESERVOIR	1
4702-46	SPRING, COMPRESSION (FOR PISTON RETURN)	1
4702-48	STRAINER	1
4702-54	CUP, CYLINDER	1
4702-AA	RING, HOLE SNAP	1
4702-AB	PLATE, PISTON STOP	1
4702-AC	CLEVIS, PUSH ROD	1
4702-AD	CAP, BLEEDER PLUG	1
4702-AE	PLUG, BLEEDER	1
4702-AF	GASKET	2
4702-AI	BOLT, UNION	1
4702-AJ	GASKET	1
4702-AK	PIN	1
4702-AL	UNION	1
4702-AM	CLAMP	2
4702-AO	WASHER	1
4702-AP	BOLT	1
4702-AR	CAP	1
4702-AS	SEAT	1
4702-AT	CYLINDER ASSY, MASTER W/RESERVOIR	1
4702-BB	SPRING, COMPRESSION	1
4702-BI	GASKET	1
4702-BL	PLUG	1
4702-BM	GASKET	2
4702-BP	BOLT, UNION	1
4702-BR	UNION	1


G203-001E

FIG. 4714
BRAKE PIPE

4714

MAIN

87/10



PART NAME CODE	PART NAME	QTY
4714-20	PIPE SUB-ASSY, BRAKE, MAIN NO.1	1
4714-22	PIPE SUB-ASSY, BRAKE, RH NO.1	1
4714-23	PIPE SUB-ASSY, BRAKE, LH NO.1	1
4714-AB	GASKET	2
4714-AC	PLUG	1
4714-AE	3-WAY SUB-ASSY	1
4714-AF	BOLT	1
4714-AK	4-WAY SUB-ASSY, BRAKE	1
4714-AL	WASHER, SPRING	1

4714-082


G203-001E

FIG. 4715
DRUM BRAKE


4715

MAIN

87/10



10K (INCL. #1)



4715 007A

PART NAME	PART NAME	QTY
CODE		
4715-01	BRAKE ASSY, RH	1
4715-02	BRAKE ASSY, LH	1
4715-10	CYLINDER ASSY, WHEEL	2
4715-10K	CYLINDER O/H KIT, WHEEL	2
4715-20	SHOE SUB-ASSY (FOR FRONT OR UPPER)	2
4715-21	SHOE SUB-ASSY (FOR REAR OR LOWER)	1
4715-22	PLATE SUB-ASSY, BACKING, RH	1
4715-23	PLATE SUB-ASSY, BACKING, LH	1
4715-30	SCREW SUB-ASSY, ADJUSTING, RH	1
4715-31	SCREW SUB-ASSY, ADJUSTING, LH	1
4715-32	PISTON SUB-ASSY, WHEEL CYLINDER	4
4715-33	CABLE & FITTING SUB-ASSY	2
4715-40	BOOT, WHEEL CYLINDER	4
4715-41	CUP, WHEEL CYLINDER PISTON	4
4715-42	LEVER, AUTOMATIC ADJUSTMENT, RH	1
4715-43	LEVER, AUTOMATIC ADJUSTMENT, LH	1
4715-44	GUIDE, CABLE	2
4715-45	SPRING, SHOE HOLD DOWN	4
4715-46	CUP, SHOE HOLD DOWN	8
4715-47	SPRING, ADJUSTER	2
4715-48	PIN, SHOE HOLD DOWN	4
4715-49	ROD, PUSH	4
4715-51	SPRING, ANCHOR TO SHOE	4
4715-AA	BOLT & WASHER SET	4
4715-AB	COVER, HOLE	2
4715-AD	PLATE, SHOE GUIDE	2
4715-AE	WASHER, SPRING	2
4715-AF	LEVER SUB-ASSY, PARKING	1
4715-AQ	STRUT, LEVER	1
4715-AH	RING, SNAP	2
4715-AI	RETAINER	2
4715-AJ	SPRING, STRUT TO SHOE	2
4715-AK	CAP, BLEEDER SCREW	2
4715-AL	SCREW, BLEEDER	2
4715-AN	SPRING, WHEEL CYLINDER	2
4715-AX	SPRING, LEVER RETURN, RH	1
4715-AY	SPRING, LEVER RETURN, LH	1
4715-BA	WASHER	2

G203-001E

FIG. 5101
FRAME & WEIGHT



5101

MAIN

87/10

20,25

J20, J25



G203-001

FIG. 5101
FRAME & WEIGHT

5101


MAIN

87/10

PART NAME	PART NAME	QTY
CODE		
5101-29	COVER SUB-ASSY, BATTERY	1
5101-30	DRAWBAR SUB-ASSY	1
5101-34	GUARD SUB-ASSY, MUD, RH	1
5101-35	GUARD SUB-ASSY, MUD, LH	1
5101-48	WEIGHT SUB-ASSY, NO-2	1
5101-AA	GUARD, MUD, FRONT	2
5101-AB	BOLT	2
5101-AC	WASHER, WAVE	4
5101-AD	HOSE, LOW PRESSURE	1
5101-AE	CLAMP SUB-ASSY	1- 2
5101-AF	BOLT, HEXAGON	1
5101-AG	WASHER, PLATE	1
5101-AI	SPONGE	1
5101-AM	WASHER, PLATE	2
5101-AP	PLATE, HANGER	2
5101-AW	WASHER, PLATE	8-10
5101-BB	BOLT	8-10
5101-BH	WASHER, SPRING	2
5101-BR	GROMMET	1
5101-B5	BOLT	4
5101-CK	INSULATOR, EDGE	1
5101-CV	PLATE	1
5101-CZ	NUT	2
5101-DA	WASHER	2
5101-DB	BOLT	4
5101-DC	PLATE, COVER	1
5101-DE	SEAL, COVER	1
5101-DG	CUSHION, SIDE COVER	1
5101-DH	RUBBER, UPPER	1
5101-DI	RUBBER, LOWER	1
5101-DJ	RUBBER, SIDE	2
5101-DL	PLATE SUB-ASSY, WEIGHT	1
5101-EJ	PLATE, CHARGER HOLE	1
5101-EK	RUBBER	1
5101-EZ	RUBBER	1
5101-FA	WASHER, SPRING	4
5101-FR	SPONGE	1

G203-002E

J20, J25



G203-001

FIG. 5201
HOOD & HINGE

5201

MAIN

87/10

PART NAME CODE	PART NAME	QTY
5201-20	HOOD SUB-ASSY. ENGINE (OR BATTERY)	1
5201-30	HINGE SUB-ASSY. ENGINE (OR BATTERY) HOOD	1
5201-32	CATCH SUB-ASSY. (FOR HOOD)	1
5201-33	STAY SUB-ASSY. ENGINE (OR BATTERY) HOOD	1
5201-40	RUBBER CUSHION (FOR HOOD)	1
5201-AC	WASHER, PLATE	9
5201-B0	NUT	2
5201-BP	HOOD SUB-ASSY. REAR	1
5201-BQ	BOLT	9
5201-BR	WASHER, SPRING	9
5201-BV	HOLDER	3
5201-BW	SCREW	15
5201-CW	SUPPORT, HOOD STAY	1

G203-002E

DIM

FIG. 5301
INSTRUMENT PANEL & FLOOR


5301

MAIN


87/10

20, 25

J20, J25



5301-0189



5301-019B

G203-001

FIG. 5301
INSTRUMENT PANEL & FLOOR

5301

MAIN

87/10

PART NAME	PART NAME	QTY
CODE		
5301-20	PANEL SUB-ASSY, INSTRUMENT	1
5301-30	TDE-BOARD SUB-ASSY, NO.1	1
5301-31	TDE-BOARD SUB-ASSY, NO.2	1
5301-34	CLAMP SUB-ASSY, PAPER	1
5301-AA	SCREW	4
5301-AB	WASHER, WAVE	4
5301-AC	PLUG	1
5301-AD	PLUG	2
5301-AE	PLUG	1
5301-AF	WASHER, PLATE	4
5301-AD	SAFETY WALK	1
5301-BB	SAFETY WALK	1
5301-BT	SAFETY WALK	1
5301-BV	BOLT	4
5301-BW	BOLT	2
5301-CD	WASHER, SPRING	4
5301-CU	RUBBER	1
5301-CV	PLATE	1
5301-CW	RUBBER	1
5301-DB	BRACKET, SEAT	2
5301-EH	MAT	1

G203-002E

FIG. 5308
DRIVER SEAT


5308

MAIN


87/10

20.25

20.25 (W/ABSORBER)



5308-111



5308-110

G203-001

FIG-5308
DRIVER SEAT


5308

MAIN


87/10

J20, J25

J20, J25 (W/ABSORBER)



5308-022



5308-008

G203-002

FIG-5308
DRIVER SEAT

5308

MAIN

87/10

PART NAME CODE	PART NAME	QTY
5308-01	SEAT ASSY	1
5308-10	CUSHION ASSY	1
5308-11	TRACK ASSY	1
5308-12	TRACK ASSY, SEAT OUTER, RH	1
5308-13	TRACK ASSY, SEAT OUTER, LH	1
5308-20	SEAT SUB-ASSY, BACK	1
5308-23	ABSORBER ASSY, SHOCK	1
5308-40	FRAME, BACK SEAT	1
5308-AA	RUBBER, VIBRATION ISOLATOR	2
5308-AC	NUT, CAP	2
5308-AF	SPRING, TENSION, BACK SEAT	2
5308-AH	PIN	4
5308-AK	RING, E	3
5308-AM	ABSORBER, SHOCK	1
5308-AN	PIN, NO.3	1
5308-AD	BUSH	1
5308-AP	ADJUSTER, ROD	1
5308-AQ	RUBBER, SEAT CUSHION	1
5308-AW	BUSH	2
5308-BC	NUT, STOPPER	2
5308-BD	BOLT, W/WASHER	2
5308-CR	WASHER, SPRING	4
5308-EA	NUT	4
5308-FF	WASHER	4
5308-FG	WASHER	2
5308-FH	ARM SUB-ASSY	1
5308-FX	LINK ASSY, SEAT	1


G203-003E

FIG. 5401
HEAD GUARD & ACCESSORY

5401

MAIN

87/10



5401-0178

PART NAME		QTY
CODE	PART NAME	
5401-30	SHEET SUB-ASSY, HEAD GUARD	1
5401-31	MIRROR SUB-ASSY, BACK	1- 2
5401-32	BRACKET SUB-ASSY, BACK MIRROR	1- 2
5401-40	REFLECTOR	2
5401-AE	PLUG, HOLE	1
5401-A1	CUSHION, SHEET	2
5401-BO	BRACKET, REFLECTOR, LH	1
5401-BP	BRACKET, REFLECTOR, RH	1
5401-BS	PLATE SUB-ASSY, HEAD GUARD	1
5401-GK	GUARD SUB-ASSY, FRONT	1
5401-GL	BUSH	2

G203-001E

5401 0178

0188

FIG. 5405
INDICATOR PLATE


5405

MAIN


87/10

20.25

J20, J25



5405-016D



5405-017D

G203-001

FIG. 5405
INDICATOR PLATE

5405

MAIN

87/10

PART NAME CODE	PART NAME	QTY
5405-AA	PLATE, CAUTION	2
5405-AC	PLATE, CAUTION	1
5405-AD	PLATE, CAUTION	2
5405-AE	PLATE, INDICATOR	1
5405-AG	PLATE, LOAD INDICATOR	1
5405-AJ	PLATE, CAUTION	1
5405-AL	MARK, TOYOTA	2
5405-AM	PLATE, SERVICE INDICATOR	1
5405-AP	STRIPE	1
5405-AQ	PLATE, CAPACITY INDICATOR	2
5405-AR	PLATE, CAUTION	1
5405-AT	PLATE, CAUTION	1
5405-AU	RIVET	4
5405-BG	PLATE, TEMPERATURE	2
5405-BH	MARK, TOYOTA	2
5405-BW	MARK, SYMBOL	2
5405-CA	PLATE, CAUTION	1
5405-CB	PLATE, INDICATOR	1
5405-CC	PLATE, CAUTION	1
5405-CN	PLATE, INDICATOR	1
5405-CR	RIVET	8
5405-DA	PLATE, LOAD CONDITION	1
5405-DB	PLATE, WARNING	4
5405-DG	PLATE, CAUTION	1

G203-002E


FIG. 5502
CANVAS CABIN & FRONT GLASS

5502


MAIN

87/10

(FRONT GLASS)






(KOG)





5502-009A

PART NAME	PART NAME	QTY
CODE		
5502-02	PANEL ASSY, FRONT GLASS	1
5502-20	PANEL SUB-ASSY, FRONT GLASS	1
5502-40	GLASS, WINDSHIELD	1
5502-50	WEATHERSTRIP	1
5502-AE	CUSHION, WINDSHIELD	2
5502-AF	PLATE, WINDSHIELD	2
5502-AG	PLATE, FRONT	1
5502-BC	SPONGE	1

G203-001E



5611-008C



5611-010B

G203-001

FIG. 5611
LAMP

5611

MAIN

87/10

PART NAME	PART NAME	QTY
CODE		
5611-01	LAMP ASSY, HEAD	2
5611-01B	BULB (FOR HEAD LAMP)	2
5611-02	LAMP ASSY, WORKING	1
5611-02B	BULB (FOR WORKING LAMP)	1
5611-03	LAMP ASSY, FLASHER	2
5611-03A	BULB (FOR FLASHER LAMP)	2
5611-03B	LENS (FOR FLASHER LAMP)	2
5611-04	LAMP ASSY, REAR COMBINATION	2
5611-04A	BULB (FOR REAR COMBINATION LAMP)	2
5611-04B	LENS (FOR REAR COMBINATION LAMP)	2
5611-05	LAMP ASSY, LICENCE	1
5611-05A	BULB (FOR LICENCE LAMP)	1
5611-07	LAMP ASSY, CLEARANCE	2
5611-07A	BULB (FOR CLEARANCE LAMP)	2
5611-07B	LENS (FOR CLEARANCE LAMP)	2
5611-09	LAMP ASSY, PILOT	1
5611-09A	BULB (FOR PILOT LAMP)	1
5611-09B	LENS (FOR PILOT LAMP)	1
5611-26	LAMP ASSY, COMBINATION PILOT	1
5611-26A	BULB (FOR COMBINATION PILOT LAMP)	2
5611-35	LAMP ASSY, ROTARY	1
5611-35A	BULB (FOR ROTARY LAMP)	1
5611-35B	LENS, W/PACKING (FOR ROTARY LAMP)	1
5611-AF	CORD, HEAD LAMP	3
5611-AI	SCREW	4-12
5611-AK	PACKING	4
5611-AL	SCREW	4
5611-AW	REFLECTOR	1
5611-BH	PLUG, HOLE	5
5611-CV	FLANGE	1


G203-002E

FIG. 5612
LAMP BRACKET

5612

MAIN

87/10



PART NAME	PART NAME	QTY
CODE		
5612-AB	BRACKET SUB-ASSY, HEAD LAMP	1
5612-AE	COVER, CLEARANCE LAMP	2
5612-AG	BRACKET, FLASHER LAMP	1
5612-AI	BRACKET SUB-ASSY, COMBINATION LAMP	1
5612-AJ	BRACKET, WORKING LAMP	1
5612-AK	GROMMET	2
5612-AM	BRACKET, REAR COMBINATION LAMP	1
5612-AN	PLATE SUB-ASSY, LICENCE	1
5612-AR	WASHER, RUBBER	4
5612-AY	GUARD SUB-ASSY, LAMP	2
5612-AZ	BRACKET SUB-ASSY, ROTARY LAMP	1
5612-BA	CLIP	1
5612-BI	PLATE, GUM	2
5612-BL	PLATE SUB-ASSY, HEAD LAMP	1
5612-BY	WASHER	4
5612-CX	BOLT	1- 4
5612-CZ	GROMMET	4


G203-001E

FIG. 5702
METER & SWITCH

5702

MAIN

87/10



PART NAME	PART NAME	QTY
CODE		
5702-05	RELAY ASSY, FLASHER	1
5702-10	HORN ASSY	1
5702-11	Buzzer ASSY, BACK	1
5702-12	CHIME ASSY, BACK	2
5702-13	SWITCH ASSY, TURN SIGNAL	1
5702-13A	SWITCH SUB-ASSY, MICRO	2
5702-14	SWITCH ASSY, LIGHT CONTROL	1
5702-15	SWITCH ASSY, STARTER	1
5702-18	SWITCH ASSY, HORN	1
5702-18A	CONTACT, HORN	1
5702-20	METER ASSY, VOLTAGE	1
5702-24	METER ASSY, HOUR	1
5702-25	INDICATOR ASSY, BATTERY CAPACITY	1
5702-30	DISPLAY ASSY	1
5702-40	SWITCH ASSY, LIMIT (FOR PUMP MOTOR)	2
5702-42	SWITCH ASSY, LIMIT (FOR BRAKE)	1
5702-43	SWITCH ASSY, LIMIT (FOR STOP LAMP)	1
5702-44	SWITCH ASSY, LIMIT (FOR PARKING BRAKE)	1
5702-4F	RELAY ASSY, BATTERY CAPACITY	1
5702-AG	BODY, SWITCH	1
5702-AH	HOLDER, HORN POINT	1
5702-AI	SPRING, HORN CONTACT	1
5702-AJ	COVER	1
5702-AK	BLOCK, LOCKING	1
5702-AL	COVER, RUBBER	1
5702-AM	HARNESS ASSY	1
5702-AN	ACTUATOR	2
5702-AD	PLATE, SWITCH	1
5702-AP	LEVER, SIGNAL	1
5702-AQ	BELLOWS	1
5702-AR	ROLLER	1
5702-AS	HOLDER, ROLLER	1
5702-AT	SPRING	1
5702-AU	BRACKET, PARKING BRAKE	1
5702-AX	HARNESS ASSY	1
5702-AY	BRACKET, CHIME	1
5702-BA	SCREW	2
5702-BG	CLIP	2
5702-CV	BOLT	1
5702-DC	VARISTOR	1
5702-DJ	BRACKET, LIMIT SWITCH	1
5702-HA	SENSOR	1

G203-001E

FIG. 5706
SPEEDOMETER & SPEED ALARM


5706

MAIN


87/10

(SPEEDOMETER)

(SPEED ALARM)



5706 005



5706 006

G203-001

5706 008

5706 008 0186

FIG-5706
SPEEDOMETER & SPEED ALARM

5706

MAIN

87/10

PART NAME CODE	PART NAME	QTY
5706-10	SPEEDOMETER ASSY	1
5706-13	PICK-UP ASSY, SPEEDOMETER	1
5706-14	BOX ASSY, SPEED ALARM	1
5706-15	RELAY ASSY	1
5706-17	BUZZER ASSY, SPEED ALARM	1
5706-20	HARNESS SUB-ASSY, SPEED ALARM	1
5706-AA	BRACKET, SPEEDOMETER	1
5706-AB	BRACKET SUB-ASSY, SPEED ALARM	1
5706-AE	HARNESS, SPEEDOMETER	1
5706-AF	HARNESS, SPEEDOMETER PICK UP	1
5706-AG	STAY, RELAY	1

G203-002E



FIG. 5801
WIPER MOTOR & BLADE

5801

MAIN

87/10

(FRONT GLASS)




PART NAME	PART NAME	QTY
CODE		
5801-10	MOTOR ASSY, WIPER	1
5801-30	BLADE SUB-ASSY, WIPER	1
5801-31	ARM SUB-ASSY, WIPER	1
5801-AA	HARNESS, WIPER	1
5801-AQ	RESISTOR ASSY	2
5801-AS	HARNESS ASSY, RESISTER	1
5801-AT	SCREW, W/WASHER	2
5801-AU	PLATE, RESISTOR SET	1
5801-AV	COVER, RESISTOR	1

G203-001E

6101

87/10

PART NAME	PART NAME	QTY
CODE		
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	2
6101-21	MAST SUB-ASSY, INNER	1
6101-22	MAST SUB-ASSY, MIDDLE	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-31	STRIP SUB-ASSY, MIDDLE MAST	2
6101-31A	SHIM, MIDDLE MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-42	ROLLER, LIFT (FOR MIDDLE MAST UPPER)	2
6101-43	ROLLER, LIFT (FOR MIDDLE MAST LOWER)	2
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	2
6101-AH	BOLT	8



G101 047

G203-001E

FIG. 6301
LIFT BRACKET & FORK


6301

FSV

87/10

FSV

(L/BACKREST)



6301 037A

PART NAME	PART NAME	QTY
CODE		
6301-03	BRACKET ASSY, LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	99
6301-43	SHAFT, SIDE ROLLER	2
6301-44	HOLDER, SIDE ROLLER SHAFT	4
6301-44A	SHIM (FOR SHAFT HOLDER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4
6301-AB	PLATE, SIDE	2
6301-AQ	BOLT	4

G203-001E




FIG. 6503
REAR LIFT CYLINDER

6503

FSV

87/10

FSV



6503-017

PART NAME	PART NAME	QTY
CODE		
6503-01	CYLINDER ASSY, LIFT, RH	1
6503-01K	CYLINDER O/H KIT, LIFT, RH	1
6503-02	CYLINDER ASSY, LIFT, LH	1
6503-02K	CYLINDER O/H KIT, LIFT, LH	1
6503-11	VALVE ASSY, SAFETY DOWN	1
6503-20	CYLINDER SUB-ASSY, LIFT, RH	1
6503-21	CYLINDER SUB-ASSY, LIFT, LH	1
6503-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6503-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6503-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6503-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH	1
6503-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6503-AA	RING, WEAR	2
6503-AB	PACKING, U	2
6503-AC	RING, BACK UP	2
6503-AE	PACKING, U	2
6503-AF	RING, O	2
6503-AG	SEAL, DUST	2
6503-AH	RING, O	1
6503-AI	SHIM	99
6503-AK	BRACKET SUB-ASSY, LIFT CYLINDER	2
6503-AL	BUSHING	4
6503-AM	SPACER	2
6503-AN	SHIM	99

G203-001E

FIG. 6511
TILT CYLINDER

6511

FSV

87/10

FSV

FSV (TABLE)

テイルト角度表
TABLE OF TILT RANGE

生産期間 PROD DATE	型 式 MODELS	タイヤ TIRE	繰 高 LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8003-	FV, M, SV, V	SINGLE	H2000-H3700		8D - 12D
8003-	FV, M, SV, V	DOUBLE	H2000-H4500		6D - 12D
8003-	FV, M, SV, V	SINGLE	H4000-H5000		8D - 8D
8003-	FV, M, SV, V	DOUBLE	H5000		8D - 8D
8003-	FV, M, SV, V		H2000	FRONT GLASS	8D - 10D
8003-	FSV		H3700-H4700	DOMESTIC	8D - 8D
8003-	FSV		H5000-H8500	DOMESTIC	3D - 8D
8003-	FSV		H3700-H6600	EXPORT	8D - 8D
8003-	FV, M, SV, V	SINGLE	H2000-H3700	AUSTRALIA	3D - 12D
8003-	FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	3D - 10D
8003-	FV, M, SV, V	SINGLE	H4000-H5000	AUSTRALIA	3D - 8D
8003-	FSV			AUSTRALIA	3D - 8D
8003-	FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	3D - 12D
8003-	FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	3D - 8D

6511-011

6511-086

G203-001





FIG. 6302
CHAIN & CHAIN WHEEL

6302

FSV

87/10

FSV



PART NAME		QTY
CODE	PART NAME	
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21A	NUT, CHAIN ADJUST (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-22	CHAIN SUB-ASSY (REAR)	2
6302-22K	BOLT KIT, CHAIN ANCHOR, NO.2 (REAR)	2
6302-22L	BOLT KIT, CHAIN ANCHOR, NO.2 (REAR)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-42	WHEEL, CHAIN (REAR)	4
6302-42A	RING, SHAFT SNAP (FOR CHAIN WHEEL)	4
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2
6302-AI	SPACER	2
6302-AL	COVER, CHAIN WHEEL	2
6302-BV	STOPPER, CHAIN	1

G203-001E


FIG. 6502
FRONT LIFT CYLINDER

6502

FSV

87/10

FSV



6502 047

PART NAME	PART NAME	QTY
CODE		
6502-01	CYLINDER ASSY, LIFT	1
6502-01K	CYLINDER O/H KIT, LIFT	1
6502-11	VALVE ASSY, SAFETY DOWN	1
6502-20	CYLINDER SUB-ASSY, LIFT	1
6502-21	ROD SUB-ASSY, LIFT CYLINDER	1
6502-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6502-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6502-AA	BUSHING	1
6502-AB	RING, O	1
6502-AC	RING, BACK UP	1
6502-AD	PACKING, U	1
6502-AE	RING, BACK UP	1
6502-AF	SEAL, DUST	1
6502-AG	RING, O	1
6502-AH	PLUG	1
6502-AI	RING, O	1
6502-AK	WASHER, PLATE	2
6502-AL	BOLT	2
6502-AM	WASHER, SPRING	2

G203-001E


FIG. 6511
TILT CYLINDER

6511

FSV

87/10

J20, J25, FSV (TILT BOOTS, TILT GAGE)



PART CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	4
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AN	COLLAR	4
6511-AD	SPACER, TILT CONTROL	2
6511-AR	BOLT	2
6511-AT	BOOT SUB-ASSY	2
6511-AU	BAR SUB-ASSY, TILT GAUGE	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE	1
6511-AW	PLATE, TILT CYLINDER INDICATOR	1
6511-BB	FITTING, GREASE	2
6511-BN	WASHER, PLATE	2
6511-BP	NUT	2
6511-BS	WIRE, CYLINDER BOOT	2
6511-BT	BOLT	4
6511-BU	WASHER	2
6511-CV	WASHER	4

G203-002E


FIG. 6701
OIL PUMP

6701

FSV


87/10

FSV



PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-16	GEAR & BUSH SET	1
6701-44	FLANGE, MOUNTING	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2
6701-BF	WASHER	2

G203-001E



6705-362

G203-001


FIG. 6705
OIL CONTROL VALVE

6705

FSV

87/10

FSV [2/2]



PART NAME	PART NAME	QTY
CODE		
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AG	SPRING	1
6705-AI	RING, O	1
6705-AK	HOLDER, SPRING	4
6705-AN	SCREW	8
6705-AD	PLUG	4
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AT	STOPPER	1
6705-AU	STOPPER	2
6705-AV	RING, O	1
6705-AX	RING, O	3
6705-AY	RING, O	2
6705-BA	SPRING, COMPRESSION	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BQ	RING, O	5
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-CL	BOLT	1
6705-DW	PLUG	1
6705-EX	BRACKET SUB-ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-FA	INSULATOR	4
6705-FZ	END, SPOOL	1
6705-GA	HOUSING, OUTLET	1

6705-363

G203-002E


FIG. 6709
OIL CONTROL VALVE LINK

6709

FSV

87/10

FSV



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-24	LEVER SUB-ASSY, CONTROL VALVE, NO.5	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-40	KNOB, OIL CONTROL VALVE LEVER	1
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-AA	BRACKET SUB-ASSY	1
6709-AF	SPACER	1
6709-LO	CAP	1

G203-001E

FIG-6801
BODY PIPING

6801

FSV

87/10

PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-12	VALVE ASSY, FLOW REGULATOR	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	ICAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT)	2
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	2
6801-50A	ICLAMP (FOR LIFT TO TANK NO.1 HOSE)	4
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	ICLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	ICLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	ICLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK)	1
6801-59A	ICLAMP (FOR LIFT TO TANK NO.2 HOSE)	2
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE	4
6801-AB	ICLAMP	1
6801-AC	RING, O	4
6801-AG	ICLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AK	ICLAMP	1
6801-AP	PIPE	1
6801-AR	FITTING	1
6801-AS	FITTING	1
6801-AT	FITTING	1
6801-AV	RING, O	3
6801-AW	ELBOW SUB-ASSY, 3-WAY	1
6801-AX	ICAP, OIL TANK OVERFLOW PIPE	1
6801-AZ	SPRING, COMPRESSION	1
6801-BA	PLUG	1
6801-BB	SPRING, COMPRESSION	1
6801-BC	BALL, STEEL	1
6801-BD	RING, O	1
6801-BF	BRACKET, FLOW REGULATOR	1
6801-B5	BOLT	2
6801-BT	WASHER	4
6801-BU	BOLT	2
6801-CH	FITTING	1
6801-CV	WASHER	2
6801-FB	BOLT	1
6801-FD	BOLT	1
6801-FF	WASHER	1
6801-FG	WASHER	1

G203-002E


FIG. 6802
MAST PIPING

6802

FSV

87/10

F5V



6802-016A

PART NAME	PART NAME	QTY
CODE		
6802-20	PULLEY SUB-ASSY, HOSE GUIDE, NO.1	1
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFT)	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT)	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AA	PIN, HOSE GUIDE PULLEY	1
6802-AC	RING, O	1
6802-AD	COLLAR	1
6802-A1	BRACKET, PIPE	1
6802-AJ	CLAMP	2
6802-AK	GUIDE SUB-ASSY, HOSE	1

G203-001E


FIG. 6101
MAST

6101

FV

87/10

FV



6101 048

PART NAME	PART NAME	QTY
CODE		
6101-20	MAST SUB-ASSY, OUTER	1
6101-20R	BUSH, MAST SUPPORT	2
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-53	CUSHION, MAST (FOR INNER MAST)	2
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	2
6101-AH	BOLT	4
6101-AI	STOPPER	2
6101-AJ	SHIM, STOPPER	99

G203-001E


FIG. 6301
LIFT BRACKET & FORK

6301

FV

87/10

FV



6301 03RA

PART NAME	PART NAME	QTY
CODE		
6301-03	BRACKET ASSY, LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-43	SHAFT, SIDE ROLLER	2
6301-44	HOLDER, SIDE ROLLER SHAFT	4
6301-44A	SHIM (FOR SHAFT HOLDER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4
6301-AB	PLATE, SIDE	2
6301-AG	BOLT	4

G203-001E


FIG. 6302
CHAIN & CHAIN WHEEL

6302

FV

87/10

FV



PART NAME	PART NAME	QTY
CODE		
6302-20A	NUT, CHAIN ADJUST	2
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2
6302-AI	SPACER	2
6302-BV	STOPPER, CHAIN	1

G203-001E


FIG. 6502
FRONT LIFT CYLINDER

6502

FV

87/10

FV



6502 028

PART NAME	PART NAME	QTY
CODE		
6502-01	CYLINDER ASSY, LIFT	1
6502-01K	CYLINDER O/H KIT, LIFT	1
6502-11	VALVE ASSY, SAFETY DOWN	1
6502-20	CYLINDER SUB-ASSY, LIFT	1
6502-21	ROD SUB-ASSY, LIFT CYLINDER	1
6502-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6502-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6502-AA	BUSHING	1
6502-AB	RING, O	1
6502-AC	RING, BACK UP	1
6502-AD	PACKING, U	1
6502-AE	RING, BACK UP	1
6502-AF	SEAL, DUST	1
6502-AG	RING, O	1
6502-AH	PLUG	1
6502-AI	RING, O	1
6502-AL	BOLT	2

G203-001E


FIG. 6503
REAR LIFT CYLINDER

6503

FV

87/10

FV



6503-004B

PART NAME	PART NAME	QTY
CODE		
6503-01	CYLINDER ASSY, LIFT, RH	1
6503-01K	CYLINDER O/H KIT, LIFT, RH	1
6503-02	CYLINDER ASSY, LIFT, LH	1
6503-02K	CYLINDER O/H KIT, LIFT, LH	1
6503-11	VALVE ASSY, SAFETY DOWN	1
6503-20	CYLINDER SUB-ASSY, LIFT, RH	1
6503-21	CYLINDER SUB-ASSY, LIFT, LH	1
6503-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6503-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6503-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6503-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH	1
6503-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6503-AA	RING, WEAR	2
6503-AC	RING, BACK UP	2
6503-AD	RING, □	2
6503-AE	PACKING, U	2
6503-AG	SEAL, DUST	2
6503-AH	RING, □	1
6503-AI	SHIM	99
6503-AJ	RING, BACK UP	2
6503-AK	BRACKET SUB-ASSY, LIFT CYLINDER	2
6503-AL	BUSHING	4
6503-AM	SPACER	2
6503-AN	SHIM	99
6503-AP	PLUG	2
6503-BB	BOLT	2

6203-001E

FIG. 6511
TILT CYLINDER

6511


FV

87/10

FV

FV (TABLE)

テイルト角度表
TABLE OF TILT RANGE



6511-086

生産期間 PROD DATE	型 式 MODELS	タイヤ TIRE	揚 場 LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8003-	FV, M, SV, V	SINGLE	H2000-H3700		6D - 12D
8003-	FV, M, SV, V	DOUBLE	H2000-H4500		6D - 12D
8003-	FV, M, SV, V	SINGLE	H4000-H5000		6D - 6D
8003-	FV, M, SV, V	DOUBLE	H5000		6D - 6D
8003-	FV, M, SV, V		H2000	FRONT GLASS	6D - 10D
8003-	FSV		H3700-H4700	DOMESTIC	6D - 6D
8003-	FSV		H5000-H6500	DOMESTIC	3D - 6D
8003-	FSV		H3700-H6500	EXPORT	6D - 6D
8003-	FV, M, SV, V	SINGLE	H2000-H3700	AUSTRALIA	3D - 12D
8003-	FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	3D - 10D
8003-	FV, M, SV, V	SINGLE	H4000-H5000	AUSTRALIA	3D - 6D
8003-	FSV			AUSTRALIA	3D - 6D
8003-	FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	3D - 12D
8003-	FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	3D - 6D

0511-011

G203-001


FIG. 6511
TILT CYLINDER

6511

FV

87/10

J20, J25..FV (TILT BOOTS, TILT GAGE)



PART NAME	PART NAME	QTY
CODE		
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	4
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AN	COLLAR	4
6511-AD	SPACER, TILT CONTROL	2
6511-AR	BOLT	2
6511-AT	BOOT SUB-ASSY	2
6511-AU	BAR SUB-ASSY, TILT GAUGE	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE	1
6511-AW	PLATE, TILT CYLINDER INDICATOR	1
6511-BB	FITTING, GREASE	2
6511-BN	WASHER, PLATE	2
6511-BP	NUT	2
6511-BS	WIRE, CYLINDER BOOT	2
6511-BT	BOLT	4
6511-BU	WASHER	2
6511-CV	WASHER	4

G203-002E


FIG. 6701
OIL PUMP

6701

FV

87/10

FV



6701-073A

PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-16	GEAR & BUSH SET	1
6701-44	FLANGE, MOUNTING	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2
6701-BF	WASHER	2

G203-001E


FIG. 6705 OIL CONTROL VALVE

6705

FV

87/10

FV (2/2)



PART NAME	PART NAME	QTY
CODE		
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AG	SPRING	1
6705-AI	RING, O	1
6705-AK	HOLDER, SPRING	4
6705-AN	SCREW	8
6705-AD	PLUG	4
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AT	STOPPER	1
6705-AU	STOPPER	2
6705-AV	RING, O	1
6705-AX	RING, O	3
6705-AY	RING, O	2
6705-BA	SPRING, COMPRESSION	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BQ	RING, O	5
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-CL	BOLT	1
6705-DW	PLUG	1
6705-EX	BRACKET SUB-ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-FA	INSULATOR	4
6705-FZ	END, SPOOL	1
6705-GA	HOUSING, OUTLET	1

6705-363

G203-002E


FIG-6709
OIL CONTROL VALVE LINK

6709

FV

87/10

FV



PART NAME	PART NAME	QTY
CODE		
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-24	LEVER SUB-ASSY, CONTROL VALVE, NO.5	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-40	KNOB, OIL CONTROL VALVE LEVER	1
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-AA	BRACKET SUB-ASSY	1
6709-AF	SPACER	1
6709-LO	CAP	1

G203-001E

FIG. 6801
BODY PIPING




FV (1/21)

6801

FY

87/10

FY 12/21



6801-156

6801-153

G203-001

FIG-6801
BODY PIPING

6801

FV

87/10

PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-12	VALVE ASSY, FLOW REGULATOR	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT)	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	2
6801-46	FITTING (FOR LIFT CYLINDER)	1
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-53	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-53A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-54	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AK	CLAMP	1
6801-AR	FITTING	1
6801-AS	FITTING	1
6801-AT	FITTING	1
6801-AV	RING, O	5
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-AZ	SPRING, COMPRESSION	1
6801-BA	PLUG	1
6801-BB	SPRING, COMPRESSION	1
6801-BC	BALL, STEEL	1
6801-BD	RING, O	1
6801-BE	BOLT	2
6801-BU	BOLT	2
6801-CH	FITTING	1
6801-CV	WASHER	2
6801-FB	BOLT	1
6801-FD	BOLT	1
6801-FF	WASHER	1
6801-FG	WASHER	1

G203-002E


FIG. 6802
MAST PIPING

6802

FV

87/10

FV



6802-016

PART NAME	PART NAME	QTY
CODE		
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFT)	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT)	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AB	FITTING	1
6802-AC	RING, O	2
6802-AF	GUARD SUB-ASSY, HOSE	1

G203-001E


FIG-6101
MAST

6101

SV

87/10

SV



6101 055

PART NAME	PART NAME	QTY
CODE		
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	2
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-53	CUSHION, MAST (FOR INNER MAST)	1
6101-AC	STOPPER, INNER MAST	1
6101-AD	FITTING, GREASE	2

G203-001E

6101 058

0227

FIG 6301
LIFT BRACKET & FORK



6301

SV

87/10

SV

(82017)



91611 40R14

6301 043A


PART NAME	PART NAME	QTY
CODE		
6301-03	BRACKET ASSY, LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-43	SHAFT, SIDE ROLLER	2
6301-44	HOLDER, SIDE ROLLER SHAFT	4
6301-44A	SHIM (FOR SHAFT HOLDER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2

G203-001E

6302

87/10

PART NAME	PART NAME	QTY
CODE		
6302-20	CHAIN SUB-ASSY	2
6302-20A	NUT, CHAIN ADJUST	2
6302-20L	BOLT KIT, CHAIN ANCHOR, NO.2	2
6302-20M	BOLT KIT, CHAIN EYE	2
6302-30	BEAM SUB-ASSY, CHAIN	1
6302-30A	BUSHING	2
6302-31	PIN SUB-ASSY, CHAIN WHEEL	1
6302-40	WHEEL, CHAIN	2
6302-AC	CLAMP, CHAIN ANCHOR BOLT	2
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AQ	PIN, SPRING	2
6302-AP	COLLAR, CHAIN WHEEL	4



G203-001E



FIG. 6501
LIFT CYLINDER

6501

SV

87/10

SV



6501-011

PART NAME	PART NAME	QTY
CODE		
6501-01	CYLINDER ASSY, LIFT, RH	1
6501-01K	CYLINDER O/H KIT, LIFT, RH	1
6501-02	CYLINDER ASSY, LIFT, LH	1
6501-02K	CYLINDER O/H KIT, LIFT, LH	1
6501-11	VALVE ASSY, SAFETY DOWN	1
6501-20	CYLINDER SUB-ASSY, LIFT, RH	1
6501-21	CYLINDER SUB-ASSY, LIFT, LH	1
6501-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6501-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6501-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6501-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH	1
6501-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6501-AA	RING, WEAR	2
6501-AB	PACKING, U	2
6501-AC	RING, BACK UP	2
6501-AE	PACKING, U	2
6501-AF	RING, D	2
6501-AG	SEAL, DUST	2
6501-AH	RING, D	1
6501-A1	SHIM	99
6501-AK	BRACKET SUB-ASSY, LIFT CYLINDER	2
6501-AL	BUSHING	4
6501-AM	SPACER	2
6501-AN	SHIM	99

G203-001E

FIG. 6511
TILT CYLINDER

6511


SV

87/10

SV

SV (TABLE)

テイルト角度表
TABLE OF TILT RANGE



生産期間 PROD DATE	型 式 MODELS	タイ 揚 TIRE LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8003-	FV, M, SV, V	SINGLE H2000-H3700		8D - 12D
8003-	FV, M, SV, V	DOUBLE H2000-H4500		6D - 12D
8003-	FV, M, SV, V	SINGLE H4000-H5000		6D - 8D
8003-	FV, M, SV, V	DOUBLE H5000		8D - 8D
8003-	FV, M, SV, V	H2000	FRONT GLASS	8D - 10D
8003-	FSV	H3700-H4700	DOMESTIC	8D - 6D
8003-	FSV	H5000-H6500	DOMESTIC	3D - 8D
8003-	FSV	H3700-H6500	EXPORT	6D - 6D
8003-	FV, M, SV, V	SINGLE H2000-H3700	AUSTRALIA	3D - 12D
8003-	FV, M, SV, V	H2000	FRONT GLASS AUSTRALIA	3D - 10D
8003-	FV, M, SV, V	SINGLE H4000-H5000	AUSTRALIA	3D - 8D
8003-	FSV		AUSTRALIA	3D - 6D
8003-	FV, M, SV, V	DOUBLE H2000-H4500	AUSTRALIA	3D - 12D
8003-	FV, M, SV, V	DOUBLE H5000	AUSTRALIA	3D - 6D

6511 D11

6511-086

G203-001

6511 086

6511 011 021


FIG. 6511
TILT CYLINDER

6511

SV

87/10

J20, J25, SV (TILT BOOTS, TILT GAGE)



6511-082

PART NAME	PART NAME	QTY
CODE		
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	4
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AN	COLLAR	4
6511-AO	SPACER, TILT CONTROL	2
6511-AR	BOLT	2
6511-AT	BOOT SUB-ASSY	2
6511-AU	BAR SUB-ASSY, TILT GAUGE	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE	1
6511-AW	PLATE, TILT CYLINDER INDICATOR	1
6511-BB	FITTING, GREASE	2
6511-BN	WASHER, PLATE	2
6511-BP	NUT	2
6511-BS	WIRE, CYLINDER BOOT	2
6511-BT	BOLT	4
6511-BU	WASHER	2
6511-CV	WASHER	4

G203-002E


FIG. 6701
PUMP

6701

SV

87/10

SV



PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-16	GEAR & BUSH SET	1
6701-44	FLANGE, MOUNTING	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2
6701-BF	WASHER	2

G203-001E


FIG-6705
OIL CONTROL VALVE

6705

SV

87/10

SV (1/2)




6705-362

G203-001

FIG. 6705
OIL CONTROL VALVE

SV (2/2)



6705

SV

87/10

PART NAME	PART NAME	QTY
CODE		
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE D/H KIT, OIL CONTROL	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AG	SPRING	1
6705-AI	RING, O	1
6705-AK	HOLDER, SPRING	4
6705-AN	SCREW	8
6705-AD	PLUG	4
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AT	STOPPER	1
6705-AU	STOPPER	2
6705-AV	RING, O	1
6705-AX	RING, O	3
6705-AY	RING, O	2
6705-BA	SPRING, COMPRESSION	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BQ	RING, O	5
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-CL	BOLT	1
6705-DM	PLUG	1
6705-EX	BRACKET SUB-ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-FA	INSULATOR	4
6705-FZ	END, SPOOL	1
6705-GA	HOUSING, OUTLET	1

6705-363

G203-002E


FIG-6709
6709 CONTROL VALVE LINK

6709

SV

87/10

SV




PART NAME	PART NAME	QTY
CODE		
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-24	LEVER SUB-ASSY, CONTROL VALVE, NO.5	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-40	KNOB, OIL CONTROL VALVE LEVER	1
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-AA	BRACKET SUB-ASSY	1
6709-AF	SPACER	1
6709-LO	CAP	1

G203-001E

6801


87/10

SV (2/2)



A schematic diagram of a branched polymer structure. It features a central vertical chain with several side branches. Labels include '51' at the top, '51A' and 'AW' on the upper branches, '59' on the main chain, '59A' on a lower branch, and 'AP' at the bottom left. The diagram illustrates the connectivity and branching of the polymer segments.

A diagram showing a corner formed by two lines meeting at a vertex. A black dot is located in the corner. Two rectangles are positioned near the dot: one labeled 'AX' and another labeled 'AB'. The rectangle 'AX' is oriented vertically, and the rectangle 'AB' is oriented horizontally. The dot is positioned between the two rectangles.



(20D, 35D, 45D,
45SD, OIL FULL)

A diagram of a cell with two labels: 'AB' at the top and 'AX' at the bottom. The cell is represented by a rounded rectangle with internal structures. A line connects 'AB' to a point on the cell's boundary, and another line connects 'AX' to a point on the cell's boundary.

G203-001

FIG. 6801
BODY PIPING

6801

SV

87/10

PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-12	VALVE ASSY, FLOW REGULATOR	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	ICAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT)	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	2
6801-46	FITTING (FOR LIFT CYLINDER)	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	2
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE)	4
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK)	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE)	2
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE	4
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	2
6801-AK	CLAMP	1
6801-AP	PIPE	1
6801-AR	FITTING	1
6801-AS	FITTING	1
6801-AT	FITTING	1
6801-AV	RING, O	3
6801-AW	ELBOW SUB-ASSY, 3-WAY	1
6801-AX	ICAP, OIL TANK OVERFLOW PIPE	1
6801-AZ	SPRING, COMPRESSION	1
6801-BA	PLUG	1
6801-BB	SPRING, COMPRESSION	1
6801-BC	BALL, STEEL	1
6801-BD	RING, O	1
6801-BE	PROTECTOR	1
6801-B5	BOLT	2
6801-BT	WASHER	4
6801-BU	BOLT	2
6801-CH	FITTING	1
6801-CV	WASHER	2
6801-FB	BOLT	1
6801-FD	BOLT	1
6801-FF	WASHER	1
6801-FG	WASHER	1

6203-002E


FIG. 6101
MAST

6101

V

87/10

V



PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	2
6101-BH	CAP, MAST SUPPORT	2

6101-276

G203-001E


Fig. 6301
LIFT BRACKET & FORK

6301

V

87/10

V



6301-D43A


PART NAME	PART NAME	QTY
CODE		
6301-03	BRACKET ASSY, LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LEFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-43	SHAFT, SIDE ROLLER	2
6301-44	HOLDER, SIDE ROLLER SHAFT	4
6301-44A	SHIM (FOR SHAFT HOLDER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-AA	COVER, LIFT BRACKET ROLLER	4

G203-001E

6302

87/10

Y



PART NAME	PART NAME	QTY
CODE		
6302-20	CHAIN SUB-ASSY	2
6302-20K	BOLT KIT, CHAIN ANCHOR, NO.1	2
6302-20L	BOLT KIT, CHAIN ANCHOR, NO.2	2
6302-40	WHEEL, CHAIN	2
6302-40A	RING, SHAFT SNAP (FOR CHAIN WHEEL)	2
6302-AD	NUT, HEXAGON	6
6302-AH	COVER, CHAIN WHEEL	2
6302-AN	NUT, HEXAGON	2
6302-BH	NUT, HEXAGON	4

G203-001E





FIG. 6501
LIFT CYLINDER

6501

y

87/10

✓



6501-038A

PART NAME	PART NAME	QTY
CODE		
6501-01	CYLINDER ASSY, LIFT, RH	1
6501-01K	CYLINDER D/H KIT, LIFT, RH	1
6501-02	CYLINDER ASSY, LIFT, LH	1
6501-02K	CYLINDER D/H KIT, LIFT, LH	1
6501-10	VALVE ASSY, FLOW REGULATOR	1
6501-11	VALVE ASSY, SAFETY DOWN	1
6501-20	CYLINDER SUB-ASSY, LIFT, RH	1
6501-21	CYLINDER SUB-ASSY, LIFT, LH	1
6501-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6501-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6501-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6501-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH	1
6501-41	COVER, LIFT CYLINDER	2
6501-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6501-AA	RING, WEAR	2
6501-AB	PACKING, U	2
6501-AC	RING, BACK UP	2
6501-AE	PACKING, U	2
6501-AF	RING, O	2
6501-AG	SEAL, DUST	2
6501-AH	RING, O	1
6501-AI	SHIM	99
6501-AM	SPACER	4
6501-AN	SHIM	99
6501-AO	SUPPORT, LIFT CYLINDER	1
6501-AQ	RING, O	1
6501-AZ	RUBBER	2
6501-B1	PISTON	1
6501-BJ	RDDY	1
6501-BK	SPRING	1
6501-BL	RING, SNAP	1
6501-BQ	PLATE	4
6501-BR	RUBBER	2

G203-001E


FIG-6511
TILT CYLINDER

6511

V 87/10

V [TABLE]

テイルト角度表
TABLE OF TILT RANGE



生産期間 PROD DATE	型 式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8003	FV, M, SV, V	SINGLE	H2000-H3700		6D - 12D
8003	FV, M, SV, V	DOUBLE	H2000-H4500		6D - 12D
8003	FV, M, SV, V	SINGLE	H4000-H5000		6D - 6D
8003	FV, M, SV, V	DOUBLE	H5000		6D - 6D
8003	FV, M, SV, V		H2000	FRONT GLASS	6D - 10D
8003	FSV		H3700-H4700	DOMESTIC	6D - 6D
8003	FSV		H5000-H6500	DOMESTIC	3D - 6D
8003	FSV		H3700-H6500	EXPORT	6D - 6D
8003	FV, M, SV, V	SINGLE	H2000-H3700	AUSTRALIA	3D - 12D
8003	FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	3D - 10D
8003	FV, M, SV, V	SINGLE	H4000-H5000	AUSTRALIA	3D - 6D
8003	FSV			AUSTRALIA	3D - 6D
8003	FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	3D - 12D
8003	FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	3D - 6D

6511-011

6511-086

G203-001

6511 086

6511 011 0243


FIG. 6511
TILT CYLINDER

6511

V

87/10

J20, J25..V (TILT BOOTS, TILT GAGE)



6511-082

PART NAME	PART NAME	QTY
CODE		
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER, FR	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	4
6511-AA	RING, HOLE SNAP	2
6511-AB	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AN	COLLAR	4
6511-AD	SPACER, TILT CONTROL	2
6511-AR	BOLT	2
6511-AT	BOOT SUB-ASSY	2
6511-AU	BAR SUB-ASSY, TILT GAUGE	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE	1
6511-AW	PLATE, TILT CYLINDER INDICATOR	1
6511-BB	FITTING, GREASE	2
6511-BN	WASHER, PLATE	2
6511-BP	NUT	2
6511-BS	WIRE, CYLINDER BOOT	2
6511-BT	BOLT	4
6511-BU	WASHER	2
6511-CV	WASHER	4

G203-002E


FIG - 6701
OIL PUMP

6701

Y

87/10


Y



6701-073A

PART NAME	PART NAME	QTY
CODE		
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-16	GEAR & BUSH SET	1
6701-64	FLANGE, MOUNTING	1
6701-65	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RINGS, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2
6701-BF	WASHER	2

G203-001E




6705-362

G203-001

FIG. 6705
OIL CONTROL VALVE

V 12/21



6705

V

87/10

PART NAME	PART NAME	QTY
CODE		
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AD	RING, O	1
6705-AE	RING, O	2
6705-AG	SPRING	1
6705-AI	RING, O	1
6705-AK	HOLDER, SPRING	4
6705-AN	SCREW	8
6705-AD	PLUG	4
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AT	STOPPER	1
6705-AU	STOPPER	2
6705-AV	RING, O	1
6705-AX	RING, O	3
6705-AY	RING, O	2
6705-BA	SPRING, COMPRESSION	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BQ	RING, O	5
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-CL	BOLT	1
6705-DW	PLUG	1
6705-EX	BRACKET SUB-ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-FA	INSULATOR	4
6705-FZ	END, SPOOL	1
6705-GA	HOUSING, OUTLET	1

6705-363

G203-002E


FIG. 6709
D/L CONT

6709

Y

87/10

3



6709-157


PART NAME	PART NAME	QTY
CODE		
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-24	LEVER SUB-ASSY, CONTROL VALVE, NO.5	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-40	KNOB, OIL CONTROL VALVE LEVER	1
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-AA	BRACKET SUB-ASSY	1
6709-AF	SPACER	1
6709-LO	CAP	1

G203-001E


6801

87/10


✓ [2/2]



(20D, 35D, 45D, 45SD,
COLD FISHER, R-PROOF FISHER,
OIL FULL, RUST PROOF)



6801-157



G203-001

PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	ICAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	2
6801-46	FITTING (FOR LIFT CYLINDER)	1
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	2
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE)	4
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK)	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE)	2
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE	4
6801-AB	CLAMP	1
6801-AC	RING, O	4
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	2
6801-AK	CLAMP	1
6801-AD	RING, O	1
6801-AP	PIPE	1
6801-AS	FITTING	1
6801-AW	ELBOW SUB-ASSY, 3-WAY	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE	1
6801-BS	BOLT	2
6801-BT	WASHER	4
6801-BU	BOLT	2
6801-BW	BOLT	1
6801-CH	FITTING	1
6801-CV	WASHER	2
6801-EM	HOSE, HIGH PRESSURE	1
6801-FB	BOLT	1
6801-FC	WASHER	1
6801-FD	BOLT	1
6801-FF	WASHER	1
6801-FG	WASHER	1