

**TOYOTA  
INDUSTRIAL  
VEHICLE**

**PARTS CATALOG**

FBA30

No.G210-1

**TOYOTA MOTOR CORPORATION  
TOYODA AUTOMATIC LOOM WORKS, LTD.**

# TOYOTA

## FORKLIFT TRUCK

### PARTS CATALOG

MODEL	-----	FBA30	-----
FRAME NO.	-----	FBA30	-----
LIFTING HEIGHT	----- mm		

#### DESCRIPTION

UL-approved Model Type E
UL-approved Model Type EE
Cold Storage Model Type 45S
Deadman Seat Brake
Fully Oil Charged Lift Cylinder


TOYOTA MOTOR CORPORATION  
TOYODA AUTOMATIC LOOM WORKS, LTD.

#### QUICK REFERENCE INDEX

INTRODUCTION

ELECTRICAL SYSTEM

CHASSIS

BODY

ELECTRICAL SYSTEM

MAST

HYDRAULIC SYSTEM

## GENERAL INFORMATION

This parts catalog has been prepared for the customers of Toyota Industrial Vehicles and this shows only the part name codes instead of parts numbers.

When ordering parts from your local Toyota dealer, please specify the complete model number of the truck, the engine number or frame number. Also it is essential that you specify the part name codes described in the pages of illustrations and text.

The complete model number and frame number are shown in the front page of this catalog. All the columns in this quick reference index are supposed to be filled out by both the factory and your local dealer.

For the industrial vehicle with optional equipment, which is described in the lower part of the DESCRIPTION, it is imperative for you to specify optional equipment when ordering parts.

Your Toyota dealer has always been furnished with enough information to decode the correct part numbers based on your information of model number, engine number or frame number as well as part name code.

## INFORMATIONS D'ORDRE GENERAL

Ce catalogue de pièces a été préparé pour les propriétaires de Véhicules Industriels Toyota. On n'y trouvera que les codes de désignation de pièces au lieu des numéros de pièces.

Pour la commande de pièces auprès de votre concessionnaire Toyota, prière de spécifier le numéro de modèle complet de l'engin, le numéro du moteur ou le numéro du châssis. Il est aussi nécessaire de spécifier les codes de désignation de pièces comme ils sont décrits dans les pages d'illustrations et dans le texte.

Le numéro de modèle complet et le numéro de châssis sont indiqués en première page de ce catalogue. Toutes les colonnes de l'index de référence rapide devraient être remplies par l'usine et par votre concessionnaire.

Pour le véhicule industriel avec équipement optionnel, décrit en bas de page sous la rubrique "DESCRIPTION", il convient de bien spécifier qu'il s'agit de cet équipement lors de commande de pièces.

Votre concessionnaire Toyota est toujours suffisamment informé pour décoder les numéros de pièces sur la base de votre information du numéro de modèle, du numéro de moteur ou de châssis, et des codes de désignation de pièces.

## INFORMACION GENERAL

Este catálogo de piezas ha sido preparado para los clientes de vehículos industriales de TOYOTA, e incluye tan sólo los códigos de nombre de pieza en lugar de los números de pieza.

Cuando solicite piezas a su distribuidor local de TOYOTA especifique por favor el número de modelo completo del vehículo, el número de motor o el número de bastidor. Asimismo, es esencial que Vd. especifique los códigos de nombre de pieza descritos en las páginas de ilustraciones y de texto.

El número completo de modelo y el número de bastidor se indican en la portada de este catálogo. Se supone que todas las columnas de este índice de referencia se han llenado, tanto por parte de la fábrica como por parte de su distribuidor local.

En lo que concierne a los vehículos industriales con equipos opcionales, que se describen en la parte baja de la DESCRIPCION, es absolutamente necesario que especifique equipos opcionales cuando solicite piezas de repuesto.

Su distribuidor local de TOYOTA posee la información necesaria para descifrar los números correctos de cada pieza a base de su información de número de modelo, número de motor o número de bastidor, así como el código de nombre de la pieza.

## ALLGEMEINE INFORMATION

Dieser Teilekatalog wurde für die Benutzer von Toyota Industriefahrzeugen zusammengestellt und zeigt anstelle von Teilenummern nur die Teilenamen-Kodes.

Geben Sie bei Teilebestellungen von Ihrem Toyota-Händler am Platz bitte die vollständige Modellnummer des Fahrzeugs, die Motornummer oder Fahrgestellnummer an. Es ist auch erforderlich, daß Sie die in den Illustrationen und im Text beschriebenen Teilenamen-Kodes angeben.


Die vollständige Modellnummer und Fahrgestellnummer finden Sie auf der Vorderseite dieses Katalogs. Alle Spalten in dieser Bezugstabelle sollen sowohl vom Werk als von Ihrem Händler am Platz ausgefüllt werden.

Für Industriefahrzeuge mit Sonderausstattung, welche im unteren Teil der BESCHREIBUNG erläutert ist, müssen Sie bei der Bestellung von Teilen unbedingt diesbezügliche Angaben machen.

Ihr Toyota-Händler verfügt stets über genügend Information, um die richtigen Teilenummern zu entschlüsseln, basiert auf Ihren Angaben zu Modellnummer, Motornummer oder Fahrgestellnummer und den Teilenamen-Kodes.

## ILLUSTRATION ET COMPOSITION DU DE TEXTE DE CODE DE DESIGNATION DE PIECE

Une (1) page contiendra essentiellement une illustration et ses codes de désignation de pièce. Toutefois, lorsque l'espace réservé au texte est insuffisant, la continuation se trouvera sur la page suivante.



- **Numéro de figure**  
Ce catalogue de pièces a été préparé en fonction des numéros de figures.
- **Titre de figure**  
Une désignation de pièce représentative, celle d'une pièce d'un ensemble important, est indiquée comme titre de figure de l'illustration.
- **Sous-titre**  
La désignation optionnelle ou les spécifications spéciales de chaque illustration sont indiquées.
- **Code de désignation de pièce**  
Obtenu en combinant le numéro de figure et les codes des illustrations inhérents à chaque pièce. Ce code permettra à votre concessionnaire Toyota de trouver les numéros de pièces corrects.
- **Désignation de pièce**  
La désignation de la pièce est indiquée pour chacun des codes de désignation de pièce.
- **Q'ty (quantité)**  
La colonne quantité indique les pièces utilisées de l'unité de code de désignation de pièce. La quantité maximum est indiquée quand la quantité utilisée diffère pour chacun des véhicules. Quand la quantité de pièces utilisées diffère ou lorsqu'elle dépasse 100 pièces, la quantité 99 est indiquée.
- **Numéros de pièces standard**  
Les pièces standard comme les boulons, les écrous, les rondelles, etc. sont décrits dans les numéros de pièces. Pour commander ces pièces, prière de spécifier les numéros de pièces.

## ABBILDUNG UND TEXTSEITENAUFBAU FÜR TEILENAMEN-KODE

Grundsätzlich finden Sie auf einer (1) Seite sowohl die Abbildung als auch den Teilenamen-Kode.


Wenn für den Text jedoch nicht genügend Platz vorhanden ist, wird er auf der nächsten Seite fortgesetzt.

PART NAME CODE	PART NAME	QTY
4501-01	HORN ASSY - STEERING	1
4501-02	SCREW - STEERING WHEEL	1
4501-11	PLATE ASSY - CONTACT	1
4501-19	KNOB HORN-ASSY - STEERING WHEEL	1
4501-40	BUTTON - HORN	1
4501-41	PLATE - HORN CONTACT	1
4501-42	BEAR. - HORN CONTACT	1
4501-44	SPRING - HORN	1
4501-45	PLATE - LEAD - HORN	1
4501-46	SCREW - LEAD - HORN	1
4501-47	SCREW - HORN	2
4501-48	CAP - STEERING WHEEL	1
4501-49	SCREW - STEERING WHEEL MOP SET	1
4501-50	SCREW - STEERING WHEEL LADY SET	1
4501-51	SCRET - STEERING WHEEL KNOB BRACKET	1
4501-52	SCRET - STEERING WHEEL KNOB BRACKET	1
4501-53	SCRET - WHEEL KNOB SET PLATE	1
4501-54	SCRET - WHEEL KNOB SET PLATE	1
4501-55	RING - HORN CONTACT REL.	1

- **Abbildungsnr.**  
Dieser Teilkatalog wurde nach Abbildungnummern zusammengestellt.
- **Abbildungstitel**  
Ein stellvertretender Teilenname, welcher zugleich die Bezeichnung für die Hauptbaugruppe ist, wird als Abbildungstitel der Illustration angegeben.
- **Untertitel**  
Ein zusätzlicher Name oder eine besondere Kennzeichnung werden für jede Illustration angegeben.
- **Teilenamen-Kode**  
Dies ist eine Kombination von Ziffern und Abbildungskodes, die jedes Teil betreffen. Es ist ein Schlüssel für Ihren Toyota-Händler, um die richtigen Teilenummern zu finden.
- **Teilename**  
Grundsätzlich wird der Teilename für alle Teilenamen-Kodes angegeben.
- **QTY (Menge)**  
Die Mengenspalte gibt die benutzte Stückzahl von Teilenamen-Kode-Einheiten an.  
Wenn die benutzte Stückzahl je nach Fahrzeug verschieden ist, wird die Höchstmenge angegeben.  
Wenn die benutzte Menge 100 Stück überschreiten kann, wird als Menge 99 angegeben.
- **Standardteile-Nummern**  
Die Standardteile, wie Schrauben, Muttern, Unterlegscheiben usw., sind in den Teilenummern beschrieben. Geben Sie bei Bestellung dieser Teile die Teilenummern an.

## ILLUSTRATION AND PART NAME CODE TEXT PAGE COMPOSITION

Essentially, one (1) page will present both the illustration and part name code. However, when the space for text page is not enough the next page will be used in succession.



- ① Figure number  
This parts catalog has been prepared according to the figure numbers.
- ② Figure title  
A representative part name which is the major assembly part name is shown as the figure title of the illustration.
- ③ Sub title  
The optional name or special specification of each illustration are indicated.
- ④ Part name code  
This is a combination of figure number and codes of illustrations pertaining to each part. This is a key for your Toyota dealer to find the correct part numbers.
- ⑤ Part name  
As a rule, the part name is indicated for each of the part name codes.
- ⑥ QTY (Quantity)  
The quantity column indicates the utilized pieces of part name code unit. When the utilized quantity changes according to each of the vehicles, maximum is indicated.  
When the utilized quantity of the parts differs or is more than 100 pieces, quantity 99 is indicated.
- ⑦ Standard parts numbers  
The standard parts such as the bolts, nuts, washers, etc. are described with parts numbers. When ordering these parts, specify parts numbers.

## COMPOSICION DE LAS PAGINAS DE ILUSTRACIONES Y DE TEXTO DE CODIGOS DE NOMBRE DE PIEZAS

Básicamente, una (1) página incluirá tanto la ilustración como el código de nombre de la pieza.

No obstante, si el espacio no fuese suficiente, se utilizará la página siguiente.

- ① Número de figura  
Este catálogo de piezas se ha preparado de acuerdo con los números de las figuras.
- ② Título de las figuras  
Como título de las figuras de la página de ilustraciones, se incluye un nombre que sea representativo del nombre del mayor conjunto.
- ③ Subtítulo  
Se indican el nombre opcional o las especificaciones especiales de cada ilustración.
- ④ Código de nombre de pieza  
Se trata de una combinación de número de figura y de código de las ilustraciones correspondientes a cada pieza. Esta es la clave para que su distribuidor local de TOYOTA pueda encontrar el número de pieza correcto.
- ⑤ Nombre de la pieza  
Como norma, se indica el nombre de cada uno de los códigos de nombre de pieza.
- ⑥ QTY (Cantidad)  
La columna de cantidad indica el número de piezas utilizadas de cada unidad de código de nombre de pieza.  
Cuando la cantidad utilizada es intercambiable entre cada uno de los vehículos, se indica el máximo.  
Cuando la cantidad de piezas utilizadas pueda diferir o ser superior a 100, se indica como cantidad 99.
- ⑦ Números de piezas normalizadas  
Las piezas corrientes, tales como pernos, tuercas, arandelas etc., se describen con número de pieza. Cuando solicite tales piezas, indique su número de pieza.


## DATA PLATE & SERIAL NUMBERS

For retrieving correct part numbers, it's indispensable to know the truck model, as well as frame number ( or engine number).  
Customers can obtain said information in the data plate on the truck or in this user parts catalog.

## PLAQUE DE DONNEES TECHNIQUES & NUMEROS DE SERIE

Pour relever correctement le numéro des pièces, il est indispensable de connaître le modèle de l'engin, ainsi que le numéro du châssis (ou du moteur).  
Les propriétaires peuvent trouver ladite information sur la plaque de données techniques de l'engin ou dans le présent ouvrage.

Data plate  
Placa de datos  
Plaque de données techniques  
Datenplatte




## PLACA DE DATOS Y NUMEROS DE SERIE






Para obtener los números de pieza correctos, es indispensable conocer el modelo del vehículo, así como el número del bastidor (o del motor).  
Los clientes pueden obtener dicha información por la placa de datos del vehículo o este catálogo de piezas para el usuario.

## DATENPLATTE & SERIENNUMMERN

Um die richtige Teilenummer zu ermitteln, müssen unbedingt das Fahrzeugmodell sowie die Fahrgestellnummer (oder die Motornummer) bekannt sein.  
Kunden können diese Angaben von der Datenplatte am Fahrzeug oder in diesem Teilkatalog für Benutzer entnehmen.






## FIG. INDEX


<b>FIG. 1401</b>	<b>FIG. 1402</b>	<b>FIG. 1403</b>	<b>FIG. 2401</b>	<b>FIG. 2402</b>	<b>FIG. 2403</b>	<b>FIG. 2413</b>
						
ドライブ モーター Drive Motor	ポンプ ドライブ モーター Pump Drive Motor	P/S ポンプ ドライブ モーター P/S Pump Drive Motor	コントロール パネル Control Panel	コンタクタ パネル Contactor Panel	コンタクタ アセンブリ Contactor Assy	セーフティ ブレーカー Circuit Breaker
<b>エレクトリカル グループ ELECTRICAL GROUP</b>						
						
<b>FIG. 2501</b>	<b>FIG. 2512</b>	<b>FIG. 2611</b>				
						
バッテリ Battery	バッテリ セparate チャージャー <sup>+</sup> Battery Separate Charger	アクセルレーター Accelerator				




## FIG. INDEX

FIG. 3305 	FIG. 3310 	FIG. 4101 	FIG. 4201 	FIG. 4301 	FIG. 4401 	FIG. 4402 
ギヤ ケース ト ギヤ Gear Case & Gear	チェンジ レバー Change Lever	ディファレンシャル Differential	フロント アクスル シャフト Front Axle Shaft	リヤ アクスル ト タイ ロッド Rear Axle & Tie-Rod	フロント タイヤ ト ライ Front Wheel & Tire	フロント タイヤ ト ライ(ダブル) Front Wheel & Tire (Double)
<b>シャシ グループ</b> <b>CHASSIS GROUP</b>						
 <p>The diagram shows a front-three-quarter view of a vehicle's chassis. Various parts are numbered from 1 to 16. Numbered callouts point to specific components: 1 points to the front wheel; 2 points to the front suspension; 3 points to the engine/transmission area; 4 points to the rear suspension; 5 points to the rear wheel; 6 points to the rear differential; 7 points to the rear axle; 8 points to the front frame rail; 9 points to the rear frame rail; 10 points to the front wheel hub; 11 points to the rear wheel hub; 12 points to the front wheel bearing; 13 points to the rear wheel bearing; 14 points to the front wheel bearing housing; 15 points to the rear wheel bearing housing; 16 points to the front wheel bearing housing.</p>						
FIG. 4715 	FIG. 4714 	FIG. 4702 	FIG. 4701 	FIG. 4601 	FIG. 4510 	FIG. 4508 
ドラム ブレーキ Drum Brake	ブレーキ パイプ Brake Pipe	ブレーキ マスター シリンダ Brake Master Cylinder	ブレーキ ペダル Brake Pedal	パークィング ブレーキ Parking Brake	ステアリング オイル ポンプ Steering Oil Pump	ステアリング パワー シリンダ Steering Power Cylinder


## FIG. INDEX




フレーム ト ウエイト  
Frame & Weight




フード ト ヒンジ  
Hood & Hinge




インストルメントパネル ト フロア  
Instrument Panel & Floor




ドライバーシート  
Driver Seat



ヘッドガード ト アクセサリ  
Head Gaurd & Accessory




インジケーター プレート  
Indicator Plate



キャンバス キャビネット フロント ガラス  
Canvas Cabin & Front Glass

FIG. 5602




ワイヤリング ト クランプ  
Wiring & Clamp

FIG. 5611



ランプ  
Lamp

FIG. 5612




ランプ ブラケット  
Lamp Bracket

FIG. 5702




メータ ト スイッチ  
Meter & Switch

FIG. 5801



ワイパー モーター ト ブレード  
Wiper Motor & Blade


FIG. 5706












スピードメーター ト スピードアラーム  
Speedo Meter & Speed Alarm

0000-004

### ボディ、エレクトリカル グループ BODY, ELECTRICAL GROUP




## FIG. INDEX

						
マスト Mast	リフト ブラケット フォーク Lift Bracket & Fork	チェーン チューン ホイール Chain & Chain Wheel	リフト シリンダ Lift Cylinder	フロント リフト シリンダ Front Lift Cylinder	リヤ リフト シリンダ Rear Lift Cylinder	リフト シリンダ Lift Cylinder
						
						フロント リフト シリンダ Front Lift Cylinder
						
						リヤ リフト シリンダ Rear Lift Cylinder
						
						ティルト シリンダ Tilt Cylinder
						
						オイル ポンプ Oil Pump
						
			マスト バイピング Mast Piping	ボディ バイピング Body Piping	オイル コントロール バルブ リンク Oil Control Valve Link	オイル コントロール バルブ Oil Control Valve

0000-056

FIG. 0901 STANDARD TOOL

0901



PART NAME CODE	PART NAME	QTY
0901-01	TOOL SET, STANDARD -----	1
0901-10	SPANNER SET -----	1
0901-11	PUMP ASSY, GREASE -----	1
0901-12	METER ASSY, HYDRAULIC SAILING -----	1
0901-40	BAG, TOOL -----	1
0901-41	PRIERS -----	1
0901-42	DRIVER, SCREW -----	1
0901-43	WRENCH, MONKEY -----	1
0901-45	ROD, THERMOMETER -----	1
0901-46	FUSE -----	1
0901-47	WRENCH, HUB NUT BOX -----	1


(MAIN ) ( 1)

G210


FIG. 1401 DRIVE MOTOR

1401

(UL-E)



1401-010




1401-011

FIG. 1401 DRIVE MOTOR

1401

(UL-EE)



1401 D12

PART NAME CODE	PART NAME	QTY
1401-01	MOTOR ASSY, DRIVE	1
1401-01A	BEARING, DRIVE MOTOR, NO.1	1
1401-01B	BEARING, DRIVE MOTOR, NO.2	1
1401-10	YOKE ASSY	1
1401-11	HOLDER ASSY, BRUSH	4
1401-12	ARMATURE ASSY, DRIVE	1
1401-16A	BOLT, STUD (TERMINAL)	1
1401-40	BRUSH, DRIVE MOTOR	4
1401-41	BRACKET, NO.1	1
1401-41A	SEAL, OIL (FOR BRACKET)	1
1401-42	BRACKET, NO.2	1
1401-43	COVER, MOTOR	1
1401-44	COVER, BRUSH	1
1401-45	BRACKET, DRIVE MOTOR MOUNTING, NO.1	1
1401-46	BRACKET, DRIVE MOTOR MOUNTING, NO.2	1
1401-50	RUBBER, CUSHION (FOR MOTOR MOUNTING)	2
1401-AC	INSULATOR	8
1401-AD	WASHER, PLATE	8
1401-AE	WASHER, SPRING	8
1401-AF	NUT	8
1401-AG	WASHER, PLATE	4
1401-AQ	PLATE, CUSHION RUBBER	1
1401-AS	WASHER, WAVE	1


(MAIN ) ( 2)

G210


FIG. 1402 PUMP MOTOR

1402

(UL-E)



1402-031




1402-031

FIG. 1402 PUMP MOTOR

1402

{UL-EE}



1402-032.A


PART NAME CODE	PART NAME	QTY
1402-01	MOTOR ASSY, PUMP -----	1
1402-01A	BEARING, PUMP MOTOR, NO.1 -----	1
1402-01B	BEARING, PUMP MOTOR, NO.2 -----	1
1402-10	YUKE ASSY, PUMP MOTOR -----	1
1402-11	HOLDER ASSY, BRUSH -----	4
1402-12	ARMATURE ASSY, PUMP MOTOR -----	1
1402-16A	BOLT, STUD (TERMINAL) -----	1
1402-35	INSULATOR SUB-ASSY, MOTOR MOUNTING -----	3
1402-40	BRUSH, PUMP MOTOR -----	4
1402-41	BRACKET, NO.1 -----	1
1402-42	BRACKET, NO.2 -----	1
1402-43	COVER, MOTOR -----	1
1402-44	COVER, BRUSH -----	1
1402-45	BRACKET, PUMP MOTOR MOUNTING -----	1
1402-48	PLATE, PUMP MOTOR SET -----	1
1402-AB	INSULATOR -----	4
1402-AC	WASHER, PLATE -----	4
1402-AD	WASHER, SPRING -----	4
1402-AE	NUT -----	4
1402-AN	WASHER, PLATE -----	2
1402-AQ	BOLT -----	3
1402-AR	WASHER, SPRING -----	7
1402-AS	NUT -----	7

(MAIN ) ( 3)

G210

FIG. 1403 POWER STEERING PUMP DRIVE MOTOR

1403



PART NAME CODE	PART NAME	QTY
1403-01	MOTOR ASSY, POWER STEERING -----	1
1403-01A	BEARING, POWER STEERING MOTOR -----	2
1403-10	YOKE ASSY, POWER STEERING MOTOR -----	1
1403-11	HOLDER ASSY, BRUSH -----	4
1403-12	ARMATURE ASSY, POWER STEERING -----	1
1403-16A	BOLT, STUD (TERMINAL) -----	1
1403-30	BRACKET SUB-ASSY, MOTOR MOUNTING -----	1
1403-31	INSULATOR SUB-ASSY, BODY MOUNTING -----	3
1403-40	BRUSH, POWER STEERING MOTOR -----	4
1403-41	BRACKET, NO.1 -----	1
1403-42	BRACKET, NO.2 -----	1
1403-44	COVER, BRUSH -----	1
1403-AB	INSULATOR -----	4
1403-AC	BOLT -----	4
1403-AD	WASHER, SPRING -----	4
1403-AE	NUT -----	4
1403-AF	FINGER -----	1
1403-AG	WASHER, PLATE -----	4
1403-AH	WASHER, PLATE -----	4
1403-AI	WASHER, SPRING -----	4


1403-003

(MAIN ) ( 4)

G210

FIG. 2401 CONTROL PANEL

2401




2401-016

FIG. 2401 CONTROL PANEL

2401

(20D, 35D, 45D)




2401-019

**2401**

PART NAME CODE	PART NAME	QTY
2401-D1	PANEL ASSY, DRIVE CONTROL	1
2401-I0	GENERATOR ASSY, SIGNAL	1
2401-40	THYRISTOR, MAIN	1
2401-41	THYRISTOR, SUB	1
2401-42	CONDENSER	1
2401-45	SENSOR, CURRENT	1
2401-46	DIODE	2
2401-51	HEATSINK, NO.1	1
2401-52	REACTOR (L1)	1
2401-53	REACTOR (L2)	1
2401-54	HEATSINK, NO.2	1
2401-55	THYRISTOR, SUB	1
2401-AC	COVER	1
2401-AE	INSULATOR	2
2401-AJ	NUT	1
2401-AN	BASE	1
2401-AT	BAR	1
2401-AU	BAR	1
2401-AX	INSULATOR	4
2401-BU	SCREW	2
2401-BE	SCREW	4
2401-BF	BAR	1
2401-BG	HOLDER, TERMINAL	2
2401-BH	HARNESS ASSY, WIRING	1
2401-BK	WIRING	1
2401-BM	WASHER, SPRING	1
2401-BN	WASHER, PLATE	1
2401-BP	WASHER, PLATE	4
2401-BQ	WASHER, SPRING	4
2401-BR	BASE	1
2401-BT	SHEET	1
2401-BU	BRACKET SUB-ASSY, CAPACITOR	1
2401-BV	BRACKET SUB-ASSY	1
2401-BW	MAT	1
2401-BX	MAT	1
2401-BY	BRACKET SUB-ASSY, TERMINAL	1
2401-BZ	SHEET	1
2401-CA	PLATE, NAME	1
2401-CB	GROMMET	4
2401-CC	PLATE	1
2401-CO	NUT	4
2401-CE	SLEEVE	1

FIG. 2402 CONTACTOR PANEL


**2402**

2402-021

FIG. 2402 CONTACTOR PANEL

2402

(UL-EE)



2402-030

**2402**

PART NAME CORE	PART NAME	QTY
2402-01	PANEL ASSY, CONTACTOR -----	1
2402-30	COVER SUB-ASSY, CONTACTOR -----	1
2402-41	FUSE (F1) -----	1
2402-42	FUSE (F2) -----	1
2402-44	FUSE -----	2
2402-AI	INSULATOR -----	2
2402-AJ	BAR -----	1
2402-AK	BAR -----	1
2402-AL	BAR -----	2
2402-AM	BAR -----	1
2402-AN	BAR -----	1
2402-AO	BASE -----	1
2402-AP	HOLDER, TERMINAL -----	2
2402-AQ	STUD -----	4
2402-AT	BAR -----	1
2402-AU	BAR -----	1
2402-AV	HARNESS ASSY, WIRING -----	1
2402-AX	HANDLE -----	2
2402-AZ	SCREW -----	2
2402-BA	NUT -----	8
2402-BB	WASHER -----	12
2402-BC	WASHER, SPRING -----	8
2402-BE	BAR -----	1
2402-BI	COVER -----	1
2402-BK	HOLDER, TERMINAL -----	1
2402-BR	NUT -----	15
2402-BS	BOOT -----	1
2402-BY	PLATE, TERMINAL NUMBER -----	1
2402-BZ	PLATE, NAME -----	1
2402-CA	PLATE SUB-ASSY, CONTACTOR -----	1
2402-CF	WASHER, PLATE -----	50
2402-CC	WASHER, SPRING -----	30
2402-CH	BAND -----	1
2402-CJ	PLATE, FUSE -----	1
2402-CW	BRACKET SUB-ASSY, TERMINAL -----	1
2402-CX	BOARD, PUMP CONTROL -----	1
2402-DR	PLATE, TERMINAL -----	1
2402-DC	BOLT, STUD -----	10
2402-DD	HOLDER SUB-ASSY, FUSE -----	1
2402-DE	PLATE, TERMINAL -----	1
2402-DF	STAND SUB-ASSY, PRINT BOARD -----	1
2402-DG	COVER, PRINT BOARD -----	1
2402-DH	BAR -----	2
2402-DI	BAR -----	1
2402-DJ	BAR -----	1

FIG. 2403 CONTACTOR ASSY

**2403**

(UL-EE)






FIG. 2403 CONTACTOR ASSY


**2403**

[DRIVE]

[SHORT]



2403-019




2403-020

FIG. 2403 CONTACTOR ASSY

2403

[PUMP]



PART NAME CODE	PART NAME	QTY
2403-09	CONTACTOR ASSY, POWER STEERING, LARGE -----	1
2403-10	CONTACTOR ASSY, DRIVE -----	2
2403-11	CONTACTOR ASSY, SHORT -----	1
2403-12	CONTACTOR ASSY, PUMP -----	2
2403-13	CONTACTOR ASSY, POWER STEERING -----	1
2403-20	CONTACT SUB-ASSY, DRIVE MOVING -----	2
2403-21	CONTACT SUB-ASSY, SHORT MOVING -----	1
2403-30	COVER SUB-ASSY, CONTACTOR -----	1
2403-40	CONTACT, DRIVE FIXED, NO.1 -----	2
2403-41	CONTACT, DRIVE FIXED, NO.2 -----	2
2403-42	CONTACT, SHORT FIXED -----	1
2403-44	CONTACT, POWER STEERING FIXED -----	1
2403-46	DIODE -----	1
2403-47	FUSE (F3) -----	1
2403-50	CONTACT, POWER STEERING -----	1
2403-52	CONTACT, MOVING -----	1
2403-53	CONTACT, STATIONARY -----	2
2403-AA	MOVING, CONTACT -----	1
2403-AB	COVER -----	1
2403-AC	POLE -----	2
2403-AD	BUSHING, STEPPED, NO.1 -----	2
2403-AF	SPRING, NO.1 -----	2
2403-AG	SPRING, NO.2 -----	2
2403-AI	SWITCH, MICRO -----	1
2403-AS	BASE -----	1
2403-AV	HOLDER, TERMINAL -----	1
2403-AW	PLATE, TERMINAL NUMBER -----	1
2403-AX	WIRING SUB-ASSY -----	1
2403-AY	NUT -----	4
2403-RZ	WASHER, SPRING -----	4
2403-BA	WASHER, PLATE -----	6
2403-BF	WIRING -----	2
2403-BG	WIRE, LEAD -----	3
2403-BH	COIL -----	2
2403-BI	INSULATOR -----	3
2403-BJ	SUPPORT -----	3
2403-BK	FRAME -----	3
2403-BQ	PLATE, FUSE -----	1
2403-BR	COVER -----	1
2403-BS	PLATE, TERMINAL -----	1
2403-BT	BRACKET SUB-ASSY, TERMINAL -----	1
2403-BU	BOLT, STUO -----	2
2403-BV	WIRING SUB-ASSY -----	1

FIG. 2413 CIRCUIT BREAKER

2413



PART NAME CODE	PART NAME	QTY
2413-01	BREAKER ASSY, CIRCUIT	1
2413-10	BOARD ASSY, CIRCUIT	1
2413-20	BASE SUB-ASSY, BREAKER	1
2413-40	REGISTER	1
2413-AA	TERMINAL BLOCK, FUSE	1
2413-AB	NUT	4
2413-AC	WASHER, SPRING	4
2413-AD	WASHER, PLATE	8
2413-AE	SPACER	2
2413-AF	COVER	1
2413-AG	PLATE, TERMINAL NUMBER (N1)	1
2413-AH	PLATE, TERMINAL NUMBER (NO)	1

2413-001

FIG. 2501 BATTERY

2501

(G.S)



2501-053

2501-005


**2501**

PART NAME CODE	PART NAME	QTY
2501-01	BATTERY ASSY, W/CASE -----	1
2501-10	PLUG ASSY, VENT -----	35
2501-11	SENSOR ASSY, LEVEL -----	1
2501-20	CASE SUB-ASSY, BATTERY -----	1
2501-30	LEVER SUB-ASSY, EMERGENCY -----	1
2501-40	KNOB, EMERGENCY LEVER -----	1
2501-41	PLUG, BATTERY -----	1
2501-AA	COVER, TERMINAL, LH -----	1
2501-AB	COVER, TERMINAL, RH -----	3
2501-AC	COVER, TERMINAL -----	1
2501-AD	PLUG, VENT -----	36
2501-AE	CAP -----	36
2501-AF	PACKING -----	36
2501-AG	FLOAT -----	36
2501-AH	BRACKET -----	1
2501-AN	CAP -----	1
2501-AO	PACKING -----	1
2501-AP	FLOAT -----	1
2501-AU	BRACKET SUB-ASSY, EMERGENCY LEVER -----	1
2501-AV	BUSHING -----	2
2501-AW	SPRING, TORSION -----	1
2501-AZ	BUSHING -----	1
2501-BA	STOPPER SUB-ASSY, BATTERY CASE -----	1
2501-BB	SPRING, BATTERY STOPPER -----	1
2501-BB	HANGER -----	2
2501-BP	RUBBER, CUSHION -----	7

FIG. 2512 BATTERY SEPARATE CHARGER

2512

(G.S)



PART NAME CODE	PART NAME	QTY
2512-01	CHARGER ASSY, BATTERY SEPARATE	1
2512-11	LAMP ASSY, CHARGING	1
2512-13	CABLE ASSY, CHARGER (DC)	1
2512-14	SWITCH ASSY, MAGNET	1
2512-20	TRANSFORMER SUB-ASSY	1
2512-34	SWITCH SUB-ASSY, MAGNET	1
2512-35	RELAY SUB-ASSY, THERMAL	1
2512-40	HANDLE	1
2512-41	ELEMENT, SILICON, FORWARD	6
2512-44	PLUG	1
2512-46	CABLE (AC)	1
2512-AC	TERMINAL	2
2512-AD	METER ASSY, AMPERE	1
2512-AE	SHUNT	1
2512-AF	TIMER ASSY, TOTAL	1
2512-AL	CABLE	2
2512-AM	FUSE ASSY	1
2512-AN	AVT ASSY	1
2512-AO	RESISTOR	1
2512-AR	RESISTOR	1

2512-018



(MAIN) ( 10 )

G210

FIG. 2611 ACCELERATOR

2611

(ACCELERATOR BOX)




2611 D12

2611 D11

**2611**

PART NAME CODE	PART NAME	QTY
2611-10	SWITCH ASSY, ACCELERATOR (PEDAL TYPE) -----	1
2611-4D	VARI-OHM -----	1
2611-41	PEDAL, ACCELERATOR -----	1
2611-42	ARM, ACCELERATOR LINK -----	1
2611-43	ROD, ACCELERATOR PEDAL -----	1
2611-44	SWITCH, MICRO -----	2
2611-47	PAD, PEDAL -----	1
2611-48	ROD, ACCELERATOR LINK -----	1
2611-49	BOOT -----	1
2611-50	END, CONNECTING ROD, NO.1 -----	1
2611-51	END, CONNECTING ROD, NO.2 -----	1
2611-52	SPRING, TENSION, NO.1 -----	2
2611-53	SPRING, TENSION, NO.2 -----	1
2611-AA	BUSHING -----	2
2611-AB	BUSHING -----	2
2611-AF	SHAFT -----	1
2611-AG	CAM -----	1
2611-AI	PIN, SPRING -----	1
2611-AK	BUSHING -----	2
2611-AR	SUPPORT -----	1
2611-BB	SCREW -----	4
2611-BI	SCREW -----	4
2611-BK	BRACKET, PEDAL -----	1
2611-BL	PIN, W/WASHER -----	1
2611-BM	ROLLER, ACCELERATOR LINK -----	1
2611-BN	BOLT -----	1
2611-BQ	NUT -----	1
2611-BP	HOLDER -----	1
2611-B5	LEVER, SWITCH -----	1
2611-BU	SPACER -----	3
2611-BY	CLAMP -----	1
2611-BZ	HARNESS SUB-ASSY -----	1
2611-CA	PIN, SPRING -----	1
2611-CB	PLATE -----	2

FIG. 3305 GEAR CASE &amp; GEAR

**3305**

PART NAME CODE	PART NAME	QTY
3305-01	CASE ASSY, GEAR -----	1
3305-20	CASE SUB ASSY, GEAR -----	1
3305-20A	GASKET, GEAR CASE -----	1
3305-40	GEAR, OUTPUT -----	1
3305-41	GEAR, DRIVE -----	1
3305-41A	BEARING (FOR DRIVE GEAR) -----	1
3305-AA	BOLT -----	4
3305-AB	WIRE -----	2


3305-001

(MAIN ) ( 12)

G210

FIG. 3310 CHANGE LEVER


3310



PART NAME CODE	PART NAME	QTY
3310-10	SHAFT ASSY, DIRECTION SWITCH -----	1
3310-10A	BUSH, NO.1 (FOR DIRECTION SWITCH SHAFT) -----	1
3310-10B	BUSH, NO.2 (FOR DIRECTION SWITCH SHAFT) -----	1
3310-10C	BUSH, NO.3 (FOR DIRECTION SWITCH SHAFT) -----	2
3310-21	CAM SUB-ASSY, DIRECTION SWITCH -----	1
3310-31	SHAFT SUB-ASSY, DIRECTION SWITCH -----	1
3310-40	LEVER -----	1
3310-42	HOUSING, CHANGE LEVER -----	1
3310-43	SWITCH, MICRO, NO.1 -----	1
3310-45	KNOB -----	1
3310-46	BOOT (FOR CONTROL SHAFT) -----	1
3310-50	HOUSING, ROLLER -----	1
3310-51	ROLLER -----	1
3310-52	SPRING, COMPRESSION -----	1
3310-AF	SPRING, PIN STOPPER -----	1
3310-AG	ROLLER, NEEDLE -----	1
3310-AH	STAY, DIRECTION SWITCH BRACKET -----	1
3310-AI	BRACKET SUB-ASSY, DIRECTION SWITCH -----	1
3310-AJ	PIN, SPRING -----	1
3310-AK	PLATE -----	1
3310-AL	NUT, PLATE -----	3
3310-AM	PLATE, CHANGE LEVER -----	1
3310-AN	PLATE, INDICATOR -----	1
3310-AO	SCREW -----	2
3310-AP	PIN, SPRING -----	1
3310-AQ	SCREW -----	4
3310-AR	SCREW -----	2

FIG. 4101 DIFFERENTIAL

4101




4101 011

4101

PART NAME CODE	PART NAME	QTY
4101-02	CASE ASSY, DIFFERENTIAL -----	1
4101-10	RING GEAR & PINION SET, DIFFERENTIAL -----	1
4101-10A	BEARING, DRIVE PINION -----	2
4101-10B	BEARING, DRIVE PINION PILOT -----	1
4101-10C	NUT, LOCK -----	1
4101-10D	SHIM, BEARING PRELOAD ADJUST -----	99
4101-20	CASE SUB-ASSY, DIFFERENTIAL -----	1
4101-20A	NUT, ADJUSTING -----	2
4101-20B	BEARING, DIFFERENTIAL CASE -----	2
4101-40	HOUSING, DIFFERENTIAL -----	1
4101-40B	RING, O (FOR DIFFERENTIAL HOUSING) -----	1
4101-40C	PLUG, BREATHER (FOR DIFFERENTIAL HOUSING) --	1
4101-44	PLUG (FOR INPUT SHAFT) -----	1
4101-44A	PACKING (FOR INPUT SHAFT PLUG) -----	1
4101-46	GEAR, SIDE -----	2
4101-46A	WASHER, SIDE GEAR THRUST -----	2
4101-47	SPIDER -----	1
4101-48	PINION -----	4
4101-48A	WASHER, PINION THRUST -----	4
4101-49	PLUG, DRAIN -----	1
4101-49A	GASKET, DRAIN -----	1
4101-50	RETAINER, DRIVE PINION BEARING -----	1
4101-500	SHIM, DIFFERENTIAL DRIVE PINION BEARING ----	99
4101-54	CAP, RING GEAR THRUST SCREW -----	1
4101-55	BOLT, RING GEAR SET -----	12
4101-AB	BOLT -----	16
4101-AC	SCREW, RING GEAR THRUST -----	1
4101-AD	NUT -----	1
4101-AF	LOCK, ADJUSTING -----	2
4101-AG	PLUG, W/HEAD STRAIGHT SCREW -----	1
4101-AH	GASKET -----	1
4101-AI	PLUG -----	1
4101-AJ	GASKET -----	1
4101-AK	BOLT -----	2
4101-AL	BOLT -----	4
4101-AO	SPACER, BEARING -----	1

FIG. 4201 FRONT AXLE SHAFT

4201




4201-019

PART NAME CODE	PART NAME	QTY
4201-40	SHAFT, FRONT AXLE -----	2
4201-40A	WASHER, CORN -----	16
4201-40B	WASHER, SPRING (FOR FRONT AXLE SHAFT) -----	16
4201-40C	SEAL, OIL (FOR FRONT AXLE SHAFT) -----	2
4201-40D	GASKET, FRONT AXLE SHAFT -----	2
4201-41	HUB, FRONT AXLE -----	2
4201-41A	SEAL, OIL (FOR FRONT AXLE HUB) -----	2
4201-41B	BEARING, NO.1 (FOR FRONT AXLE HUB) -----	2
4201-41C	BEARING, NO.2 (FOR FRONT AXLE HUB) -----	2
4201-41D	NUT, BEARING LOCK -----	2
4201-41E	BOLT, HUB -----	12
4201-41F	BOLT, STUD (FOR FRONT AXLE SHAFT) -----	16
4201-41G	NUT, HUB -----	12
4201-41H	BOLT, DOUBLE WHEEL STOP -----	12
4201-42	DRUM, BRAKE -----	2
4201-43	BRACKET, FRONT AXLE, RH -----	1
4201-43A	NUT, BRAKE SET SELF -----	8
4201-43B	RING, O (FOR FRONT AXLE BRACKET) -----	2
4201-44	BRACKET, FRONT AXLE, LH -----	1
4201-49	PLATE, LOCK NUT -----	2
4201-53	HOUSING, FRONT AXLE -----	2
4201-53A	RING, O (FOR FRONT AXLE HOUSING) -----	2
4201-AA	BOLT -----	4
4201-AB	BOLT, BRACKET SET -----	4
4201-AC	BOLT, STUD BRAKE SET -----	16
4201-AD	WASHER, CO SPRING -----	16
4201-AE	BOLT -----	2
4201-AJ	BOLT -----	16
4201-AP	NUT -----	16

FIG. 4301 REAR AXLE &amp; TIE-ROD




4301



PART NAME CODE	PART NAME	QTY
4301-01	AXLE ASSY, RR	1
4301-10	END ASSY, TIE-ROD, NO.1	2
4301-10A	NUT, CASTLE (FOR TIE-ROD END)	4
4301-10B	NUT (RH THREADS)	2
4301-11	END ASSY, TIE-ROD, NO.2	2
4301-11B	NUT (LH THREADS)	2
4301-13K	TIE-ROD KIT	1
4301-20	BEAM SUB-ASSY, REAR AXLE	1
4301-20A	BUSH, REAR AXLE BEAM	2
4301-20B	SHIM, REAR AXLE BEAM	1
4301-23	BELLCRANK SUB-ASSY, STEERING	1
4301-23A	BEARING (FOR STEERING BELLCRANK)	2
4301-23B	SEAL, OIL (FOR STEERING BELLCRANK)	2
4301-23K	SEAL KIT, BELLCRANK PIN	1
4301-40	KNUCKLE, STEERING, RH	1
4301-41	KNUCKLE, STEERING, LH	1
4301-42	PIN, STEERING KNUCKLE KING	2
4301-42A	BEARING, STEERING KNUCKLE THRUST	2
4301-42B	SEAL, OIL, NO.1	4
4301-42C	BEARING, NEEDLE	4
4301-42D	SHIM, STEERING KNUCKLE	99
4301-42K	SEAL KIT, KING PIN	2
4301-43	PIN, KING PIN LOCK	2
4301-44	HUB, REAR AXLE	2
4301-44A	BEARING, INNER	2
4301-44B	BEARING, OUTER	2
4301-44C	BOLT, HUB	12
4301-44D	NUT, HUB	12
4301-44E	PIN, REAR AXLE COTTER	2
4301-44F	SEAL, OIL (FOR REAR AXLE HUB)	2
4301-44G	NUT, CASTLE (FOR REAR AXLE HUB)	2
4301-45	CAP, REAR AXLE HUB	2
4301-47	TIE-ROD	2
4301-48	PIN, BELLCRANK	1
4301-AA	BOLT	2
4301-AB	FITTING, GREASE	4
4301-AC	FITTING, GREASE	1
4301-AD	WASHER, CRAW	2
4301-AE	SHIM	99
4301-AF	PLATE, STOPPER	1
4301-AG	WASHER	2

FIG. 4401 FRONT WHEEL & TIRE (SINGLE)

**4401**



4401-004


ITEM NAME CODE	PART NAME	QTY
4401-01	WHEEL ASSY -----	2
4401-13	TIRE ASSY -----	2
4401-14	CHAIN ASSY, TIRE -----	1
4401-20	WHEEL SUB-ASSY, DISC -----	2
4401-40	BAND, CHAIN -----	2
4401-AB	RING, LOCK -----	2
4401-AE	TUBE SUB-ASSY -----	2
4401-AF	FLAP -----	2
4401-AG	RING, SIDE -----	2

(MAIN ) ( 17)



G210

FIG. 4402 FRONT WHEEL &amp; TIRE (DOUBLE)

4402



(2-PIECE RING)




4402-004

PART NAME CODE	PART NAME	QTY
4402-02	WHEEL ASSY, INNER	2
4402-03	MHFL ASSY, OUTER	2
4402-13	TIRE ASSY	4
4402-14	CHAIN ASSY, TIRE	1
4402-21	WHEEL SUB-ASSY, DISC, INNER	2
4402-22	WHEEL SUB-ASSY, DISC, OUTER	2
4402-40	BAND, CHAIN	2
4402-41	EXTENSION, WHEEL TUBE VALVE	2
4402-AB	RING, LOCK	4
4402-AE	TUBE SUB-ASSY	4
4402-AF	FLAP	4
4402-AG	RING, SIDE	4


(MAIN ) ( 18 )

G210

FIG. 4403 REAR WHEEL &amp; TIRE

**4403**

(UNIQUE, TRUKUSH)



PART NAME CODE	PART NAME	QTY
4403-01	WHEEL ASSY -----	2
4403-13	TIRE ASSY -----	2
4403-20	WHEEL SUB-ASSY, DISC -----	2
4403-20A	BOLT, DISC WHEEL SET -----	12
4403-20B	NUT, WHEEL SET -----	12
4403-20C	WASHER, WHEEL SET -----	12
4403-AE	TUBE SUB-ASSY -----	2
4403-AF	FLAP -----	2

4403-003



(MAIN) ( 19 )

G210

FIG. 4501 STEERING WHEEL

4501

(UL-EE)



4501 004



4501 006 A

**4501**

PART NAME CODE	PART NAME	QTY
4501-01	WHEEL ASSY, STEERING -----	1
4501-10	KNOB ASSY, STEERING WHEEL -----	1
4501-30	KNOB SUB-ASSY, STEERING WHEEL -----	1
4501-40	BUTTON, HORN -----	1
4501-42	PLATE, HORN CONTACT -----	1
4501-43	SEAT, HORN CONTACT -----	1
4501-44	SPRING, HORN -----	1
4501-45	PLATE, LEAD -----	1
4501-AA	SCREW -----	1
4501-AB	WASHER -----	3
4501-AC	SCREW -----	3
4501-A0	CAP, STEERING WHEEL -----	1
4501-AE	BOLT, STEERING WHEEL KNOB SET -----	1
4501-AF	BRACKET, STEERING WHEEL KNOB -----	1
4501-AG	SEAT, STEERING WHEEL KNOB BRACKET -----	1
4501-AH	SEAT, STEERING WHEEL KNOB BRACKET -----	1
4501-AI	SEAT, WHEEL KNOB SET PLATE -----	1
4501-AJ	PLATE, STEERING WHEEL KNOB SET -----	1
4501-AK	RING, HORN CONTACT NO.1 -----	1
4501-AN	SPRING, LEAD -----	1
4501-AO	SPACER, NO.3 -----	3
4501-AP	SPACER, NO.5 -----	3
4501-AQ	SPACER, NO.5 -----	1
4501-AR	SPACER, NO.4 -----	2
4501-AS	SPACER, NO.1 -----	1
4501-AT	PLATE, HORN BUTTON SET -----	1
4501-AU	RING, HORN CONTACT NO.2 -----	1
4501-AV	SCREW -----	3

FIG. 4502 STEERING POST

4502



4502-019


4502-018

**4502**

PART NAME CODE	PART NAME	QTY
4502-01	POST ASSY, STEERING -----	1
4502-10	GEAR ASSY, STEERING -----	1
4502-10K	GEAR D/H KIT, STEERING -----	1
4502-11	BALL SCREW SET -----	1
4502-11A	BEARING, NO.1 (FOR BALL SCREW SET) -----	1
4502-11B	BEARING, NO.2 (FOR BALL SCREW SET) -----	1
4502-11C	BEARING, THRUST (FOR BALL SCREW SET) -----	2
4502-12	BODY ASSY, VALVE -----	1
4502-20	JACKET SUB-ASSY, MAST -----	1
4502-21	BOX SUB-ASSY, STEERING GEAR -----	1
4502-21B	BEARING, NO.1 (FOR SECTOR SHAFT) -----	1
4502-21C	SEAL, OIL (FOR SECTOR SHAFT) -----	1
4502-30	COVER SUB-ASSY, SIDE -----	1
4502-30A	BUSH, SECTOR SHAFT, NO.2 -----	1
4502-30C	RING, O (FOR SIDE COVER) -----	1
4502-31	VALVE SET, RELIEF -----	1
4502-33	BODY SET, VALVE -----	1
4502-33A	RING, O (FOR VALVE BODY SET) -----	2
4502-40	SHAFT, SECTOR -----	1
4502-45	COVER, TOP -----	1
4502-45A	RING, O (FOR TOP COVER) -----	1
4502-46	COVER, END -----	1
4502-46C	RING, O (FOR END COVER) -----	1
4502-49	GROMMET, STEERING COLUMN (INSULATOR) -----	1
4502-AA	WASHER, SPRING -----	11
4502-AB	BOLT -----	4
4502-AE	STAY SUB-ASSY, STEERING -----	1
4502-AF	CLAMP -----	1
4502-AG	CLAMP, STEERING COLUMN, LOWER -----	1
4502-AK	BOLT, STUD -----	4
4502-AL	PLUG, OIL -----	1
4502-AM	BOLT, ADJUSTING -----	1
4502-AN	PLATE, ADJUSTING -----	1
4502-AU	BOLT -----	4
4502-AP	NUT -----	1
4502-AS	SEAL, OIL -----	1
4502-AT	COLLAR -----	1
4502-AU	RING, SNAP -----	1
4502-AV	PACKING -----	2
4502-AW	NUT -----	1
4502-AX	NUT -----	1
4502-AY	NUT, LOCK -----	1
4502-AZ	BOLT -----	3
4502-BB	RING, SNAP -----	1
4502-BB	SEAT -----	8
4502-BC	SPRING -----	4
4502-BD	STOPPER, BALANCE PISTON -----	1
4502-BE	RING, O -----	1
4502-BF	VALVE SUB-ASSY, RELIEF -----	1
4502-BG	SPRING, BALANCE PISTON -----	1

FIG. 4507 DRAG LINK &amp; STEERING PIPING

4507



PART NAME CODE	PART NAME	QTY
4507-10	END ASSY, DRAG LINK	2
4507-10A	NUT, CASTLE (FOR DRAG LINK END)	2
4507-11	END ASSY, POWER CYLINDER	2
4507-11A	NUT, CASTLE (FOR POWER CYLINDER END)	2
4507-30	PIPE SUB-ASSY, NO.1 (STEERING TO CYLINDER)	1
4507-31	PIPE SUB-ASSY, NO.2 (STEERING TO CYLINDER)	1
4507-32	PIPE SUB-ASSY (PUMP TO STEERING)	1
4507-40	ROD, DRAG LINK, NO.1	1
4507-41	ARM, PITMAN	1
4507-42	HOSE, POWER CYLINDER, NO.1	1
4507-43	HOSE, POWER CYLINDER, NO.2	1
4507-44	END, POWER CYLINDER	1
4507-45	HOSE, POWER STEERING PUMP SUCTION	1
4507-46	HOSE, HIGH PRESSURE (PUMP TO STEERING)	1
4507-AA	CLAMP, END	2
4507-AB	CLAMP, PIPE	1
4507-AC	CLAMP, END	2
4507-AD	BOLT	2
4507-AF	BOLT	2
4507-AQ	CLAMP	2
4507-AS	FITTING	1
4507-AT	FITTING	1
4507-AU	RING, O	2
4507-BB	CLAMP	1
4507-BD	WASHER, SPRING	2
4507-BE	NUT	2
4507-BF	WASHER, SPRING	2
4507-BG	NUT	2
4507-BH	BOLT, STAINLESS	1
4507-BI	WASHER	1


4507-006

(MAIN ) ( 22)

G210

FIG. 4508 STEERING POWER CYLINDER


4508



PART NAME CODE	PART NAME	QTY
4508-01	CYLINDER ASSY., POWER -----	1
4508-01K	PACKING KIT, POWER CYLINDER -----	1
4508-20	CYLINDER SUB-ASSY, POWER -----	1
4508-40	ROD, PISTON -----	1
4508-40A	NUT, SELF LOCK (FOR PISTON) -----	1
4508-41	PISTON -----	2
4508-42	RING, PISTON -----	1
4508-43	GUIDE, ROD -----	1
4508-AA	BUSHING -----	1
4508-AB	RING, SNAP -----	1
4508-AC	SEAL, DUST -----	1
4508-AD	RING, O -----	1
4508-AI	COLLAR, REAR COVER -----	1
4508-AJ	SEAT -----	2
4508-AK	RING, SNAP -----	1
4508-AL	PACKING, U -----	1
4508-AM	RING, BACK UP -----	1

FIG. 4510 STEERING OIL PUMP

4510




PART NAME CODE	PART NAME	QTY
4510-01	PUMP ASSY, POWER STEERING -----	1
4510-01K	PUMP KIT, POWER STEERING -----	1
4510-41	FLANGE, MOUNTING -----	1
4510-42	COVER -----	1
4510-43	SHAFT, PINION -----	1
4510-43A	BUSH (FOR PINION SHAFT) -----	2
4510-44	GEAR, INTERNAL -----	1
4510-AA	SEAL, OIL -----	1
4510-AB	HOUSING, OIL PUMP -----	1
4510-AC	SEGMENT -----	1
4510-AD	BOLT -----	4
4510-AE	PIN -----	1
4510-AF	RING, O -----	2
4510-AG	JOINT, OLDHAM -----	1

(MAIN ) ( 24)

G210

FIG. 4601 PARKING BRAKE

4601



PART NAME CODE	PART NAME	QTY
4601-10	HANDLE ASSY, PARKING BRAKE -----	1
4601-25	CABLE SUB-ASSY, PARKING BRAKE, NO. 2 -----	1
4601-29	LEVER SUB-ASSY, INTERMEDIATE -----	1
4601-AE	BAR SUB-ASSY, EQUALIZER -----	1
4601-AF	PIN, W/HOLE -----	1
4601-AG	PULLEY -----	1
4601-AH	CLAMP, WIRE SET -----	1
4601-AI	CLAMP -----	1
4601-AL	PIN, W/HOLE -----	1
4601-AP	BUSHING -----	1
4601-AQ	RING, SNAP -----	1
4601-AR	BOLT -----	2
4601-AS	WASHER, SPRING -----	2

4601 D08

(MAIN ) ( 25)



G210

FIG 4602 DEAD-MAN BRAKE

4602

(UL-E, UL-EE)

(UL-E, UL-EE)



4602 002


4602 001

**4602**

PART NAME CODE	PART NAME	QTY
4602-01	BRAKE ASSY, DEAD-MAN	1
4602-20	SHOE SUB-ASSY, BRAKE	2
4602-29	FRAME SUB-ASSY, SEAT	1
4602-32	LINK SUB-ASSY, DEAD-MAN BRAKE	1
4602-41	DRUM, DEAD-MAN BRAKE	1
4602-50	SPRING, BRAKE LINK	4
4602-AA	NUT, SELF LOCK	1
4602-AB	WASHER, PLATE	1
4602-AC	COLLAR	1
4602-AD	ROD SUB-ASSY, DEAD MAN BRAKE	1
4602-AE	PIN, W/HOLE	2
4602-AF	ROD SUB-ASSY, CONTROL VALVE	1
4602-AG	TURNBUCKLE	1
4602-AH	NUT	1
4602-AI	SHAFT	1
4602-AJ	BOLT	1
4602-AK	PLATE, SEAT FRAME STOPPER	1
4602-AL	LEVER ASSY, BRAKE	1
4602-AM	STRUT	1
4602-AN	PIN, BRAKE LEVER	2
4602-AO	WASHER, PLATE	2
4602-AP	PIN, SNAP	2
4602-AQ	SPRING, SHOE RETURN	1
4602-AR	NUT	3
4602-AS	PLATE, GUIDE	1
4602-AT	STUD	2
4602-AU	WASHER, LOCK	2
4602-AV	NUT, STRUT	1
4602-AW	BRACKET	1

FIG. 4701 BRAKE PEDAL

4701



PART NAME CODE	PART NAME	QTY
4701-20	PEDAL SUB-ASSY, BRAKE -----	1
4701-20A	BUSH (FOR BRAKE PEDAL) -----	2
4701-22	BRACKET SUB-ASSY, BRAKE PEDAL -----	1
4701-40	PAD, PEDAL -----	1
4701-47	SPRING, TENSION (FOR PEDAL RETURN) -----	1
4701-AA	SPACER -----	1
4701-AB	BOLT -----	1
4701-AG	BOLT, ADJUST -----	1
4701-AL	BRACKET, STOP SWITCH -----	1
4701-AQ	BOLT, STAINLESS -----	4
4701-AR	WASHER, SPRING -----	4
4701-BE	SWITCH ASSY, LIMIT -----	1
4701-BF	SCREW -----	1


4701-021

(MAIN ) ( 27)

G210

FIG. 4702 BRAKE MASTER CYLINDER

4702




PART NAME CODE	PART NAME	QTY
4702-01K	CYLINDER O/H KIT, MASTER -----	1
4702-10	PISTON SUB-ASSY, MASTER CYLINDER -----	1
4702-11	RESERVOIR SET, MASTER CYLINDER -----	1
4702-31	BRACKET SUB-ASSY, RESERVOIR -----	1
4702-40	ROD, PUSH -----	1
4702-41	CUP, CYLINDER -----	1
4702-42	BOOT -----	1
4702-43	HOSE, RESERVOIR -----	1
4702-45	CAP, RESERVOIR -----	1
4702-46	SPRING, COMPRESSION (FOR PISTON RETURN) -----	1
4702-AA	RING, HOLE SNAP -----	1
4702-AB	PLATE, PISTON STOP -----	1
4702-AC	CLEVIS, PUSH ROD -----	1
4702-AD	CAP, BREATHER PLUG -----	1
4702-AF	GASKET -----	2
4702-AI	BOLT, UNION -----	1
4702-AJ	GASKET -----	1
4702-AK	PIN -----	1
4702-AL	UNION -----	1
4702-AM	CLAMP -----	2
4702-AN	FLOAT -----	1
4702-AO	WASHER -----	1
4702-AP	BOLT -----	1
4702-AS	SEAT -----	1
4702-AT	CYLINDER ASSY, MASTER W/RESERVOIR -----	1
4702-AU	ROD SUB-ASSY, MASTER CYLINDER PUSH -----	1
4702-AV	RETAINER -----	1
4702-AW	ROD, CONNECTING -----	1
4702-AX	RETAINER -----	1
4702-AY	SPRING, CONICAL -----	1
4702-AZ	SEAL, VALVE -----	1
4702-BA	PLUG -----	1
4702-BB	SPRING, COMPRESSION -----	1
4702-BC	RESERVOIR, MASTER CYLINDER -----	1

4702 003

FIG. 4714 BRAKE PIPE

4714



PART NAME CODE	PART NAME	QTY
4714-20	PIPE SUB-ASSY, BRAKE, MAIN NO.1	1
4714-22	PIPE SUB-ASSY, BRAKE, RH NO.1	1
4714-23	PIPE SUB-ASSY, BRAKE, LH NO.1	1
4714-AE	3-WAY SUB-ASSY	1
4714-AF	BOLT	1
4714-AL	WASHER, SPRING	1


4714-009

(MAIN ) ( 29)

G210

FIG. 4715 DRUM BRAKE


4715



PART NAME CODE	PART NAME	QTY
4715-01	BRAKE ASSY, RH -----	1
4715-02	BRAKE ASSY, LH -----	1
4715-10	CYLINDER ASSY, WHEEL -----	2
4715-10K	CYLINDER O/H KIT, WHEEL -----	2
4715-20	SHOE SUB-ASSY (FOR FRONT OR UPPER) -----	2
4715-21	SHOE SUB-ASSY (FOR REAR OR LOWER) -----	2
4715-22	PLATE SUB-ASSY, BACKING, RH -----	1
4715-23	PLATE SUB-ASSY, BACKING, LH -----	1
4715-30	SCREW SUM-ASSY, ADJUSTING, RH -----	1
4715-31	SCREW SUM-ASSY, ADJUSTING, LH -----	1
4715-32	PISTON SUB-ASSY, WHEEL CYLINDER -----	4
4715-33	CABLE & FITTING SUB-ASSY -----	2
4715-40	BOGT, WHEEL CYLINDER -----	4
4715-41	CUP, WHEEL CYLINDER PISTON -----	4
4715-42	LEVER, AUTOMATIC ADJUSTMENT, RH -----	1
4715-43	LEVER, AUTOMATIC ADJUSTMENT, LH -----	1
4715-44	GUIDE, CABLE -----	2
4715-45	SPRING, SHOE HOLD DOWN -----	8
4715-46	CUP, SHOE HOLD DOWN -----	16
4715-47	SPRING, ADJUSTER -----	2
4715-48	PIN, SHOE HOLD DOWN -----	8
4715-49	ROD, PUSH -----	4
4715-51	SPRING, ANCHOR TO SHOE -----	4
4715-AA	BOLT & WASHER SET -----	4
4715-AB	COVER, HOLE -----	2
4715-AD	PLATE, SHOE GUIDE -----	2
4715-AE	WASHER, SPRING -----	2
4715-AF	LEVER SUB-ASSY, PARKING -----	1
4715-AG	STRUT, LEVER -----	1
4715-AH	RING, SNAP -----	2
4715-AI	RETAINER -----	2
4715-AJ	SPRING, STRUT TO SHOE -----	2
4715-AK	CAP, BREATHER SCREW -----	2
4715-AL	SCREW, BREATHER -----	2
4715-AN	SPRING, WHEEL CYLINDER -----	2
4715-AX	SPRING, LEVER RETURN, RH -----	1
4715-AY	SPRING, LEVER RETURN, LH -----	1

FIG. 5101 FRAME &amp; WEIGHT

5101



PART NAME CODE	PART NAME	QTY
5101-29	COVER SUB-ASSY, BATTERY	1
5101-30	DRAW-BAR SUB-ASSY	1
5101-34	GUARD SUB-ASSY, MUD, RH	1
5101-35	GUARD SUB-ASSY, MUD, LH	1
5101-47	WEIGHT SUB-ASSY, NO.1	1
5101-48	WEIGHT SUB-ASSY, NO.2	1
5101-AA	GUARD, MUD, FRONT	2
5101-AB	BOLT	4
5101-AC	WASHER, WAVE	4
5101-AD	HOSE, LOW PRESSURE	2
5101-AE	CLAMP SUB-ASSY	2
5101-AF	BOLT, HEXAGON	1
5101-AG	PLATE, WASHER	1
5101-AI	SPONGE	1
5101-AM	WASHER, PLATE	2
5101-AW	WASHER, PLATE	10
5101-BB	BOLT	10
5101-BD	WASHER, PLATE	2
5101-BZ	GROMMET	1
5101-CZ	NUT	2
5101-DA	WASHER	2
5101-DC	PLATE, COVER	1
5101-DE	SEAL, COVER	1


6101-015

(MAIN ) ( 31)

G210

FIG 5201 HOOD &amp; HINGE

5201



PART NAME CODE	PART NAME	QTY
5201-11	HOOD ASSY, BATTERY	1
5201-25	HOOD SUB ASSY, BATTERY, FRONT	1
5201-26	HOOD SUB-ASSY, BATTERY, REAR	1
5201-30	HINGE SUB-ASSY, BATTERY HOOD	2
5201-AU	INSULATOR	1
5201-BV	HOLDER	4
5201-BX	BOLT	2
5201-BY	WASHER, SPRING	4
5201-CW	SUPPORT, HOOD STAY	1
5201-FF	LATCH	4
5201-FG	LATCH	4
5201-FH	PLATE	4


5201-014

(MAIN ) ( 32)

G210

FIG. 5301 INSTRUMENT PANEL &amp; FLOOR

5301



PART NAME CODE	PART NAME	QTY
5301-20	PANEL SUB-ASSY, INSTRUMENT -----	1
5301-30	TOE-BOARD SUB-ASSY, NO.1 -----	1
5301-31	TOE-BOARD SUB-ASSY, NO.2 -----	1
5301-34	CLAMP SUB-ASSY, PAPER -----	1
5301-AA	SCREW -----	4
5301-AB	WASHER, WAVE -----	4
5301-AC	PLUG -----	1
5301-AD	PLUG -----	2
5301-AE	PLUG -----	1
5301-AF	WASHER, PLATE -----	4
5301-AO	SAFETY WALK -----	1
5301-BS	SAFETY WALK -----	1
5301-BI	SAFETY WALK -----	1
5301-BV	BOLT -----	4
5301-CD	WASHER, SPRING -----	4
5301-CU	RUBBER -----	1
5301-CV	PLATE -----	1
5301-CW	RUBBER -----	1

5301 021



(MAIN ) ( 33)

G210

FIG. 5308 DRIVER SEAT

**5308**

(W/ABSORBER)



5308-014


5308-008

**5308**

PART NAME CODE	PART NAME	QTY
5308-01	SEAT ASSY -----	1
5308-10	CUSHION ASSY -----	1
5308-11	TRACK ASSY -----	1
5308-12	TRACK ASSY, SEAT OUTER, RH -----	1
5308-13	TRACK ASSY, SEAT OUTER, LH -----	1
5308-20	SEAT SUB-ASSY, BACK -----	1
5308-40	FRAME, BACK SEAT -----	1
5308-AA	RUBBER, VIBRATION ISOLATOR -----	2
5308-AB	BRACKET, NUMBER PLATE -----	1
5308-AC	NUT, CAP -----	2
5308-AD	WIRE -----	1
5308-AE	WASHER -----	2
5308-AF	SPRING, TENSION, BACK SEAT -----	2
5308-AG	LINK -----	2
5308-AH	PIN -----	4
5308-AJ	COIL, SPRING -----	2
5308-AK	E-RING -----	4
5308-AL	PIN, NO.2 -----	2
5308-AM	SHOCK ABSORBER -----	1
5308-AP	ADJUSTER, ROD -----	1
5308-AR	HOOK, SEAT CUSHION -----	10
5308-AS	RING, E -----	2
5308-BB	CUSHION -----	1
5308-BC	NUT, STOPPER -----	1
5308-BD	BOLT, W/WASHER -----	4

FIG. 5401 HEAD GUARD &amp; ACCESSORY

5401




PART NAME CODE	PART NAME	QTY
5401-30	SHEET SUB-ASSY, HEAD GUARD	1
5401-31	MIRROR SUB-ASSY, RACK	1
5401-32	BRACKET SUB-ASSY, BACK MIRROR	2
5401-AE	PLUG, HOLE	1
5401-AI	CUSHION, SEAT	2
5401-BS	PLATE SUB-ASSY, HEAD GUARD	1
5401-BW	CHAIN SUB-ASSY, DRAG	1

5401-022

(MAIN ) ( 35)

G210

FIG. 5405 INDICATOR PLATE

**5405**

5405-01B

PART NAME CODE	PART NAME	QTY
5405-AA	PLATE, CAUTION -----	2
5405-AC	PLATE, CAUTION -----	1
5405-AD	PLATE, CAUTION -----	2
5405-AE	PLATE, INDICATOR -----	1
5405-AG	PLATE, LOAD INDICATOR -----	1
5405-AK	PLATE, INDICATOR -----	1
5405-AL	TOYOTA MARK -----	1
5405-AM	PLATE, SERVICE INDICATOR -----	1
5405-AP	STRIPE -----	2
5405-AQ	PLATE, CAPACITY INDICATOR -----	2
5405-AR	PLATE, CAUTION -----	1
5405-AT	PLATE, CAUTION -----	1
5405-AU	RIVET -----	4
5405-BG	PLATE, TEMPERATURE -----	2
5405-BH	MARK, TOYOTA -----	2
5405-BW	MARK, SYMBOL -----	2
5405-CA	PLATE, CAUTION -----	1
5405-CU	PLATE, INDICATOR -----	1
5405-CC	PLATE, CAUTION -----	1
5405-CN	PLATE, INDICATOR -----	1
5405-CQ	PLATE, SEQUENCE DIAGRAM -----	1
5405-CY	PLATE, CAUTION -----	1


(MAIN ) ( 36)

G210

FIG. 5502 CANVAS CABIN &amp; FRONT GLASS

**5502**

(FRONT GLASS)




PART NAME CODE	PART NAME	QTY
5502-02	PANEL ASSY, FRONT GLASS -----	1
5502-20	PANEL SUD-ASSY, FRONT GLASS -----	1
5502-40	GLASS, WINDSHIELD -----	1
5502-50	WEATHER STRIP -----	1
5502-AE	CUSHION, WINDSHIELD -----	2
5502-AF	PLATE, WINDSHIELD -----	2
5502-AG	PLATE, FRONT -----	1

5502-006

FIG. 5602 WIRING & CLAMP

**5602**





5602-02

(8209)	
54	N1 ~ F
55	P12 ~ F
CD	P13 ~ A
BC	N1 ~ NT
BP	NO ~ F

23	P22 ~ AC
24	P1 ~ P1
50	P3 ~ F
61	P4 ~ E
52	P5 ~ A
53	P6 ~ B
54	N1 ~ FD
55	P12 ~ AC
60	P6 ~ PB
61	N1 ~ N1
62	P2 ~ P2
63	P5 ~ P5
AO	N1 ~ BD
BC	NO ~ N1
BP	NO ~ FD

5602-02




5602-02

**5602**

PART NAME CODE	PART NAME	QTY
5602-15	FUSE ASSY -----	1
5602-20	HARNESS SUB-ASSY, WIRING -----	1
5602-21	HARNESS SUB-ASSY, PANEL -----	1
5602-22	HARNESS SUB-ASSY, RR -----	1
5602-23	WIRING SUB-ASSY, POWER STEERING -----	1
5602-24	WIRING SUB-ASSY, POWER STEERING -----	1
5602-30	CONNECTOR SUB-ASSY -----	1
5602-31	CONNECTOR SUB-ASSY, BATTERY -----	1
5602-40	FUSE -----	2
5602-44	CORO, HEAD LAMP -----	2
5602-50	WIRING, DRIVE MOTOR, NO.1 -----	1
5602-51	WIRING, DRIVE MOTOR, NO.2 -----	1
5602-52	WIRING, DRIVE MOTOR, NO.3 -----	1
5602-53	WIRING, DRIVE MOTOR, NO.4 -----	1
5602-54	WIRING, PUMP MOTOR, NO.1 -----	1
5602-55	WIRING, PUMP MOTOR, NO.2 -----	1
5602-60	WIRING, CONTROLLER, NO.1 -----	1
5602-61	WIRING, CONTROLLER, NO.2 -----	1
5602-62	WIRING, CONTROLLER, NO.3 -----	1
5602-63	WIRING, CONTROLLER, NO.3 -----	1
5602-AA	CLAMP -----	6
5602-A0	HARNESS, POWER STEERING -----	1
5602-B4	HARNESS ASSY -----	2
5602-B8	HARNESS, LIMIT SWITCH -----	1
5602-BC	WIRING SUB-ASSY, BREAKER -----	1
5602-B0	HARNESS, D100E, ROTARY LAMP -----	1
5602-BH	HARNESS, SIDE BRAKE SWITCH -----	1
5602-BI	HARNESS ASSY, DIRECTION -----	1
5602-BJ	HARNESS, STOP LAMP SWITCH -----	1
5602-BK	HARNESS, BRAKE SWITCH -----	1
5602-BM	GROMMET -----	3
5602-BN	HARNESS ASSY, REAR COMBINATION -----	1
5602-BP	WIRING SUB-ASSY, PUMP MOTOR -----	1
5602-BQ	HARNESS, ROTARY LAMP -----	1
5602-BS	RUBBER, CABLE, NO.2 -----	1
5602-BV	BUSH -----	2
5602-BW	BOOT -----	99
5602-BY	COVER SUB-ASSY, HARNESS -----	1
5602-CA	HARNESS, FLASHER LAMP -----	2
5602-CC	HARNESS ASSY, CONTACTOR -----	1
5602-CO	WIRING SUB-ASSY, PUMP MOTOR -----	1

FIG. 5611 LAMP

5611



PART NAME CODE	PART NAME	QTY
5611-01	LAMP ASSY, HEAD -----	2
5611-01a	BULB (FOR HEAD LAMP) -----	2
5611-02	LAMP ASSY, WORKING -----	1
5611-02b	BULB (FOR WORKING LAMP) -----	1
5611-03	LAMP ASSY, FLASHER -----	2
5611-03a	BULB (FOR FLASHER LAMP) -----	2
5611-03b	LENS (FOR FLASHER LAMP) -----	2
5611-04	LAMP ASSY, REAR COMBINATION -----	2
5611-04a	BULB (FOR REAR COMBINATION LAMP) -----	2
5611-04b	LENS (FOR REAR COMBINATION LAMP) -----	2
5611-05	LAMP ASSY, LICENCE -----	1
5611-05a	BULB (FOR LICENCE LAMP) -----	1
5611-07	LAMP ASSY, CLEARANCE -----	2
5611-07a	BULB (FOR CLEARANCE LAMP) -----	2
5611-07b	LENS (FOR CLEARANCE LAMP) -----	2
5611-09	LAMP ASSY, PILOT -----	1
5611-09a	BULB (FOR PILOT LAMP) -----	1
5611-09b	LENS (FOR PILOT LAMP) -----	1
5611-26	LAMP ASSY, COMBINATION PILOT -----	1
5611-26a	BULB (FOR COMBINATION PILOT LAMP) -----	2
5611-35	LAMP ASSY, ROTARY -----	1
5611-AF	CORD, HEAD LAMP -----	3
5611-AI	SCREW -----	4
5611-AK	PACKING -----	4
5611-AL	SCREW -----	4
5611-AS	LAMP ASSY, PILOT -----	1


5611-013

(MAIN ) ( 39)

G210

FIG. 5612 LAMP BRACKET

5612



PART NAME CODE	PART NAME	QTY
5612-AB	BRACKET SUB-ASSY, HEAD LAMP -----	1
5612-AG	BRACKET, FLASHER LAMP -----	1
5612-AJ	BRACKET, WORKING LAMP -----	1
5612-AM	BRACKET, REAR COMBINATION LAMP -----	1
5612-AN	PLATE SUB-ASSY, LICENCE -----	1
5612-AR	WASHER, RUBBER -----	4
5612-AN	COLLER -----	4
5612-AX	PLATE SUB-ASSY, REAR OPTION -----	1
5612-RY	GUARD SUB-ASSY, LAMP -----	2
5612-AZ	BRACKET SUB-ASSY, ROTARY LAMP -----	1
5612-BI	PLATE, GUM -----	2
5612-BK	BOLT -----	2
5612-BL	PLATE SUB-ASSY, HEAD LAMP -----	1

5612.023







(MAIN ) ( 40)

G210

FIG. 5702 METER & SWITCH

**5702**

(UL-EE)



5702-006


**5702**

PART NAME CODE	PART NAME	QTY
5702-05	RELAY ASSY, FLASHER -----	1
5702-07	BOX ASSY, OVER DISCHARGE -----	1
5702-10	HORN ASSY -----	1
5702-11	BUZZER ASSY, BACK -----	1
5702-12	CHIME ASSY, BACK -----	2
5702-13	SWITCH ASSY, TURN SIGNAL -----	1
5702-13A	SWITCH SUB-ASSY, MICRO -----	2
5702-14	SWITCH ASSY, LIGHT CONTROL -----	1
5702-15	SWITCH ASSY, STARTER -----	1
5702-18	SWITCH ASSY, HORN -----	1
5702-18A	CONTACT, HORN -----	1
5702-20	METER ASSY, VOLTAGE -----	1
5702-24	METER ASSY, HOUR -----	1
5702-25	INDICATOR ASSY, BATTERY CAPACITY -----	1
5702-40	SWITCH ASSY, LIMIT (FOR PUMP MOTOR) -----	1
5702-44	SWITCH ASSY, LIMIT, (FOR PARKING BRAKE) -----	1
5702-AF	RELAY ASSY, BATTERY CAPACITY -----	1
5702-AG	BODY, SWITCH -----	1
5702-AH	HOLDER, HORN POINT -----	1
5702-AI	SPRING, HORN CONTACT -----	1
5702-AJ	COVER -----	1
5702-AK	LUCKING BLOCK -----	1
5702-AL	COVER, RUBBER -----	1
5702-AM	HARNESS ASSY -----	1
5702-AN	ACTUATOR -----	2
5702-AO	PLATE, SWITCH -----	1
5702-AP	LEVER SIGNAL -----	1
5702-AQ	BELLows -----	1
5702-AR	ROLLER -----	1
5702-AS	HOLDER, ROLLER -----	1
5702-AT	SPRING -----	1
5702-AU	BRACKET, PARKING BRAKE -----	1
5702-AX	HARNESS ASSY -----	1
5702-AY	BRACKET, CHIME -----	1
5702-BB	COVER, LIMIT SWITCH, NO.1 -----	1
5702-BC	SEAL, COVER -----	1
5702-BD	COVER SUB-ASSY, LIMIT SWITCH, NO.2 -----	1
5702-BE	COVER, BRAKE SWITCH -----	1



FIG. 5706 SPEEDOMETER & SPEED ALARM

**5706**

(SPEEDOMETER)



(SPEEDOMETER)



5706-005



5706-006

**5706**

PART NAME CODE	PART NAME	QTY
5706-10	SPEEDOMETER ASSY -----	1
5706-13	PICK-UP ASSY, SPEEDOMETER -----	1
5706-14	BOX ASSY, SPEED ALARM -----	1
5706-15	RELAY ASSY -----	1
5706-17	BUZZER ASSY, SPEED ALARM -----	1
5706-20	HARNESS SUB-ASSY, SPEED ALARM -----	1
5706-AA	BRACKET, SPEEDOMETER -----	1
5706-AB	BRACKET SUB-ASSY, SPEED ALARM -----	1
5706-AE	HARNESS, SPEEDOMETER -----	1
5706-AF	HARNESS, SPEEDOMETER PICK UP -----	1
5706-AG	STAY, RELAY -----	1

FIG. 5801 WIPER MOTOR &amp; BLADE

5801




PART NAME CODE	PART NAME	QTY
5801-10	MOTOR ASSY, WIPER -----	1
5801-30	BLADE SUB-ASSY, WIPER -----	1
5801-31	ARM SUB-ASSY, WIPER -----	1
5801-AA	HARNESS, WIPER -----	1
5801-AQ	RESISTER ASSY -----	2
5801-AS	HARNESS ASSY, RESISTER -----	1
5801-AT	SCREW, W/WASHER -----	2
5801-AU	PLATE, RESISTOR SET -----	1
5801-AV	COVER, RESISTOR -----	1

FIG. 6101 MAST

6101

F




8109 064

PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER -----	1
6101-20B	BUSH, MAST SUPPORT -----	1
6101-21	MAST SUB-ASSY, INNER -----	1
6101-30	STRIP SUB-ASSY, OUTER MAST -----	2
6101-30A	SHIM, OUTER MAST STRIP -----	99
6101-40	ROLLER, LIFT (FOR OUTER MAST) -----	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST) -----	99
6101-41	ROLLER, LIFT (FOR INNER MAST) -----	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST) -----	99
6101-A0	FITTING, GREASE -----	2
6101-AF	COVER, ROLLER -----	2
6101-AG	PIN, SPRING -----	1
6101-AK	STOPPER, REAR CYLINDER -----	1

FIG. 6301 LIFT BRACKET &amp; FORK

6301

F



PART NAME CODE	PART NAME	QTY
6301-03	BRACKET ASSY, LIFT -----	1
6301-20	BACKREST SUB-ASSY -----	1
6301-21	FORK SUB-ASSY -----	2
6301-22	BRACKET SUB-ASSY, LIFT -----	1
6301-40	ROLLER, LIFT (UPPER, LOWER) -----	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER) -----	2
6301-40B	SHIM, LIFT ROLLER -----	99
6301-41	ROLLER, LIFT (CENTER) -----	2
6301-41A	RING, SHAFT SNAP (CENTER) -----	2
6301-42	ROLLER, SIDE -----	2
6301-42A	SHIM (FOR SIDE ROLLER) -----	99
6301-46	PIN, FORK STOPPER -----	2
6301-47	KNOB, FORK STOPPER PIN -----	2
6301-48	SPRING, FORK STOPPER PIN -----	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN) -----	2
6301-AA	COVER, LIFT BRACKET ROLLER -----	4
6301-AB	PLATE, SIDE -----	2

6301-041


(F ) ( 2)

G210

FIG. 6302 CHAIN &amp; CHAIN WHEEL

6302

F




PART NAME CODE	PART NAME	QTY
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21A	NUT, CHAIN ADJUST (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-A0	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2

FIG. B505 FRONT LIFT CYLINDER

6505

F



PART NAME CODE	PART NAME	QTY
6505-01	CYLINDER ASSY, LIFT	1
6505-01K	CYLINDER O/H KIT, LIFT	1
6505-20	CYLINDER SUB-ASSY, LIFT	1
6505-21	ROD SUB-ASSY, LIFT CYLINDER	1
6505-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6505-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6505-AA	SEAL, DUST	1
6505-AB	RING, O	1
6505-AC	RING, BACK UP	1
6505-AD	RING, O	1
6505-AE	RING, BACK UP	1
6505-AF	PACKING, U	1
6505-AH	BUSHING	1
6505-AI	PLUG	1

6505-007A


(F ) ( 4)

G210

FIG. 6506 REAR LIFT CYLINDER

**6506**

F



6506-001

PART NAME CODE	PART NAME	QTY
6506-01	CYLINDER ASSY, LIFT -----	1
6506-01K	CYLINDER O/H KIT, LIFT -----	1
6506-10	VALVE ASSY, FLOW REGULATOR -----	1
6506-20	CYLINDER SUB-ASSY, LIFT -----	1
6506-21	ROD SUB-ASSY, LIFT CYLINDER -----	1
6506-30	GUIDE SUB-ASSY, CYLINDER ROD -----	1
6506-40	PISTON, LIFT CYLINDER -----	1
6506-42	SLEEVE, LIFT CYLINDER ROD GUIDE -----	1
6506-AA	SEAL, DUST -----	1
6506-AB	RING, BACK UP -----	1
6506-AC	PACKING, U -----	1
6506-AD	RING, O -----	1
6506-AE	RING, BACK UP -----	1
6506-AF	RING, O -----	1
6506-AG	SPACER, LIFT CYLINDER -----	1
6506-AH	RING, SPACER -----	1
6506-AI	RING, WEAR -----	1
6506-AJ	RING, SHAFT SNAP -----	1
6506-HK	PLUG -----	1
6506-AL	RING, O -----	1

(F ) ( 5)


G210

FIG. 6511 TILT CYLINDER

6511

F

F



テイルト角度表  
TABLE OF TILT RANGE

生産期間 PROD DATE	型式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000		6D - 12D
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500		6D - 12D
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000		6D - 6D
8009-	F, FV, M, SV, V	DOUBLE	H5000		6D - 6D
8009-	F, FV, M, SV, V		H2000	FRONT GLASS	6D - 10D
8009-	FSV, FS		H3700-H8500		6D - 6D
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000	AUSTRALIA	3D - 12D
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	3D - 12D
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000	AUSTRALIA	3D - 6D
8009-	F, FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	3D - 6D
8009-	F, FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	3D - 10D
8009-	FV, M, SV, V		H3700-H8500	AUSTRALIA	3D - 6D


6511-019

6511-010

FIG. 6511 TILT CYLINDER

6511

F




PART NAME CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT -----	2
6511-01K	CYLINDER O/H KIT, TILT -----	2
6511-20	CYLINDER SUB-ASSY, TILT -----	2
6511-20A	BUSH, PIN (FOR CYLINDER) -----	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON -----	2
6511-21B	NUT, CASTLE -----	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD -----	2
6511-31	PIN SUB-ASSY, TILT CYLINDER -----	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR -----	2
6511-40	PISTON, TILT CYLINDER -----	2
6511-41	COVER, TILT CYLINDER -----	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE -----	2
6511-44	JOINT, PISTON ROD -----	2
6511-50	SEAL, GREASE -----	2
6511-AA	RING, HOLE SNAP -----	2
6511-AB	SEAL, DUST -----	2
6511-AC	RING, BACK UP -----	2
6511-AO	RING, O -----	2
6511-AE	RING, BACK UP -----	2
6511-AG	PACKING, U -----	2
6511-AH	PLATE, STOPPER -----	2
6511-AI	RING, HOLE SNAP -----	2
6511-AJ	RING, O -----	2
6511-AK	PACKING, U -----	4
6511-AL	SHIM, TILT CONTROL -----	99
6511-AM	SPACER, TILT CONTROL -----	2
6511-AN	RING, O -----	4
6511-AO	COLLAR -----	4
6511-AT	SPACER, TILT CONTROL -----	2
6511-AU	BOOT SUB-ASSY -----	2
6511-AV	BAR SUB-ASSY, TILT GAUGE -----	1
6511-AW	BRACKET SUB-ASSY, TILT GAUGE -----	1
	PLATE, TILT CYLINDER INDICATOR -----	1

FIG. 6701 OIL PUMP

6701

F



PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AO	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2


6701-016

(F) (7) G210

FIG. 6705 OIL CONTROL VALVE

6705

F






6705 056

FIG. 6705 OIL CONTROL VALVE

**6705**

F (3-WAY..UL-EE)






6705-D43

FIG. 6705 OIL CONTROL VALVE

**6705**

F (3-WAY)









6705-057

FIG. 6705 OIL CONTROL VALVE

**6705**

F (4-WAY)




6705-058

FIG. 6705 OIL CONTROL VALVE

6705

F (4-WAY..UL-EE)




6705-044

FIG. 6705 OIL CONTROL VALVE

**6705**

F (4-WAY)



6705-D68

# 6705

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE U/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, OUTLET	1
6705-AC	RING, O	1
6705-AD	RING, O	1
6705-AE	RING, O	1
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AO	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BI	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2

(F ) ( B )

G210

PART NAME CODE	PART NAME	QTY
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	2
6705-CA	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-DW	PLUG	1
6705-EX	BRACKET SUB-ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-EZ	RING, O	1
6705-FA	INSULATOR	4
6705-FN	FITTING	2

(F ) ( 9 )


G210

FIG. 7609 OIL CONTROL VALVE LINK


**6709**

F

F (3-WAY)



6709-016




6709-017

FIG. 7609 OIL CONTROL VALVE LINK

**6709**

F (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1 -----	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2 -----	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3 -----	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4 -----	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1 -----	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD) -----	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2 -----	1
6709-40	KNOB, OIL CONTROL VALVE LEVER -----	2
6709-41	PIN, OIL CONTROL VALVE LEVER -----	1
6709-41A	BUSH (FOR LEVER PIN) -----	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1 -----	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2 -----	2
6709-50	TURNBUCKLE -----	1
6709-AA	BRACKET SUB-ASSY -----	1
6709-AC	NUT -----	1
6709-AF	SPACER -----	1
6709-AG	BOLT, STUD -----	2


6709 018

(F ) ( 10 ) G210

FIG. 6801 BODY PIPING

6801

F



PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION -----	1
6801-11	FILTER ASSY, RETURN -----	1
6801-15A	PLUG (FOR OIL TANK DRAIN) -----	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG) -----	1
6801-20	PIPE SUB-ASSY (PUMP INLET) -----	1
6801-20A	RING, O (FOR OIL PUMP INLET) -----	1
6801-21A	RING, O (FOR OIL PUMP OUTLET) -----	1
6801-22	PIPE SUB-ASSY (PUMP TO VALVE) -----	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT) -----	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR) -----	1
6801-26	OUTLET SUB-ASSY, OIL TANK -----	1
6801-26A	PACKING, OIL TANK COVER -----	1
6801-27	CAP SUB-ASSY, OIL TANK -----	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) ---	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) ---	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT) -----	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR) -----	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT) -----	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR) -----	1
6801-45	FITTING (FOR TILT CYLINDER) -----	2
6801-46	FITTING (FOR LIFT CYLINDER) -----	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE) -----	2
6801-52	HOSE, LDW PRESSURE, NO.2 (VALVE TO TANK) ---	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE) -----	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP) -----	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE) -----	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE) -----	1
6801-AB	CLAMP -----	1
6801-AC	RING, O -----	4
6801-AQ	BOLT -----	8
6801-AF	FLANGE, SPLIT -----	1
6801-AG	CLAMP -----	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE -----	1
6801-AI	RING, O -----	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE -----	1
6801-BS	BOLT -----	1
6801-BT	WASHER -----	1
6801-BV	FLANGE -----	2

6801-D11


(F ) ( 11)

G21D

FIG. 6802 MAST PIPING

6802

F



PART NAME CODE	PART NAME	QTY
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFTY)	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFTY)	2
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AB	FITTING	1
6802-AC	RING, O	2

6802 001


(F ) ( 12)

G210

FIG. 6101 MAST

6101

FS



6101-076


PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER -----	1
6101-200	BUSH, MAST SUPPORT -----	1
6101-21	MAST SUB-ASSY, INNER -----	1
6101-22	MAST SUB-ASSY, MIDDLE -----	1
6101-30	STRIP SUB-ASSY, OUTER MAST -----	2
6101-30A	SHIM, OUTER MAST STRIP -----	99
6101-31	STRIP SUB-ASSY, MIDDLE MAST -----	2
6101-31A	SHIM, MIDDLE MAST STRIP -----	99
6101-40	ROLLER, LIFT (FOR OUTER MAST) -----	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST) -----	99
6101-41	ROLLER, LIFT (FOR INNER MAST) -----	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST) -----	99
6101-42	ROLLER, LIFT (FOR MIDDLE MAST UPPER) -----	2
6101-42A	SHIM, LIFT ROLLER (FOR MIDDLE MAST UPPER) --	99
6101-43	ROLLER, LIFT (FOR MIDDLE MAST LOWER) -----	2
6101-43A	SHIM, LIFT ROLLER (FOR MIDDLE MAST LOWER) --	99
6101-A0	FITTING, GREASE -----	2
6101-AF	COVER, ROLLER -----	2
6101-AG	PIN, SPRING -----	1
6101-AL	TOP, LIFT CYLINDER -----	1

(FS ) ( 1) G21D

FIG. 6301 LIFT BRACKET &amp; FORK

6301

FS



PART NAME CODE	PART NAME	QTY
6301-03	BRACKET ASSY, LIFT -----	1
6301-20	BACKREST SUB-ASSY -----	1
6301-21	FORK SUB-ASSY -----	2
6301-22	BRACKET SUB-ASSY, LIFT -----	1
6301-40	ROLLER, LIFT (UPPER, LOWER) -----	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER) -----	2
6301-40B	SHIM, LIFT ROLLER -----	99
6301-41	ROLLER, LIFT (CENTER) -----	2
6301-41A	RING, SHAFT SNAP (CENTER) -----	2
6301-42	ROLLER, SIDE -----	2
6301-42A	SHIM (FOR SIDE ROLLER) -----	99
6301-46	PIN, FORK STOPPER -----	2
6301-47	KNOB, FORK STOPPER PIN -----	2
6301-48	SPRING, FORK STOPPER PIN -----	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN) -----	2
6301-AA	COVER, LIFT BRACKET ROLLER -----	4
6301-AB	PLATE, SIDE -----	2


(FS ) ( 2)

G210

FIG. 6302 CHAIN &amp; CHAIN WHEEL

6302

FS



PART NAME CODE	PART NAME	QTY
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21A	NUT, CHAIN ADJUST (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-22	CHAIN SUB-ASSY (REAR)	2
6302-22K	BOLT KIT, CHAIN ANCHOR, NO.1 (REAR)	2
6302-22L	BOLT KIT, CHAIN ANCHOR, NO.2 (REAR)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-42	WHEEL, CHAIN (REAR)	2
6302-42A	RING, SHAFT SNAP (FOR CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2
6302-AK	PLATE, CHAIN ANCHOR	2
6302-AL	COVER, CHAIN WHEEL	4
6302-AQ	BOLT	2

6302-026


(FS ) ( 3)

6210

FIG. 6505 FRONT LIFT CYLINDER

6505

FS



PART NAME CODE	PART NAME	QTY
6505-01	CYLINDER ASSY, LIFT	1
6505-01K	CYLINDER O/H KIT, LIFT	1
6505-20	CYLINDER SUB-ASSY, LIFT	1
6505-21	ROD SUB-ASSY, LIFT CYLINDER	1
6505-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6505-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6505-AA	SEAL, DUST	1
6505-AB	RING, O	1
6505-AC	RING, BACK UP	1
6505-AD	RING, O	1
6505-AE	RING, BACK UP	1
6505-AF	PACKING, U	1
6505-AH	BUSHING	1
6505-AI	PLUG	1

6505-009


(FS ) ( 4)

G210

FIG. 6506 REAR LIFT CYLINDER

6506

FS



6506-002

PART NAME CODE	PART NAME	QTY
6506-01	CYLINDER ASSY, LIFT	1
6506-01K	CYLINDER O/H KIT, LIFT	1
6506-10	VALVE ASSY, FLOW REGULATOR	1
6506-20	CYLINDER SUB-ASSY, LIFT	1
6506-21	ROD SUB-ASSY, LIFT CYLINDER	1
6506-30	GUIDE SUB-ASSY, CYLINDER ROD	1
6506-40	PISTON, LIFT CYLINDER	1
6506-41	COVER, LIFT CYLINDER	1
6506-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6506-AA	SEAL, DUST	1
6506-AC	PACKING, U	1
6506-AF	RING, O	1
6506-AG	SPACER, LIFT CYLINDER	1
6506-AI	RING, NEAR	1
6506-AL	RING, O	1
6506-AM	RING, STOPPER	1
6506-AN	RING, BACK UP	1
6506-AU	PACKING	1
6506-AP	RING, BACK UP	1
6506-AQ	RING, O	1
6506-AR	RING, SHAFT SNAP	1

(FS ) ( 5)


G210

FIG. 6511 TILT CYLINDER

6511

FS

FS

テイルト角度表  
TABLE OF TILT RANGE


生産期間 PROD DATE	型式 MODELS	タイヤ TIRE	揚高 LIFTING HEIGHT	備考 DESCRIPTION	テイルト角 TILT RANGE
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000		BD - 12D
8009	F, FV, M, SV, V	DOUBLE	H2000-H4500		BD - 12D
8009	F, FV, M, SV, V	SINGLE	H4500-H5000		BD - BD
8009	F, FV, M, SV, V	DOUBLE	H5000		BD - BD
8009	F, FV, M, SV, V		H2000	FRONT GLASS	BD - 10D
8009	FSV, FS		H3700-H6500		BD - 6D
8009	F, FV, M, SV, V	SINGLE	H2000-H4000	AUSTRALIA	3D - 12D
8009	F, FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	3D - 12D
8009	F, FV, M, SV, V	SINGLE	H4500-H5000	AUSTRALIA	3D - 6D
8009	F, FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	3D - 6D
8009	F, FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	3D - 10D
8009	FV, M, SV, V		H3700-H6500	AUSTRALIA	3D - 6D

6511-019

FIG. 6511 TILT CYLINDER

6511

FS



6511-013

(FS ) ( 6)


G210

PART NAME CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT -----	2
6511-01K	CYLINDER D/H KIT, TILT -----	2
6511-20	CYLINDER SUB-ASSY, TILT -----	2
6511-20A	BUSH, PIN (FOR CYLINDR) -----	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON -----	2
6511-21B	NUT, CASTLE -----	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD -----	2
6511-31	PIN SUB-ASSY, TILT CYLINDER -----	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR -----	2
6511-40	PISTON, TILT CYLINDER -----	2
6511-41	COVER, TILT CYLINDER -----	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE -----	2
6511-44	JOINT, PISTON ROD -----	2
6511-50	SEAL, GREASE -----	2
6511-AA	RING, HOLE SNAP -----	2
6511-AB	SEAL, DUST -----	2
6511-AC	RING, BACK UP -----	2
6511-AD	RING, O -----	2
6511-AE	RING, BACK UP -----	2
6511-AF	PACKING, U -----	2
6511-AG	PLATE, STOPPER -----	2
6511-AH	RING, HOLE SNAP -----	2
6511-AI	RING, O -----	2
6511-AJ	PACKING, U -----	4
6511-AK	SHIM, TILT CONTROL -----	99
6511-AL	SPACER, TILT CONTROL -----	2
6511-AM	RING, U -----	4
6511-AN	COLLAR -----	4
6511-AO	SPACER, TILT CONTROL -----	2
6511-AT	BOOT SUB-ASSY -----	2
6511-AU	BAR SUB-ASSY, TILT GAUGE -----	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE -----	1
6511-AW	PLATE, TILT CYLINDER INDICATOR -----	1

FIG. 6701 OIL PUMP

**6701**

FS



PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL -----	1
6701-01K	PUMP D/H KIT, OIL -----	1
6701-10	GEAR SET -----	1
6701-11	BUSH SET, NO.1 -----	2
6701-43	BODY -----	1
6701-44	FLANGE, MOUNTING -----	1
6701-45	COVER -----	1
6701-AA	SEAL, BUSHING -----	2
6701-AB	RING, BACKING, RH -----	2
6701-AC	RING, BACKING, LH -----	2
6701-AD	SEAL, OIL -----	1
6701-AE	RING, SNAP -----	1
6701-AF	BOLT -----	4
6701-AG	WASHER, SPRING -----	4
6701-AH	SEAL, BODY -----	2
6701-AI	BOLT -----	2


6701-018

(FS ) ( 7 ) G210

FIG. 6705 OIL CONTROL VALVE

6705

FS






6705-058

FIG. 6705 OIL CONTROL VALVE

**6705**

FS (3-WAY..UL-EE)






6705-043

FIG. 6705 OIL CONTROL VALVE

**6705**

FS (3-WAY)





6705-057

FIG. 6705 OIL CONTROL VALVE

6705

FS (4-WAY)




6706 058

FIG. 6705 OIL CONTROL VALVE

6705

FS (4-WAY..UL-EE)




6705 044

FIG. 6705 OIL CONTROL VALVE

**6705**

FS (4-WAY)



6705 054

# 6705

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL -----	1
6705-01K	VALVE O/H KIT, OIL CONTROL -----	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1 -----	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2 -----	1
6705-20	VALVE SET, PILOT RELIEF, NO.1 -----	1
6705-21	VALVE SET, PILOT RELIEF, NO.2 -----	1
6705-23	HOUSING & SPOOL SET, NO.1 -----	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1 -----	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2 -----	1
6705-40	COVER, SPRING -----	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN) -----	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING) -----	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING) -----	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING) -----	2
6705-AA	BOLT -----	4
6705-AB	HOUSING, OUTLET -----	1
6705-AC	RING, O -----	1
6705-AD	RING, O -----	1
6705-AE	RING, O -----	1
6705-AF	BALL, STEEL -----	1
6705-AG	SPRING -----	1
6705-AH	SPRING, COMPRESSION -----	1
6705-AI	RING, O -----	1
6705-AJ	STOPPER -----	1
6705-AK	HOLDER, SPRING -----	2
6705-AL	WASHER, PLATE -----	2
6705-AM	RING, SHAFT SNAP -----	2
6705-AN	SCREW -----	4
6705-AO	PLUG -----	2
6705-AP	RING, O -----	4
6705-AQ	RING, BACK UP -----	4
6705-AR	HOLDER, SEAL -----	2
6705-AS	SCREW -----	4
6705-AT	STOPPER -----	1
6705-AU	STOPPER -----	1
6705-AV	RING, O -----	2
6705-AX	RING, O -----	3
6705-AY	RING, O -----	3
6705-BA	SPRING, COMPRESSION -----	1
6705-BB	WIRE, ORIFICE TURNING -----	1
6705-BC	SPRING, COMPRESSION -----	2
6705-BD	PLUNGER, CHECK -----	2
6705-BE	STOPPER -----	1
6705-BG	WASHER -----	4
6705-BH	PLUG -----	1
6705-BI	PLUG -----	1
6705-BJ	SEAT, VALVE -----	1
6705-BL	SEAT, INSERT -----	2
6705-BM	VALVE SUB-ASSY, RELIEF -----	1
6705-BN	RING, O -----	1
6705-BO	SPRING -----	1
6705-BP	STOPPER -----	1
6705-BQ	RING, O -----	2

(FS ) ( B)

G210

PART NAME CODE	PART NAME	QTY
6705-BR	RING, O -----	2
6705-BT	FITTING -----	1
6705-BU	FITTING -----	1
6705-BV	FITTING -----	2
6705-BW	FITTING -----	1
6705-BX	FITTING -----	2
6705-BY	FITTING -----	1
6705-BZ	PLUG -----	2
6705-CA	FITTING -----	1
6705-CC	PLUG -----	2
6705-CH	NUT -----	4
6705-DW	PLUG -----	1
6705-EX	BRACKET SUB-ASSY, TILT -----	1
6705-EY	BRACKET SUB-ASSY, LIFT -----	1
6705-EZ	RING, O -----	1
6705-FA	INSULATOR -----	4
6705-FN	FITTING -----	2

(FS ) ( 9)


G210

FIG. 6709 OIL CONTROL VALVE LINK


**6709**

FS

FS (3-WAY)



6709-016




6709-017

FIG. 6709 OIL CONTROL VALVE LINK

6709

FS (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	----- 1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	----- 1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	----- 1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	----- 1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	---- 2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	----- 4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	---- 1
6709-40	KNOB, OIL CONTROL VALVE LEVER	----- 2
6709-41	PIN, OIL CONTROL VALVE LEVER	----- 1
6709-41A	BUSH (FOR LEVER PIN)	----- 4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	----- 2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	----- 2
6709-50	TURNBUCKLE	----- 1
6709-AA	BRACKET SUB-ASSY	----- 1
6709-AC	NUT	----- 1
6709-AF	SPACER	----- 1
6709-AG	BOLT, STUD	----- 2


6709-01B

(FS ) ( 10 ) G21D

FIG. 6801 BODY PIPING

**6801**

FS



6801-011

PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION -----	1
6801-11	FILTER ASSY, RETURN -----	1
6801-15A	PLUG (FOR OIL TANK DRAIN) -----	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG) -----	1
6801-20	PIPE SUB-ASSY (PUMP INLET) -----	1
6801-20A	RING, O (FOR OIL PUMP INLET) -----	1
6801-21A	RING, O (FOR OIL PUMP OUTLET) -----	1
6801-22	PIPE SUB-ASSY (PUMP TO VALVE) -----	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT) -----	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR) -----	1
6801-26	OUTLET SUB-ASSY, OIL TANK -----	1
6801-26A	PACKING, OIL TANK COVER -----	1
6801-27	CAP SUB-ASSY, OIL TANK -----	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) --	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) --	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT) -----	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR) -----	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT) -----	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR) -----	1
6801-45	FITTING (FOR TILT CYLINDER) -----	2
6801-46	FITTING (FOR LIFT CYLINDER) -----	1
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK) -----	1
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE) -----	2
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE) -----	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK) -----	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE) -----	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP) -----	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE) -----	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE) -----	1
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE -----	2
6801-AC	RING, O -----	4
6801-AD	BOLT -----	8
6801-AF	FLANGE, SPLIT -----	1
6801-AG	CLAMP -----	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE -----	1
6801-BS	BOLT -----	1
6801-BT	WASHER -----	1
6801-BV	FLANGE -----	2


(FS) ( 11)

G210

FIG. 6802 MAST PIPING

**6802**

FS



PART NAME CODE	PART NAME	QTY
6802-20	PULLEY SUB-ASSY, HOSE GUIDE, NO.1 -----	1
6802-20	PIPE SUB-ASSY, NO.1 (FRONT LIFT) -----	1
6802-40	HOSE, HIGH PRESSURE (FRONT LIFT PULLEY) -----	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER) -----	1
6802-AA	PIN, HOSE GUIDE PULLEY -----	1
6802-AC	RING, O -----	1
6802-AD	COLLAR -----	1
6802-AE	STOPPER SUB-ASSY, HIGH PRESSURE HOSE -----	1
6802-AR	RING, U -----	1

6802-017A


(FS ) ( 12)

G210

FIG. 6101 MAST

6101

FSV




6101-051

PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER -----	1
6101-20B	BUSH, MAST SUPPORT -----	1
6101-21	MAST SUB-ASSY, INNER -----	1
6101-22	MAST SUB-ASSY, MIDDLE -----	1
6101-30	STRIP SUB-ASSY, OUTER MAST -----	2
6101-30A	SHIM, OUTER MAST STRIP -----	99
6101-31	STRIP SUB-ASSY, MIDDLE MAST -----	2
6101-31A	SHIM, MIDDLE MAST STRIP -----	99
6101-40	ROLLER, LIFT (FOR OUTER MAST) -----	2
6101-41	ROLLER, LIFT (FOR INNER MAST) -----	2
6101-42	ROLLER, LIFT (FOR MIDDLE MAST UPPER) -----	2
6101-43	ROLLER, LIFT (FOR MIDDLE MAST LOWER) -----	2
6101-A0	FITTING, GREASE -----	2
6101-AF	COVER, ROLLER -----	2
6101-AH	BOLT -----	8

FIG. 6301 LIFT BRACKET &amp; FORK

6301

FSV



PART NAME CODE	PART NAME	QTY
6301-20	BACKREST SUB-ASSY -----	1
6301-21	FORK SUB-ASSY -----	2
6301-22	BRACKET SUB-ASSY, LIFT -----	1
6301-40	ROLLER, LIFT (UPPER, LOWER) -----	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER) -----	2
6301-40B	SHIM, LIFT ROLLER -----	99
6301-41	ROLLER, LIFT (CENTER) -----	2
6301-41A	RING, SHAFT SNAP (CENTER) -----	2
6301-42	ROLLER, SIDE -----	2
6301-42A	SHIM (FOR SIDE ROLLER) -----	4
6301-43	SHAFT, SIDE ROLLER -----	2
6301-44	HOLDER, SIDE ROLLER SHAFT -----	4
6301-44A	SHIM (FOR SHAFT HOLDER) -----	99
6301-46	PIN, FORK STOPPER -----	2
6301-47	KNOB, FORK STOPPER PIN -----	2
6301-48	SPRING, FORK STOPPER PIN -----	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN) -----	2
6301-AA	COVER, LIFT BRACKET ROLLER -----	4
6301-AB	PLATE, SIDE -----	2

6301-040


(FSV ) ( 2)

G210

FIG. 6302 CHAIN &amp; CHAIN WHEEL

6302

FSV




PART CODE	PART NAME	QTY
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-22	CHAIN SUB-ASSY (REAR)	2
6302-22K	BOLT KIT, CHAIN ANCHOR, NO.1 (REAR)	2
6302-22L	BOLT KIT, CHAIN ANCHOR, NO.2 (REAR)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-42	WHEEL, CHAIN (REAR)	2
6302-42A	RING, SHAFT SNAP (FOR CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2

FIG. 6502 FRONT LIFT CYLINDER

6502

FSV



PART NAME CODE	PART NAME	QTY
6502-01	CYLINDER ASSY, LIFT	1
6502-01K	CYLINDFR D/H KIT, LIFT	1
6502-11	VALVE ASSY, SAFETY DOWN	1
6502-20	CYLINDER SUB-ASSY, LIFT	1
6502-21	ROD SUB-ASSY, LIFT CYLINDER	1
6502-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6502-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6502-AA	BUSHING	1
6502-AB	RING, O	1
6502-AC	RING, BACK UP	1
6502-AD	PACKING, U	1
6502-AE	RING, BACK UP	1
6502-AF	SEAL, DUST	1
6502-AG	RING, O	1
6502-AH	PLUG	1
6502-AI	RING, O	1

6502-009


(FSV ) ( 4)

G210

FIG. 6503 REAR LIFT CYLINDER

6503

FSV





PART NAME C04	PART NAME	QTY
6503-01	CYLINDER ASSY, LIFT, RH	1
6503-01K	CYLINDER D/H KIT, LIFT, RH	1
6503-02	CYLINDER ASSY, LIFT, LH	1
6503-02K	CYLINDER D/H KIT, LIFT, LH	1
6503-11	VALVE ASSY, SAFETY DOWN	1
6503-20	CYLINDER SUB-ASSY, LIFT, RH	1
6503-21	CYLINDER SUB-ASSY, LIFT, LH	1
6503-22	ROD SUB-ASSY, LIFT CYLINDER, RH	1
6503-23	ROD SUB-ASSY, LIFT CYLINDER, LH	1
6503-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH	1
6503-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH	1
6503-42	SLEEVE, LIFT CYLINDER ROD GUIDE	2
6503-AR	RING, WEAR	2
6503-AB	PACKING, U	2
6503-AE	PACKING, U	2
6503-AF	RING, O	2
6503-AG	SEAL, DUST	2
6503-AH	RING, O	1
6503-AI	SHIM	2- 3
6503-AK	BRACKET SUB-ASSY, LIFT CYLINDER	2
6503-AL	BUSHING	4
6503-AM	SPACER	2
6503-AN	SHIM	99
6503-AP	PLUG	2
6503-AQ	RING, BACK UP	2
6503-BB	BOLT	2

FIG. 6511 TILT CYLINDER

6511

FSV

FSV



6511-010

テイルト角度表  
TABLE OF TILT RANGE


生産期間 PROD DATE	製式 MODELS	タイヤ TIRE	高 LIFTING HEIGHT	備考 DESCRIPTION	テイルト角 TILT RANGE
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000		60 - 120
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500		60 - 120
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000		60 - 80
8009-	F, FV, M, SV, V	DOUBLE	H5000		60 - 80
8009-	F, FV, M, SV, V		H2000	FRONT GLASS	60 - 100
8009-	FSV, FS		H3700-H6500		60 - 60
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000	AUSTRALIA	30 - 120
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	30 - 120
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000	AUSTRALIA	30 - 60
8009-	F, FV, M, SV, V	DOUBLE	HS000	AUSTRALIA	30 - 60
8009-	F, FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	30 - 100
8009-	FV, M, SV, V		H3700-H6500	AUSTRALIA	30 - 60

6511-019

FIG. 6511 TILT CYLINDER

6511

FSV




PART NAME CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT -----	2
6511-01K	CYLINDER O/H KIT, TILT -----	2
6511-20	CYLINDER SUB-ASSY, TILT -----	2
6511-20A	BUSH, PIN (FOR CYLINDER) -----	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON -----	2
6511-21B	NUT, CASTLE -----	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD -----	2
6511-31	PIN SUB-ASSY, TILT CYLINDER -----	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR -----	2
6511-40	PISTON, TILT CYLINDER -----	2
6511-41	COVER, TILT CYLINDER -----	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE -----	2
6511-44	JOINT, PISTON ROD -----	2
6511-50	SEAL, GREASE -----	2
6511-AA	RING, HOLE SNAP -----	2
6511-AB	SEAL, DUST -----	2
6511-AC	RING, BACK UP -----	2
6511-AD	RING, O -----	2
6511-AE	RING, BACK UP -----	2
6511-AF	PACKING, U -----	2
6511-AG	PLATE, STOPPER -----	2
6511-AH	RING, HOLE SNAP -----	2
6511-AI	RING, O -----	2
6511-AJ	PACKING, U -----	4
6511-AK	SHIM, TILT CONTROL -----	99
6511-AL	SPACER, TILT CONTROL -----	2
6511-AM	RING, O -----	4
6511-AN	COLLAR -----	4
6511-AO	SPACER, TILT CONTROL -----	2
6511-AT	BUOT SUB-ASSY -----	2
6511-AU	BAR SUB-ASSY, TILT GAUGE -----	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE -----	1
6511-AW	PLATE, TILT CYLINDER INDICATOR -----	1

FIG. 6701 OIL PUMP

6701

FSV



PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2


6701-01A

(FSV ) ( ? ) G210

FIG. 6705 OIL CONTROL VALVE

6705

FSV



N°05 056

FIG. 6705 OIL CONTROL VALVE

**6705**

FSV (3-WAY,UL-EE)







FIG. 6705 OIL CONTROL VALVE

**6705**

FSV (3-WAY)









6705 057

FIG. 6705 OIL CONTROL VALVE

**6705**

FSV (4-WAY)




6705-058

FIG. 6705 OIL CONTROL VALVE

6705

FSV (4-WAY,UL-EE)




6705 044

FIG. 6705 OIL CONTROL VALVE

6705

FSV (4-WAY)



6705-000

# 6705

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, OUTLET	1
6705-AC	RING, O	1
6705-AD	RING, O	1
6705-AE	RING, O	1
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AO	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BI	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BQ	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2

(FSV ) ( 8 )

G210

PART NAME CODE	PART NAME	QTY
6705-BR	RING, O	2
6705-BI	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	2
6705-CA	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-DW	PLUG	1
6705-EX	BRACKET SUB-ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-EZ	RING, O	1
6705-FA	INSULATOR	4
6705-FN	FITTING	2

(FSV ) ( 9 )



G210

FIG. 6709 OIL CONTROL VALVE LINK

6709

FSV

FSV (3-WAY)




6709-016

6709-017

FIG. 6709 OIL CONTROL VALVE LINK

**6709**

FSV (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	----- 1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	----- 1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	----- 1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	----- 1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	----- 2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	----- 4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	----- 1
6709-40	KNOB, OIL CONTROL VALVE LEVER	----- 2
6709-41	PIN, OIL CONTROL VALVE LEVER	----- 1
6709-41A	BUSH (FOR LEVER PIN)	----- 4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	----- 2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	----- 2
6709-50	TURNBUCKLE	----- 1
6709-AA	BRACKET SUB-ASSY	----- 1
6709-AC	NUT	----- 1
6709-AF	SPACER	----- 1
6709-AG	BOLT, STUD	----- 2


6709 016

(FSV ) ( 10 ) G210

FIG. 6801 BODY PIPING

6801

FSV



PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION	1
6801-11	FILTER ASSY, RETURN	1
6801-12	VALVE ASSY, FLOW REGULATOR	1
6801-15A	PLUG (FOR OIL TANK DRAIN)	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG)	1
6801-20	PIPE SUB-ASSY (PUMP INLET)	1
6801-20A	RING, O (FOR OIL PUMP INLET)	1
6801-21A	RING, O (FOR OIL PUMP OUTLET)	1
6801-22	PIPE SUB-ASSY (PUMP TO VALVE)	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT)	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR)	1
6801-26	OUTLET SUB-ASSY, OIL TANK	1
6801-26A	PACKING, OIL TANK COVER	1
6801-27	CAP SUB-ASSY, OIL TANK	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE)	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT)	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT)	2
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR)	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR)	1
6801-45	FITTING (FOR TILT CYLINDER)	2
6801-46	FITTING (FOR LIFT CYLINDER)	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)	2
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE)	3
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE)	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE)	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP)	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE)	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE)	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE)	2
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE	4
6801-AC	RING, O	4
6801-AO	BOLT	8
6801-AF	FLANGE, SPLIT	1
6801-AG	CLAMP	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE	1
6801-AI	RING, O	2
6801-AR	FITTING	1
6801-AS	FITTING	1
6801-AT	FITTING	1
6801-AU	RING, O	3
6801-AV	RING, O	3
6801-AW	ELBOW SUB-ASSY, 3-WAY	1
6801-AZ	SPRING, COMPRESSION	1
6801-BA	PLUG	1
6801-BB	SPRING, COMPRESSION	1
6801-BC	BALL, STEEL	1
6801-BD	RING, O	1
6801-BS	BOLT	1
6801-BT	WASHER	1
6801-BV	FLANGE	2


(FSV ) ( 11)

G210

FIG. 6802 MAST PIPING

6802

FSV



PART NAME CODE	PART NAME	QTY
6802-20	PULLEY SUB-ASSY, HOSE GUIDE, NO.1 -----	1
6802-25	BRACKET SUB-ASSY, GUIDE PULLEY -----	1
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFT) -----	1
6802-31	PIPE SUB-ASSY, NO.2 (FRONT LIFT) -----	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT) -----	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER) -----	1
6802-AA	PIN, HOSE GUIDE PULLEY -----	1
6802-AC	RING, O -----	1
6802-AD	COLLAR -----	1
6802-AH	CLAMP -----	1


(FSV ) ( 12)

G210

FIG. 6101 MAST

6101

FV



6101-052 A


PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER -----	1
6101-208	BUSH, MAST SUPPORT -----	1
6101-21	MAST SUB-ASSY, INNER -----	1
6101-30	STRIP SUB-ASSY, OUTER MAST -----	2
6101-30A	SHIM, OUTER MAST STRIP -----	99
6101-40	ROLLER, LIFT (FOR OUTER MAST) -----	2
6101-41	ROLLER, LIFT (FOR INNER MAST) -----	2
6101-53	CUSHION, MAST (FOR INNER MAST) -----	2
6101-AD	FITTING, GREASE -----	2
6101-AF	COVER, ROLLER -----	2
6101-AH	BOLT -----	4
6101-AI	STOPPER -----	2
6101-AJ	SHIM, STOPPER -----	6
6101-AM	BOLT -----	4

(FV ) ( 1 ) G210

FIG. 6301 LIFT BRACKET &amp; FORK

6301

FV



PART NAME CODE	PART NAME	QTY
6301-20	BACKREST SUB-ASSY -----	1
6301-21	FORK SUB-ASSY -----	2
6301-22	BRACKET SUB-ASSY, LIFT -----	1
6301-40	ROLLER, LIFT (UPPER, LOWER) -----	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER) -----	4
6301-40B	SHIM, LIFT ROLLER -----	99
6301-41	ROLLER, LIFT (CENTER) -----	2
6301-42	ROLLER, SIDE -----	2
6301-42A	SHIM (FOR SIDE ROLLER) -----	4
6301-43	SHAFT, SIDE ROLLER -----	2
6301-44	HOLDER, SIDE ROLLER SHAFT -----	4
6301-44A	SHIM (FOR SHAFT HOLDER) -----	99
6301-46	PIN, FORK STOPPER -----	2
6301-47	KNOB, FORK STOPPER PIN -----	2
6301-48	SPRING, FORK STOPPER PIN -----	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN) -----	2
6301-AA	COVER, LIFT BRACKET ROLLER -----	4
6301-AB	PLATE, SIDE -----	2

6301-022


(FV ) ( 2)

G210

FIG. 6302 CHAIN &amp; CHAIN WHEEL

6302

FV



6302-017.A

PART NAME CODE	PART NAME	QTY
6302-21	CHAIN SUB-ASSY (FRONT)	2
6302-21A	NUT, CHAIN ADJUST (FRONT)	2
6302-21K	BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)	2
6302-21M	BOLT KIT, CHAIN EYE (FRONT)	2
6302-41	WHEEL, CHAIN (FRONT)	2
6302-41A	RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL)	2
6302-45	SUPPORT, CHAIN WHEEL	1
6302-AD	NUT, HEXAGON	2
6302-AE	WASHER, CHAIN SPECIAL	2
6302-AH	COVER, CHAIN WHEEL	2


(FV) ( 3 ) G210

FIG. 6502 FRONT LIFT CYLINDER

6502

FV

01



6502-001A

PART NAME CODE	PART NAME	QTY
6502-01	CYLINDER ASSY, LIFT -----	1
6502-01K	CYLINDER O/H KIT, LIFT -----	1
6502-11	VALVE ASSY, SAFETY DOWN -----	1
6502-20	CYLINDER SUB-ASSY, LIFT -----	1
6502-21	ROD SUB-ASSY, LIFT CYLINDER -----	1
6502-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD -----	1
6502-42	SLEEVE, LIFT CYLINDER ROD GUIDE -----	1
6502-AA	BUSHING -----	1
6502-AB	RING, O -----	1
6502-AC	RING, BACK UP -----	1
6502-AD	PACKING, U -----	1
6502-AE	RING, BACK UP -----	1
6502-AF	SEAL, DUST -----	1
6502-AG	RING, O -----	1
6502-AH	PLUG -----	1
6502-AI	RING, O -----	1
6502-AL	BOLT -----	2


(FV ) ( 4)

G210

FIG. 6503 REAR LIFT CYLINDER

6503

FV




PART NAME CODE	PART NAME	QTY
6503-01	CYLINDER ASSY, LIFT, RH -----	1
6503-01K	CYLINDER O/M KIT, LIFT, RH -----	1
6503-02	CYLINDER ASSY, LIFT, LH -----	1
6503-02K	CYLINDER O/M KIT, LIFT, LH -----	1
6503-11	VALVE ASSY, SAFETY DOWN -----	1
6503-20	CYLINDER SUB-ASSY, LIFT, RH -----	1
6503-21	CYLINDER SUB-ASSY, LIFT, LH -----	1
6503-22	ROD SUB-ASSY, LIFT CYLINDER, RH -----	1
6503-23	ROD SUB-ASSY, LIFT CYLINDER, LH -----	1
6503-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH -----	1
6503-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH -----	1
6503-42	SLEEVE, LIFT CYLINDER ROD GUIDE -----	2
6503-AA	RING, WEAR -----	2
6503-AC	RING, BACK UP -----	2
6503-AD	RING, O -----	2
6503-AE	PACKING, U -----	2
6503-AG	SEAL, DUST -----	2
6503-AH	RING, O -----	1
6503-AI	SHIM -----	2- 3
6503-AK	BRACKET SUB-ASSY, LIFT CYLINDER -----	2
6503-AL	BUSHING -----	4
6503-AM	SPACER -----	2
6503-AN	SHIM -----	99
6503-AP	PLUG -----	2

FIG. 6511 TILT CYLINDER

6511

FV

FV



テイルト角度表  
TABLE OF TILT RANGE

生産期間 PROD DATE	型式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8009	F, FV, M, SV, V	SINGLE	H2000-H4000		6D - 12D
8009	F, FV, M, SV, V	DOUBLE	H2000-H4500		6D - 12D
8009	F, FV, M, SV, V	SINGLE	H4500-H5000		6D - 6D
8009	F, FV, M, SV, V	DOUBLE	H5000		6D - 6D
8009	F, FV, M, SV, V		H2000	FRONT GLASS	6D - 10D
8009	FSV, FS		H3700-H6500		6D - 6D
8009	F, FV, M, SV, V	SINGLE	H2000-H4000	AUSTRALIA	3D - 12D
8009	F, FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	3D - 12D
8009	F, FV, M, SV, V	SINGLE	H4500-H5000	AUSTRALIA	3D - 6D
8009	F, FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	3D - 6D
8009	F, FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	3D - 10D
8009	FV, M, SV, V		H3700-H6500	AUSTRALIA	3D - 6D

6511-019


6511-010



FIG. 6511 TILT CYLINDER

6511

FV




PART NAME CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT -----	2
6511-01K	CYLINDER O/H KIT, TILT -----	2
6511-20	CYLINDER SUB-ASSY, TILT -----	2
6511-20A	BUSH, PIN (FOR CYLINDER) -----	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON -----	2
6511-21B	NUT, CASTLE -----	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD -----	2
6511-31	PIN SUB-ASSY, TILT CYLINDER -----	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR -----	2
6511-40	PISTON, TILT CYLINDER -----	2
6511-41	COVER, TILT CYLINDER -----	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE -----	2
6511-44	JOINT, PISTON ROD -----	2
6511-50	SEAL, GREASE -----	2
6511-AA	RING, HOLE SNAP -----	2
6511-AB	SEAL, DUST -----	2
6511-AC	RING, BACK UP -----	2
6511-AD	RING, O -----	2
6511-AE	RING, BACK UP -----	2
6511-AF	PACKING, U -----	2
6511-AG	PLATE, STOPPER -----	2
6511-AH	RING, HOLE SNAP -----	2
6511-AI	RING, O -----	2
6511-AJ	PACKING, U -----	4
6511-AK	SHIM, TILT CONTROL -----	99
6511-AL	SPACER, TILT CONTROL -----	2
6511-AM	RING, O -----	4
6511-AN	COLLAR -----	4
6511-AD	SPACER, TILT CONTROL -----	2
6511-AT	BOOT SUB-ASSY -----	2
6511-AU	BAR SUB-ASSY, TILT GAUGE -----	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE -----	1
6511-AW	PLATE, TILT CYLINDER INDICATOR -----	1

FIG. 6701 OIL PUMP

6701

FV



PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL -----	1
6701-01K	PUMP S/H KIT, OIL -----	1
6701-10	GEAR SET -----	1
6701-11	BUSH SET, NO.1 -----	2
6701-43	BODY -----	1
6701-44	FLANGE, MOUNTING -----	1
6701-45	COVER -----	1
6701-AA	SEAL, BUSHING -----	2
6701-AB	RING, BACKING, RH -----	2
6701-AC	RING, BACKING, LH -----	2
6701-AD	SEAL, DIL -----	1
6701-AE	RING, SNAP -----	1
6701-AF	BOLT -----	4
6701-AG	WASHER, SPRING -----	4
6701-AH	SEAL, BODY -----	2
6701-AI	BOLT -----	2


6701-Q1B

(FV) ( 7 ) Q210

FIG. 6705 OIL CONTROL VALVE

6705

FV




6705-056

FIG. 6705 OIL CONTROL VALVE

6705

FV (3-WAY,UL-EE)






6705 043

FIG. 6705 OIL CONTROL VALVE

6705

FV (3-WAY)









6705-057

FIG. 6705 OIL CONTROL VALVE

**6705**

FV (4-WAY)




6705-056

FIG. 6705 OIL CONTROL VALVE

**6705**

FV (4-WAY..UL-EE)




6705 044

FIG. 6705 OIL CONTROL VALVE

6705

FV (4-WAY)



6705 060

# 6705

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL -----	1
6705-01K	VALVE G/H KIT, OIL CONTROL -----	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1 -----	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2 -----	1
6705-20	VALVE SET, PILOT RELIEF, NO.1 -----	1
6705-21	VALVE SET, PILOT RELIEF, NO.2 -----	1
6705-23	HOUSING & SPOOL SET, NO.1 -----	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1 -----	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2 -----	1
6705-40	COVER, SPRING -----	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN) -----	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING) -----	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING) -----	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING) -----	2
6705-AA	BOLT -----	4
6705-AB	HOUSING, OUTLET -----	1
6705-AC	RING, O -----	1
6705-AD	RING, O -----	1
6705-AE	RING, O -----	1
6705-AF	BALL, STEEL -----	1
6705-AG	SPRING -----	1
6705-AH	SPRING, COMPRESSION -----	1
6705-AI	RING, O -----	1
6705-AJ	STOPPER -----	1
6705-AK	HOLDER, SPRING -----	2
6705-AL	WASHER, PLATE -----	2
6705-AM	RING, SHAFT SNAP -----	2
6705-AN	SCREW -----	4
6705-AO	PLUG -----	2
6705-AP	RING, O -----	4
6705-AQ	RING, BACK UP -----	4
6705-AR	HOLDER, SEAL -----	2
6705-AS	SCREW -----	4
6705-AT	STOPPER -----	1
6705-AU	STOPPER -----	1
6705-AV	RING, O -----	2
6705-AX	RING, O -----	3
6705-AY	RING, O -----	3
6705-BA	SPRING, COMPRESSION -----	1
6705-BB	WIRE, ORIFICE TURNING -----	1
6705-BC	SPRING, COMPRESSION -----	2
6705-BQ	PLUNGER, CHECK -----	2
6705-BE	STOPPER -----	1
6705-BG	WASHER -----	4
6705-BH	PLUG -----	1
6705-BI	PLUG -----	1
6705-BJ	SEAT, VALVE -----	1
6705-BL	SEAT, INSERT -----	2
6705-BM	VALVE SUB-ASSY, RELIEF -----	1
6705-BN	RING, O -----	1
6705-BO	SPRING -----	1
6705-BP	STOPPER -----	1
6705-BQ	RING, O -----	2

(FV ) ( 8 ) G210

PART NAME CODE	PART NAME	QTY
6705-BR	RING, O -----	2
6705-BT	FITTING -----	1
6705-BU	FITTING -----	1
6705-BV	FITTING -----	2
6705-BW	FITTING -----	1
6705-BX	FITTING -----	2
6705-BY	FITTING -----	1
6705-BZ	PLUG -----	2
6705-CA	FITTING -----	1
6705-CC	PLUG -----	2
6705-CH	NUT -----	4
6705-DW	PLUG -----	1
6705-EX	BRACKET SUB-ASSY, TILT -----	1
6705-EY	BRACKET SUB-ASSY, LIFT -----	1
6705-EZ	RING, O -----	1
6705-FA	INSULATOR -----	4
6705-FN	FITTING -----	2


(FV ) ( 9 ) G210

FIG. 6709 OIL CONTROL VALVE LINK


**6709**

FV

FV (3-WAY)



6709-016




6709-017

FIG. 6709 OIL CONTROL VALVE LINK

6709

FV (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNUBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AF	SPACER	1
6709-AG	BOLT, STUD	2


6709 018

(FV ) ( 10 ) G210

FIG. 8801 BODY PIPING

6801

FV



PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION -----	1
6801-11	FILTER ASSY, RETURN -----	1
6801-12	VALVE ASSY, FLOW REGULATOR -----	1
6801-15A	PLUG (FOR OIL TANK DRAIN) -----	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG) -----	1
6801-20	PIPE SUB-ASSY (PUMP INLET) -----	1
6801-20A	RING, O (FOR OIL PUMP INLET) -----	1
6801-21A	RING, O (FOR OIL PUMP OUTLET) -----	1
6801-22	PIPE SUB-ASSY (PUMP TO VALVE) -----	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT) -----	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR) -----	1
6801-26	OUTLET SUB-ASSY, OIL TANK -----	1
6801-26A	PACKING, OIL TANK COVER -----	1
6801-27	CAP SUB-ASSY, OIL TANK -----	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) -----	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) -----	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT) -----	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT) -----	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR) -----	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT) -----	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR) -----	1
6801-45	FITTING (FOR TILT CYLINDER) -----	2
6801-46	FITTING (FOR LIFT CYLINDER) -----	1
6801-51	CLAMP (FOR VALVE TO TANK NO.1 HOSE) -----	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK) -----	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE) -----	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP) -----	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE) -----	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE) -----	1
6801-AB	CLAMP -----	1
6801-AC	RING, O -----	4
6801-AD	BOLT -----	8
6801-AF	FLANGE, SPLIT -----	1
6801-AG	CLAMP -----	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE -----	1
6801-AI	RING, O -----	1
6801-AR	FITTING -----	1
6801-AS	FITTING -----	1
6801-AT	FITTING -----	1
6801-AV	RING, O -----	4
6801-AX	CAP, OIL TANK OVERFLOW PIPE -----	1
6801-AZ	SPRING, COMPRESSION -----	1
6801-BH	PLUG -----	1
6801-BB	SPRING, COMPRESSION -----	1
6801-BC	BALL, STEEL -----	1
6801-BD	RING, O -----	1
6801-BS	BOLT -----	1
6801-BT	WASHER -----	1
6801-BV	FLANGE -----	2

6801-019A


(FV ) ( 11)

G210

FIG. 6802 MAST PIPING

**6802**

FV



PART NAME CODE	PART NAME	QTY
6802-30	PIPE SUB-ASSY, NO.1 (FRONT LIFT)	1
6802-41	HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT)	1
6802-48	FITTING (FOR FRONT LIFT CYLINDER)	1
6802-AB	FITTING	1
6802-AC	RING, O	2

6802-009-A


(FV ) ( 12)

G210

FIG. 6101 MAST

6101

M



6101-050


PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER -----	1
6101-20B	BUSH, MAST SUPPORT -----	1
6101-21	MAST SUB-ASSY, INNER -----	1
6101-30	STRIP SUB-ASSY, OUTER MAST -----	2
6101-30A	SHIM, OUTER MAST STRIP -----	99
6101-40	ROLLER, LIFT (FOR OUTER MAST) -----	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST) -----	99
6101-41	ROLLER, LIFT (FOR INNER MAST) -----	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST) -----	99
6101-53	CUSHION, MAST (FOR INNER MAST) -----	2
6101-AA	PIN, SPRING -----	2
6101-AB	GUIDE, CHAIN WHEEL SUPPORT -----	2
6101-AC	STOPPER, INNER MAST -----	2
6101-AD	FITTING, GREASE -----	2
6101-AE	BOLT, STOPPER -----	2
6101-AF	COVER, ROLLER -----	2

(M ) ( 1 ) G21G

FIG. 6301 LIFT BRACKET &amp; FORK

6301

M



PART NAME CODE	PART NAME	QTY
6301-03	BRACKET ASSY, LIFT -----	1
6301-20	BACKREST SUB-ASSY -----	1
6301-21	FORK SUB-ASSY -----	2
6301-22	BRACKET SUB-ASSY, LIFT -----	1
6301-40	ROLLER, LIFT (UPPER, LOWER) -----	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER) -----	2
6301-40B	SHIM, LIFT ROLLER -----	99
6301-41	ROLLER, LIFT (CENTER) -----	2
6301-41A	RING, SHAFT SNAP (CENTER) -----	2
6301-42	ROLLER, SIDE -----	2
6301-42A	SHIM (FOR SIDE ROLLER) -----	99
6301-46	PIN, FORK STOPPER -----	2
6301-47	KNOB, FORK STOPPER PIN -----	2
6301-48	SPRING, FORK STOPPER PIN -----	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN) -----	2
6301-AA	COVER, LIFT BRACKET ROLLER -----	4

6301-042


(M ) ( 2)

G210

FIG. 6302 CHAIN &amp; CHAIN WHEEL

6302

M



PART NAME CODE	PART NAME	QTY
6302-20	CHAIN SUB-ASSY -----	2
6302-20A	NUT, CHAIN ADJUST -----	2
6302-20K	BOLT KIT, CHAIN ANCHOR, NO.1 -----	2
6302-20M	BOLT KIT, CHAIN EYE -----	2
6302-40	WHEEL, CHAIN -----	2
6302-40A	RING, SHAFT SNAP (FOR CHAIN WHEEL) -----	2
6302-45	SUPPORT, CHAIN WHEEL -----	1
6302-AA	PLATE, CHAIN STOPPER -----	2
6302-AC	CLAMP, CHAIN ANCHOR BOLT -----	2
6302-AD	NUT, HEXAGON -----	2
6302-AE	WASHER, CHAIN SPECIAL -----	2
6302-AG	BUSHING -----	2
6302-AH	COVER, CHAIN WHEEL -----	2


(M ) ( 3)

G210

FIG. 6504 LIFT CYLINDER

6504

M



PART NAME CODE	PART NAME	QTY
6504-01	CYLINDER ASSY, LIFT	1
6504-01K	CYLINDER O/H KIT, LIFT	1
6504-10	VALVE ASSY, FLOW REGULATOR	1
6504-20	CYLINDER SUB-ASSY, LIFT	1
6504-21	ROD SUB-ASSY, LIFT CYLINDER PISTON	1
6504-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD	1
6504-40	PISTON, LIFT CYLINDER	1
6504-41	COVER, LIFT CYLINDER	1
6504-42	SLEEVE, LIFT CYLINDER ROD GUIDE	1
6504-AA	SPACER, LIFT CYLINDER	1
6504-AB	RING, STOPPER	1
6504-AC	RING, WEAR	1
6504-AD	RING, BACK UP	1
6504-AE	PACKING, U	1
6504-AF	RING, BACK UP	1
6504-AG	RING, O	1
6504-AH	RING, SHAFT SNAP	1
6504-AI	SEAL, DUST	1
6504-AJ	PACKING, U	1
6504-AK	RING, O	1
6504-AL	RING, O	1

(M) (4)


G210

FIG. 6511 TILT CYLINDER

6511

M

M



6511-010

テイルト角度表  
TABLE OF TILT RANGE


生産期間 PROD DATE	型式 MODELS	タイヤ TIRE	揚 高 LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000		60-120
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500		60-120
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000		60-80
8009-	F, FV, M, SV, V	DOUBLE	H5000		60-60
8009-	F, FV, M, SV, V		H2000	FRONT GLASS	60-100
8009-	FSV, FS		H3700-H6500		60-60
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000	AUSTRALIA	30-120
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	30-120
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000	AUSTRALIA	30-60
8009-	F, FV, M, SV, V	DOUBLE	H6000	AUSTRALIA	30-60
8009-	F, FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	30-100
8009-	FV, M, SV, V		H3700-H6500	AUSTRALIA	30-60

6511-019

FIG. 6511 TILT CYLINDER

6511

M



PART NAME CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT	2
6511-01K	CYLINDER O/H KIT, TILT	2
6511-20	CYLINDER SUB-ASSY, TILT	2
6511-20A	BUSH, PIN (FOR CYLINDER)	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON	2
6511-21B	NUT, CASTLE	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD	2
6511-31	PIN SUB-ASSY, TILT CYLINDER	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR	2
6511-40	PISTON, TILT CYLINDER	2
6511-41	COVER, TILT CYLINDER	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE	2
6511-44	JOINT, PISTON ROD	2
6511-50	SEAL, GREASE	2
6511-AA	RING, HOLE SNAP	2
6511-A8	SEAL, DUST	2
6511-AC	RING, BACK UP	2
6511-AD	RING, O	2
6511-AE	RING, BACK UP	2
6511-AF	PACKING, U	2
6511-AG	PLATE, STOPPER	2
6511-AH	RING, HOLE SNAP	2
6511-AI	RING, O	2
6511-AJ	PACKING, U	4
6511-AK	SHIM, TILT CONTROL	99
6511-AL	SPACER, TILT CONTROL	2
6511-AM	RING, O	4
6511-AN	COLLAR	4
6511-AO	SPACER, TILT CONTROL	2
6511-AT	BOOT SUB-ASSY	2
6511-AU	BAR SUB-ASSY, TILT GAUGE	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE	1
6511-AW	PLATE, TILT CYLINDER INDICATOR	1

6511-013


(M) ( ) ( 5 )

G210

FIG. 6701 OIL PUMP

**6701**

M



PART NO.	PART NAME	QTY
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP O/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AO	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2


6701-01A

(M) (6) G210

FIG. 6705 OIL CONTROL VALVE

6705

M




6705-056

FIG. 6705 OIL CONTROL VALVE

**6705**

M (3-WAY..UL-EE)






6705 043

FIG. 6705 OIL CONTROL VALVE

6705

M (3-WAY)









6705 052

FIG. 6705 OIL CONTROL VALVE

6705

M (4-WAY)



6705-054

FIG. 6705 OIL CONTROL VALVE

**6705**

M (4-WAY UL-EE)





FIG. 6705 OIL CONTROL VALVE

6705

M (4-WAY)



6705-058

# 6705

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, OUTLET	1
6705-AC	RING, O	1
6705-AD	RING, O	1
6705-AE	RING, O	1
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AO	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BA	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BI	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2

(M ) ( 7)

G210

PART NAME CODE	PART NAME	QTY
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	2
6705-CA	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-DW	PLUG	1
6705-EX	BRACKET SUB ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-EZ	RING, O	1
6705-FA	INSULATOR	4
6705-FN	FITTING	2

(M ) ( 8)



G210

FIG. 6709 OIL CONTROL VALVE LINK

6709

M (3-WAY)

M




6709-016

6709-017

FIG. 6709 OIL CONTROL VALVE LINK


6709

M (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AF	SPACER	1
6709-AG	BOLT, STUD	2

FIG. 6801 BODY PIPING

**6801****M**

PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION -----	1
6801-11	FILTER ASSY, RETURN -----	1
6801-15A	PLUG (FOR OIL TANK DRAIN) -----	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG) -----	1
6801-20	PIPE SUB-ASSY (PUMP INLET) -----	1
6801-20A	RING, O (FOR OIL PUMP INLET) -----	1
6801-21A	RING, O (FOR OIL PUMP OUTLET) -----	1
6801-22	PIPE SUB-ASSY (PUMP TO VALVE) -----	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT) -----	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR) -----	1
6801-26	OUTLET SUB-ASSY, OIL TANK -----	1
6801-26A	PACKING, OIL TANK COVER -----	1
6801-27	CAP SUB-ASSY, OIL TANK -----	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) --	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) --	1
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT) -----	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR) -----	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT) -----	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR) -----	1
6801-45	FITTING (FOR TILT CYLINDER) -----	2
6801-46	FITTING (FOR LIFT CYLINDER) -----	1
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK) -----	1
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE) -----	2
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE) -----	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK) -----	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE) -----	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP) -----	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE) -----	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE) -----	1
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE -----	2
6801-AB	CLAMP -----	1
6801-AC	RING, O -----	4
6801-AD	BOLT -----	8
6801-AF	FLANGE, SPLIT -----	1
6801-AG	CLAMP -----	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE -----	1
6801-AI	RING, O -----	1
6801-AW	ELBOW SUB-ASSY, 3-WAY -----	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE -----	1
6801-BS	BOLT -----	1
6801-BT	WASHER -----	1
6801-BV	FLANGE -----	2


6801-011

(M) ( 10 ) G210

FIG. 6101 MAST

6101

SV




PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER -----	1
6101-20B	BUSH, MAST SUPPORT -----	1
6101-21	MAST SUB-ASSY, INNER -----	1
6101-30	STRIP SUB-ASSY, OUTER MAST -----	2
6101-30A	SHIM, OUTER MAST STRIP -----	99
6101-40	ROLLER, LIFT (FOR OUTER MAST) -----	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST) -----	99
6101-41	ROLLER, LIFT (FOR INNER MAST) -----	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST) -----	99
6101-53	CUSHION, MAST (FOR INNER MAST) -----	2
6101-AC	STOPPER, INNER MAST -----	2
6101-AD	FITTING, GREASE -----	2

(SV ) ( 1) G210

FIG. 6301 LIFT BRACKET &amp; FORK

6301

SV



PART NAME CODE	PART NAME	QTY
6301-03	BRACKET ASSY, LIFT	1
6301-20	BACKREST SUB-ASSY	1
6301-21	FORK SUB-ASSY	2
6301-22	BRACKET SUB-ASSY, LIFT	1
6301-40	ROLLER, LIFT (UPPER, LOWER)	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER)	2
6301-40B	SHIM, LIFT ROLLER	99
6301-41	ROLLER, LIFT (CENTER)	2
6301-41A	RING, SHAFT SNAP (CENTER)	2
6301-42	ROLLER, SIDE	2
6301-42A	SHIM (FOR SIDE ROLLER)	99
6301-46	PIN, FORK STOPPER	2
6301-47	KNOB, FORK STOPPER PIN	2
6301-48	SPRING, FORK STOPPER PIN	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN)	2
6301-52	ROLLER, SIDE, NO.2	2
6301-52C	RING, SHAFT SNAP (FOR SIDE ROLLER)	4
6301-53	PIN, SIDE ROLLER	2
6301-53A	SHIM (FOR SIDE ROLLER PIN)	99

6301-026 A


(SV) ( 2 )

G210

FIG. 6302 CHAIN &amp; CHAIN WHEEL

6302

SV



6302-037A

PART NAME CODE	PART NAME	QTY
6302-20	CHAIN SUB-ASSY -----	2
6302-20A	NUT, CHAIN ADJUST -----	2
6302-20I	BOLT KIT, CHAIN ANCHOR, NO.2 -----	2
6302-20M	BOLT KIT, CHAIN EYE -----	2
6302-30	BEAM SUB-ASSY, CHAIN -----	1
6302-30A	BUSHING -----	2
6302-31	PIN SUB-ASSY, CHAIN WHEEL -----	2
6302-40	WHEEL, CHAIN -----	2
6302-AC	CLAMP, CHAIN ANCHOR BOLT -----	2
6302-AD	NUT, HEXAGON -----	2
6302-AE	WASHER, CHAIN SPECIAL -----	2
6302-AO	PIN, SPRING -----	2
6302-AP	COLLAR, CHAIN WHEEL -----	4


(SV ) ( 3)

G210

FIG. 6501 LIFT CYLINDER

6501

SV




PART NAME CODE	PART NAME	QTY
6501-01	CYLINDER ASSY, LIFT, RH -----	1
6501-01K	CYLINDER O/H KIT, LIFT, RH -----	1
6501-02	CYLINDER ASSY, LIFT, LH -----	1
6501-02K	CYLINDER O/H KIT, LIFT, LH -----	1
6501-11	VALVE ASSY, SAFETY DOWN -----	1
6501-20	CYLINDER SUB-ASSY, LIFT, RH -----	1
6501-21	CYLINDER SUB-ASSY, LIFT, LH -----	1
6501-22	ROD SUB-ASSY, LIFT CYLINDER, RH -----	1
6501-23	ROD SUB-ASSY, LIFT CYLINDER, LH -----	1
6501-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH -----	1
6501-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH -----	1
6501-42	SLEEVE, LIFT CYLINDER ROD GUIDE -----	2
6501-AA	RING, WEAR -----	2
6501-AB	PACKING, U -----	2
6501-AC	RING, BACK UP -----	2
6501-AE	PACKING, U -----	2
6501-AF	RING, O -----	2
6501-AG	SEAL, DUST -----	2
6501-AH	RING, O -----	2
6501-AI	SHIM -----	99
6501-AK	BRACKET SUB-ASSY, LIFT CYLINDER -----	2
6501-AL	BUSHING -----	4
6501-AM	SPACER -----	2
6501-AN	SHIM -----	99

FIG. 6511 TILT CYLINDER

6511

SV

SV



6511-010

テイルト角度表  
TABLE OF TILT RANGE


生産期間 PROD DATE	型式 MODELS	タイヤ TIRE	揚高 LIFTING HEIGHT	備考 DESCRIPTION	ティルト角 TILT RANGE
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000		6D - 12D
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500		6D - 12D
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000		6D - 6D
8009-	F, FV, M, SV, V	DOUBLE	H5000		6D - 6D
8009-	F, FV, M, SV, V		H2000	FRONT GLASS	6D - 10D
8009-	FSV, FS		H3700-H6500		6D - 6D
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000	AUSTRALIA	3D - 12D
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	3D - 12D
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000	AUSTRALIA	3D - 6D
8009-	F, FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	3D - 6D
8009-	F, FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	3D - 10D
8009-	FV, M, SV, V		H3700-H6500	AUSTRALIA	3D - 6D

6511-019

FIG. 6511 TILT CYLINDER

6511

SV




PART NAME CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT -----	2
6511-01K	CYLINDER O/H KIT, TILT -----	2
6511-20	CYLINDER SUB-ASSY, TILT -----	2
6511-20A	BUSH, PIN (FOR CYLINDER) -----	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON -----	2
6511-21H	NUT, CASTLE -----	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD -----	2
6511-31	PIN SUB-ASSY, TILT CYLINDER -----	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR -----	2
6511-40	PISTON, TILT CYLINDER -----	2
6511-41	COVER, TILT CYLINDER -----	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE -----	2
6511-44	JOINT, PISTON ROD -----	2
6511-50	SEAL, GREASE -----	2
6511-AA	RING, HOLE SNAP -----	2
6511-AB	SEAL, DUST -----	2
6511-AC	RING, BACK UP -----	2
6511-AD	RING, O -----	2
6511-AE	RING, BACK UP -----	2
6511-AF	PACKING, U -----	2
6511-AG	PLATE, STOPPER -----	2
6511-AH	RING, HOLE SNAP -----	2
6511-AI	RING, O -----	2
6511-AJ	PACKING, U -----	4
6511-AK	SHIM, TILT CONTROL -----	99
6511-AL	SPACER, TILT CONTROL -----	2
6511-AM	RING, O -----	4
6511-AN	COLLAR -----	4
6511-AO	SPACER, TILT CONTROL -----	2
6511-AT	BOOT SUB-ASSY -----	2
6511-AU	BAR SUB-ASSY, TILT GAUGE -----	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE -----	1
6511-AW	PLATE, TILT CYLINDER INDICATOR -----	1

FIG. 8701 OIL PUMP

6701

SV



91111-51025  
 94612-11000  
 94512-01000

PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL	1
6701-01K	PUMP D/H KIT, OIL	1
6701-10	GEAR SET	1
6701-11	BUSH SET, NO.1	2
6701-43	BODY	1
6701-44	FLANGE, MOUNTING	1
6701-45	COVER	1
6701-AA	SEAL, BUSHING	2
6701-AB	RING, BACKING, RH	2
6701-AC	RING, BACKING, LH	2
6701-AD	SEAL, OIL	1
6701-AE	RING, SNAP	1
6701-AF	BOLT	4
6701-AG	WASHER, SPRING	4
6701-AH	SEAL, BODY	2
6701-AI	BOLT	2


6701-018

(SV) (6) G210

FIG. 6705 OIL CONTROL VALVE

6705

SV




6705-056

FIG. 6705 OIL CONTROL VALVE

**6705**

SV (3-WAY, UL-EE)






6705-043

FIG. 6705 OIL CONTROL VALVE

6705

SV (3-WAY)









6705-Q57

FIG. 6705 OIL CONTROL VALVE

**6705**

SV (4-WAY)




6705-068

FIG. 6705 OIL CONTROL VALVE

6705

SV (4-WAY, UL-EE)




6705-044

FIG. 6705 OIL CONTROL VALVE

6705

SV (4-WAY)



6706 059

# 6705

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL -----	1
6705-01K	VALVE D/H KIT, OIL CONTROL -----	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1 -----	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2 -----	1
6705-20	VALVE SET, PILOT RELIEF, NO.1 -----	1
6705-21	VALVE SET, PILOT RELIEF, NO.2 -----	1
6705-23	HOUSING & SPOOL SET, NO.1 -----	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1 -----	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2 -----	1
6705-40	COVER, SPRING -----	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN) -----	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING) -----	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING) -----	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING) -----	2
6705-AA	BOLT -----	4
6705-AB	HOUSING, OUTLET -----	1
6705-AC	RING, O -----	1
6705-AO	RING, O -----	1
6705-AE	RING, O -----	1
6705-AF	BALL, STEEL -----	1
6705-AG	SPRING -----	1
6705-AH	SPRING, COMPRESSION -----	1
6705-AI	RING, O -----	1
6705-AJ	STOPPER -----	1
6705-AK	HOLDER, SPRING -----	2
6705-AL	WASHER, PLATE -----	2
6705-AM	RING, SHAFT SNAP -----	2
6705-AN	SCREW -----	4
6705-AQ	PLUG -----	2
6705-AP	RING, O -----	4
6705-AQ	RING, BACK UP -----	4
6705-AR	HOLDER, SEAL -----	2
6705-AS	SCREW -----	4
6705-AT	STOPPER -----	1
6705-AU	STOPPER -----	1
6705-AV	RING, O -----	2
6705-AX	RING, O -----	3
6705-AY	RING, O -----	3
6705-BA	SPRING, COMPRESSION -----	1
6705-BB	WIRE, ORIFICE TURNING -----	1
6705-BC	SPRING, COMPRESSION -----	2
6705-BD	PLUNGER, CHECK -----	2
6705-BE	STOPPER -----	1
6705-BG	WASHER -----	4
6705-BH	PLUG -----	1
6705-BI	PLUG -----	1
6705-BJ	SEAT, VALVE -----	1
6705-BL	SEAT, INSERT -----	2
6705-BM	VALVE SUB-ASSY, RELIEF -----	1
6705-BN	RING, O -----	1
6705-BO	SPRING -----	1
6705-BP	STOPPER -----	1
6705-BQ	RING, O -----	2

(SV ) ( 7)

G210

PART NAME CODE	PART NAME	QTY
6705-BR	RING, O -----	2
6705-BT	FITTING -----	1
6705-BU	FITTING -----	1
6705-BV	FITTING -----	2
6705-BW	FITTING -----	1
6705-BX	FITTING -----	2
6705-BY	FITTING -----	1
6705-BZ	PLUG -----	2
6705-CA	FITTING -----	1
6705-CC	PLUG -----	2
6705-CH	NUT -----	4
6705-DW	PLUG -----	1
6705-EX	BRACKET SUB-ASSY, TILT -----	1
6705-EY	BRACKET SUB-ASSY, LIFT -----	1
6705-EZ	RING, O -----	1
6705-FA	INSULATOR -----	4
6705-FN	FITTING -----	2

(SV ) ( 8)


G210

FIG. 6709 OIL CONTROL VALVE LINK


**6709**

SV

SV (3-WAY)



6709-014




6709-017

FIG. 6709 OIL CONTROL VALVE LINK

**6709**

SV (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	----- 1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	----- 1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	----- 1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	----- 1
6709-50	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	----- 2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	----- 4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	----- 1
6709-40	KNOB, OIL CONTROL VALVE LEVER	----- 2
6709-41	PIN, OIL CONTROL VALVE LEVER	----- 1
6709-41A	BUSH (FOR LEVER PIN)	----- 4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	----- 2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	----- 2
6709-50	TURNBUCKLE	----- 1
6709-AA	BRACKET SUB-ASSY	----- 1
6709-AC	NUT	----- 1
6709-AF	SPACER	----- 1
6709-AG	BOLT, STUD	----- 2


6709 018

(SV ) ( 9 ) 0210

FIG. 6801 BODY PIPING

6801

SV



PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION -----	1
6801-11	FILTER ASSY, RETURN -----	1
6801-12	VALVE ASSY, FLOW REGULATOR -----	1
6801-15A	PLUG (FOR OIL TANK DRAIN) -----	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG) -----	1
6801-20	PIPE SUB-ASSY (PUMP INLET) -----	1
6801-20A	RING, O (FOR OIL PUMP INLET) -----	1
6801-21A	RING, O (FOR OIL PUMP OUTLET) -----	1
6801-22	PIPE SUB-ASSY (PUMP TO VALVE) -----	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT) -----	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR) -----	1
6801-26	OUTLET SUB-ASSY, OIL TANK -----	1
6801-26A	PACKING, OIL TANK COVER -----	1
6801-27	CAP SUB-ASSY, OIL TANK -----	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) --	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) --	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT) --	2
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT) --	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR) --	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT) --	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR) --	1
6801-45	FITTING (FOR TILT CYLINDER) -----	2
6801-46	FITTING (FOR LIFT CYLINDER) -----	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK) -----	2
6801-50A	CLAMP (FDR LIFT TO TANK NO.1 HOSE) -----	3
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE) -----	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK) -----	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE) -----	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP) -----	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE) -----	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE) -----	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK) -----	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE) -----	3 - 4
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE -----	4
6801-AB	CLAMP -----	1
6801-AC	RING, O -----	4
6801-AD	BOLT -----	8
6801-AF	FLANGE, SPLIT -----	1
6801-AG	CLAMP -----	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE -----	1
6801-AI	RING, O -----	2
6801-AP	PIPE -----	1
6801-AS	FITTING -----	1
6801-AT	FITTING -----	1
6801-AV	RING, O -----	2
6801-AW	ELBOW SUB-ASSY, 3-WAY -----	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE -----	1
6801-AZ	SPRING, COMPRESSION -----	1
6801-BA	PLUG -----	1
6801-BB	SPRING, COMPRESSION -----	1
6801-BC	BALL, STEEL -----	1
6801-BS	BOLT -----	1
6801-HT	WASHER -----	1

6801-01BA

(SV ) ( 10) G210

**6801**

PART NAME CODE	PART NAME	QTY
6801-BV	FLANGE -----	2


(54 ) ( 11)

G210

FIG. 6101 MAST

**6101**

V



6101-049


PART NAME CODE	PART NAME	QTY
6101-20	MAST SUB-ASSY, OUTER	1
6101-20B	BUSH, MAST SUPPORT	1
6101-21	MAST SUB-ASSY, INNER	1
6101-30	STRIP SUB-ASSY, OUTER MAST	2
6101-30A	SHIM, OUTER MAST STRIP	99
6101-40	ROLLER, LIFT (FOR OUTER MAST)	2
6101-40A	SHIM, LIFT ROLLER (FOR OUTER MAST)	99
6101-41	ROLLER, LIFT (FOR INNER MAST)	2
6101-41A	SHIM, LIFT ROLLER (FOR INNER MAST)	99
6101-AD	FITTING, GREASE	2
6101-AF	COVER, ROLLER	1

(V) ( ) ( 1 ) G210

FIG. 6301 LIFT BRACKET &amp; FORK

6301

V



PART NAME CODE	PART NAME	QTY
6301-03	BRACKET ASSY, LIFT -----	1
6301-20	BACKREST SUB-ASSY -----	1
6301-21	FORK SUB-ASSY -----	2
6301-22	BRACKET SUB-ASSY, LIFT -----	1
6301-40	ROLLER, LIFT (UPPER, LOWER) -----	4
6301-40A	RING, SHAFT SNAP (UPPER, LOWER) -----	2
6301-40B	SHIM, LIFT ROLLER -----	99
6301-41	ROLLER, LIFT (CENTER) -----	2
6301-41A	RING, SHAFT SNAP (CENTER) -----	2
6301-42	ROLLER, SIDE -----	2
6301-42A	SHIM (FOR SIDE ROLLER) -----	99
6301-46	PIN, FORK STOPPER -----	2
6301-47	KNOB, FORK STOPPER PIN -----	2
6301-48	SPRING, FORK STOPPER PIN -----	2
6301-49	PIN, SPRING (FOR FORK STOPPER PIN) -----	2
6301-52	ROLLER, SIDE, NO.2 -----	2
6301-52C	RING, SHAFT SNAP (FOR SIDE ROLLER) -----	4
6301-53	PIN, SIDE ROLLER -----	2
6301-53A	SHIM (FOR SIDE ROLLER PIN) -----	99
6301-AA	COVER, LIFT BRACKET ROLLER -----	2
6301-AH	COVER, LIFT BRACKET, SIDE ROLLER -----	2


(V) (2)

G210

FIG. 6302 CHAIN &amp; CHAIN WHEEL

**6302**

V



PART	NAME	QTY
6302-20	CHAIN SUB-ASSY	2
6302-20K	BOLT KIT, CHAIN ANCHOR, NO.1	2
6302-2UL	BOLT KIT, CHAIN ANCHOR, NO.2	2
6302-4U	WHEEL, CHAIN	2
6302-4DA	RING, SHAFT SNAP (FOR CHAIN WHEEL)	2
6302-RD	NUT, HEXAGON	4
6302-AH	COVER, CHAIN WHEEL	2
6302-RV	NUT, LOCK	2

6302-0006


(V) (3)

6210

FIG. 6501 LIFT CYLINDER

6501

V



PART NAME CODE	PART NAME	QTY
6501-01	CYLINDER ASSY, LIFT, RH -----	1
6501-01K	CYLINDER O/H KIT, LIFT, RH -----	1
6501-02	CYLINDER ASSY, LIFT, LH -----	1
6501-02K	CYLINDER O/H KIT, LIFT, LH -----	1
6501-11	VALVE ASSY, SAFETY DOWN -----	1
6501-20	CYLINDER SUB-ASSY, LIFT, RH -----	1
6501-21	CYLINDER SUB-ASSY, LIFT, LH -----	1
6501-22	ROD SUB-ASSY, LIFT CYLINDER, RH -----	1
6501-23	ROD SUB-ASSY, LIFT CYLINDER, LH -----	1
6501-30	GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH -----	1
6501-31	GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH -----	1
6501-42	SLEEVE, LIFT CYLINDER ROD GUIDE -----	2
6501-AA	RING, WEAR -----	2
6501-AB	PACKING, U -----	2
6501-AC	RING, BACK UP -----	2
6501-AE	PACKING, U -----	2
6501-AF	RING, O -----	2
6501-AG	SEAL, DUST -----	2
6501-AH	RING, O -----	2
6501-AI	SHIM -----	99
6501-AK	BRACKET SUB-ASSY, LIFT CYLINDER -----	2
6501-AL	BUSHING -----	4
6501-AM	SPACER -----	2
6501-AN	SHIM -----	99
6501-AQ	RING, O -----	2
6501-AT	PLUG -----	2
6501-BD	BOLT -----	2

(V) (4)


G210

FIG. 6511 CYLINDER

6511

V

V

テイルト角度表  
TABLE OF TILT RANGE

生産期間 PROD DATE	型式 MODELS	タイヤ TIRES	揚 高 LIFTING HEIGHT	備 考 DESCRIPTION	テイルト角 TILT RANGE
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000		60 - 120
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500		60 - 120
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000		60 - 60
8009-	F, FV, M, SV, V	DOUBLE	H5000		60 - 60
8009-	F, FV, M, SV, V		H2000	FRONT GLASS	60 - 100
8009	FSV, FS		H3700-H6500		60 - 60
8009-	F, FV, M, SV, V	SINGLE	H2000-H4000	AUSTRALIA	30 - 120
8009-	F, FV, M, SV, V	DOUBLE	H2000-H4500	AUSTRALIA	30 - 120
8009-	F, FV, M, SV, V	SINGLE	H4500-H5000	AUSTRALIA	30 - 60
8009-	F, FV, M, SV, V	DOUBLE	H5000	AUSTRALIA	30 - 60
8009-	F, FV, M, SV, V		H2000	FRONT GLASS AUSTRALIA	30 - 100
8009-	FV, M, SV, V		H3700-H6500	AUSTRALIA	30 - 60


6511-010

6511-010

FIG. 6511 CYLINDER

6511

V



6511 013

PART NAME CODE	PART NAME	QTY
6511-01	CYLINDER ASSY, TILT -----	2
6511-01K	CYLINDER O/H KIT, TILT -----	2
6511-20	CYLINDER SUB-ASSY, TILT -----	2
6511-20A	BUSH, PIN (FOR CYLINDER) -----	2
6511-21	ROD SUB-ASSY, TILT CYLINDER PISTON -----	2
6511-21B	NUT, CASTLE -----	2
6511-30	GUIDE SUB-ASSY, TILT CYLINDER ROD -----	2
6511-31	PIN SUB-ASSY, TILT CYLINDER -----	2
6511-32	PIN SUB-ASSY, TILT CYLINDER, RR -----	2
6511-40	PISTON, TILT CYLINDER -----	2
6511-41	COVER, TILT CYLINDER -----	2
6511-42	SLEEVE, TILT CYLINDER ROD GUIDE -----	2
6511-44	JOINT, PISTON ROD -----	2
6511-50	SEAL, GREASE -----	2
6511-AA	RING, HOLE SNAP -----	2
6511-AB	SEAL, DUST -----	2
6511-AC	RING, BACK UP -----	2
6511-AD	RING, O -----	2
6511-AE	RING, BACK UP -----	2
6511-AF	PACKING, U -----	2
6511-AG	PLATE, STOPPER -----	2
6511-AH	RING, HOLE SNAP -----	2
6511-AI	RING, O -----	2
6511-AJ	PACKING, U -----	4
6511-AK	SHIM, TILT CONTROL -----	99
6511-AL	SPACER, TILT CONTROL -----	2
6511-AM	RING, O -----	4
6511-AN	COLLAR -----	4
6511-AO	SPACER, TILT CONTROL -----	2
6511-AT	BOOT SUB-ASSY -----	2
6511-AU	BAR SUB-ASSY, TILT GAUGE -----	1
6511-AV	BRACKET SUB-ASSY, TILT GAUGE -----	1
6511-AW	PLATE, TILT CYLINDER INDICATOR -----	1


(V) (5)

G210

FIG. 6701 OIL PUMP

6701

V



PART NAME CODE	PART NAME	QTY
6701-01	PUMP ASSY, OIL -----	1
6701-01K	PUMP O/H KIT, OIL -----	1
6701-10	GEAR SET -----	1
6701-11	BUSH SET, NO.1 -----	2
6701-43	BODY -----	1
6701-44	FLANGE, MOUNTING -----	1
6701-45	COVER -----	1
6701-AA	SEAL, BUSHING -----	2
6701-AB	RING, BACKING, RH -----	2
6701-AC	RING, BACKING, LH -----	2
6701-AO	SEAL, OIL -----	1
6701-AE	RING, SNAP -----	1
6701-AF	BOLT -----	4
6701-AG	WASHER, SPRING -----	4
6701-AH	SEAL, BODY -----	2
6701-AI	BOLT -----	2


6701-018

(V) (6) G210

FIG. 6705 OIL CONTROL VALVE

6705

V




6705-056

FIG. 6705 OIL CONTROL VALVE

**6705**

V (3-WAY..UL-EE)






6705-040

FIG. 6705 OIL CONTROL VALVE

6705

V (3-WAY)









6705-057

FIG. 6705 OIL CONTROL VALVE

**6705**

V (4-WAY)




6705 058

FIG. 6705 OIL CONTROL VALVE

**6705**

V (4-WAY..UL-EE)




6705-044

FIG. 6705 OIL CONTROL VALVE

6705

V (4-WAY)



**6705**

PART NAME CODE	PART NAME	QTY
6705-01	VALVE ASSY, OIL CONTROL	1
6705-01K	VALVE O/H KIT, OIL CONTROL	1
6705-10	VALVE ASSY, PLUNGER SECTION, NO.1	1
6705-11	VALVE ASSY, PLUNGER SECTION, NO.2	1
6705-20	VALVE SET, PILOT RELIEF, NO.1	1
6705-21	VALVE SET, PILOT RELIEF, NO.2	1
6705-23	HOUSING & SPOOL SET, NO.1	1
6705-25	HOUSING & SPOOL SET, ATTACHMENT, NO.1	1
6705-26	HOUSING & SPOOL SET, ATTACHMENT, NO.2	1
6705-40	COVER, SPRING	2
6705-41	SPRING, COMPRESSION (FOR SPOOL RETURN)	2
6705-50A	RING, O, NO.1 (FOR VALVE FITTING)	2
6705-50B	RING, O, NO.2 (FOR VALVE FITTING)	1
6705-50C	RING, O, NO.3 (FOR VALVE FITTING)	2
6705-AA	BOLT	4
6705-AB	HOUSING, OUTLET	1
6705-AC	RING, O	1
6705-AD	RING, O	1
6705-AE	RING, O	1
6705-AF	BALL, STEEL	1
6705-AG	SPRING	1
6705-AH	SPRING, COMPRESSION	1
6705-AI	RING, O	1
6705-AJ	STOPPER	1
6705-AK	HOLDER, SPRING	2
6705-AL	WASHER, PLATE	2
6705-AM	RING, SHAFT SNAP	2
6705-AN	SCREW	4
6705-AO	PLUG	2
6705-AP	RING, O	4
6705-AQ	RING, BACK UP	4
6705-AR	HOLDER, SEAL	2
6705-AS	SCREW	4
6705-AT	STOPPER	1
6705-AU	STOPPER	1
6705-AV	RING, O	2
6705-AX	RING, O	3
6705-AY	RING, O	3
6705-BB	SPRING, COMPRESSION	1
6705-BB	WIRE, ORIFICE TURNING	1
6705-BC	SPRING, COMPRESSION	2
6705-BD	PLUNGER, CHECK	2
6705-BE	STOPPER	1
6705-BG	WASHER	4
6705-BH	PLUG	1
6705-BI	PLUG	1
6705-BJ	SEAT, VALVE	1
6705-BL	SEAT, INSERT	2
6705-BM	VALVE SUB-ASSY, RELIEF	1
6705-BN	RING, O	1
6705-BO	SPRING	1
6705-BP	STOPPER	1
6705-BQ	RING, O	2

(V ) ( 7)

G210

PART NAME CODE	PART NAME	QTY
6705-BR	RING, O	2
6705-BT	FITTING	1
6705-BU	FITTING	1
6705-BV	FITTING	2
6705-BW	FITTING	1
6705-BX	FITTING	2
6705-BY	FITTING	1
6705-BZ	PLUG	2
6705-CA	FITTING	1
6705-CC	PLUG	2
6705-CH	NUT	4
6705-DW	PLUG	1
6705-EX	BRACKET SUB-ASSY, TILT	1
6705-EY	BRACKET SUB-ASSY, LIFT	1
6705-EZ	RING, O	1
6705-FA	INSULATOR	4
6705-FN	FITTING	2

(V ) ( 8)


G210

FIG. 6709 OIL CONTROL VALVE LINK


**6709**

V (3-WAY)

V



6709-016




6709-017

FIG. 6709 OIL CONTROL VALVE LINK

6709

V (4-WAY)



PART NAME CODE	PART NAME	QTY
6709-20	LEVER SUB-ASSY, CONTROL VALVE, NO.1	1
6709-21	LEVER SUB-ASSY, CONTROL VALVE, NO.2	1
6709-22	LEVER SUB-ASSY, CONTROL VALVE, NO.3	1
6709-23	LEVER SUB-ASSY, CONTROL VALVE, NO.4	1
6709-30	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1	2
6709-30A	PIN (FOR CONTROL VALVE LEVER ROD)	4
6709-31	ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2	1
6709-40	KNOB, OIL CONTROL VALVE LEVER	2
6709-41	PIN, OIL CONTROL VALVE LEVER	1
6709-41A	BUSH (FOR LEVER PIN)	4
6709-48	BOOT, CONTROL VALVE LINK, NO.1	2
6709-49	BOOT, CONTROL VALVE LINK, NO.2	2
6709-50	TURNBUCKLE	1
6709-AA	BRACKET SUB-ASSY	1
6709-AC	NUT	1
6709-AF	SPACER	1
6709-AG	BOLT, STUD	2

6709-016


(V) (9)

G210

FIG. 6801 BODY PIPING

6801

V



PART NAME CODE	PART NAME	QTY
6801-10	FILTER ASSY, SUCTION -----	1
6801-11	FILTER ASSY, RETURN -----	1
6801-12	VALVE ASSY, FLOW REGULATOR -----	1
6801-15A	PLUG (FOR OIL TANK DRAIN) -----	1
6801-15B	GASKET (FOR OIL TANK DRAIN PLUG) -----	1
6801-20	PIPE SUB-ASSY (PUMP INLET) -----	1
6801-20A	RING, O (FOR OIL PUMP INLET) -----	1
6801-21A	RING, O (FOR OIL PUMP OUTLET) -----	1
6801-22	PIPE SUB-ASSY (PUMP TO VALVE) -----	1
6801-23	PIPE SUB-ASSY (TILT CYLINDER FRONT) -----	1
6801-24	PIPE SUB-ASSY (TILT CYLINDER REAR) -----	1
6801-26	OUTLET SUB-ASSY, OIL TANK -----	1
6801-26A	PACKING, OIL TANK COVER -----	1
6801-27	CAP SUB-ASSY, OIL TANK -----	1
6801-30	HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) --	1
6801-32	HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) --	1
6801-33	HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT) --	2
6801-34	HOSE, HIGH PRESSURE, NO.1 (TILT FRONT) -----	1
6801-35	HOSE, HIGH PRESSURE, NO.1 (TILT REAR) -----	1
6801-36	HOSE, HIGH PRESSURE, NO.2 (TILT FRONT) -----	1
6801-37	HOSE, HIGH PRESSURE, NO.2 (TILT REAR) -----	1
6801-45	FITTING (FOR TILT CYLINDER) -----	2
6801-46	FITTING (FOR LIFT CYLINDER) -----	2
6801-50	HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK) -----	2
6801-50A	CLAMP (FOR LIFT TO TANK NO.1 HOSE) -----	3
6801-51	HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK) -----	1
6801-51A	CLAMP (FOR VALVE TO TANK NO.1 HOSE) -----	2
6801-52	HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK) -----	1
6801-52A	CLAMP (FOR VALVE TO TANK NO.2 HOSE) -----	2
6801-55	HOSE, LOW PRESSURE (TANK TO PUMP) -----	1
6801-55A	CLAMP (FOR TANK TO PUMP HOSE) -----	2
6801-56	HOSE, LOW PRESSURE (STEERING TO VALVE) -----	1
6801-59	HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK) -----	1
6801-59A	CLAMP (FOR LIFT TO TANK NO.2 HOSE) -----	3 - 4
6801-AA	BAND, LIFT CYLINDER OVERFLOW HOSE -----	4
6801-AB	CLAMP -----	1
6801-AC	RING, O -----	4
6801-AD	BOLT -----	8
6801-AF	FLANGE, SPLIT -----	1
6801-AG	CLAMP -----	1
6801-AH	BRACKET SUB-ASSY, TILT HOSE -----	1
6801-AI	RING, O -----	2
6801-AP	PIPE -----	1
6801-AS	FITTING -----	1
6801-AT	FITTING -----	1
6801-AV	RING, O -----	2
6801-AW	ELBOW SUB-ASSY, 3-WAY -----	1
6801-AX	CAP, OIL TANK OVERFLOW PIPE -----	1
6801-AZ	SPRING, COMPRESSION -----	1
6801-BA	PLUG -----	1
6801-BB	SPRING, COMPRESSION -----	1
6801-BC	BALL, STEEL -----	1
6801-BO	RING, O -----	1

**6801**

PART NAME CODE	PART NAME	QTY
6801-BS	BOLT -----	1
6801-BT	WASHER -----	1
6801-BV	FLANGE -----	2

(V ) ( 11) G210