



MT 5519
Telescopic Handler

Parts Manual
Catalog 50960027 Rev. B



Manitou Americas, Inc.

One Gehl Way
P. O. Box 179
West Bend, WI 53095-0179 U.S.A

MT 5519
Telescopic Handler

Parts Manual
Catalog 50960027 Rev. B

For parts orders contact your Manitou Americas Dealer or call:
Factory Parts Department (262) 334-6653.
Websites: www.us.manitou.com / www.manitouamericasdealer.com

Introduction

MT 5519 Telescopic Handler

When ordering service parts, specify the correct part number, full description, quantity required, the machine model number, and serial number. For your safety, and continued proper operation, use only genuine Manitou service parts.


“Right” and “left” are determined from a position sitting on the seat inside the cab and facing forward.

Manitou North America, Inc. reserves the right to make changes or improvements in the design or construction of any part of the machine without incurring the obligation to install such changes on previously delivered machines.



NOTE: This parts manual identifies both standard and optional features for this model. Depending on the features of your machine, some of the items identified in the parts lists may, or may not, be included with your machine.

SERIAL NUMBER



Model	Engine	Unit Number	
MT 5519	Y	D	00 0000
		Year (D=12, E=13, etc.)	Month

Serial number breaks are indicated as follows:

- (SN 999 and before) - indicates serial numbers up to and including 999.
- (SN 1000 - 2000) - indicates serial numbers from 1000 to 2000.
- (SN 999 and up) - indicates serial numbers including 999 and after.


SCHEMATICS AND MANUALS

Hydraulic and electrical schematics can be found in the Operator's and Service Manuals for this machine. Engine parts are shown in the Engine Parts Manual PN 917304. The Operator's Manual for this machine is PN 50960028.

ABBREVIATIONS IN THIS MANUAL


ASSD	Assembled
ASSY	Assembly
AR	As Required
CB	Carriage Bolt
CFPD	Contact Factory Parts Department
CP	Cotter Pin
CS	Cap Screw (Bolt)
CYL	Cylinder
DIA	Diameter
EU	European Union (standards)
FHCS	Flat Head Cap Screw
GR	Grade
HB	Hex Bolt
HLN	Hex Lock Nut
HN	Hex Nut
HP	High Pressure
HYD	Hydraulic
IN	Inch(es)
INS	Insert
LN	Lock Nut
LW	Lock Washer
M	Meter or Meters
MM/mm	Millimeter
NA	Not Applicable
NPT	National Pipe Thread
NSS	Not Sold Separately
ORB	O-ring Boss
REF	Reference
SHCS	Socket Head Cap Screw
SLTD	Slotted
SN	Serial Number or Slotted Nut
SQ	Square
W/	With
W/O	Without

ICONS




Tilt
Cylinder
parts are
on page 247.

Identifies where
additional pages
for component
parts, seals, and
kits can be found.




Interior Cab
Options are
on page 18.

Identifies where
additional
information can
be found.



Refer to page
126 for the
warning
decal.

Alerts and directs
user to investigate
more information.



NOTE:
Hydraulic
bulkhead
fitting.

Identifies missing,
hidden parts, or
adds informational
comments.



Warning or
Important
Information



Important
information to
follow



Seal Kit




Repair Kit




	PAGE
INTRODUCTION	Inside Front Cover
Table of Contents	.1
Filters	.4
 CAB	
Cab	.6
Instrument Panel and Switches	.8
Fuses, Relays, and Wire Harnesses	.10
Front and Rear Lights (Option)	.12
Front and Rear Window - Enclosed Cab (Option)	.14
Wiper (Option) - Front and Top Window	.16
Window (Option) - Top and Left	.18
One-Piece Door (Option)	.20
Split-Door (Option)	.22
Heater (Option)	.24
A/C-Heater (A/C - Option)	.25
A/C Circuit (A/C - Option)	.26
A/C Compressor and Mount (A/C - Option)	.28
Heater Circuit (A/C - Option)	.30
A/C Condenser (A/C - Option)	.32
Steering Column and Shifter Group	.34
Seat	.36
Pedals - Brake and Accelerator	.38
Cab Mounts	.40
Window Guards (Option)	.41
 CHASSIS	
Engine Compartment - Hoods	.42
Engine Compartment - Front, Rear, and Backwall	.44
Engine Compartment - Belly Pan	.46
Front Cover, Mirror, and Washer Bottle	.47
Covers - Rear and Back-up Alarm	.48
Battery	.50
Fuel Tank	.52
 ENGINE	
Fuel Circuit	.54
Oil Filter, Air Heater, and Dipstick	.56
Fan, Alternator, and Starter	.57
Electrical—Switches, Sensors, and Relays	.58
Flex Plate and Engine Mounts	.59
Radiator	.60
Air Intake and Filter	.62
Exhaust and Heat Shields	.64

AXLE, FRONT	PAGE
Mounts, Wheels, Fenders and Driveshaft	66
Front and Rear Axle - Steer Cylinders and Tie Rods	68
Front Axle - Central Housing	69
Front Axle - Differential	70
Front Axle - Reduction Hub	72
Front Axle - Brake	74
 AXLE, REAR	
Rear Axle - Central Housing	76
Rear Axle - Differential	77
Rear Axle - Reduction Hub	78
 BOOM	
Outer Boom - Front	80
Outer Boom - Rear	82
Inner Boom - Front	84
Inner Boom - Rear	85
Dynattach® Mount Assembly	86
 BOOM HYDRAULICS	
Lift Cylinder Group	88
Extend Cylinder Group	90
Tilt / Slave Cylinder Group	92
Auxiliary Hydraulics Group	94
 HYDRAULICS	
Hydraulic Tank Group	96
Hydraulic Circuit - Cooler and Filter	98
Hydraulic Circuit - Hydraulic Pump	100
Hydraulic Drive Pump, Hydrostatic Motor, and Inching Valve	102
Control and Isolation Valves	104
Steer Motor and Steer Select Valve	106
Brake Valves	108
Hydraulic Drive Pump Test Ports	109
 HYDRAULIC COMPONENTS	
Hydraulic Drive Pump	110
Hydraulic Pump	111
Hydraulic Drive Motor—(Hydrostatic Motor)	112
Slave Cylinder Isolation Valve	113
Control Valve	114
Steer Motor	116
Steer Select Valve	117


	PAGE
Parking Brake Valve	.118
Brake Valve	.119
 HYDRAULIC CYLINDERS	
Lift Cylinder	.120
Slave Cylinder	.122
Tilt Cylinder	.124
Boom Extend Cylinder	.126
Rotate Carriage Cylinder	.128
Fork-Shift Cylinder	.129
 ATTACHMENTS	
Carriage Forks	.130
Standard Carriage	.132
Rotating Carriage (Series I)	.134
Rotating Carriage (Series II)	.136
Fork-Shift Carriage	.138
Truss Boom	.140
Bucket	.141
 DECALS	
Decals	.142
 INDEX	
Numerical Index List	.146
Subject Index	.152
 REFERENCE	
O-Ring Tables	.158
Adapter (Fittings) Torque Guide	.159
Metric Bolt Torque Guide	.160
SAE Bolt Torque Guide	.161




Engine Oil




Fuel/Water Separator




Fuel




Hydraulic Oil




Air - Primary




Air - Secondary



Alternator/Fan



A/C Compressor
(when equipped with
air conditioning)




Cab Air
(when equipped with heater or A/C)

MT 5519 Telescopic Handler

Filters and Belts

All




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200116	FILTER, ENGINE OIL	1	07	51200167	FILTER, AIR (<i>primary</i>)	1
02	51200020	FILTER, FUEL/WATER SEP.	1	08	51200172	FILTER, AIR (<i>secondary</i>)	1
03	809827	BOWL, FUEL/WATER SEP.	1	09	51200613	BELT, FAN/ALTERNATOR	1
04	50380272	DRAIN, FUEL/WATER SEP.	1	10	51200614	BELT, A/C COMPRESSOR	1
05	51200019	FILTER, FUEL (<i>on firewall</i>)	1	11	51200000	FILTER, CAB AIR (<i>option</i>)	1
06	51200177	FILTER, HYDRAULIC OIL	1				



Cab
Cab

50960027/B1112

Instrument Panel and Switches



Instrument Panel and Switches

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200014	PANEL, DASH 1 <i>(does not include switches or display)</i>		11	808923	SWITCH, WIPER/WASHER 1 <i>(front window)</i>	
02	51200537	DISPLAY, CAN & INSTRUMENTS . 1		12	808923	SWITCH, WIPER/WASHER 1 <i>(top window)</i>	
03	808922	SWITCH, STEER MODE. 1		13	808438	SWITCH, PUSH-BUTTON <i>(horn)</i> . . 1	
04	51200625	SWITCH, TWO SPEED. 1		14	808438	SWITCH, PUSH-BUTTON <i>(starter)</i> . 1	
05	809694	HOLE PLUG, SWITCH. AR		15	808073	SWITCH, IGNITION w/KEY. 1	
06	808921	SWITCH, PARK BRAKE 1			808074	KEY ONLY (2 keys) 1	
07	808926	SWITCH, LIGHTS 1					
08	808927	SWITCH, TURN SIGNALS 1					
09	808924	SWITCH, HAZARD LIGHTS 1					
10	813379	SWITCH, STROBE 1					





NOTE: Switches shown in the Illustration or listed on this page are for reference purposes only—your machine may be configured differently than shown here.

Cab

Fuses, Relays, and Wire Harnesses

MT 5519 Telescopic Handler




Ref.	Part No.	Description	Function/Comments
01	808394	MINI FUSE, 15 AMP	(BATTERY) IGNITION SWITCH, HORN
02	51200538	MINI FUSE, 20 AMP	(IGNITION) TRANSMISSION, PARK BRAKE, PWP, STEER SELECT, INJ.
03	808394	MINI FUSE, 15 AMP	(IGNITION) LIGHTS, INCHING
04	809190	MINI FUSE, 25 AMP	(IGNITION) HEATER, CAN DISPLAY
05	809190	MINI FUSE, 25 AMP	(IGNITION) TOP WIPER
06	809190	MINI FUSE, 25 AMP	(IGNITION) FRONT WIPER
07	808395	MICRO RELAY, 20 AMP	LIGHTS
08	808395	MICRO RELAY, 20 AMP	TOP WIPER
09	808395	MICRO RELAY, 20 AMP	FRONT WIPER
10	808892	CHANGE-OVER RELAY	IGNITION
11	808892	CHANGE-OVER RELAY	PARK BRAKE
12	51200626	MAXI FUSE, 80 AMP	ALTERNATOR
13	51200626	MAXI FUSE, 80 AMP	AIR HEATER
14	808500	MAXI FUSE, 60 AMP	CHASSIS POWER
15	808500	MAXI FUSE, 60 AMP	STARTER
16	51200627	MAXI FUSE, 40 AMP	A/C EVAPORATOR <i>(when equipped with A/C option)</i>
17	51200628	MAXI FUSE, 30 AMP	A/C CONDENSER <i>(when equipped with A/C option)</i>
18	51200629	MINI FUSE, 10 AMP	(IN-LINE) ECU POWER
19	51200630	SOLENOID, 12 VDC	STARTER
	51200631	CAP	<i>(not shown—not included with solenoid)</i>
	51200632	HN 5/16 C2ZY	<i>(not shown—not included with solenoid)</i>
20	51200633	RELAY, 20 AMP	ECU
21	51200633	RELAY, 20 AMP	FUEL RACK
22	51200630	SOLENOID, 12 VDC	AIR HEATER
	51200631	CAP	<i>(not shown—not included with solenoid)</i>
	51200632	HN 5/16 C2ZY	<i>(not shown—not included with solenoid)</i>
23	813465	CAN/TERMINATE RECEPTACLE	
24	51200634	MODULE, SHIFTER	
25	808735	TURN SIGNAL FLASHER	<i>(when equipped with light package option)</i>
26	51200635	DIODE PACK	DRIVE TRAIN CONTROLS <i>(located under the front chassis cover, part of frame wire harness)</i>
27	808396	DIODE PACK	BRAKE LIGHT/TURN SIGNAL CIRCUIT <i>(Light Package Option)</i> <i>(located the under dash near the switches—part of light package harness)</i>
28	808577	DIODE PACK	BRAKE LIGHT/TURN SIGNAL CIRCUIT <i>(Light Package Option)</i> <i>(located the under dash near the switches—part of light package harness)</i>
29	808576	CLEAR COVER, DIODE PACK	
30	51200636	FUSE BLOCK W/COVER	<i>(does not include fuses)</i>
--	51200637	WIRE HARNESS, FRAME	
--	51200638	WIRE HARNESS, CANOPY	
--	51200639	WIRE HARNESS, ENGINE	
--	51200539	WIRE HARNESS, LIGHT PACKAGE (option)	- Refer to next page for more information.




NOTE: For additional wire harnesses, refer to their relative location in this parts manual (e.g., Boom section for boom lights).




NOTE: Fuses, relays, and other items shown on these pages are for reference purposes only; your machine might be configured differently and might not include the options shown on this—or other pages—in this parts manual.



Turn Signal Flasher
(Located behind the front dash and switch panel.)






Diode Packs



Diode Pack Cover

Front and Rear Lights (Option)




MT 5519 Telescopic Handler

Cab

Front and Rear Lights (Option)

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808889	HEAD LIGHT	2	09 ^a	813849	3/8" LOCK WASHER	4
02	808595	1/2" FLAT WASHER	2	10 ^a	51200644	M8-1.25X100 C8.8 BOLT	4
03	808471	3/8"-16 WHIZ LOCK NUT	2				
04	808341	GROMMET, 5/8"	AR				
05 ^a	51200640	TAIL LIGHT, LH	1	--	51200539	HARNESS, LIGHT PACKAGE	1
06 ^a	51200641	TAIL LIGHT, RH	1			(Dash to rear lights: includes two diode packs—refer to previous page for diode information.)	
07 ^a	51200642	TAIL LIGHT, MOUNT	2				
08 ^a	51200643	TAIL LIGHT, RETAINER	2	--	808901	WIRE HARNESS, HEAD LIGHT . . .	2
				--	808344	GROMMET 13/16"	1

-- ITEMS NOT SHOWN --





MT 5519 Telescopic Handler

Cab



Front and Rear Window - Enclosed Cab (Option)

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808490	5/16"-18 ACORN NUT	AR	15 ^a	51200008	MOUNT, REAR-WINDOW STAY . . .	1
02	808420	5/16"-18X1" BUTTON HD BOLT . . .	4	16	808481	PIN, ROLL - 3/16"x1/2"	3
03	808421	5/16"-18X3/4" BUTTON HD BOLT .	8	17	808488	HOLD OPEN, L-STYLE.	2
04	808491	BUSHING, STEEL	4	18	808487	HOLD OPEN, L-STYLE.	1
05	808483	GROMMET, 1/2"IDX1/4"GROOVE .	6	19 ^a	809325	MOUNT, WIND. HOLD OPEN (RH). 1	
06	808422	5/16" FLAT WASHER (BLACK). . . .	4	20 ^a	808255	MOUNT, WIND. HOLD OPEN (LH). 1	
07	808495	HINGE, FRONT WINDOW	2				
08	808485	HINGE, PLASTIC (<i>rear window</i>) . .	1				
09	809320	GLASS, REAR.	1	a	<i>Use the parts listed below to fasten mount to frame:</i>		
10	809321	BULB SEAL, REAR GLASS	1	--	809180	1/4" FLAT WASHER	AR
11	51200645	BULB SEAL, FRONT GLASS	1	--	809181	1/4" LOCK WASHER.	AR
12	809317	GLASS, FRONT	1	--	808600	1/4"-20X5/8" BUTTON HD BOLT. AR	
14	808486	PIN, QUICK DETACH.	AR				


Wiper (Option) - Front and Top Window



**Late-Style
Wiper**





**Early-Style
Wiper**



Wiper (Option) - Front and Top Window

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	50380577	WIPER BLADE, 16"	1	21	808570	TOWER SEAL, TRICO WIPER	1
02		WIPER ARM, PANTOGRAPH	1	22	808561	WIPER MOTOR, TRICO	1
	50380576	Front Window		23	808320	ADAPTER/WET ARM	1
	50380682	Top Window		24	808089	BOTTLE, DUAL -PUMP WASHER	1
03	50380579	PLATE, PANTO ARM MOUNT	1	-- ITEMS NOT SHOWN --			
04	50380583	PIN, PANTO ARM MOUNT	1	(Windshield Wiper Harness)			
05	808568	M5, ACORN NUT	1	--	809182	HARNESS, TOP WIPER	1
06	808564	M8, ACORN NUT	1	--	809183	HARNESS, FRONT WIPER	1
07	808320	WIPER BLADE, 16"	1	(Windshield Washer System)			
08	808569	ADAPTER, PIN LOCK	1	--	808321	HARNESS, WASHER BOTTLE	1
09		WIPER ARM, PANTOGRAPH	1	--	808347	TUBING, WASHER (15-1/2')	1
	NSS	Front window—see note a		a The early style front wiper arm is no longer available; it will be necessary to order part number 50380585 Wiper Arm Kit, which contains items 1-4.			
	NSS	Top window—see note b					
10	808574	PANTO ADAPTER PLATE	1	b The early style front wiper arm is no longer available; it will be necessary to order part number 50380683 Wiper Arm Kit, which contains items 1-4.			
11	51200646	WASHER, #10 WEATHERTITE	1				
12	808572	SCREW, M5 16mm	1				
13	808562	COVER WIPER MOTOR	1				
14	808573	BOLT / 10-24x1.25 HEX GR5	1				
15	808479	WASHER/BLK NYLON	1				
16	51200646	WASHER, #10 WEATHERTITE	2				
17	808840	NUT/ACORN #10-24 BLK	1				
18	808571	RAIN SHIELD	1				
19	808563	M18, NUT	1				
20	808565	GASKET, PANTO ADAPTER	1				





MT 5519 Telescopic Handler

Cab


Window (Option) - Top and Left

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01 ^a	809324	GLASS, TOP	1	08	809323	GLASS, LEFT REAR.	1
02	808490	5/16"-18 ACORN NUT	AR	09	809322	BULB SEAL, LEFT GLASS.	1
03	808252	WINDOW MOUNT.	2	10	808253	WINDOW MOUNT.	2
04	808483	GROMMET, 1/2"IDX1/4"GROOVE .	4				
05	808491	BUSHING, STEEL	4	a	Use P/N 808934 Adhesive Kit to attach top glass to cab.		
06	808422	5/16" FLAT WASHER (BLACK). . . .	4				
07	808420	5/16"-18X1" BUTTON HD BOLT . . .	4				

Cab

One-Piece Door (Option)

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler


Cab

One-Piece Door (Option)


Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	51200647	CAB DOOR, ONE-PIECE 1 (includes items 1-10, 12, and 29-31)		21	808310	LATCH RELEASE, INTERIOR 1	
01	808303	WELDMENT, CAB DOOR FRAME . 1			809185	1/4-20X1-1/4" FLAT HD SCREW . . 2	
02	808246	BULB SEAL, DOOR FRAME 1			808600	1/4-20X5/8" BUTTON HD BOLT . . 1	
03	808238	GLASS, UPPER DOOR 1			809186	M6-1X12 8.8 BOLT 2	
04	808239	GLASS, LOWER DOOR 1			808484	FLAT WASHER (BLACK) 1	
05	808419	5/16"-18X1-3/4" BUTTON HD BOLT 5			808661	1/4"-20 NYLON INSERT NUT 2	
06	808422	5/16" FLAT WASHER (BLACK) . . . 5			808891	1/2" HOLE PLUG 2	
07	808491	BUSHING, STEEL 8		22	808086	STRIKER 1	
08	808483	GROMMET, 1/2"IDX1/4"GROOVE . 8			809187	7/16" LOCK WASHER 1	
09	808490	5/16"-18 ACORN NUT (BLACK) . . AR			809188	7/16" FLAT WASHER 1	
10	809184	5/16"-18X2" BUTTON HD BOLT . . 3			51200013	7/16"-14 NUT 1	
11	51200012	3/8"x5" BOLT 3		23	51200648	DOOR RESTRAINT STRAP 2	
12	808137	WELDMENT, DOOR HINGE 3		26	809184	5/16"X2" BUTTON HD BOLT 4	
14	808663	3/8" NYLON INSERT NUT 3		27	51200649	TUBE, STAND-OFF 6	
20	808327	HANDLE, EXT. DOOR LOCKING . . 1		28	51200650	HINGE, BOLT-ON 3	
	808097	KEY ONLY 1		29	813610	5/16" FLAT WASHER AR	
				30	808555	5/16" WHIZ NUT AR	
				31	809494	5/16"X3" STUD AR	
				32	813433	COVER (included with #21) 1	

Split-Door (Option)

MT 5519 Telescopic Handler




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200652	DOOR, TOP. 1 (includes items 3-7, 9-14, 16-17, 39-41)	1	23	808555	FLANGE LOCK NUT 5/16" 2	2
02	51200653	DOOR, BOTTOM. 1 (includes items 13, 16-27, 31-38)	1	24	51200648	DOOR RETAINER. 1	1
03	808490	5/16"-18 ACORN NUT (BLACK). . AR		25	813610	FW 5/16" AWZY. 1	1
04	813389	1/4" ACORN NUT (BLACK). 1	1	26	808327	HANDLE, EXTERIOR LOCKING .. 1	1
05	51200654	FRAME, UPPER DOOR. 1	1		808097	KEY ONLY. 1	1
06	51200655	BULB SEAL, UPPER DOOR. 1	1	27	809186	SHCS M6-1x12 C8.8 ZY DIN912 .. 2	2
07	51200656	GLASS, UPPER DOOR. 1	1	28	808086	STRIKER. 1	1
08	51200012	CS 3/8" x 5" C5ZY. 2	2	29	809188	FW 7/16" AWZY. 1	1
09	808483	GROMMET, .50X0.25X0.81. AR		30	51200013	HN 7/16" FLEXLOCK GR5. 1	1
	808491	BUSHING, STEEL (not shown) .. AR		31	809185	FHSCS 1/4"x1-1/4" CZY. 2	2
10	51200664	CS 1/4" x 2-1/2" C5ZY. 1	1	32	51200651	HLN INST 1/4 CZY. 2	2
11	808094	GLASS MOUNT. 1	1	33	813433	COVER (included with #34) 1	1
12	808489	DOOR HOLDER (set). 1	1	34	808310	LATCH RELEASE, INTERIOR 1 (includes cover: item #33)	1
13	808137	DOOR HINGE. 3	3	35	813549	BHSCS 3/8"x1-1/4" CZY. 1	1
14	808419	BHSC 5/16" x 1-3/4" C RIE. 615	615	36	51200660	HN M12-1.00 F8ZY DIN934. 1	1
813656		HLN 3/8" CZY. 3	3	37	51200661	FN 1/2 ANZY. 2	2
16	51200657	CS 3/8" x 7" C5ZY. 1	1	38	813430	STRIKER. 1	1
17	808422	FW 5/16 RIE. AR		39	51200662	FHSCS M6-1x25 C8.8 DIN7901 .. 2	2
18	808420	BHSCS 5/16" x 1-3/4" C RIE. 1	1	40	51200663	HN M6-1.00 C8 DIN934. 1	1
19	808239	GLASS, LOWER DOOR. 1	1	41	813417	LATCH, ROTARY (RIGHT). 1	1
20	51200658	BULB SEAL, LOWER DOOR. 1	1	42	809494	5/16"x3" STUD. AR	
21	51200659	FRAME, LOWER DOOR. 1	1	43	809184	5/16"x2" BUTTON HD BOLT. 5	5
22	809494	STUD 5/16" x 3" GR5. 1	1	44	51200649	TUBE, STAND-OFF. 6	6
				45	51200650	HINGE, BOLT-ON. 3	3




Cab Heater (Option)

MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808318	HEATER ASSEMBLY 1 (Includes items 5, 6, 8, 9 and 10)		07	808600	1/4"-20X5/8" BUTTON HD BOLT . 10	
	809351	BLOWER MOTOR (only) 1		08	808496	VALVE, WATER 1	
02	51200030	GRILL, DEFROSTER 2		09	808412	LOUVER 1	
03	808324	INSTRUMENT PANEL 1		10	51200031	RESISTOR BLOCK 1	
04	808325	DECAL, HEAT CONTROL 1		-- ITEMS NOT SHOWN --			
05	808352	CONTROL, TEMPERATURE 1		--	NSS	5/8" HEATER HOSE (10') 1	
	809165	KNOB ONLY AR		--	51200665	HOSE CLAMP, SAE #10 AR	
06	808411	SWITCH, VARIABLE SPEED 1					




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200032	HVAC ASSEMBLY	1	09	51200038	RECTIFIER PACK	1
		(Includes items 2-9)		10	51200039	LOUVER	1
	51200033	FAN (only - included with item 1) . .	1	11	51200040	DECAL, A/C HEATER CONTROL . .	1
02	51200034	FILTER COVER	1	12	808411	SWITCH, VARIABLE SPEED	1
03	51200000	FILTER, CAB AIR	1	13	51200041	KNOB	2
04	51200035	EVAPORATOR/HEATER COIL	1	14	51200042	MODULE, A/C CONTROL	1
05	808412	LOUVER	1	15	51200030	GRILL, VENT	2
06	51200045	EXPANSION VALVE	1	16	808600	1/4"-20X5/8" BUTTON HD BOLT .	10
07	51200036	COLD CONTROL SWITCH	1	17	51200043	PANEL, HVAC CONTROL	1
08	51200037	RELAY	1	18	51200044	HOSE, OVERFLOW	1

Cab

A/C Circuit - (A/C Option)

MT 5519 Telescopic Handler




Cab

A/C Circuit - (A/C Option)

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	813516	CONDENSER	1	15	51200059	CS 3/8" x 5/8" C5ZY	1
02	51200666	HOSE, #6 CONDENSER/DRYER. .	1	16	813713	CDS 3/8" x 1" C5ZY	1
03	51200047	O-RING.	AR	17	51200671	A/C COMPRESSOR	1
04	51200667	HOSE, #8 COND./COMPRESSOR. 1					
05	51200049	O-RING.	AR		-- ITEMS NOT SHOWN --		
06	51200035	EVAPORATOR/HEATER COIL	1	--	51200672	WIRE HARNESS, A/C COND.	1
07	51200051	O-RING.	AR			(Connects to A/C condenser, routes through A/C hose guard—back of cab, connects to A/C evaporator wire harness,A/C compressor, and the fuse box.)	
08	51200056	A/C DRYER (does not include #9) .	1				
09	51200057	SWITCH, BINARY	1				
10	51200668	HOSE, #6 DRYER/EVAPORATOR. 1					
11	51200669	HOSE, #10 COMP./EVAPORATOR. 1					
12	808471	HN FL SLOC 3/8" CZY	2				
13	51200670	BRACKET, DRYER MOUNT	1	--	51200673	WIRE HARNESS, A/C EVAP.	1
14	51200058	CLAMP, DRYER	1			(Connects to A/C evaporator—in cab, the A/C-heater solenoid, the A/C condenser wire harness, and the fuse box.)	

A/C Compressor and Mount (A/C Option)

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Cab



A/C Compressor and Mount (A/C Option)

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200671	A/C COMPRESSOR	1	13	51200683	LN INST M8-1.25 C8 ZY DIN985 . .	2
		(includes items 2-6)		14	51200684	PLATE, CLAMP 3/8"-16.	2
02	51200674	CLUTCH, A/C COMPRESSOR	1	15	51200685	CS 3/8" x 2-1/2" F5ZY SP	1
03	NSS	COMPRESSOR BODY	1	16	51200686	WASHER SPHERICAL 3/8"	1
04	51200675	O-RING SET, MANIFOLD	1	17	51200687	YOKE, CLEVIS 3/8"-24 UNF.	1
05	51200676	A/C COMPRESSOR MANIFOLD . .	1	18	51200688	PLATE, TORSION WRENCH	1
06	51200677	HW HMS M10 x 20	1	19	51200689	CLAMP, TORSION MOUNT	2
07	51200678	PULLEY, A/C CRANK	1	20	51200690	MOUNT, SUSPENSION	1
08	51200679	FW M10 ZY DIN125	3	21	813591	FW 3/8" AWZY	4
09	51200680	CS M10-1.5x30 C10.9 ZY DIN931 .	3	22	814029	CS 3/8" x 1-3/4" C5ZY	4
10	51200614	BELT, A/C COMPRESSOR	1	23	51200691	PLATE, COMPRESSOR BASE	1
11	51200681	A/C COMPRESSOR MOUNT	1	24	51200692	CS M8-1.25x130 C8.8 ZY DIN931 .	2
12	51200682	HN LF SLOC 3/8" CZ	2	25	51200012	CS 3/8" x 5" C5ZY	2

Cab

Heater Circuit - (A/C - Option)

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Cab


Heater Circuit - (A/C - Option)

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200063	CLAMP, HOSE #10	6	07	51200696	ST-L HB10-MBSPT06	1
02	51200693	HEATER HOSE, 5/8" x 63"	1	08	51200697	ST FP06-MBSPT06	1
03	51200694	HEATER HOSE, 5/8" X 100"	1	09	808844	SHUT-OFF, MANUAL	1
04	51200066	ST 1/2MPT x 5/8" HOSE	2	10	51200698	HEATER HOSE, 5/8" x 32"	1
05 ^a	51200067	HEATER-A/C SOLENOID	1				
06	51200695	VALVE BRACKET	1	a	<i>Solenoid valve is attaches to the A/C evaporator wire harness (P/N 51200673).</i>		

Cab

A/C Condenser - (A/C Option)

MT 5519 Telescopic Handler



Cab





A/C Condenser - (A/C Option)

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200069	CONDENSER ASSEMBLY	1	12	51200075	FW 5/16" ZY SEALING	4
		<i>(includes items 1-10)</i>		13	51200076	LN LG FL SERR 5/16 CZ	4
02	51200070	COVER, CONDENSER HOUSING .	1	14	50380634	COVER, A/C HOSES	1
03	51200071	BHSCS 1/4" x 1/2"	17	15	813367	SELF-TAP SCREW 1/4" x 1/2"	3
04	808545	FLANGE LN 1/4"-20	2				
05	813517	SELF-TAP SCREW 3/16" x 5/8" . . .	6				
06	51200072	MOUNT, CONDENSER COIL	1	--	51200672	WIRE HARNESS, A/C COND. . . .	1
07	813516	CONDENSER COIL	1			<i>(Connects to A/C condenser, routes through A/C hose guard (back of cab), connects to A/C evaporator wire harness, A/C compressor, and the fuse box.)</i>	
08	51200073	CONDENSER HOUSING	1				
09	51200074	RELAY	1				
10	813514	CONDENSER FAN ASSEMBLY . . .	2				
11	808421	BHSCS 5/16" x 3/4"	4				


Cab

Steering Column and Shifter Group


MT 5519 Telescopic Handler



Transmission Shift Module
(Located next to fuse box—
under the load charts.)




Steer Motor
also shown on
page 116.



Cab


Steering Column and Shifter Group

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808435	CAP, STEERING WHEEL	1	08	813549	3/8"-16X1-1/4" BUTTON HD BOLT .	4
02	808436	NUT, STEERING WHEEL	1	09	51200702	MOTOR, STEER	1
03	808432	STEERING WHEEL	1	10	808099	MODULE, F-N-R SHIFTER	1
04	808586	M5X.8X35mm HX SKTHD BOLT . .	2				
05	808262	COLUMN, STEERING	1				
06	51200701	F-N-R SHIFTER (<i>includes #7</i>) . . .	1			-- ITEMS NOT SHOWN --	
	809130	BOOT	1	--	51200703	WIRE HARNESS, FNR SHIFTER . .	1
07	813560	CLAMP, SHIFTER(<i>included w/ #6</i>) .	1				



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	813608	SEAT, OPERATOR'S (wo/armrest) . . . 1		12 ^{cd}	808835	BELLOWS, SUSPENSION SEAT . . . 1	
02	51200704	SEAT BELT (includes tethers) 1				(includes seat belt / tether bracket)	
03	813609	7/16"-20X1" BOLT AR		13	808343	PEDESTAL / BOLT-ON SEAT 1	
04	808598	7/16" FLAT WASHER AR					
05	808625	7/16"-20 NYLON INSERT NUT . . AR		26 ^c	813615	BELLOWS, SEAT (boot only) 1	
06	808899	BRACKET, TETHER 2		27 ^c	813616	ADJUSTMENT KNOB 1	
07 ^a	51200705	MOUNT, SEAT BELT 1		28 ^c	813617	SHOCK, SUSP. SEAT 1	
08	813610	5/16" FLAT WASHER AR					
09	808555	5/6"-18 NYLON INSERT NUT . . . AR					
10 ^b	809195	SEAT RISER 1					
11	813598	5/16"-18X1" BOLT AR					


- a Use this bracket for standard and suspension seats. Discard the bracket that is included with the suspension.
- b Not used with suspension seat
- c Used for suspension seat option only
- d Discard tether bracket and use item #7 on all applications.



Cab

Pedals - Brake and Accelerator


MT 5519 Telescopic Handler



Pedals - Brake and Accelerator

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200706	BRAKE/THROTTLE FRAME	1	29	51200718	SHAFT COLLAR	1
02	813849	3/8" LOCK WASHER	AR	30	808484	1/4"x1"OD WASHER	1
03	813574	3/8"x1" BOLT	AR	31	809742	1/4"x1/2" BOLT	1
04	808714	VALVE, MASTER CYL. BRAKE . . .	1	32	51200719	BRAKE PEDAL WELDMENT	1
05	51200707	BRAKE LINKAGE WELDMENT . . .	1	33	808674	RETURN SPRING	1
06	51200708	1/2" NUT	1	34	51200720	5/16"-18 UNF JAM NUT	2
07	808675	YOKE, CLEVIS 1/2"	1	35	51200721	7/16" JAM NUT	1
08	813629	BALL JOINT LINKAGE 5/16"	2	36	808630	1/8"x1" COTTER PIN	1
09	51202289	5/16"x1" SOCKET HEAD BOLT . . .	2	37	813697	3/8"x1-1/2" BOLT	3
10	51200710	INCHING VALVE	1	38	813591	3/8" FLAT WASHER	3
11	813630	ROD, LINKAGE	1	39	808663	3/8" NYLON INSERT NUT	3
12	51200711	NYLON SPACER	AR	40	51200722	SPRING, THROTTLE RETURN . . .	1
13	813658	BALL JOINT 10-32 x 1/4"	2	41	813659	HN MS #10-32 FZY	1
14	51200712	CUSHION BLOCK, BRAKE	AR	42	51200723	ROD, THREADED 10-32UNF	1
15	808729	PLATE	2	43	51200651	HLN INST 1/4" CZY	1
17	814382	5/16"x2-1/4" BOLT	AR	44	51200090	CS 1/4x2 C5ZY	1
18	813602	PAD, PEDAL	AR	45	51200724	SENSOR, THROTTLE	1
19	51200713	1/4"x1-1/2" SH BOLT	1		809180	FW 1/4" (not shown)	2
20	809180	1/4" FLAT WASHER	1		813570	CS 1/4x3/4" (not shown)	2
21	808663	3/8" NYLON INSERT NUT	AR	46	51200726	BRACKET, THROTTLE	1
22	51200714	THROTTLE PEDAL WELD.	1	47	51200727	RING, SPACER	1
23	51200715	THROTTLE PEDAL ARM	1	48	51200728	HLN INST 1/4 FZY	1
24	813713	3/8"x1-1/4" BOLT	1	49a	NSS	LEVER, INCHING VALVE	1
25	51200716	THROTTLE LEVER WELD.	1	50a	51200729	SHCS M5-0.8x20 C8.8ZY	1
26	808466	1/2"x27/64 CLEVIS PIN	1	51	809181	1/4" FW	1
27	813651	BALL STUD	2				
28	51200717	BRAKE LEVER WELDMENT	1				


a Included with item #10.




Cab

Cab Mounts


MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200437	1"-8X2-1/4" GR8 BOLT	2	03	809198	1"-8 CLASS C LOCK NUT	4
02	51200095	1" SAE FLAT WASHER.....	8	04	809313	1"-8X3" GR8 BOLT	4



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200730	FRONT WINDOW GUARD	1	04	813591	3/8" FLAT WASHER	AR
02	51200731	TOP WINDOW GUARD	1	05	813849	3/8" WHIZ NUT	AR
03	813574	3/8"X1" BOLT	AR				
						-- ITEMS NOT SHOWN --	
				--	813591	3/8" FLAT WASHER	AR



MT 5519 Telescopic Handler

Chassis


Engine Compartment - Hoods

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	50380327	HOOD	1	17	808545	1/4" FLANGE LOCK NUT	4
02	51200732	HINGE	2	18	51200737	HN FL CLOC 1/4" CZY	4
03	51200733	HINGE BACKER	2	19	813369	#10-24 NUT	4
04	51200734	3/8"X1/2" BOLT	8	20	814202	LW #10 RZY	4
05	813657	FW 3/8 ANZY	AR	21	51200738	LATCH, T-HANDLE	1
06	50380217	BULB SEAL 3.3"	1	22	809106	KEY ONLY (CH751) (not shown) . PR	
07	50380218	BULB SEAL 20.4"	1	23	813656	HLN INST 3/8 C5ZY	4
08	50380219	BULB SEAL 25.8"	1	24	51200739	STRIKER	2
09	50380135	BRACKET	1	25	50380058	STRIKER MOUNT	2
10	51200735	BRACKET, GAS SPRING	1	26	51200740	CB 3/8" x 3/4" C5ZY	4
11	813677	CS 3/8"X3/4"	2	27	51200741	FW 13/32 ZY	2
12	813651	BALL STUD (3/8" thread)	2	28	51200742	#10-24X1" SCREW	4
13	51200736	LN INST 5/16"	AR	29	51200743	BRACKET, HOOD LATCH	1
14	50380359	GAS SPRING	2	30	51200744	SEAL, EDGE 3/8" x 1-1/4"	1
15	809291	DECAL, HOT SURFACE	1	31	51200745	BULB SEAL 48"	1
16	50380360	EXHAUST SHIELD	1				

Chassis

MT 5519 Telescopic Handler

Engine Compartment - Front, Rear, and Backwall



MT 5519 Telescopic Handler

Chassis


Engine Compartment - Front, Rear, and Backwall

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200746	BACKWALL, ENGINE COMPART. .	1	10	813656	HLN INST 3/8 CZY	1
02	51200747	LW INTERNAL 3/8 AZY	1	11	51200740	CB 3/8" x 1-1/4" C5ZY	1
		<i>(used to insure proper grounding)</i>		12	808498	CS 5/16" x 3/4" C5ZY	1
03	813657	FW 3/8 ANZY	AR	13	51200750	FW 5/16 HT ZY	1
04	813574	CS 3/8" x 1" C5ZY	AR	14	51200751	COOLER MOUNT/BULKHEAD . . .	1
05	808607	SHCS 3/8"x 3/4"	18	15	51200565	CS FL LOCK 3/8"x 1" C5ZY	2
06	51200748	WHEEL WELL GUARD, FRONT . .	1	16	808555	FLN 5/16".	1
07	814679	WING NUT 3/8 ACZY	1	17	51200752	BRACE, RADIATOR/COOLER . . .	1
		<i>(used to secure air cleaner assy.)</i>		18	51200753	WHEEL WELL BRACKET, REAR . .	1
08	813677	CS 3/8" x 3/4" C5ZY	AR	19	51200754	WHEEL WELL GUARD, REAR . . .	1
09	51200749	WHEEL WELL BRACKET, FRONT .	1				

Chassis

Engine Compartment - Belly Pan


MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	813574	CS 3/8"X1"	AR	07	51200757	BELLY PAN, ENGINE	1
02	813591	FW 3/8"	AR	08	51200758	BELLY PAN, HYDRO. DRIVE	1
03	51200755	ACCESS, COMPRESSOR	1	09	808629	CS 1/2"-13 x 1-1/2"	3
04	51200756	OIL DRAIN COVER	1	10	813337	FW 1/2"	3
05	813570	1/4"X3/4" BOLT	2				
06	808545	1/4" FLANGE LOCK NUT	2				

Chassis

Front Cover, Mirror, and Washer Bottle




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200759	FRONT COVER, FRAME	1	12 ^a	808089	WASHER BOTTLE, w/PUMPS	1
02	51200760	LATCH COVER	1	13 ^a	813610	5/16" FLAT WASHER	AR
03	808437	HORN, 12VDC	1	14 ^a	808498	5/16"X3/4" BOLT	AR
	51200734	3/8"X1/2" BOLT	1	15 ^a	51200762	MOUNT, WASHER BOTTLE	1
	813591	3/8" FLAT WASHER	1	16	51200763	TRIM/EDGE 10"	1
04	808665	1/2" NYLON INSERT NUT	2	17	51200764	TRIM/EDGE 2"	4
05	808595	1/2" FLAT WASHER	AR				
06	808612	1/2"X1-3/4" BOLT	2			-- ITEMS NOT SHOWN --	
07	51200761	MIRROR MOUNT, RH	1	--	808321	HARNESS, WASHER BOTTLE . . .	1
08	809288	5/8" NUT	1	--	808347	TUBING, WASHER (15-1/2 FT.) . . .	1
09	813360	BAR, MIRROR END	1				
10	809880	MIRROR	1				
11	808555	5/16" WHIZ NUT	AR	a		Used on units with a cab enclosure option.	

Chassis

Covers - Rear and Back-up Alarm

MT 5519 Telescopic Handler




MT 5519 Telescopic Handler


Chassis


Covers - Rear and Back-up Alarm

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200765	FUEL ACCESS LATCH	1	09	808897	BACK-UP ALARM	1
02	51200766	FUEL TANK ACCESS COVER	1		51200773	5/16"X5/8" BOLT	AR
03	51200767	HINGE	2		813610	5/16" FLAT WASHER	AR
	51200768	6 MM NYLON INSERT NUT	8			<i>(Backup alarm is located on chassis above the rear axle—left side.)</i>	
	51200769	6 MM FLAT WASHER	8	10	51200774	TRIM/EDGE 0.13"X12"	1
04	51200770	FUEL TANK COVER	1			-- HIDDEN FROM VIEW --	
05	51200771	3/8"X1/2" BOLT	2			(Attaches to frame to protect hydraulic hoses)	
06	813849	3/8" LOCK WASHER	2	11	51200775	TRIM 3/4"X18.5"	1
07	813591	3/8" FLAT WASHER	2	12	51200776	TRIM 3/4"X14.5"	1
08	51200772	TOW PIN	1				



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	NSS	BATTERY, GR 31 BCI (950 CCA) . . .	1	13	50380205	BULB SEAL	1
02	808471	HN FL SLOC 3/8 CZY	2	14	50380207	BULB SEAL	2
03	813677	CS 3/8 x 3/4 C5ZY	6	15	51200780	BATTERY BOX/AIR INTAKE	1
04	50380053	BATTERY COVER.	1	16	51200781	BATTERY CABLE, NEG. 39"	1
05	51200777	NUT, 3/8-16 WING ZINC PH.	1	17	51200782	BATTERY CABLE, POS. 52"	1
06	50380181	STRAP, BATTERY HOLD-DOWN . . .	1	18	808707	STRAP, GRND 4GA 14"	1
07	50380206	BULB SEAL	1	19	51200679	FW M10 ZY DIN125	2
08	813657	FW 3/8 ANZY.	4	20	51200783	CS M10-1.5x16 C8.8 ZY	2
09	51200778	TEST PORT COUPLER	1	21	51200740	CB 3/8X1-1/4 C5ZY.	1
10	51200779	ADAP., ST BLKHD MJ06-MJ06. . .	1	22	51200747	LW INTERNAL 3/8" AZY	1
11	50380179	GROMMET, CABLE SEAL	1	23	813657	FW 3/8 ANZY.	1
12	50380197	HEAT SHIELD (self-adhesive). . . .	1	24	813656	HLN INST 3/8 CZY	1





MT 5519 Telescopic Handler


Chassis

Fuel Tank

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200784	FUEL TANK WELDMENT	1	06	814517	ADAP., -8ORM -6JICM 90°	1
02	808439	GASKET, FUEL SENDER	1	07	51200114	FUEL CAP	1
03 ^a	51200785	SENDER, FUEL LEVEL	1	08	51200734	3/8"x1/2" BOLT	4
04	51200101	#10-32X1/2" RD SCREW	AR	09	813849	3/8" LOCK WASHER	4
05	51200786	HOSE, FUEL 5/16"x86"	1	10	813678	1/2"-14 PLUG, MAGNETIC BI	1
		<i>(Fuel supply and return; refer to next page for location of fuel lines on the engine.)</i>		11	51200788	ADAP., -8ORM -6JICM LNG 90°	1
				a	<i>Includes gasket item #2</i>		

Engine Fuel Circuit

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler


Engine Fuel Circuit

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200789	HOSE, FUEL 5/16"x16"	1	15 ^a	51200786	HOSE, FUEL 5/16"x86" (supply) . . .	1
02	51200789	HOSE, FUEL 5/16"x16"	1	16	51200793	FUEL PUMP, ELECTRIC.	1
03	51200790	HOSE, FUEL 5/16"x60"	1	17	51200794	HOSE, FUEL 5/16"x5-1/2"	1
04	51200567	CLAMP, HOSE #05 M	AR	18 ^b	51200795	FUEL/WATER SEP. ASY.	1
05	813677	CS 3/8"x3/4" C5ZY	2	19	813598	CS 5/16"x1" C5ZY	2
06	813591	FW 3/8" AWZY	2	20	50380271	FITTING, T190	2
07	808555	FLN 5/16"-18	4	21	51200796	CS M10-1.5x35 C8.8 ZY D931 . . .	2
08	814344	CS 5/16"x1-1/4" C5ZY	2	22	51200797	CS M10 ZY DIN127	2
09	50380136	FUEL FILTER MOUNT BRACKET . 1 (bolts to firewall—holds item #11)		23	51200798	BRACKET, FILTER MOUNT	1
10 ^a	51200786	HOSE, FUEL 5/16"x86" (return) . . .	1	a	Refer to previous page for location of fuel supply and return hoses on the fuel tank.		
11		FUEL FILTER ASSEMBLY		b.	Fuel/Water Separator Assembly includes the fuel mount, 90° fittings (item 20), fuel/water separator filter (P/N 51200020) , fuel/water separator bowl (P/N 809827), and water drain (P/N 50380272).		
	51200791	FUEL FILTER MOUNT (head)	1				
	51200019	FUEL FILTER (spin-on element) . . .	1				
12	51200792	CLAMP, VINYL 5/8" DOUBLE	1				
13	813570	CS 1/4"x3/4" C5ZY	2				
14	808545	FLN 1/4"-20 ZP	2				

Engine

MT 5519 Telescopic Handler


Oil Filter, Air Heater, and Dipstick



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200799	DIPSTICK ASSEMBLY	1	16 ^b	50220157	AIR HEATER	1
02	51200800	CS M8-1.25x16 C8.8 ZY DIN931. AR			51200808	GASKET (<i>not shown—non-asb.</i>) . . .	1
03	51200801	LW M8 ZY DIN127.	2	17	51200809	CS FL M8-1.25x35 C8.8 ZY	4
04	51200802	BRACKET, DIPSTICK	1	18 ^a	51200810	CLAMP, VINYL 3/4"x7/16"	1
05	808555	FLN 5/16"-18	4	19	51200798	BRACKET, FILTER MOUNT	1
06	51200803	CLAMP, VINYL 1/2"x7/16"	1	20	51200116	FILTER, ENGINE OIL	1
07	814206	CS 5/16"x5/8" C5ZY	1	21	51200812	FILTER MOUNT (<i>head</i>)	1
08 ^a	51200804	CLAMP, VINYL 5/8"x7/16"	2	22	813598	CS 5/16"x1" C5ZY	3
09	51200805	FW M8 ZY DIN125.	AR	23	51200796	CS M10-1.5x35 C8.8.	2
10	51200806	OIL FILTER ADAPTER	1	24	51200797	LW M10 ZY DIN127.	2
11	813708	ST MJ08-MORB08	2				
12	814291	ST MJ10-MORB10	2				
13	50380247	HOSE, REMOTE OIL -10	1				
14	50380248	HOSE, REMOTE OIL -8	1				
15 ^b	51200807	AIR HEATER MANIFOLD 90°	1				
	51200808	GASKET (<i>not shown—non-asb.</i>) . . .	1				

a Used to retain engine wire harness.

b Two non-asbestos gasket (51200808) are used: one between item 15 (air heater manifold) and the engine block, and the other between item 15 (air heater manifold) and item 16 (air heater).




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200613	V-BELT 42"	1	15	51200821	LN INST M10-1.5 C8 ZY	1
02	51200813	CS M8-1.25x45 C8.8 DIN931	1	16	51200822	SPACER, ALTERNATOR.	1
03	51200805	FW M8 ZY DIN125	7	17	51200823	CS M10-1.5x130 C8.8 ZY	1
04	51200814	ADJUSTER, ALTERNATOR	1	18	51200824	CS M8-1.25x25 C8.8 ZY	1
05	51200815	SPACER, ALTERNATOR.	1	19	51200825	SPACER, FAN	1
06	51200816	ALTERNATOR, 95AMP	1	20	51200809	CS FL M8-1.25x35 C8.8	8
07	51200817	FW M5 ZY DIN125	1	21	50380056	FAN, SUCKER 19" 3H.	1
08	51200818	HN M5-0.8 C8 ZY DIN934.	1				
09	51200819	BLOCK HEATER, ENGINE (option).1					
13	51200820	STARTER, 12V 3KW.	1				
14	51200552	HN M8-1.25 C8 ZY DIN934.	1				

NOTE: Refer to engine parts manual 917304 for more information.



Engine

MT 5519 Telescopic Handler

Electrical—Switches, Sensors, and Relays



NOTE: Refer to engine parts manual 917304 for more information regarding engine components.




Electrical Mount
(Fastens to firewall—inside engine compartment)

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200826	SENDER, OIL PRESSURE	1	13	51200829	CLAMP, HOSE 1.25x0.41	1
02	51200827	SENDER, WATER TEMP.	1	14	808498	CS 5/16" x 3/4" C5ZY	1
03	51200828	CS M6-1x20 C8.8	1	15	51200830	ELECTRICAL MOUNT	1
04	51200651	HLN INST 1/4 CZY	7	16 ^a	51200831	ECU	1
05	51200630	SOLENOID (starter)	1	17	813610	FW 5/16 AWZY	3
06	51200632	HN 5/16" C2ZY	4	18	51200636	FUSE BOX W/COVER (no fuses) . .	1
07	51200631	COVER, ELECTRICAL	2	19	51200832	TRIM	1
08	51200630	SOLENOID (air heater)	1				
09	51200633	RELAY, 20 AMP (ECU)	1				
10	51200633	RELAY, 20 AMP (fuel rack)	1				
11	51200736	HLN INST 5/16" CZY	4				
12	51200750	FW 5/16 HT ZY	2				


^a Requires software programming from Yanmar dealer.

NOTE: Refer to engine parts manual 917304 for more information.



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200833	MOUNT, ENGINE (REAR)	2	14	51200797	M10 LOCK WASHER	6
02	51200797	M10 LOCK WASHER	8	15	51200838	MOUNT, ENGINE (FRONT)	1
03	51200834	M10-1.5X25 C8.8 BOLT	8	16	51200796	M10-1.5X35 C8.8 BOLT	2
04	51200797	M10 LOCK WASHER	8	17	51200797	M10 LOCK WASHER	2
05	51200834	M10-1.5X25 C8.8 BOLT	8	18	51200839	ADAPTER PLATE	1
06	51200797	M10 LOCK WASHER	4	19	51200840	FLEX PLATE	1
07	51200834	M10-1.5X25 C8.8 BOLT	4	20	51200798	BRACKET, FILTER MOUNT	1
08	51200555	HLN INST 5/8" CZY	4	21	51200841	ISOLATOR (REAR)	2
09	51200835	WASHER, SNUBBING	8				
11	51200836	ISOLATOR (FRONT)	2				
12	51200837	5/8"X4-1/2" CARRIAGE BOLT	4				
13	51200796	M10-1.5X35 C8.8 BOLT	6				

NOTE: Refer to engine parts manual 917304 for more information regarding the flywheel housing and additional engine components.



MT 5519 Telescopic Handler


Engine Radiator

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200789	HOSE, 5/16" x 15-1/2"	1	10	813531	CS 5/16" x 1/2" C5ZY	2
02	51200842	BOTTLE, OVERFLOW	1	11	51200847	HOSE, RADIATOR (<i>lower</i>)	1
03	51200843	CLAMP, HOSE #44	1	12	51200848	FAN SHROUD	1
04	51200568	CLAMP, HOSE #24	4	13	50220154	DRAIN, 1/4" NPT 90°.	1
05	51200844	FW 11/32 ZY	4	14	51200849	RADIATOR/COOLER ASSY.	1
06	808498	CS 5/16" x 3/4" C5ZY	6	15	50380215	BULB-SEAL 0.72 x 24-3/4"	2
07	51200845	HOSE, RADIATOR (<i>upper</i>)	1	16	50380216	BULB-SEAL 0.72 x 13-7/16"	1
08	51200846	FAN GUARD	1	17	50220155	RADIATOR CAP, 14 LBS.	1
09	813610	FW 5/16"	4	18	808555	FLANGE LOCK NUT 5/16"-18	2

Engine

Air Intake and Filter

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler


Engine Air Intake and Filter

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200850	AIR CLEANER ASSEMBLY.....1 (Includes items 2 and 10-13; does not include item #3.)	1	10	51200167	PRIMARY AIR FILTER	1
02	NSS	HOUSING	1	11	51200172	SECONDARY AIR FILTER	1
03	51200851	CLAMP, AIR CLEANER MOUNT. . .	1	12	NSS	END CAP.....	1
04	814679	WING NUT 3/8-16 ACZY.....	1		51200856	LATCH	3
05	51200852	BRACKET, AIR CLEANER	1	13	51200857	EVACUATOR VALVE.....	1
06	51200853	CB SN 5/16" x 1" C5ZY.....	2	14	50380168	HOSE, AIR INTAKE.....	1
07	51200854	HN LG FL 5/16 C2ZY	2	15	809207	CLAMP, HOSE (#44).....	1
08	51200855	CLAMP, HOSE #52	4	16	51200858	HOSE, AIR INTAKE.....	1
09	50380046	INTAKE SEAL	1	17	51200859	AIR RESTRICTOR INDICATOR ...	1
				18	51200860	COUPLING, AIR RESTRICTOR ...	1


Engine

Exhaust and Heat Shields

MT 5519 Telescopic Handler




**Late-Style
Starter Air Plenum**



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200861	BLANKET, EXHAUST MANIFOLD .	1	07	51200809	CS FL M8-1.25x35 C8.8 ZY	4
02	51200862	GASKET, EXHAUST	1	08	51200679	FW M10 ZY DIN125	AR
03	51200552	HN M8-1.25 C8 ZY DIN934	4	09	51200783	CS M10-1.5x16 C8.8 ZY	1
04	51200801	LW M8 ZY DIN127	4	10 ^a	50380542	STARTER AIR PLENUM	1
05	51200863	CS M8-1.25x20 C8.8 ZY DIN931 . .	4		51202290	CS M8-1.25x45 C8.8 (<i>not shown</i>) . .	1
06	50380090	MUFFLER (<i>standard</i>)	AR		51200813	CS M8-1.25x75 C8.8 (<i>not shown</i>) . .	1
	50380091	CATALYTIC MUFFLER (<i>option</i>) . .	AR				


a Verify which air plenum is installed on the machine before ordering. The late-style (current) air plenum is shown as item #10 on the facing page. The early-style air plenum is shown in the illustration below. If the machine is equipped with the early-style air plenum it will be necessary to order the Starter Air Plenum Kit P/N 50380526. This kit includes the late-style air plenum, a new fuel filter mount bracket, hardware, and instructions.



Axles

MT 5519 Telescopic Handler

Mounts, Wheels, Fenders and Driveshaft



MT 5519 Telescopic Handler

Axles

Mounts, Wheels, Fenders and Driveshaft

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200864	AXLE, REAR (221/83)	1	17	51200871	U-JOINT STRAP KIT	1
02	51200865	AXLE, FRONT (603/211/69)	1			(includes 4 straps and 8 bolts)	
03 ^a	51200866	FENDER MOUNT	AR	18	51200872	DRIVESHAFT	1
04 ^a	51200867	FENDER, REAR	1			(includes item 19)	
05	51200868	FENDER, FRONT	1	19	51200873	U-JOINT	2
06	808607	3/8"X3/4" BUTTON HD BOLT.	AR			(included with item 18)	
07	813591	3/8" FLAT WASHER	AR				
08	808471	3/8" FLANGE LOCK NUT.	AR				
09	51200869	1"X8" CARRIAGE BOLT GR8	4				
10	51200870	AXLE MOUNT PLATE	2				
11	51200095	1" FLAT WASHER	AR				
12	809198	1" LOCK NUT / CLASS C.	AR				
13	808418	M20-2.5X130 BOLT	4				
14	808599	M20-2.5 LOCK NUT	4				
15	50380341	16.5x9.75 WHEEL (rimonly)	1				
		(purchase tires locally)					
15c	50380344	SOLID TIRE/WHEEL SET	4				
	50380432	POLY-FILL FOAM WHEEL SET	4				
16	808876	M22-1.5 WHEEL NUT	AR				

--ITEMS NOT SHOWN--


(Grease zerks for steering case - pivot)

20	51200874	ZERK, 1/8"NPTM 45°.	AR
21 ^b	51200875	ZERK, 1/8"NPTF 45°	AR
22 ^b	51200876	NIPPLE/CLOSE PIPE 1/8"	AR

a Rear fender and rear mount are optional.

b Used instead of 51200874 zerk where fender mounts are being used.


c When ordering, specify right or left side.



Axles

MT 5519 Telescopic Handler

Front and Rear Axle - Steer Cylinders and Tie Rods




Ref. No.	Part No.	Description	Qty. Req.
01	51200877	STEER CYLINDER	1
02	51200878	RING	2
03	51200879	ARTICULATED TIE ROD	2
04	51200880	CYLINDER BOLT	4

Ref. No.	Part No.	Description	Qty. Req.
05 ^a		SEAL KIT	1
	51200881	(Cylinder Stamped 211.24.623.04)	
	51200882	(Cylinder Stamped 211.24.623.12)	

a Before ordering, locate the part number stamped on the steer cylinder.

-- ITEMS NOT SHOWN --

--	808076	ADAP, M18ORM -8JICM STR.	4
		(Connects steering hydraulic hoses to the steer cylinder.)	




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	809050	SNAP RING.....	1	03	51200269	MAGNETIC PLUG.....	1
02	51200267	PLUG.....	1	04	51200883	HOUSING	1

Axles

Front Axle - Differential

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Axles


Front Axle - Differential

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200884	GEAR.....	1	23		DIFFERENTIAL SIDE GEAR	1
02	51200885	SNAP RING.....	1		51200916	<i>Note a and b</i>	
03	51200886	BEARING.....	1		51200917	<i>Note c and d</i>	
04	51200887	SNAP RING.....	1	24	51200918	BOLT	12
05	808516	VENT.....	1	25	51200919	FRICTION WASHER.....	1
06	51200888	SPACER	1	26	51200920	SNAP RING.....	1
07	51200889	BEARING.....	2	27	51200921	SHIM	1
08	51200890	RING NUT.....	1		51200922	SHIM	1
09	51200891	RING	1		51200923	SHIM	1
	51200892	RING	1	28	51200924	BEARING.....	1
10	51200893	SHIM.....	AR	29	51200925	SNAP RING.....	1
	51200894	SHIM.....	AR	30	51200926	BEARING.....	1
	51200895	SHIM.....	AR	31	51200927	CLUTCH DISC	7
11	51200896	BEVEL GEAR SET	1	32	51200928	INTERMEDIATE CLUTCH DISC...	8
12	51200897	SHIM.....	AR	33	51200929	SEAL	1
	51200898	SHIM.....	AR	34	51200930	BALL BEARING.....	1
	51200899	SHIM.....	AR	35	51200931	GEAR.....	1
	51200900	SHIM.....	AR	36	51200932	SNAP RING.....	1
13	51200901	BEARING.....	1	37	51200933	BEARING.....	1
14		DIFFERENTIAL CARRIER	1	38	51200934	SEAL	1
	51200902	<i>Note a</i>		39	51200269	PLUG.....	1
	51200903	<i>Note b and c</i>		40	51200935	SPRING WASHER	8
15	51200904	FRICTION WASHER.....	1	41	51200936	BOLT	8
16		DIFFERENTIAL SIDE GEAR	1	42	51200270	MAGNETIC PLUG.....	1
	51200905	<i>Note a and b</i>		43	51200937	DOWEL	1
	51200906	<i>Note c</i>		44	51200938	PLUG.....	1
17		DIFFERENTIAL PINION	4	45	51200939	FLANGE	1
	51200907	<i>Note a and b</i>		46	51200940	O-RING	1
	51200908	<i>Note c</i>		47	51200880	BOLT	6
18	51200909	FRICTION WASHER.....	4	48	51200941	COVER	1
19		PIN.....	2	49	51200942	CLUTCH DISC	1
	51200910	<i>Note a</i>					
	50220067	<i>Note b and c</i>					
20	51200912	DOWEL	3	a	<i>Axle SN K.ITA.528691 and up</i>		
21		PIN.....	1	b	<i>Axle SN I.ITA.517518 - SN K.ITA.528690</i>		
	51200913	<i>Note a</i>		c	<i>Axle SN I.ITA.517517 and before</i>		
	50220067	<i>Note b and c</i>		d	<i>Includes items #16 (51200905) and #17 (51200907).</i>		
22	51200915	SHAFT RETAINER	1				

Axles

Front Axle - Reduction Hub

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Axles

Front Axle - Reduction Hub

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200943	O-RING	2	34	51200966	BEARING.....	6
02	808516	VENT.....	1	36	818169	PLUG.....	2
03	51200944	BOLT.....	16	37	51200339	BOLT.....	4
04	51200945	AXLE CASE.....	1	38	51200967	PLANET GEAR CARRIER	2
05 ^e	51200946	THRUST BUSHING.....	2	39	51200968	FRICTION WASHER.....	2
06	51200947	SEAL.....	4	40	51200969	NUT.....	16
07	51200948	UNIVERSAL JOINT.....	2	41	51200970	STUD.....	16
08	51200949	PIVOT PIN.....	2	42	51200971	BEARING.....	4
09	809046	GREASE FITTING.....	4	43	51200972	WHEEL HUB.....	2
10	808543	PLUG.....	4	45	808313	STUD.....	8
11	808525	BOLT.....	20	46	808177	WASHER.....	8
12	51200950	SHIM.....	AR	47	808180	NUT.....	8
	51200951	SHIM.....	AR	48 ^b	51200973	PLANET GEAR CARRIER	2
	51200952	SHIM.....	AR	50	51200974	AXLE CASE.....	1
13	51200953	SEAL.....	2	51	51200975	BOLT.....	16
14	51200954	BUSHING	2	52 ^c	51200340	STEERING ADJUST BOLT.....	4
15	51200955	BUSHING/BEARING.....	2	56 ^d	51200976	RING GEAR SUPPORT	2
16	51200956	PIVOT PIN.....	2				
19 ^a	51200957	STEERING CASE (includes #5) ...	1				
20 ^a	51200958	STEERING CASE (includes #5) ...	1				
21	51200269	PLUG.....	1				
22	51200338	SEAL.....	2				
23	51200959	WHEEL STUD.....	16				
25	51200580	O-RING	2				
26	809445	SNAP RING.....	2				
27	809439	RING GEAR	2				
28	51200960	RING GEAR SUPPORT	2				
29	51200961	LOCKING PLATE	2				
30	51200962	RING	2				
31	51200963	SNAP RING.....	2				
32	51200964	SNAP RING.....	6				
33	51200965	PLANET GEAR.....	6				

a Refer to the upper illustration on the facing page before ordering parts; be sure to note the direction of forward travel when determining correct parts. Includes one of item #5 thrust bushing, already pressed into the steering case.

b Includes items 32, 33, 34, 38 and 39.

c Includes adjusting bolt and jam nut.


d Includes items 26 - 28.

e Included with items 19 and 20.

Axles

Front Axle - Brakes

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Axles


Front Axle - Brakes

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200977	BRAKE DISC.....	6	17	51200997	SNAP RING.....	2
02	51200978	INTERMEDIATE BRAKE DISC....	6	18	51200998	SPRING.....	1
03		BUSHING	1	19	51200999	BACK-UP RING.....	4
	51200979	<i>Note a and b</i>		20	51201000	O-RING	4
	51200976	<i>Note c</i>		21	51200912	DOWEL	1
04 ^d	51200981	DETENTE BALL.....	AR	22	51202001	PISTON.....	1
05		SPACER	1	23	51202002	O-RING	3
	51200982	<i>Note a and b</i>		24	51202003	PIN.....	3
	51200983	<i>Note c</i>		25	51202004	O-RING	1
06	51200984	SHIM	2	26	51202005	O-RING	1
	51200985	SHIM	2	27	51202006	PISTON.....	1
	51200986	SHIM	2	28	51202007	SPRING.....	2
	51200987	SHIM	2	29	51202008	RING NUT	1
	51200988	SHIM	2	30	51202009	BOLT	2
07		INTERMEDIATE BRAKE DISC....	1	31	51202010	O-RING	2
	51200989	<i>Note a</i>		32	51202011	SPACER	2
	51200990	<i>Note b</i>		33	51202012	BOLT	1
	51200991	<i>Note c</i>		34	51200349	SEAL WASHER.....	2
08	51200992	ROLL PIN	2	35	51200347	BOLT	2
09	51200993	PISTON	1				
10	51200994	O-RING	1	a	<i>Axle SN K.ITA.528691 and up</i>		
11	51200995	PLUG.....	1	b	<i>Axle SN K.ITA.521434 - SN K.ITA.528690</i>		
12	51200348	BLEED SCREW	2	c	<i>Axle SN K.ITA.521433 and before</i>		
13	808543	PLUG.....	2	d	<i>Axle SN K.ITA.521434 and up uses 2 detente balls; axle SN K.ITA.521433 and before uses 1 detente ball.</i>		
14	51200996	BACK-UP RING.....	1				
15	51200350	O-RING	1				
16	51200351	BACK-UP RING.....	1				


Axles

Rear Axle - Central Housing


MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	809050	SNAP RING.....	1	05	808552	REDUCTION BUSHING	4
02	51200267	PLUG	1	06	51202014	THRUST BUSHING.....	2
03	51200270	MAGNETIC PLUG.....	1	07	809046	GREASE FITTING.....	2
04	51202013	SUPPORT	2	08	51202015	SUPPORT (complete as shown)...	2



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202016	NUT	1	15		DIFFERENTIAL SIDE GEAR	2
02	51202017	FLANGE	1		51202021	<i>Note a and b</i>	
03	51200889	BEARING.....	2		51202022	<i>Note c</i>	
04	809053	SEAL	1	16		DIFFERENTIAL PINION	4
05	51200888	SPACER	1		51200907	<i>Note a and b</i>	
06	51200893	SHIM	1		51200908	<i>Note c</i>	
	51200894	SHIM	1	17	51200909	FRICTION WASHER.....	4
	51200895	SHIM	1	18		PIN.....	2
07	51200891	RING	1		51200910	<i>Note a</i>	
	51200892	RING	1		50220067	<i>Note b and c</i>	
08	51202018	SPACER	1	19	51200912	DOWEL	3
09	51202019	BEVEL GEAR	1	20		PIN.....	1
10	51200918	BOLT	12		51200913	<i>Note a</i>	
11	51200897	SHIM	2		50220067	<i>Note b and c</i>	
	51200898	SHIM	2	21	51200915	SHAFT RETAINER	1
	51200899	SHIM	2	22	51202023	COVER PLATE	1
	51200900	SHIM	2	25	51202024	O-RING	1
12	51200901	BEARING.....	2				
13	51202020	DIFFERENTIAL CARRIER	1				
14	51200904	FRICTION WASHER.....	2				
				a	Axle S/N K.ITA.529750 and up		
				b	Axle S/N I.ITA.516674 - S/N K.ITA.529749		
				c	Axle S/N I.ITA.516673 and before		



MT 5519 Telescopic Handler

Axles


Rear Axle - Reduction Hub

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200943	O-RING	2	34	51200966	BEARING.	6
02	808516	VENT	1	36	818169	PLUG	2
03	51200944	BOLT	16	37	51200339	BOLT	4
04	51200945	AXLE CASE	1	38	51200967	PLANET GEAR CARRIER	2
05 ^e	51200946	THRUST BUSHING	2	39	51200968	FRICTION WASHER	2
06	51200947	SEAL	4	40	51200969	NUT	16
07	51200948	UNIVERSAL JOINT	2	41	51200970	STUD	16
08	51200949	PIVOT PIN	2	42	51200971	BEARING.	4
09	809046	GREASE FITTING	4	43	51200972	WHEEL HUB	2
10	808543	PLUG	4	44	51202025	AXLE CASE	1
11	808525	BOLT	20	45	808313	STUD	8
12	51200950	SHIM	2	46	808177	WASHER	8
	51200951	SHIM	2	47	808180	NUT	8
	51200952	SHIM	2	48 ^b	51200973	PLANET GEAR CARRIER	2
13	51200953	SEAL	2	52 ^c	51200340	STEERING ADJUST BOLT	4
14	51200954	BUSHING	2	56 ^d	51200976	RING GEAR SUPPORT	2
15	51200955	BUSHING/BEARING	2				
16	51200956	PIVOT PIN	2				
19 ^a	51200957	STEERING CASE (includes #5) ...	1	a	<i>Refer to the upper illustration on the facing page before ordering parts; be sure to note the direction of forward travel when determining correct parts. Includes one of item #5 thrust bushing, already pressed into the steering case.</i>		
20 ^a	51200958	STEERING CASE (includes #5) ...	1				
21	51200269	PLUG	1	b	<i>Includes items 32, 33, 34, 38 and 39.</i>		
22	51200338	SEAL	2				
23	51200959	WHEEL STUD	16	c	<i>Includes adjusting bolt and jam nut.</i>		
25	51200580	O-RING	2				
26	809445	SNAP RING	2	d	<i>Includes items 26 - 28.</i>		
27	809439	RING GEAR	2				
28	51200960	RING GEAR SUPPORT	2	e	<i>Included with items 19 and 20.</i>		
29	51200961	LOCKING PLATE	2				
30	51200962	RING	2				
31	51200963	SNAP RING	2				
32	51200964	SNAP RING	6				
33	51200965	PLANET GEAR	6				

Boom

Outer Boom - Front

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Boom Outer Boom - Front

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202035	OUTER BOOM WELDMENT	1	17 ^a	808471	3/8" WHIZ LOCK NUT	AR
02	808797	INCLINOMETER-ANGLE IND.	1	18 ^a	51202029	LIGHT BRACKET	1
	809492	#8X5/8" RND HD MACH.SCREW.	2	19 ^a	808595	1/2" FLAT WASHER	AR
03	809486	5/16"-18X1" BTNHD BOLT	2	20 ^a	51202030	3/8"X1-3/8" BOLT	AR
04	813610	5/16" FLAT WASHER	2	21 ^a	808890	WORK LIGHT	2
05	808800	PLATE, BOOM ANGLE IND.	1	22	51202031	BOOM REST PAD.	1
06	808902	5/16"-18 NUTSERT	2	23	813549	3/8"X1-1/4" BTTN HD BOLT	2
07	51200059	3/8"X5/8" BOLT.	AR				
08	813849	3/8" LOCK WASHER	AR				
09	808693	3"X4" SLIDE PAD	AR				
10	814029	3/8"X1-3/4" BOLT	AR				
11	51202034	SLIDE PAD SPACER	AR	-- a	51202032	WIRE HARNESS, BOOM LIGHTS	1
12	808692	4"X6" SLIDE PAD	AR	-- a	51202033	TIE STRAP 0.171X11".	16
13		SHIM.	AR				
	51202026	1/16"X3"X4"		a		When equipped with optional boom work lights	
	51202027	1/8"X3"X4"					
14	808700	4"X6"X1/16" SHIM	AR	b		Also used on the side of the boom with a vinyl clamp to secure boom wire harness	
15	813677	3/8"X3/4" BOLT.	AR				
16 ^{ab}	51202028	BOOM LIGHT SPACER	AR				

-- ITEMS NOT SHOWN --

-- a	51202032	WIRE HARNESS, BOOM LIGHTS	1
-- a	51202033	TIE STRAP 0.171X11".	16


a When equipped with optional boom work lights

b Also used on the side of the boom with a vinyl clamp to secure boom wire harness

Boom

Outer Boom - Rear

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Boom


Outer Boom - Rear

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202035	OUTER BOOM WELDMENT	1	06	51202037	BOOM PIVOT PIN	1
02	51200382	1/2"X4" BOLT	1	07	51200400	3/8"X2-3/4" BOLT	1
03	51202038	1/2" NYLON INSERT NUT	1	08	51202039	SLAVE CYL PIN (ROD END)	1
04	808424	1/4"-28 GREASE ZERK	2	09	808663	3/8" NYLON INSERT NUT	1
05	51202036	BUSHING	2				


Boom

Inner Boom - Front


MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202040	INNER BOOM WELDMENT	1	10 ^b	808727	TOP PLATE, TWIN CUSHION	2
02 ^a	813656	3/8" NYLON INSERT NUT	AR	11 ^b	808832	TUBE CLAMP, DOUBLE	4
03 ^a	808881	PLATE, TWIN CLAMP	AR	12 ^b	51202044	5/16"X2-1/2" STUD	4
04 ^a	808880	CLAMP, 5/8" TWIN TUBE.	AR				
05	51202041	5/16"X2-1/4" BTTN HD BOLT. . . .	AR				
06	51202042	PIVOT PIN.	1	<i>a</i>	<i>Mounted inside of boom through inner clamp access hole</i>		
07	51202038	1/2" NYLON INSERT NUT	1	<i>b</i>	<i>When equipped with auxiliary hydraulic option</i>		
08	51202043	1/2"X3-3/4" BOLT	1				
09 ^b	808662	5/16" NUT	4				



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202040	INNER BOOM WELDMENT 1		09	51202045	EXTEND CYL. SUPPORT PAD . . . 1	
		(includes item 16)		10	813591	3/8" FLAT WASHER 2	
02	808692	4"X6" SLIDE PAD 2		11	813849	3/8" LOCK WASHER AR	
03	808700	4"X6"X1/16" SHIM AR		12	813677	3/8"X3/4" BOLT AR	
04	813849	3/8" LOCK WASHER AR		13	51202046	SLIDE PAD, HOSE GUIDE 1	
05	814211	3/8"X7/8" BOLT AR		14	51202047	EXTEND CYL. SUPPORT 1	
06	813677	3/8"X3/4" BOLT AR		15	51200059	3/8"X5/8" BOLT AR	
07	808693	3"X4" SLIDE PAD AR					
08		SHIM AR					
	51202026	1/16"X3"X4"					
	51202027	1/8"X3"X4"					




MT 5519 Telescopic Handler

Boom

Dynattach® Mount Assembly

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202048	DYNATTACH WELDMENT 1 <i>(includes items 3, 4 and 16)</i>		09	809546	LOCK AND PIN ASSEMBLY 1 <i>(does not include item 7)</i>	
02	808424	1/4"-28 GREASE ZERK STR. . . . AR		10	809531	PIN, TILT CYLINDER ROD 1	
03	51202049	PIVOT BEARING 1		11	813656	3/8" NYLON INSERT NUT 1	
04	808811	BUSHING, LOCK PIN 2		12	51200400	3/8"X2-3/4" BOLT 1	
05	808786	LOCK SPRING 1		13	51202038	1/2" NYLON INSERT NUT 1	
06	808787	SPRING MOUNT 1		14	51202043	1/2"X3-3/4" BOLT 1	
07	808633	3/16"X1-3/4" ROLL PIN 1		15	51202042	PIN, PIVOT 1	
08	808038	DECAL, DYNATTACH UNLOCKED 1 <i>(adheres to item 9)</i>		16	51202051	PIVOT BEARING 2	




MT 5519 Telescopic Handler

Boom Hydraulics Lift Cylinder Group

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	<i>Note a</i>	LIFT CYLINDER	2	08	814291	ADAP -10ORM -8JICM STR	2
02	808665	1/2" NYLON INSERT NUT	2	09	51202055	VALVE, CONTROL	1
03	51202052	PIN, LIFT CYLINDER	2				
04	813711	1/2"X4" BOLT GR5	2			-- ITEMS NOT SHOWN --	
05	51202053	ADAP., -10ORM -8JICM 90°	2	--	51202056	NYLON SLEEVE	1
06	51202054	HOSE, -8 A8/DM8 97"	1			(used with items 6 and 7)	
07	51202054	HOSE, -8 A8/DM8 97"	1				




a



Boom Hydraulics

Extend Cylinder Group

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Boom Hydraulics Extend Cylinder Group


Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	Note a	CYLINDER, EXTEND	1	17	51202063	PIN, EXTEND ROD END	1
02	51202057	ADAP., -8ORM -10JICM 90°	2	18	814233	PAD, SLIDE 1-1/2"X4"	2
03	51202058	PIN, EXTEND CYL. BASE	1	19	813849	3/8" LOCK WASHER	4
04	808663	3/8" NYLON INSERT NUT	1	20	51200059	3/8"X5/8" BOLT	4
05	813711	3/8"X3" BOLT.	1				
06	51202059	HOSE, -8 H10/DL8 68"	1				
07	51202059	HOSE, -8 H10/DL8 68"	1				
08	51202060	TUBE, EXTEND	1				
09	51202061	TUBE, RETRACT	1				
10 ^b	808645	5/16"X1-1/2" BOLT	1				
11 ^b	808881	CUSHION PLATE	1				
12 ^b	808880	CLAMP, CUSHION DBL	1				
14	814291	ADAP., -10ORM -8JICM STR	2				
15	51202055	CONTROL VALVE	1				
16	51202062	SNAP RING, INT 1.5"OD.	2				

-- ITEMS NOT SHOWN --

--	51202056	NYLON SLEEVE	1
----	----------	------------------------	---

(used with items 6 and 7)

a





b These components fasten to the left-rear outer boom and retain the hydraulic tubes: items 8 and 9.

Boom Hydraulics

Tilt / Slave Cylinder Group

MT 5519 Telescopic Handler





Ref. No.	Part No.	Description	Qty. Req.
01	51200400	3/8"X2-3/4" BOLT	3
02	51202039	PIN, SLAVE (rod end)	1
03	808663	3/8" NYLON INSERT NUT	AR
04	Note a	CYLINDER, SLAVE	1
05	51202064	PIN, SLAVE (base end)	1
06	814308	ADAP., -8ORM -8JICM 90°.	AR
07	51202065	HOSE, -8 A8/A8 25"	1
08	51202065	HOSE, -8 A8/A8 25"	1
09	51202066	VALVE, SLAVE ISOLATION	1
10	813708	ADAP., -8ORM -8JICM STR	1
11	51202067	HOSE, -8 A8/H10 70"	1
12	51202068	HOSE, -8 DL8/H10 55"	1
13	808880	CUSHION, CLAMP	AR
14	808881	PLATE, CUSHION	AR
15	51200111	5/16"X2-1/3" BOLT	1
16	51202069	TUBE, TILT (retract)	1
17	51202070	TUBE, TILT (extend)	1
18	51200101	5/16"X1-1/2" BOLT	AR
19 ^b	51202071	HOSE, -6 A8/P-364 270" TWIN	1

Ref. No.	Part No.	Description	Qty. Req.
20	51202072	PIN, TILT (base end)	1
21	813711	3/8"X3" BOLT	1
22	Note a	CYLINDER, TILT	1
23	809531	PIN, TILT (rod end)	1
24	51202073	HOSE, -8 A8/DL8 54"	2
25	814291	ADAP., -10ORM -8JICM STR	2
26	51202055	CONTROL VALVE	1
27	51202074	5/16"x3-1/2" BOLT	2
28	813610	5/16" FLAT WASHER	2



-- ITEMS NOT SHOWN --

--	51202056	NYLON SLEEVE	1
----	----------	------------------------	---

(used with items 7 and 8)

a Refer to page 122 and 124 for cylinder information.

b Refer to page 84 for clamps to secure hose.



MT 5519 Telescopic Handler


Boom Hydraulics Auxiliary Hydraulics Group

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202055	CONTROL VALVE.....	1	14	808727	PLATE, CLAMP.....	2
02	814291	ADAP., -10ORM -8JICM STR.....	2	15	808662	5/16" NYLON INSERT NUT.....	4
03	51202075	HOSE, -8 DL8/H10 70".....	1	16	813708	ADAP., -8ORM -8JICM STR.....	2
04	51202075	HOSE, -8 DL8/H10 70".....	1	17	808796	COUPLER SET.....	1
05	51202076	TUBE, AUXILIARY.....	1				
06	51202077	TUBE, AUXILIARY.....	1				
07	808880	CUSHION, CLAMP.....	AR	--	51202056	NYLON SLEEVE.....	1
08	808881	PLATE, CUSHION.....	AR				
09	51200111	5/16"X2-1/3" BOLT.....	1				
10	51200101	5/16"X1-1/2" BOLT.....	AR				
11	809493	5/16"X2-1/4" STUD.....	4				
12	808832	CLAMP, TUBE.....	4				
13 ^a	51202078	HOSE, -6 A8/P-364 300" TWIN....	1				

-- ITEMS NOT SHOWN --

-- 51202056 NYLON SLEEVE..... 1
(used with items 3 and 4)

a Refer to page 84 for
clamps to secure hose.



MT 5519 Telescopic Handler



MT 5519 Telescopic Handler


Hydraulics Hydraulic Tank Group

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202079	TANK COVER	1	16	51202083	HOSE, -6 A6/A6 24"	1
02	808789	GASKET, RUBBER	1	17	51202086	HOSE, 1-1/2" X 14-1/2"	1
03	51200547	CS 3/8" x 7/8" C5ZY	10	18	51202087	90 HB24-MAORB24	1
04	813657	FW 3/8" ZY	AR	19	51202088	ST HB24-MAORB24	1
05	813596	ST MJ06 MORB06	3	20	51202089	HOSE, 1-1/2" x 24"	1
06	51202080	HOSE, -6 A6/DM6 30"	1	21	51202090	90 HB24-MAORB20	1
		(refer to page 108, item 9)		22	51202091	45 MJ06-MAORB06	1
07	813597	90 MJ06-MAORB06	5	23	51202083	HOSE, -6 A6/A6 24"	1
08	51202081	HOSE, -6 A6/DM8 34"	1	24	813712	CS 5/16" x 2" C5ZY	2
		(refer to page 107, item 14)		25	51202092	FLUID LEVEL SIGHT GAUGE	1
09	51202082	HOSE, -6 A6/DM6 24"	1	26	51202093	MANIFOLD, TANK LEVEL	1
		(refer to page 103, item 16)		27	813664	90 MJ12-MAORB12	2
10	809829	FILLER/CAP W/LOCK TAB	1	28	813678	PLUG, 1/2-14 MAGNETIC	1
	813667	GASKET, CAP (not shown)	1	29	50380258	HOSE, -12 A12/45S12 14-1/2"	1
	809660	GASKET, FILL NECK (not shown)	2			(refer to page 99, item 13)	
11	808555	FLN 5/16"	4	30	50380252	HOSE, -12 A12/45S12 23"	1
12	814206	CS 5/16 x 5/8 C5ZY	2			(refer to page 99, item 11)	
13	51202083	HOSE, -6 A6/A6 24"	1	31	813839	45 MJ12-MAORB12	1
14	51202084	HYDRAULIC FILL WELDMENT	1	32	51202094	HOSE, -12 A12/DS12 86"	1
15	51202085	CLAMP, T-BOLT 2"	4			(refer to page 103, item 19)	

Hydraulics

MT 5519 Telescopic Handler

Hydraulic Circuit - Cooler and Filter




MT 5519 Telescopic Handler

Hydraulics


Hydraulic Circuit - Cooler and Filter

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	50380212	VALVE MOUNT	1	22	51202099	SWITCH, FILTER RESTRICTION. . 1	
02	813657	FW 3/8 ANZY.	1			(included with item #24)	
03	813677	CS 3/8 x 3/4 C5ZY	1	23	51202100	CS FL LOCK 3/8 x 5/8 C5ZY	4
04	51200651	HLN INST 1/4 CZY	2		51200747	LW INTERNAL 3/8 AZY.	1
05	809181	FW 1/4 AWZY	2			(use one tooth washer for grounding)	
06	51202095	CHECK VALVE (cold start by-pass)	1	24 ^a	51202101	HYDRAULIC FILTER ASSEMBLY.	1
07	51202096	CS 1/4 x 2-3/4 C5ZY.	2		51200177	FILTER ELEMENT (only)	1
08	813749	ST MORB16-FJS16.	1	25	814414	CUSHION, TUBE 3/4".	2
09	814495	ST MJ16-MORB16	1	26	814322	CUSHION PLATE	1
10	813844	ST MJ12-MORB16	1	27	809493	STUD, 5/16" x 2-1/4" GR5.	2
11	50380252	HOSE, -12 A12/45S12 23"	1	28	808662	NYLON INSERT NUT, 5/16"	2
12	813664	90 MJ12-MAORB12	3	29	50380120	TUBE, RETURN OIL	1
13	50380258	HOSE, -12 A12/45S12 14-1/2"	1	30	808295	HOSE, -8 A8/DM8 46".	1
14	51200570	45 MJ12-MAORB16	1	31	50380250	TUBE, RETURN OIL	1
15	51202097	HOSE, -12 A12/A12 68"	1	32	808779	ST MJ12 MORB16	1
16	814394	90 BLKHD MJ12-MJ12	1	33	51202102	CHECK VALVE, 65 PSI.	1
17	51200849	RADIATOR/COOLER ASY.	1	34	51202103	ST MORB16-FJS12.	1
18	50380133	TUBE, CHARGE OIL.	1	35	51200410	TEE MJ12-FJS12-MJ12	1
19	813839	45 MJ12-MAORB12	1	36	51202104	ST JICF12-JICM8	1
20	51202098	TEE RUN MJ12-MAORB16-MJ12.	1	37	51202105	90 MJ12-MAORB10	1
21	50380125	TUBE, FILTER-COOLER.	1	38	51202055	CONTROL VALVE (joysticks).	1





a Includes filter element (PN 51200177) and filter restriction switch—item #22.



Hydraulic Drive Pump
(attached to engine)



Control Valve
(inside cab)



MT 5519 Telescopic Handler

Hydraulics


Hydraulic Circuit - Hydraulic Pump

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202106	HOSE, -10 A12/DL10 40"	1	06	813338	CS 1/2x1-1/4 C5ZY	2
02	51202107	REDUCER, FJ12-MJ06	1	07	51202090	90 HB24-MAORB20	1
03	51200410	ADAP., -12JIC SWIVEL	1	08	51202085	CLAMP, T-BOLT 2"	2
04	813844	ST MJ12 MORB16	1	09	51202088	ST HB24-MAORB24	1
05	51202108	HYDRAULIC PUMP (Refer to hydraulic components pages for seals, gaskets, and o-rings.)	1	10	51202089	HOSE, 1-1/2" x 24" 100R4	1
				11	50380253	HOSE, -4 A6/DS6 11"	1
				12	51200779	ST BLKHD MJ06-MJ06	1
				13	51200778	TEST PORT, -6JICF	1

Hydraulics

MT 5519 Telescopic Handler

Hydraulic Drive Pump and Hydrostatic Motor



MT 5519 Telescopic Handler

Hydraulics


Hydraulic Drive Pump and Hydrostatic Motor

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202109	HOSE, -6 A6/DL6 54"	1	17	51200710	INCHING VALVE	1
02	813596	ST MJ06 MOR5B	1	18	813597	90 MJ06-MAORB06	1
03	51202110	SPLIT FLANGE KIT, C62-12	2	19	51202094	HOSE, -12 A12/DS12 86"	1
04	51202111	90 MJ12-C62-12	2			(drive motor to rear of hydraulic tank)	
05	50380170	HOSE, -16 A12 C62-16 22.9"	1	20	51202114	ADAP., HYD. TEMP. SWITCH.	1
06	51202112	HYDRAULIC DRIVE ASSEMBLY	1	21	51202115	TEMPERATURE SWITCH.	1
07	813839	45 MJ12 MAORB12.	1	22	51202116	MOTOR, HYDROSTATIC DRIVE	1
08	51202113	SPLIT FLANGE KIT, C62-16	2	23	51200940	O-RING (drive motor to front axle)	1
09	50380257	HOSE, -12 A12/DL12 23"	1	24	51202117	LW M16 ZY DIN127.	4
10	813704	90 MJ12 FJS12	1	25	51202118	CS M16-2x50 C8.8 ZY DIN931	4
11	814326	ST MJ12-MORB12	1	26	813746	90 MJ12-MAORB16	1
12	50380170	HOSE, -16 A16 C62-16 22.9"	1	27	51202097	HOSE, -12 A12/A12 68"	1
13	50380255	HOSE, -6 A6/DL6 18"	1			(refer to page 99, item 15)	
14	813596	ST MJ06-MORB06	1	28	51202119	CS 5/8" x 1-3/4" C5ZY.	2
15	814469	TEE RUN MJ06-MAORB06-MJ06.	1	29	51202120	FW M16 (hardened)	2
16	51202082	HOSE, -6 A6/DM6 24"	1				

Hydraulics

Control and Isolation Valves



MT 5519 Telescopic Handler



Hydraulics

Control and Isolation Valves


Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202054	HOSE, -8 A8/DM8 97"	1	25	51202067	HOSE, -8 A8/H10 70"	1
02	51202059	HOSE, -8 H10/DL8 68"	1	26	51202066	VALVE, SLAVE ISOLATION	1
03 ^a	51202075	HOSE, -8 H10/DM8 70"	1		809743	5/16"X3-1/2" BOLT	2
04	51202073	HOSE, -8 A8/DL8 54"	1		813610	5/16" FLAT WASHER	2
05	813597	ADAP., -6ORM -6JICM 90°	1	27	51202055	VALVE, CONTROL	1
06	51202121	HOSE, -4 A4/A6 36"	1		51200111	5/16"X2-1/2" BOLT	2
07	814291	ADAP., -10ORM -10JICM STR	1		808555	5/16" WHIZ NUT	2
08	51202106	HOSE, -10 A12/DL10 40"	1		51200863	M8X20 8.8 BOLT	1
09	51202122	HOSE, -6 A8/DM8 36"	1		813610	5/16" FLAT WASHER	1
10	814308	ADAP., -8ORM -8JICM 90°	5	28	51202103	ST MORB16-FJS12	1
11	814452	ADAP., -10ORM -8JICM STR	AR	29	51202102	CHECK VALVE, 65 PSI	1
12	51202073	HOSE, -8 A8/DL8 54"	1	30	813844	ST MJ12 MORB16	1
13 ^a	51202075	HOSE, -8 H10/DM8 70"	1	31	50380250	TUBE, RETURN OIL	1
14	51202059	HOSE, -8 H10/DL8 68"	1			(refer to page 99, item 31)	
15	51202054	HOSE, -8 A8/DM8 97"	1				
16	808295	HOSE, -8 A8/DM8 46"	1			-- ITEMS NOT SHOWN --	
17	51200410	ADAP., -12 SWVL. RUN TEE	1			(Hose Protection Sleeve)	
19	51202104	ADAP., -12JICFS -8JICM STR	1	--	51202056	SLEEVE, HOSE (4' long)	4
20	51202105	ADAP., -10ORM -12JICM 90°	1				
21	51202065	HOSE, -8 A8/A8 25"	1				
22	51202065	HOSE, -8 A8/A8 25"	1	a		When the unit is not equipped with auxiliary hydraulic option, use P/N 51202124 ADAP., -8 Cap.	
23	51202068	HOSE, -8 DL8/H10 55"	1				
24	813708	ADAP., -8ORM -8JICM STR	AR				



Hydraulics

Steer Motor and Steer Select Valve

MT 5519 Telescopic Handler



MT 5519 Telescopic Handler

Hydraulics


Steer Motor and Steer Select Valve

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200702	MOTOR, STEER	1	10	51202126	HOSE, -6 A6/DM8 40"	1
02	813550	ADAP, -4ORM -4JICM 90°	1	11	51202127	HOSE, -6 A8/DM8 32"	1
03	51202121	HOSE, -4 A4/A6 36"	1	12	51202122	HOSE, -6 A8/DS8 36"	1
04	808877	VALVE, STEER SELECT	1	13	808763	VALVE, CHECK, -8ORM	1
	808627	1/4"X3" BOLT	2	14	51202081	HOSE, -6 A6/DM8 34"	1
	808545	1/4" WHIZ LOCK NUT	2	15	813708	ADAP, -8ORM -8JICM STR.	3
05	813597	ADAP, -6ORM -6JICM 90°	2	-- ITEMS NOT SHOWN -- (steer cylinders on front and rear axle)			
06	51202125	HOSE, -6 A6/DM8 20"	1				
07	813596	ADAP, -6ORM -6JICM STR.	2	--	808076	ADAP, M18ORM -8JICM STR.	4
08	51202128	HOSE, -6 A6/A8 106"	1				
09	51202128	HOSE, -6 A6/A8 106"	1				


Hydraulics

Brake Valves and Inching Valve

MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	814300	PLUG, -4ORM SAE	1	07	51202130	HOSE, -4 A6/DM6 36"	1
02	808905	MANIFOLD, BRAKE	1	08	51202080	HOSE, -6 A6/DS6 30"	1
	51202133	1/4"X1-3/4" BOLT	2	09	51202080	HOSE, -6 A6/DM6 30"	1
	808589	1/4" LOCK WASHER	2	10	808714	VALVE, MASTER CYLINDER	1
03	809790	SWITCH, PRESSURE 150 PSI	1	11	808703	ADAP, HYDROMAX -4JICM STR	1
04	814479	ADAP, -4ORM -4JICM STR	1	12	51200091	HOSE, -4 A4/A4 18"	1
05	51202129	PARKING BRAKE VALVE	1	13	51202131	HOSE, -4 A4/DS6 16"	1
	809112	1/4"X1-1/2" BOLT	2	14	808804	ADAP, M14X1.50RM -6JICM	2
	809181	1/4" FLAT WASHER	2	16	813550	ADAP, -4ORM -4JICM 90°	1
06	813597	ADAP, -6ORM -6JICM 90°	3	17	51202132	HOSE, -6 A6/DM6 54"	1




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51200778	TEST PORT, -6JICF	2	07	51202129	VALVE, PARK BRAKE.....	1
02	51200779	ST BLKHD MJ06-MJ06.....	1	08	51202130	HOSE, -4 A6/DM6 36".....	1
03	50380253	HOSE, -4 A6/DS6 11"	1	09	51202134	TEST PORT, STAUFF20 -4ORB...	2
04	51202107	REDUCER, F12-JICM06.....	1	10	814461	SWVL TEE -6	1
05	51200410	SWVL TEE -12	1	11	813596	ST JICM06-MORB06.....	1
06	813597	90 JICM06-ORB06	1				


Hydraulic Components

Hydraulic Drive Pump

MT 5519 Telescopic Handler




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01 ^a	NSS	HYDRAULIC DRIVE PUMP	1	10	51202143	SEAL KIT / COMPLETE	1
02 ^b	51202135	PRESSURE RELIEF VALVE	2	11	51202112	HYDRAULIC DRIVE ASSEMBLY . .	1
03 ^b	51202136	PRESSURE RELIEF VALVE	1				
04 ^b	51202137	CONTROL VALVE	1	a	Order item #11 hydraulic drive assembly, which includes hydraulic pump P/N 51202108		
05	51202138	RETAINING RING	1				
06	51202139	SHAFT SEAL RING	1	b	When ordering parts, provide the serial number of the drive pump to the factory parts department; some components may require a different part number than the one shown.		
07	51202140	PAIR/SWITCHING SOLENOIDS . . .	1				
08 ^b	51202141	4/3-WAY DIRECTIONAL VALVE . . .	1				
		(includes item 7)					
09 ^b	51202142	PRESSURE OVERRIDE VALVE . . .	1				




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01 ^a	51202108	HYDRAULIC PUMP	1	05	51202147	SEAL KIT	1
02	51202144	O-RING	1			(individual seals not shown)	
03	51202145	SPACER	1				
04	51202146	O-RING	1	a		Included with hydraulic drive assembly.	


Hydraulic Drive Motor—(Hydrostatic Motor)



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202116	HYDRAULIC DRIVE MOTOR1 (includes all items shown)		06	51200940	O-RING (drive motor to axle)1 (included with front axle, not included with item7.)	
02	51202140	SOLENOID SET (pair)1		07	51202151	SEAL KIT, COMPLETE1 (includes items 3-5 and all other seals for drive motor [not shown])	
03	51202148	RETAINING RING1					
04	51202149	SHAFT SEAL RING1					
05	51202150	BACKUP PLATE1					




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
--	51202066	ISOLATION MANIFOLD 1 (includes all parts shown)		01	51202152	COUNTER BALANCE VALVE 2	
					808955	SEAL KIT FOR CB VALVE AR	
				02	51202153	CHECK VALVE 2	
					809154	SEAL KIT 1	



Hydraulic Components


Control Valve

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00 ^a	51202055	MAIN VALVE [HC-D4/4] <i>(complete)</i>	1	17 ^c	51202169	WORK SECTION	1
01	51202154	CONTROL HANDLE, 6"	1			<i>(includes 6, 13 and 14)</i>	
02	51202155	CONTROL HANDLE, 8"	1	18 ^d	51202170	WORK SECTION	1
03	51202156	RUBBER BOOT	2	19 ^d	51202171	WORK SECTION	1
04	51202157	JOYSTICK CONTROL ASY.	1	20 ^e	51202172	WORK SECTION	1
05	51202158	JOYSTICK CONTROL ASY.	1	21 ^f	51202173	OUTLET SECTION	1
06	51202159	ANTI SHOCK VALVE 240-A	2			<i>(includes 15)</i>	
07	51202160	ANTI SHOCK VALVE 160-A bar ...	1				
08	51202161	PLUG KIT	1				
09	51202162	RELIEF VALVE 230 bar.	1				
10	51202163	STUD KIT	4				
		<i>(includes tie bolt, nuts and washers)</i>					
11	51202164	PLUG KIT	1	a	51202174	SEAL KIT, MAIN VALVE	1
12	51202165	PLUG KIT	1	b	51202175	SEAL KIT, INLET SECTION	1
13	808360	CHECK VALVE	4	c	51202176	SEAL KIT, WORK SECTION.	1
14	51202166	SPOOL RETURN ASY. <i>(F001A)</i> ...	4	d	51202177	SEAL KIT, WORK SECTION.	2
15	51202167	PLUG KIT, 7/8"-14UNF	3	e	51202178	SEAL KIT, WORK SECTION.	1
16 ^b	51202168	INLET SECTION	1	f	51202179	SEAL KIT, OUTLET SECTION	1
		<i>(includes 7-9 and 11-12)</i>					




Ref. No.	Part No.	Description	Qty. Req.
01	51200702	STEERING CONTROL UNIT	1
02	809480	SEAL KIT	1
(Items included are not shown.)			


NOTE: Field service is limited to seals replacement.




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808877	STEER SELECT VALVE 1 (includes items 1-5)	1	03	NSS	BOLTS, MANIFOLD. 4 (included with item 2)	4
02	814532	WEATHER PAK VALVE. 1 (includes items 3 and 4)	1	04	51202291	SEAL KIT (4 o-rings) 1 (included with item 2)	1
				05	NSS	MANIFOLD 1	1



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	51202129	PARKING BRAKE VALVE 1 <i>(includes all items shown)</i>		03	809152	VALVE/3WAY/2POS 1	
01	NSS	COIL NUT <i>(included with item 3)</i> . . . 1			809153	SEAL KIT 1	
02	51200427	COIL, WEATHERPAK 12VDC 1		04	NSS	MANIFOLD 1	



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	808714	BRAKE VALVE ASY. (complete) (Unit requires two brake valves)		06	NSS	PUSH ROD	1
01	NSS	BAIL WIRE.	1	07a	809066	REPAIR KIT. (Items included are not shown.)	1
02	809638	COVER	1				
	809064	DIAPHRAGM GASKET	1				
03	NSS	BODY		a		Repair kit includes seals, cups, return spring, second arm piston, and snap ring. Piston is not included or sold separately.	
04	NSS	TUBE SEAT (not shown).	1				
05	809065	RUBBER BOOT	1				




MT 5519 Telescopic Handler

Hydraulic Cylinders

Lift Cylinder

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	51202180	LIFT CYLINDER (<i>complete</i>)	1	06	51202186	COUNTER BALANCE VALVE.	1
01	51202181	ROD WELDMENT	1		51202187	SEAL KIT (CBV)	1
		(<i>includes item 2</i>)		07	51202188	BUSHING (2"X2-1/4"X2-1/2")	1
02	51202182	BUSHING (2"X2-1/4"X3")	1	08	809155	SAE 4 PLUG	1
03	51202183	HEAD GLAND	1	09	NSS	TUBE WELDMENT	1
04	51202184	PISTON	1	10	51202189	CYLINDER SEAL KIT	1
05	51202185	LOCKNUT	1			(<i>Items included are not shown.</i>)	



MT 5519 Telescopic Handler


Hydraulic Cylinders Slave Cylinder

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	51202190	SLAVE CYLINDER <i>(complete)</i>	1	05	51202185	LOCKNUT	1
01	51202191	ROD WELDMENT	1	06	NSS	TUBE WELDMENT	1
		<i>(includes item 2)</i>		07	51202194	BUSHING <i>(1-1/2"X1-3/4"X2")</i>	1
02	51202192	BUSHING <i>(1-1/2"X1-3/4"X3")</i>	1	08	51202195	CYLINDER SEAL KIT	1
03	51202193	HEAD GLAND	1			<i>(Items included are not shown.)</i>	
04	51202184	PISTON	1				

Hydraulic Cylinders

Tilt Cylinder

MT 5519 Telescopic Handler




MT 5519 Telescopic Handler

Hydraulic Cylinders

Tilt Cylinder

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	51202196	TILT CYLINDER (<i>complete</i>)	1	06	51202186	COUNTER BALANCE VALVE	1
01	51202197	ROD WELDMENT	1		51202187	SEAL KIT (CBV)	1
		(<i>includes item 2</i>)		07	51202201	BUSHING (1-1/2"X1-3/4"X2")	2
02	51202192	BUSHING (1-1/2"X1-3/4"X3")	1	08	NSS	TUBE WELDMENT	1
03	51202198	HEAD GLAND	1	09	809155	SAE 4 PLUG	1
04	51202199	PISTON	1	10	51202202	CYLINDER SEAL KIT	1
05	51202200	3/8"-16UNC X 0.75" SET SCREW .	1			(<i>Items included are not shown.</i>)	



MT 5519 Telescopic Handler


Hydraulic Cylinders *Boom Extend Cylinder*

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	51202203	EXTEND CYLINDER (<i>complete</i>) . . .	1	07	51202209	COUNTER BALANCE VALVE	1
01	51202204	ROD WELDMENT	1		808955	SEAL KIT (CBV)	1
		(<i>includes item 2</i>)		08	51202192	BUSHING(<i>1-1/2"X1-3/4"X3"</i>)	2
02	51202205	BUSHING (<i>1-1/2"X1-3/4"X4"</i>)	1	09	51202210	CYLINDER SEAL KIT	1
04	51202206	HEAD GLAND	1			(<i>Items included are not shown.</i>)	
05	51202207	PISTON	1	10	NSS	TUBE WELDMENT	1
06	51202208	LOCKNUT	1				


Hydraulic Cylinders

Rotating-Carriage Cylinder

MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	809543	ROTATE CYLINDER (complete) . . .	1	08	809650	PISTON	1
01	809661	ROD WELDMENT	1	09	809407	3/4"-16 UN LOCKNUT	1
02	808720	BUSHING	1	10	809549	COUNTER BALANCE VALVE	2
03	809662	HEAD GLAND CAP	1		808965	SEAL KIT (CBV)	
04	809136	5/16"-18X1/4" SET SCREW	1	11	NSS	TUBE WELDMENT	1
05	809664	HEAD GLAND	1	12	809663	CYLINDER SEAL KIT	1
06	809665	SPACER, ROD	1			(Items included are not shown.)	
07	809666	SUPPORT WASHER	1				




Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
00	808834	FORK-SHIFT CYL. (<i>complete</i>)	1	04	809407	3/4\"-16 UNF LOCKNUT.	1
01	808581	ROD WELDMENT	1	05	NSS	TUBE WELDMENT	1
02	808580	HEAD GLAND	1	06	808506	SEAL KIT	1
03	808579	PISTON	1			(<i>Items included are not shown.</i>)	


Hydraulic Cylinders

Side-Shift Carriage Cylinder

MT 5519 Telehandler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	50380525	CYLINDER, SIDE-SHIFT	1	09	50220261	SEAL KIT.	1
		(includes Items 2-9)				(Includes all required seals, an	
02	50220258	ROD WELDMENT.	1			internal retaining ring, and item 4).	
03	808720	BUSHING	1	10	50220262	REPAIR KIT.	1
04 ^a	50220260	RETAINING RING.	1			(Includes item 9, plus a filler ring that	
05	50220259	HEAD GLAND.	1			is required to remove the head	
06	808579	PISTON.	1			gland.)	
07	808071	LOCK NUT, 3/4"-16	1				
08	NSS	TUBE WELDMENT	1	a		Included with seal kit (item 9).	



Ref. No.	Part No.	Description	Qty. Req.
-- 2" FORK SHAFT DIAMETER --			
01		FORK, 42"x4"x2"	2
02 ^a		FORK, 48"x2"x2"	4
03		FORK, 48"x4"x2"	2
04		FORK, 48"x5"x1-3/4"	2
05		FORK, 60"x5"x1-1/2"	2

^a Requires 2 sets (4 forks)


NOTE: Ratings are based on two forks and a 24" load on center, except for item #2, where four forks are required.

To order forks, please call the Factory Sales Department at (262) 334-6601.



WARNING

When ordering forks, select forks with a rating capacity that meets or exceeds the lifting capacity of the machine; failure to use the correct forks could result in injury or death. For more information contact dealer (or manufacturer).



MT 5519 Telescopic Handler


Attachments Standard Carriage

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01		CARRIAGE, WELDMENT	1	03	808431	WASHER, FORK SHAFT	2
	51202211	48" Carriage		04	808663	3/8"-16 NYLON INSERT NUT	2
	51202212	66" Carriage		05	51200400	3/8"-16X2-3/4" BOLT	2
02		FORK SHAFT BAR	1				
	809691	48" Carriage (50-1/2")					
	809692	66" Carriage (68-1/2")					


Attachments

Rotating Carriage (Series I)


MT 5519 Telescopic Handler



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01		ROTATE CARRIAGE, WELDMNT . 1		11	808710	ADAP, -8ORM -6JICM STR. 2	
	809670	48" Carriage				(with orifice)	
	809669	66" Carriage		12	809535	HOSE, -6 A8/A6 20" 2	
02		FORK SHAFT BAR 1		13	51200412	ADAP, -6ORM -6JICM 90°. 2	
	809691	48" Carriage (50-1/2" long)		14	808663	3/8"-16 NYLON INSERT NUT 1	
	809692	66" Carriage (68-1/2" long)		15 ^a	809547	BUTT END PIVOT PIN 1	
03	51200400	3/8"-16X2-3/4" BOLT 2		16	51200400	3/8"-16X2-3/4" BOLT AR	
04	808431	RETAINER..... 2		17	809543	ROTATE CYLINDER 1	
05	808663	3/8"-16 NYLON INSERT NUT 2		18 ^a	809548	ROD END PIVOT PIN..... 1	
06	809482	2"-12 CASTELLATED NUT 1			814647	1/2"-13X3-1/2" BOLT 1	
	808687	WASHER (not shown) 1			808665	1/2"-13 NYLON INSERT NUT 1	
07	813549	3/8"-16X1-1/4" BOLT" 6		19	NSS	ROTATE PIN (welded to #20). 1	
08	813849	3/8" LOCK WASHER..... 6		20	809545	ROTATE, PLATE (includes #19). . 1	
09	808693	SLIDE PAD 3"X4" 3		21	808756	BUSHING (not shown) 1	
10	808796	QUICK COUPLER SET..... 1					
		(Couplers are not sold separately.)					



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01		ROTATE CARRIAGE, WELDMNT . 1		11	813700	ADAP, -8ORM -6JICM STR. 2	
	51202213	48" Carriage		12	809535	HOSE, -6 A8/A6 20" 2	
	51202214	66" Carriage		13	51200412	ADAP, -6ORM -6JICM 90°..... 2	
02		FORK SHAFT BAR 1		14	808661	1/4" NYLON INSERT NUT 1	
	809691	48" Carriage (50-1/2" long)		15	809547	PIVOT PIN, BASE END 1	
	809692	66" Carriage (68-1/2" long)		16	808644	1/4"X2" BOLT AR	
03	51200400	3/8"X2-3/4" BOLT 2		17	809543	ROTATE CYLINDER..... 1	
04	808431	RETAINER..... 2		18	809548	PIVOT PIN, ROD END 1	
05	808663	3/8"-16 NYLON INSERT NUT 2		19	51202215	ROTATE PIN. 1	
06	809482	2"-12 CASTELLATED NUT 1		20	51202216	CARRIAGE PIVOT 1	
07	813713	3/8"X1-1/4" BOLT"..... 6		21	51202217	SPHERICAL BEARING..... 1	
08	813849	3/8" LOCK WASHER..... 6		22	809181	1/4" FLAT WASHER..... AR	
09	808693	SLIDE PAD 3"X4" 3		23	808627	1/4"X3" BOLT..... 1	
10	808796	QUICK COUPLER SET..... 1		24	808429	WASHER 1	
		(Couplers are not sold separately.)					




MT 5519 Telehandler

Attachments Side-Shift Carriage

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	50220314	SIDE-SHIFT FRAME w/SN	1	14	51202292	HOSE, MP -6 x 30"	2
02	809691	BAR, FORKSHAFT 2" x 50-1/2" . . .	1	15	50380600	ST MJ06-MORB08 w/orifice	2
03	51200400	CS 3/8" x 2-3/4" C5ZY	2	16	808796	HYDRAULIC COUPLER SET	1
04	813656	HLN INST 3/8" CZY	2	17	808693	PAD, SLIDE 3" x 4"	2
05	808431	WASHER, FORK SHAFT	2	18	808696	LOCK, BOLT FLAT	2
06	50380541	COLLAR, 1-3/4" LOCKING	2	19	814211	CS 3/8" x 7/8" GR5	4
07	50380532	SHAFT, SIDE-SHIFT	1	20 ^a	50380535	SIDE-SHIFT MOUNT.	1
08	51200386	FITTING, GREASE 1/4" TAPER . . .	4	21 ^b	51202188	BUSHING	2
09	51200090	CS 1/4" x 2" C5ZY	2	22 ^b	51202293	BUSHING, 1-1/4" O.D. x 1" I.D. . . .	1
10	809548	PIN, CYLINDER PIVOT.	2				
11	808661	NYLON INSERT NUT, 1/4"-20 . . .	2				
12	50380525	CYLINDER, SIDE-SHIFT	1				
13	813597	90 JICM06-MAORB06.	2				

a Includes bushings: items 21 and 22.
b Included with item 20.




MT 5519 Telescopic Handler


Attachments Fork-Shift Carriage

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	809405	FORK-SHIFT, WELDMENT	1	10	809251	5/16"-18X2-1/4" BOLT	2
02	808626	3/4"-10 NYLON INSERT NUT	3	11	808728	TWIN HOSE CUSHION.	1
03	808431	FORK SHAFT WASHER	1	12	808662	5/16"-18 NYLON INSERT NUT	2
04	808616	3/4"-10X3" BOLT	1	13	808796	QUICK COUPLER SET	1
05	808822	FORK SHAFT, 50"	1	15	809252	CYLINDER MOUNT	2
06	808824	FORK SLIDE PLATE	2	16	808834	FORK SHIFT CYLINDER	1
07	814650	3/4"-10X1-1/2" BOLT	1	17	809253	3/4"-10X4" BOLT	2
08		FORK SLIDE COUPLER	1	18	808710	ADAP -8ORM -6JICM W/.06 ORF	2
	808823	<i>Used with 4" wide forks</i>		19	809254	HOSE -6 A6/A6 59"	1
	809276	<i>Used with 5" wide forks</i>		20	808826	HOSE -6 A6/A6 56"	1
09	808727	TWIN CUSHION TOP PLATE	2				

Truss Boom



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	51202218	TRUSS BOOM, 5FT.	1	-- ITEMS NOT SHOWN --			
02	808689	PINTLE HOOK	1	--	809406	ATTACH. ADAPTER PLATE.	1
03	808619	1/2"-20X1-1/4" GR 8 BOLT	4	--	51200487	DECAL, TRUSS TILT BACK	1
04	808596	1/2" LOCK WASHER.	4				



Ref. No.	Part No.	Description	Qty. Req.
01	51202220	1.0 CU. YD. BUCKET WELDMNT	. 1
	51202221	CUTTING EDGE 73.5" (<i>weld-on</i>)	. . 1

GENERAL INFORMATION

 CAUTION

ALWAYS read and follow the safety precautions on decals. Replace decals if they are damaged, or if the unit is repainted. If repainting, **BE SURE** that all applicable decals are affixed in their proper locations.

NEW DECAL APPLICATION

Before applying new decals, surfaces must be free from dirt, dust, grease and other foreign material. To apply a solid-formed decal, remove the smaller portion of the decal backing paper and apply this part of the exposed adhesive backing to the clean surface while maintaining proper position and alignment. Slowly peel off the other portion of the backing paper while applying hand pressure to smooth out decal surface. To apply a die-cut decal, first remove the backing paper. Then, properly position the decal onto the clean mounting surface. After the decal is firmly applied and smoothly pressed down, remove the front covering paper.

 IMPORTANT

When a decal is affixed to a part that is to be replaced, be sure that the replacement part has the decal applied or apply a new decal.

PAINT FINISH

Use this list to order paint for refinishing:


808020	One Gallon Red
808021	6 (12-oz. Spray Cans) Red
808043	One Gallon Gun-Metal Gray
808044	6 (12-oz. Spray Cans) Gun-Metal Gray

Decal Kits


50200526	MT 5519 Telehandler
----------	---------------------



NOTE: Decals may be purchased in kits or individually.



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808027	DECAL, WARN. TILT HAZARD....	1	08	809306	ATTACHMENT TILT/AUX.....	1
02	808037	DECAL, WARN. CARRY LOAD ...	1	09	808062	BOOM CONTROL.....	1
03	808059	DECAL, F-N-R SHIFTER	1	10	50380266	DECAL, IGNITION/HORN.....	1
04	808060	DECAL, MADE IN USA.....	1	11	808031	DECAL, PERSON. INJURY	1
05	808030	DECAL, WARN. PARK BRAKE....	1	12	808032	OPERATOR MANUAL WARNING..	1
06	808029	DECAL, DANGER/HIGH VOLT. ...	1	13	50380364	DECAL, LUBE CHART	1
07		LOAD CHART	1	14	808035	DECAL, NO RIDERS.....	1
	50380347	STANDARD CARRIAGE		15	808033	DECAL, PINCH POINT	1
	50380348	ROTATING CARRIAGE		16	51200524	DECAL, TIE DOWN.....	4
	50380349	BUCKET		17	51200525	DECAL, LIFT POINT	4
	50380350	TRUSS BOOM (JIB)		18	50380379	DECAL, MANITOU (SMALL).....	1
	50380351	FORK-SHIFT CARRIAGE					
	50380352	SIDE-SHIFT CARRIAGE					



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808036	DECAL, DANGER-HANDS OUT.	1	06	808057	DECAL, HYDRAULIC OIL	1
02	808033	DECAL, WARN. PINCH POINT . . . AR		07	50380379	DECAL, MANITOU (SMALL)	3
03	808034	DECAL, WARN. JUMP START	1	08	50380382	DECAL, MT 5519	1
04	808047	DECAL, ANTI-FREEZE	1	09	50380381	DECAL, MANISCOPIC	1
05	808054	DECAL, COOLANT PRESSURE . . .	1	10	809291	DECAL, WARN. HOT SURFACE . . 1 (located on top of hood scoop)	



Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
01	808033	DECAL, WARN. PINCH POINT . . .	1	06	808038	DECAL, QUICKATTACH UNLOCK .	1
02	808064	DECAL, QUICKATTACH	1	07	50301416	DECAL, DIESEL FUEL	1
03	808031	DECAL, DANGER-PERSONNEL . .	1	08	50380382	DECAL, MT 5519	1
04	808055	DECAL, BRAKE FLUID	1	09	51202219	NO RIDERS	1
05	50380380	DECAL, MANITOU (LARGE)	1				

Numerical Index

MT 5519 Telescopic Handler

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
50220067	71	19	50380364	143	13	51200059	27	15	51200437	40	01
50220067	71	21	50380379	143	18	51200063	31	01	51200487	140	—
50220067	77	18	50380379	144	07	51200066	31	04	51200524	143	16
50220067	77	20	50380380	145	05	51200067	31	05	51200525	143	17
50220154	61	13	50380381	144	09	51200069	33	01	51200526	142	00
50220155	61	17	50380382	144	08	51200070	33	02	51200537	09	02
50220157	56	16	50380382	145	08	51200071	33	03	51200538	11	02
50220258	130	02	50380432	67	15	51200072	33	06	51200539	11	—
50220259	130	05	50380525	130	01	51200073	33	08	51200539	13	—
50220260	130	04	50380525	137	12	51200074	33	09	51200547	97	03
50220261	130	09	50380526	65	00	51200075	33	12	51200552	57	14
50220262	130	10	50380532	137	07	51200076	33	13	51200552	65	03
50220314	137	01	50380535	137	20	51200090	137	09	51200555	59	08
50380046	63	09	50380541	137	06	51200090	39	44	51200565	45	15
50380053	51	04	50380542	65	10	51200091	108	12	51200567	55	04
50380056	57	21	50380576	17	02	51200095	40	02	51200570	99	14
50380058	43	25	50380577	17	01	51200095	67	11	51200580	73	25
50380090	65	06	50380579	17	03	51200101	53	04	51200580	79	25
50380091	65	06	50380583	17	04	51200101	93	18	51200613	05	09
50380120	99	29	50380585	17	—	51200101	95	10	51200613	57	01
50380125	99	21	50380600	137	15	51200111	105	27	51200614	05	10
50380133	99	18	50380634	33	14	51200111	93	15	51200614	29	10
50380135	43	09	50380682	17	02	51200111	95	09	51200615	07	01
50380136	55	09	50380683	17	—	51200114	53	07	51200616	07	04
50380168	63	14	51200000	05	11	51200116	05	01	51200617	07	10
50380170	103	05	51200000	25	03	51200116	56	20	51200620	07	19
50380170	103	12	51200007	07	15	51200167	05	07	51200621	07	27
50380179	51	11	51200008	07	34	51200167	63	10	51200622	07	27
50380181	51	06	51200008	15	15	51200172	05	08	51200623	07	—
50380197	51	12	51200012	21	11	51200172	63	11	51200624	07	—
50380205	51	13	51200012	23	08	51200177	05	06	51200625	09	04
50380206	51	07	51200012	29	25	51200177	99	24	51200626	11	12
50380207	51	14	51200013	21	22	51200267	69	02	51200626	11	13
50380212	99	01	51200013	23	30	51200267	76	02	51200627	11	16
50380215	61	15	51200014	07	14	51200269	69	03	51200628	11	17
50380216	61	16	51200014	09	01	51200269	71	39	51200629	11	18
50380217	43	06	51200019	05	05	51200269	73	21	51200630	11	19
50380218	43	07	51200019	55	11	51200269	79	21	51200630	11	22
50380219	43	08	51200020	05	02	51200270	71	42	51200630	58	05
50380247	56	13	51200027	07	—	51200270	76	03	51200630	58	08
50380248	56	14	51200028	07	—	51200338	73	22	51200631	11	19
50380250	105	31	51200030	24	02	51200338	79	22	51200631	58	07
50380250	99	31	51200030	25	15	51200339	73	37	51200632	58	06
50380252	97	30	51200031	24	10	51200339	79	37	51200633	11	20
50380252	99	11	51200032	25	01	51200340	73	52	51200633	11	21
50380253	101	11	51200033	25	01	51200340	79	52	51200633	58	09
50380253	109	03	51200034	25	02	51200347	75	35	51200633	58	10
50380255	103	13	51200035	25	04	51200348	75	12	51200634	11	24
50380257	103	09	51200035	27	06	51200349	75	34	51200635	11	26
50380258	97	29	51200036	25	07	51200350	75	15	51200636	11	30
50380258	99	13	51200037	25	08	51200351	75	16	51200636	58	18
50380266	143	10	51200038	25	09	51200382	83	02	51200637	11	—
50380271	55	20	51200039	25	10	51200386	137	08	51200638	11	—
50380272	05	04	51200040	25	11	51200400	133	05	51200639	11	—
50380327	43	01	51200041	25	13	51200400	134	03	51200640	13	05
50380341	67	15	51200042	25	14	51200400	134	16	51200641	13	06
50380344	67	15	51200043	25	17	51200400	135	03	51200642	13	07
50380347	143	07	51200044	25	18	51200400	137	03	51200643	13	08
50380348	143	07	51200045	25	06	51200400	83	07	51200644	13	10
50380349	143	07	51200047	27	03	51200400	87	12	51200645	15	11
50380350	143	07	51200049	27	05	51200400	93	01	51200646	17	11
50380351	143	07	51200051	27	07	51200410	99	35	51200646	17	16
50380352	143	07	51200056	27	08	51200412	134	13	51200647	21	00
50380359	43	14	51200057	27	09	51200412	135	13	51200648	21	23
50380360	43	16	51200058	27	14	51200427	118	02	51200648	23	24

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
51200649	21	27	51200708	39	06	51200766	49	02	51200813	57	02
51200649	23	44	51200710	103	17	51200767	49	03	51200813	65	10
51200650	21	28	51200710	39	10	51200768	49	03	51200814	57	04
51200650	23	45	51200711	39	12	51200769	49	03	51200815	57	05
51200651	23	32	51200712	39	14	51200770	49	04	51200816	57	06
51200651	39	43	51200713	39	19	51200771	49	05	51200817	57	07
51200652	23	01	51200714	39	22	51200772	49	08	51200818	57	08
51200653	23	02	51200715	39	23	51200773	49	09	51200819	57	09
51200654	23	05	51200716	39	25	51200774	49	10	51200820	57	13
51200655	23	06	51200717	39	28	51200775	49	11	51200821	57	15
51200656	23	07	51200718	39	29	51200776	49	12	51200822	57	16
51200657	23	16	51200719	39	32	51200777	51	05	51200823	57	17
51200658	23	20	51200720	39	34	51200778	101	13	51200824	57	18
51200659	23	21	51200721	39	35	51200778	109	01	51200825	57	19
51200660	23	36	51200722	39	40	51200778	51	09	51200826	58	01
51200661	23	37	51200723	39	42	51200779	101	12	51200827	58	02
51200662	23	39	51200724	39	45	51200779	109	02	51200828	58	03
51200663	23	40	51200726	39	46	51200779	51	10	51200829	58	13
51200664	23	10	51200727	39	47	51200780	51	15	51200830	58	15
51200665	24	—	51200728	39	48	51200781	51	16	51200830	58	16
51200666	27	02	51200729	39	50	51200782	51	17	51200831	58	16
51200667	27	04	51200730	41	01	51200783	51	20	51200832	58	19
51200668	27	10	51200731	41	02	51200783	65	09	51200833	59	01
51200669	27	11	51200732	43	02	51200784	53	01	51200834	59	03
51200670	27	13	51200733	43	03	51200785	53	03	51200834	59	05
51200671	27	17	51200734	43	04	51200786	53	05	51200834	59	07
51200671	29	01	51200734	47	03	51200786	55	10	51200835	59	09
51200672	27	—	51200734	53	08	51200786	55	15	51200836	59	11
51200672	33	—	51200735	43	10	51200788	53	11	51200837	59	12
51200673	27	—	51200736	43	13	51200789	55	01	51200838	59	15
51200674	29	02	51200736	58	11	51200789	55	02	51200839	59	18
51200675	29	04	51200737	43	18	51200789	61	01	51200840	59	19
51200677	29	06	51200738	43	21	51200790	55	03	51200841	59	21
51200678	29	07	51200739	43	24	51200791	55	11	51200842	61	02
51200679	29	08	51200740	43	26	51200792	55	12	51200843	61	03
51200679	51	19	51200740	45	11	51200793	55	16	51200844	61	05
51200679	65	08	51200740	51	21	51200794	55	17	51200845	61	07
51200680	29	09	51200741	43	27	51200795	55	18	51200846	61	08
51200681	29	11	51200742	43	28	51200796	55	21	51200847	61	11
51200682	29	12	51200743	43	29	51200796	56	23	51200848	61	12
51200683	29	13	51200744	43	30	51200796	59	13	51200849	61	14
51200684	29	14	51200745	43	31	51200796	59	16	51200849	99	17
51200685	29	15	51200746	45	01	51200797	55	22	51200850	63	01
51200686	29	16	51200747	45	02	51200797	56	24	51200851	63	03
51200687	29	17	51200747	51	22	51200798	55	23	51200852	63	05
51200688	29	18	51200747	99	23	51200798	56	19	51200853	63	06
51200689	29	19	51200748	45	06	51200798	59	20	51200854	63	07
51200690	29	20	51200749	45	09	51200799	56	01	51200855	63	08
51200691	29	23	51200750	45	13	51200800	56	02	51200856	63	12
51200692	29	24	51200750	58	12	51200801	56	03	51200857	63	13
51200693	31	02	51200751	45	14	51200801	65	04	51200858	63	16
51200694	31	03	51200752	45	17	51200802	56	04	51200859	63	17
51200695	31	06	51200753	45	18	51200803	56	06	51200860	63	18
51200696	31	07	51200754	45	19	51200804	56	08	51200861	65	01
51200697	31	08	51200755	46	03	51200805	56	09	51200862	65	02
51200698	31	10	51200756	46	04	51200805	57	03	51200863	105	27
51200701	35	06	51200757	46	07	51200806	56	10	51200863	65	05
51200702	107	01	51200758	46	08	51200807	56	15	51200864	67	01
51200702	116	01	51200759	47	01	51200808	56	15	51200865	67	02
51200702	35	09	51200760	47	02	51200808	56	16	51200866	67	03
51200703	35	—	51200761	47	07	51200809	56	17	51200867	67	04
51200704	37	02	51200762	47	15	51200809	57	20	51200868	67	05
51200705	37	07	51200763	47	16	51200809	65	07	51200869	67	09
51200706	39	01	51200764	47	17	51200810	56	18	51200870	67	10
51200707	39	05	51200765	49	01	51200812	56	21	51200871	67	17

Numerical Index

MT 5519 Telescopic Handler

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
51200872	67	18	51200916	71	23	51200961	73	29	51202013	76	04
51200873	67	19	51200917	71	23	51200961	79	29	51202014	76	06
51200874	67	20	51200918	71	24	51200962	73	30	51202015	76	08
51200875	67	00	51200918	77	10	51200962	79	30	51202016	77	01
51200875	67	21	51200919	71	25	51200963	73	31	51202017	77	02
51200876	67	00	51200920	71	26	51200963	79	31	51202018	77	08
51200876	67	22	51200921	71	27	51200964	73	32	51202019	77	09
51200877	68	01	51200922	71	27	51200964	79	32	51202020	77	13
51200878	68	02	51200923	71	27	51200965	73	33	51202021	77	15
51200879	68	03	51200924	71	28	51200965	79	33	51202022	77	15
51200880	68	04	51200925	71	29	51200966	73	34	51202023	77	22
51200880	71	47	51200926	71	30	51200966	79	34	51202024	77	25
51200881	68	05	51200927	71	31	51200967	73	38	51202025	79	44
51200882	68	05	51200928	71	32	51200967	79	38	51202026	81	13
51200883	69	04	51200929	71	33	51200968	73	39	51202026	85	08
51200884	71	01	51200930	71	34	51200968	79	39	51202027	81	13
51200885	71	02	51200931	71	35	51200969	73	40	51202027	85	08
51200886	71	03	51200932	71	36	51200969	79	40	51202028	81	16
51200887	71	04	51200933	71	37	51200970	73	41	51202029	81	18
51200888	71	06	51200934	71	38	51200970	79	41	51202030	81	20
51200888	77	05	51200935	71	40	51200971	73	42	51202031	81	22
51200889	71	07	51200936	71	41	51200971	79	42	51202032	81	00
51200889	77	03	51200937	71	43	51200972	73	43	51202033	81	00
51200890	71	08	51200938	71	44	51200972	79	43	51202034	81	11
51200891	71	09	51200939	71	45	51200973	73	48	51202035	81	01
51200891	77	07	51200940	103	23	51200973	79	48	51202035	83	01
51200892	71	09	51200940	112	06	51200974	73	50	51202036	83	05
51200892	77	07	51200940	71	46	51200975	73	51	51202037	83	06
51200893	71	10	51200941	71	48	51200976	73	56	51202038	83	03
51200893	77	06	51200942	71	49	51200976	75	03	51202038	84	07
51200894	71	10	51200943	73	01	51200976	79	56	51202038	87	13
51200894	77	06	51200943	79	01	51200977	75	01	51202039	83	08
51200895	71	10	51200944	73	03	51200978	75	02	51202039	93	02
51200895	77	06	51200944	79	03	51200979	75	03	51202040	84	01
51200896	71	11	51200945	73	04	51200981	75	04	51202040	85	01
51200897	71	12	51200945	79	04	51200982	75	05	51202041	84	05
51200897	77	11	51200946	73	05	51200983	75	05	51202042	84	06
51200898	71	12	51200946	79	05	51200984	75	06	51202042	87	15
51200898	77	11	51200947	73	06	51200985	75	06	51202043	84	08
51200899	71	12	51200947	79	06	51200986	75	06	51202043	87	14
51200899	77	11	51200948	73	07	51200987	75	06	51202044	84	12
51200900	71	12	51200948	79	07	51200988	75	06	51202045	85	09
51200900	77	11	51200949	73	08	51200989	75	07	51202046	85	13
51200901	71	13	51200949	79	08	51200990	75	07	51202047	85	14
51200901	77	12	51200950	73	12	51200991	75	07	51202048	87	01
51200902	71	14	51200950	79	12	51200992	75	08	51202049	87	03
51200903	71	14	51200951	73	12	51200993	75	09	51202051	87	16
51200904	71	15	51200951	79	12	51200994	75	10	51202052	89	03
51200904	77	14	51200952	73	12	51200995	75	11	51202053	89	05
51200905	71	16	51200952	79	12	51200996	75	14	51202054	105	01
51200906	71	16	51200953	73	13	51200997	75	17	51202054	105	15
51200907	71	17	51200953	79	13	51200998	75	18	51202054	89	06
51200907	77	16	51200954	73	14	51200999	75	19	51202054	89	07
51200908	71	17	51200954	79	14	51201000	75	20	51202055	89	09
51200908	77	16	51200955	73	15	51202001	75	22	51202055	91	15
51200909	71	18	51200955	79	15	51202002	75	23	51202056	105	—
51200909	77	17	51200956	73	16	51202003	75	24	51202056	89	—
51200910	71	19	51200956	79	16	51202004	75	25	51202056	91	—
51200910	77	18	51200957	73	19	51202005	75	26	51202056	93	—
51200912	71	20	51200957	79	19	51202006	75	27	51202056	95	—
51200912	75	21	51200958	73	20	51202007	75	28	51202057	91	02
51200912	77	19	51200958	79	20	51202008	75	29	51202058	91	03
51200913	71	21	51200959	73	23	51202009	75	30	51202059	105	02
51200913	77	20	51200959	79	23	51202010	75	31	51202059	105	14
51200915	71	22	51200960	73	28	51202011	75	32	51202059	91	06
51200915	77	21	51200960	79	28	51202012	75	33	51202059	91	07

MT 5519 Telescopic Handler

Numerical Index

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
51202060	91	08	51202102	99	33	51202153	113	02	51202212	133	01
51202061	91	09	51202103	105	28	51202154	115	01	51202213	135	01
51202062	91	16	51202103	99	34	51202155	115	02	51202214	135	01
51202063	91	17	51202104	105	19	51202156	115	03	51202215	135	19
51202064	93	05	51202104	99	36	51202157	115	04	51202216	135	20
51202065	105	21	51202105	105	20	51202158	115	05	51202217	135	21
51202065	105	22	51202105	99	37	51202159	115	06	51202218	140	01
51202065	93	07	51202106	101	01	51202160	115	07	51202219	145	09
51202065	93	08	51202106	105	08	51202161	115	08	51202220	141	01
51202066	93	09	51202107	101	02	51202162	115	09	51202221	141	01
51202067	105	25	51202107	109	04	51202163	115	10	51202289	39	09
51202067	93	11	51202108	101	05	51202164	115	11	51202290	65	10
51202068	105	23	51202108	111	01	51202165	115	12	51202291	117	04
51202068	93	12	51202109	103	01	51202166	115	14	51202292	137	14
51202069	93	16	51202110	103	03	51202167	115	15	51202293	137	22
51202070	93	17	51202111	103	04	51202168	115	16	808020	142	00
51202071	93	19	51202112	103	06	51202169	115	17	808021	142	00
51202072	93	20	51202112	110	11	51202170	115	18	808027	143	01
51202073	105	04	51202113	103	08	51202171	115	19	808029	143	06
51202073	105	12	51202114	103	20	51202172	115	20	808030	143	05
51202073	93	24	51202115	103	21	51202173	115	21	808031	143	11
51202074	93	27	51202116	103	22	51202174	115	00	808031	145	03
51202075	105	03	51202116	112	01	51202175	115	00	808032	143	12
51202075	105	13	51202117	103	24	51202176	115	00	808033	143	15
51202075	95	03	51202118	103	25	51202177	115	00	808033	144	02
51202075	95	04	51202119	103	28	51202178	115	00	808033	145	01
51202076	95	05	51202120	103	29	51202179	115	00	808034	144	03
51202077	95	06	51202121	105	06	51202180	121	00	808035	143	14
51202078	95	13	51202121	107	03	51202181	121	01	808036	144	01
51202079	97	01	51202122	105	09	51202182	121	02	808037	143	02
51202080	108	08	51202122	107	12	51202183	121	03	808038	145	06
51202080	108	09	51202124	103	03	51202184	121	04	808038	87	08
51202080	97	06	51202125	107	06	51202184	123	04	808043	142	00
51202081	107	14	51202126	107	10	51202185	121	05	808044	142	00
51202081	97	08	51202127	107	11	51202185	123	05	808047	144	04
51202082	103	16	51202128	107	08	51202186	121	06	808054	144	05
51202082	97	09	51202128	107	09	51202186	125	06	808055	145	04
51202083	97	13	51202129	108	05	51202187	125	06	808057	144	06
51202083	97	16	51202129	109	07	51202188	121	07	808058	145	07
51202083	97	23	51202129	118	—	51202188	137	21	808059	143	03
51202084	97	14	51202130	108	07	51202189	121	10	808060	143	04
51202085	101	08	51202130	109	08	51202190	123	00	808062	143	09
51202085	97	15	51202131	108	13	51202191	123	01	808064	145	02
51202086	97	17	51202132	108	17	51202192	123	02	808071	130	07
51202087	97	18	51202133	108	02	51202192	125	02	808073	09	15
51202088	101	09	51202134	109	09	51202192	127	08	808074	09	15
51202088	97	19	51202135	110	02	51202193	123	03	808076	107	—
51202089	101	10	51202136	110	03	51202194	123	07	808076	68	—
51202089	97	20	51202137	110	04	51202195	123	08	808086	21	22
51202090	101	07	51202138	110	05	51202196	125	00	808086	23	28
51202090	97	21	51202139	110	06	51202197	125	01	808089	17	24
51202091	97	22	51202140	110	07	51202198	125	03	808089	47	12
51202092	97	25	51202140	112	02	51202199	125	04	808094	23	11
51202093	97	26	51202141	110	08	51202200	125	05	808097	21	20
51202094	103	19	51202142	110	09	51202201	125	07	808097	23	26
51202094	97	32	51202143	110	10	51202202	125	10	808099	35	10
51202095	99	06	51202144	111	02	51202203	127	00	808137	21	12
51202096	99	07	51202145	111	03	51202204	127	01	808137	23	13
51202097	103	27	51202146	111	04	51202205	127	02	808177	73	46
51202097	99	15	51202147	111	05	51202206	127	04	808177	79	46
51202098	99	20	51202148	112	03	51202207	127	05	808180	73	47
51202099	99	22	51202149	112	04	51202208	127	06	808180	79	47
51202100	99	23	51202150	112	05	51202209	127	07	808238	21	03
51202101	99	24	51202151	112	07	51202210	127	09	808239	21	04
51202102	105	29	51202152	113	01	51202211	133	01	808239	23	19

Numerical Index

MT 5519 Telescopic Handler

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
808246	21	02	808471	13	03	808589	108	02	808779	99	32
808252	19	03	808471	27	12	808595	13	02	808786	87	05
808253	19	10	808479	17	15	808595	47	05	808787	87	06
808255	15	20	808481	15	16	808595	81	19	808789	97	02
808257	07	17	808482	07	29	808596	140	04	808796	134	10
808258	07	18	808483	07	30	808598	37	04	808796	135	10
808262	35	05	808483	15	05	808599	67	14	808796	137	16
808295	105	16	808484	07	28	808600	07	13	808796	95	17
808295	99	30	808484	21	21	808600	07	19	808797	81	02
808303	21	01	808484	39	30	808607	45	05	808800	81	05
808306	07	36	808485	15	08	808607	67	06	808804	108	14
808310	21	21	808486	15	14	808612	47	06	808811	87	04
808310	23	34	808487	15	18	808616	139	04	808822	139	05
808313	73	45	808488	15	17	808619	140	03	808823	139	08
808313	79	45	808489	23	12	808625	37	05	808824	139	06
808318	24	01	808490	15	01	808626	139	02	808826	139	20
808320	17	07	808490	19	02	808627	107	04	808832	84	11
808320	17	23	808490	21	09	808627	135	23	808832	95	12
808321	17	—	808490	23	03	808629	46	09	808834	129	00
808321	47	—	808491	15	04	808630	39	36	808834	139	16
808324	24	03	808491	19	05	808633	87	07	808835	37	12
808325	24	04	808491	21	07	808644	135	16	808840	17	17
808327	21	20	808491	23	09	808645	91	10	808844	31	09
808327	23	26	808492	07	05	808661	135	14	808862	07	09
808341	13	04	808493	07	05	808661	137	11	808876	67	16
808343	37	13	808495	15	07	808661	21	21	808877	107	04
808344	13	—	808496	24	08	808662	84	09	808877	117	01
808347	17	—	808498	45	12	808663	21	14	808880	84	04
808347	47	—	808498	47	14	808665	134	18	808880	91	12
808352	24	05	808498	58	14	808665	47	04	808881	84	03
808360	115	13	808498	61	06	808665	89	02	808881	91	11
808394	11	01	808500	11	14	808666	07	32	808889	13	01
808394	11	03	808500	11	15	808672	07	—	808890	81	21
808395	11	07	808506	129	06	808674	39	33	808891	07	00
808395	11	08	808516	71	05	808675	39	07	808892	11	10
808395	11	09	808516	73	02	808677	07	11	808892	11	11
808396	11	27	808516	79	02	808687	134	06	808897	49	09
808411	24	06	808525	73	11	808689	140	02	808899	37	06
808411	25	12	808525	79	11	808692	81	12	808901	13	—
808412	24	09	808543	73	10	808692	85	02	808902	81	06
808412	25	05	808545	07	19	808693	134	09	808905	108	02
808418	67	13	808545	07	26	808693	81	09	808921	09	06
808419	21	05	808545	43	17	808693	85	07	808922	09	03
808419	23	14	808552	76	05	808696	137	18	808923	09	11
808420	15	02	808555	21	30	808700	81	14	808923	09	12
808420	19	07	808561	17	22	808700	85	03	808924	09	09
808420	23	18	808562	17	13	808703	108	11	808926	09	07
808421	15	03	808563	17	19	808707	51	18	808927	09	08
808421	33	11	808564	17	06	808710	134	11	808947	61	04
808422	15	06	808565	17	20	808710	139	18	808955	113	01
808422	19	06	808568	17	05	808714	108	10	808955	127	07
808422	21	06	808569	17	08	808714	119	00	808965	128	10
808422	23	17	808570	17	21	808714	39	04	809046	73	09
808424	83	04	808571	17	18	808720	128	02	809046	76	07
808424	87	02	808572	17	12	808720	130	03	809046	79	09
808429	135	24	808573	17	14	808727	139	09	809050	69	01
808431	133	03	808574	17	10	808727	84	10	809050	76	01
808431	137	05	808576	11	29	808727	95	14	809053	77	04
808432	35	03	808577	11	28	808728	139	11	809064	119	02
808435	35	01	808579	129	03	808729	39	15	809065	119	05
808436	35	02	808579	130	06	808733	07	16	809066	119	07
808437	47	03	808580	129	02	808734	07	24	809106	43	22
808438	09	13	808581	129	01	808735	11	25	809112	108	05
808438	09	14	808586	35	04	808756	134	21	809130	35	06
808439	53	02	808589	07	31	808763	107	13	809136	128	04
808466	39	26									

MT 5519 Telescopic Handler

Numerical Index

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
809152	118	03	809492	81	02	813514	33	10	813659	39	41
809153	118	03	809493	95	11	813516	27	01	813664	97	27
809154	113	02	809493	99	27	813516	33	07	813664	99	12
809155	121	08	809494	21	31	813517	33	05	813667	97	10
809155	125	09	809494	23	22	813531	61	10	813677	43	11
809165	24	05	809494	23	42	813549	134	07	813678	53	10
809177	07	12	809531	87	10	813549	23	35	813678	97	28
809180	15	—	809531	93	23	813549	35	08	813697	39	37
809180	39	20	809535	134	12	813549	81	23	813700	135	11
809180	39	45	809535	135	12	813550	107	02	813704	103	10
809181	108	05	809543	128	00	813550	108	16	813708	56	11
809181	135	22	809543	134	17	813560	35	07	813711	89	04
809181	15	—	809543	135	17	813570	39	45	813711	91	05
809181	99	05	809545	134	20	813570	46	05	813711	93	21
809182	17	—	809546	87	09	813570	55	13	813712	97	24
809183	17	—	809547	134	15	813574	39	03	813713	27	16
809184	21	10	809547	135	15	813574	46	01	813746	103	26
809184	21	26	809548	134	18	813591	29	21	813749	99	08
809184	23	43	809548	135	18	813591	39	38	813839	103	07
809185	21	21	809548	137	10	813591	41	—	813839	97	31
809185	23	31	809549	128	10	813591	41	04	813839	99	19
809186	21	21	809638	119	02	813591	46	02	813844	101	04
809186	23	27	809650	128	08	813591	47	03	813844	99	10
809187	21	22	809660	97	10	813591	49	07	813849	13	09
809188	21	22	809661	128	01	813591	55	06	813849	134	08
809188	23	29	809662	128	03	813591	67	07	813849	135	08
809190	11	04	809663	128	12	813591	85	10	813849	39	02
809195	37	10	809664	128	05	813596	97	05	813849	41	05
809198	40	03	809665	128	06	813597	103	18	813849	49	06
809198	67	12	809666	128	07	813597	105	05	813849	53	09
809207	63	15	809669	134	01	813597	137	13	813849	85	11
809251	139	10	809670	134	01	813597	97	07	813849	91	19
809252	139	15	809691	133	02	813598	37	11	814029	29	22
809253	139	17	809691	134	02	813602	39	18	814029	81	10
809254	139	19	809691	135	02	813608	37	01	814202	43	20
809276	139	08	809691	137	02	813609	37	03	814206	56	07
809288	47	08	809692	133	02	813610	07	11	814211	137	19
809291	144	10	809692	134	02	813610	105	26	814211	85	05
809291	43	15	809692	135	02	813610	105	27	814233	91	18
809306	143	08	809694	09	05	813610	21	29	814291	56	12
809313	40	04	809742	39	31	813610	23	25	814291	89	08
809317	15	12	809743	105	26	813610	37	08	814300	108	01
809318	07	03	809790	108	03	813610	47	13	814308	105	10
809319	07	02	809827	05	03	813610	49	09	814308	93	06
809320	07	33	809829	97	10	813612	07	20	814322	99	26
809320	15	09	809880	47	10	813613	07	21	814326	103	11
809321	07	35	813337	46	10	813614	07	22	814344	55	08
809321	15	10	813338	101	06	813615	37	26	814382	39	17
809322	19	09	813357	07	23	813616	37	27	814394	99	16
809323	19	08	813360	47	09	813617	37	28	814414	99	25
809324	19	01	813367	33	15	813629	39	08	814452	105	11
809325	15	19	813369	43	19	813630	39	11	814461	109	10
809351	24	01	813374	07	37	813632	07	—	814469	103	15
809405	139	01	813376	07	39	813651	39	27	814469	93	27
809406	140	—	813377	07	40	813651	43	12	814479	108	04
809407	128	09	813378	07	38	813656	137	04	814495	99	09
809407	129	04	813379	07	—	813656	23	15	814517	53	06
809439	73	27	813379	09	10	813656	43	23	814532	117	02
809439	79	27	813389	23	04	813657	43	05	814647	134	18
809445	73	26	813417	23	41	813657	45	03	814650	139	07
809445	79	26	813430	23	38	813657	51	08	814679	45	07
809480	116	02	813433	21	32	813657	51	23	814679	63	04
809482	134	06	813433	23	33	813657	97	04	818169	73	36
809482	135	06	813465	11	23	813657	99	02	818169	79	36
809486	81	03	813469	07	25	813658	39	13			

	PAGE
A	
Accelerator Pedals	.27
A/C Compressor	.27, 29
A/C Dryer	.27
Air Cleaner Assembly	.63
Air Filter	.7, 63
Air Heater, Engine	.56
Air Restrictor Indicator	.63
Alternator	.57
Arm Rest Pad	.07
Attachment Carriage	.135
Axle	.67, 73, 79
B	
Back-Up Alarm	.49
Backwall, Engine Compartment	.45
Battery	.51
Battery Box/Air Intake	.51
Battery Cable	.51
Bellows, Seat	.37
Belly Pan, Engine	.46
Belt, A/C Compressor	.5, 29
Belt, Fan/Alternator	.5, 57
Bevel Gear, Differential	.71, 77
Blanket, Exhaust Manifold	.65
Block Heater, Engine	.57
Boom Light	.81
Boom, Inner	.84, 85
Boom, Outer	.81, 83
Boot	.35
Bottle, Dual-Pump Washer	.17
Bottle, Overflow	.61
BOWL, FUEL/WATER Separator	.05
Brake Disc	.75
Brake Lever Weldment	.39
Brake Pedal Weldment	.39
Brake Valve Assembly	.119
Bucket Weldmnt	.141
C	
Cab	.07
Cab Door, One-Piece	.21
Cab Door, Two-Piece	.23
Can/Terminate Receptacle	.11
Cap, Fuel Fill	.53
Cap, Hydraulic Fill	.97
Cap, Steering Wheel	.35
Carriage, Weldment	.133
Catalytic Muffler	.65
Change-Over Relay	.11
Check Valve	.113, 115
Check Valve, Cold Start	.99
Clamp, Shifter	.35
Clear Cover, Diode Pack	.11
Clip, Window	.07

	PAGE
Clutch Disc	.71
Cold Control Switch	.25
Column, Steering	.35
Condenser, A/C	.27, 33
Control Valve, Hydraulic	.91, 93, 95, 110, 115
Control, Temperature	.24
Coupler Set	.95
Coupling, Air Restrictor	.63
Cover	.21, 23, 71, 77, 119
Cover, Electrical	.58
Cutting Edge, Weld-On	.141
Cylinder, Extend	.127
Cylinder, Fork-Shift	.129, 139
Cylinder, Lift	.121
Cylinder, Rotating-Carriage	.128, 135, 137
Cylinder, Slave	.123
Cylinder, Steer	.68
Cylinder, Tilt	.125
 D	
Decal Kit	.142
Decal, A/C Heater Control	.25
Decal, Dynattach Unlocked	.87
Decal, Heat Control	.24
Decal, Hot Surface	.43
Differential Carrier	.71
Diode Pack	.11
Dipstick Assembly, Engine Oil	.56
Display, Can & Instruments	.9
Door	.21
Door Hinge	.23
Door Restraint Strap	.21
Door Retainer	.23
Door, Bottom	.23
Door, Top	.23
Drain, Fuel/Water Separator	.05
Drain, Radiator	.61
Driveshaft	.67
Dynattach Weldment	.87
 E	
ECU	.58
Electrical Mount	.58
Engine	.57
Engine Oil Analysis Kits	.5
Evacuator Valve	.63
Evaporator/Heater Coil	.25, 27
Exhaust Deflector	.43
Exhaust Shield	.43
Expansion Valve	.25
Extend Cyl. Support	.85
Extend Cylinder	.127

F

Fan Guard	.61
Fan, Engine Cooling	.57
Fan, Hvac	.25
Fender	.67
Filter Cover, Hvac	.25
Filter, Air	.5
Filter, Cab Air	5, 25
Filter, Engine Oil	5, 56
Filter, Fuel	5, 55
Filter, Fuel/Water Separator	.05
Filter, Hydraulic Oil	5, 99
Flex Plate	.59
Fluid Level Sight Gauge	.97
F-N-R Shifter	.35
Fork Shaft Bar	.133
Fork Slide Coupler	.139
Fork, Carriage	.131
Fork-Shift Cylinder	.129, 139
Front Cover, Frame	.47
Fuel Access Latch	.49
Fuel Filter	.55
Fuel Pump, Electric	.55
Fuel Tank Access Cover	.49
Fuel Tank Weldment	.53
Fuel/Water Separator Assembly	.55
Fuse	.11
Fuse Block W/Cover	.11, 58
Fuse Panel/Joystick Cover	.7

G

Gas Spring, Hood	.43
Gasket, Cap	.97
Gasket, Exhaust	.65
Gasket, Fill Neck	.97
Gasket, Fuel Sender	.53
Gasket, Rubber	.97
Glass, Front	.15
Glass, Left Rear	.19
Glass, Lower Door	.21, 23
Glass, Rear	7, 15
Glass, Right Hand	.07
Glass, Top	.19
Glass, Upper Door	.21, 23
Grill, Defroster	.24
Grill, Vent	.25

H

Handle, Door	.21, 23
Head Light	.13
Heat Shield	.51
Heater Assembly	.24
Heater Hose	.31
Heater-A/C Solenoid	.31
Hinge, Window	.15

	PAGE
Hood, Engine Cover	43
Hood, Rear	43
Horn, 12vdc	47
Hose, Air Intake	63
Hose, Fuel	55
Hose, Overflow	25
Hose, Radiator	61
Hose, Remote Oil Filter	56
HVAC Assembly	25
Hydraulic Drive Assembly	110
Hydraulic Drive Motor	112
Hydraulic Fill Weldment	97
Hydraulic Filter	5, 99
Hydraulic Pump	101, 103, 111
 I	
Inching Valve	39, 1103
Inclinometer-Angle Indicator	81
Indicator, Frame Level	7
Inner Boom Weldment	84, 85
Instrument Panel	24
Isolation Manifold	113
 K	
Key	21, 23, 43
 L	
Latch	23, 43
Latch Release, Interior	21, 23
Lift Cylinder	121
Light Bracket	81
Louver	24, 25
Lube Chart	143
 M	
Magnetic Plug	69, 71, 76
Manifold, Brake	108
Manifold, Tank Level	97
Micro Relay	11
Mirror	7, 47
Module, A/C Control	25
Module, F-N-R Shifter	35
Module, Shifter	11
Motor, Hydrostatic Drive	103
Motor, Steer	35, 107
Mount, Engine	59
Muffler	65
 O	
Oil Drain Cover	46
Oil Filter Adapter	56
Outer Boom Weldment	81, 83

P

Pad, Boom Slide	.81
Pad, Pedal	.39
Paint	.142
Panel	.7, 9, 25,
Parking Brake Valve	.108, 118
Pintle Hook	.140
Pressure Override Valve	.110
Pulley, A/C Crank	.29

Q

Quick Coupler Set	.135, 137, 139
-------------------	----------------

R

Radiator Cap	.61
Radiator/Cooler	.61, 99
Rectifier Pack	.25
Relay	.11, 25, 33, 58
Resistor Block	.24
Return Spring	.39
Rim, Wheel	.67
Ring Gear	.73, 79
Rotate Carriage, Weldmnt	.137
Rotating-Carriage Cylinder	.128, 135, 137

S


Screen, Window Opening (Right Side)	.7
Seat	.37
Sender, Fuel Level	.53
Sender, Oil Pressure	.58
Sender, Water Temperature	.58
Sensor, Throttle	.39
Shifter	.35
Sight Glass, Gauge	.97
Slave Cylinder	.123
Starter Air Plenum	.65
Starter, Engine	.57
Steer Cylinder	.68
Steer Select Valve	.107, 117
Steering Adjust Bolt	.79
Steering Wheel	.35
Strap, Ground	.51
Striker	.21, 23, 43
Strobe Light, Amber	.7
Switch, Binary	.27
Switch, Cold Control	.25
Switch, Filter Restriction	.99
Switch, Hazard Lights	.9
Switch, Ignition	.9
Switch, Lights	.9
Switch, Park Brake	.9
Switch, Pressure 150 Psi	.108
Switch, Push-Button Horn	.9
Switch, Push-Button Starter	.9
Switch, Steer Mode	.9

	PAGE
Switch, Strobe	.9
Switch, Strobe Light	.7
Switch, Turn Signals	.9
Switch, Two Speed	.9
Switch, Variable Speed	.24, 25
Switch, Wiper/Washer	.9
 T	
Tail Light	.13
Temperature Switch	.103
Test Port	.101, 109
Test Port Coupler	.51
Throttle Pedal	.39
Tie Rod, Axle	.68
Tilt Cylinder	.125
Tire	.67
Tow Pin	.49
Truss Boom	.140
Turn Signal Flasher	.11
 U	
U-Bolt	.7
Universal Joint	.67, 73, 79
 V	
Valve, Control	.89, 105
Valve, Master Cylinder	.39, 108
Valve, Park Brake	.109
Valve, Slave Isolation	.93, 105
Valve, Steer Select	.107
Valve, Water	.24
Vent	.71, 73, 79
 W	
Washer Bottle, with Pumps	.47
Wheel Hub	.73, 79
Wheel Stud	.73, 79
Wheel Well Guard	.45
Window Guard, Front	.41
Window Guard, Top	.41
Wiper Arm	.17
Wiper Motor	.17
Wire Harness, A/C	.27, 33
Wire Harness, Boom Lights	.81
Wire Harness, Canopy	.11
Wire Harness, Engine	.11
Wire Harness, Fnr Shifter	.35
Wire Harness, Frame	.11
Wire Harness, Head Light	.11, 13
Wire Harness, Lights	.13
Wire Harness, Strobe	.7
Wire Harness, Washer Bottle	.17, 47
Wire Harness, Wiper	.17
Work Light	.81


REFERENCE

O-RING TABLES


O-Ring Table — Male Boss Fittings

	Fitting Thread Size	Diameter "A"	Diameter "B"	Part Number
	9/16 - 18	0.468	0.078	51200605
	3/4 - 16	0.644	0.087	51200606
	7/8 - 14	0.755	0.097	51200607
	1-1/16 - 12	0.924	0.116	51200608
	1-5/16 - 12	1.171	0.116	51200609
	1-5/8 - 12	1.475	0.118	51200610
	A/C #6	0.312	0.453	51200047
	A/C #8	0.437	0.578	51200049
	A/C #10	0.562	0.703	51200051

O-Ring Table — Air Conditioning Fittings

	A/C Fitting	Diameter "A"	Diameter "B"	Part Number
	A/C #6	0.312	0.453	51200047
	A/C #8	0.437	0.578	51200049
	A/C #10	0.562	0.703	51200051

O-Ring Table — Face Seal Fittings

	Fitting Thread Size	Tube O.D.	Diameter "A"	Thickness "B"	Part Number
	9/16 - 18	1/4	0.301	0.070	50300165
	11/16 - 16	3/8	0.364	0.070	50300166
	13/16 - 16	1/2	0.489	0.070	50300167
	1-14 - 14	5/8	0.614	0.070	51200611
	1-13/16 - 12	3/4	0.739	0.070	51200612
	1-7/16 - 12	1	0.926	0.070	50300168

REFERENCE ADAPTER (FITTINGS) TORQUE GUIDE

Use these torque values when tightening hydraulic, fuel, or coolant adapters (fittings).

SAE "O-Ring" Boss (Steel) Adapters					
Size		Pounds-Force Foot (lb.-ft.)		Newton Meter (N-m)	
Dash	Fractional	Minimum	Maximum	Minimum	Maximum
-3	3/16	8	10	11	13
-4	1/4	14	16	19	21
-5	5/16	18	20	24	27
-6	3/8	24	26	32	35
-8	1/2	50	60	68	81
-10	5/8	72	80	97	108
-12	3/4	125	135	170	183
-14	7/8	160	180	216	244
-16	1	200	220	271	298
-20	1-1/4	210	280	285	380
-24	1-1/2	270	360	366	488

JIC 37° and 45° (Machined or Flared) Adapters					
Size		Pounds-Force Foot (lb.-ft.)		Newton Meter (N-m)	
Dash	Fractional	Minimum	Maximum	Minimum	Maximum
-4	1/4	10	11	13	15
-5	5/16	13	15	17	20
-6	3/8	17	19	23	26
-8	1/2	34	38	46	51
-10	5/8	50	56	68	78
-12	3/4	70	78	95	106
-16	1	94	104	127	141
-20	1-1/4	124	138	168	187
-24	1-1/2	156	173	211	234
-32	2	219	243	297	329

REFERENCE

METRIC BOLT TORQUE GUIDE

Use these torque values when tightening hardware—excluding: lock nuts, thread-forming, self-tapping, and metal screws—unless otherwise specified.

Grade 8.8		Grade 10.9		Grade 12.9	
-----------	---	------------	---	------------	---

Metric Coarse-Pitch Thread	All torque values are in Foot-Pounds and Newton Meters (Nm).				
	DIN 912, DIN 931, DIN 933, etc...			DIN 7984	
	8.8	10.9	12.9	8.8	10.9
M5	4.1 (5.5)	6 (8)	7 (10)	4 (5)	5 (7)
M6	7 (10)	10 (14)	13 (17)	6.3 (8.5)	9 (12)
M8	18 (25)	26 (35)	31 (42)	15 (20)	22 (30)
M10	33 (45)	48 (65)	59 (80)	30 (40)	44 (59)
M12	64 (87)	81 (110)	108 (147)	51 (69)	74 (100)
M14	100 (135)	133 (180)	170 (230)	81 (110)	118 (160)
M16	155 (210)	203 (275)	258 (350)	125 (170)	184 (250)
M18	207 (280)	302 (410)	354 (480)	181 (245)	254 (345)
M20	302 (410)	420 (570)	509 (690)	251 (340)	361 (490)
M22	406 (550)	575 (780)	686 (930)	339 (460)	487 (660)
M24	524 (710)	738 (1000)	878 (1190)	435 (590)	620 (840)
M27	767 (1040)	1092 (1480)	1305 (1770)	642 (870)	922 (1250)
M30	1047 (1420)	1482 (2010)	1770 (2400)	885 (1200)	1254 (1700)

Metric Fine-Pitch Thread	All torque values are in Foot-Pounds and Newton Meters (Nm).				
	DIN 912, DIN 931, DIN 933, etc...			DIN 7984	
	8.8	10.9	12.9	8.8	10.9
M8X1.0	18 (25)	27 (37)	32 (43)	16 (22)	24 (32)
M10X1.0	37 (50)	55 (75)	65 (88)	32 (43)	48 (65)
M10X1.25	36 (49)	52 (71)	61 (83)	31 (42)	46 (62)
M12X1.25	64 (87)	96 (130)	111 (150)	55 (75)	81 (110)
M12X1.5	61 (83)	92 (125)	107 (145)	53 (72)	77 (105)
M14X1.5	100 (135)	148 (200)	173 (235)	89 (120)	129 (175)
M16X1.5	155 (210)	229 (310)	266 (360)	133 (180)	195 (265)
M18X1.5	232 (315)	332 (450)	391 (530)	199 (270)	284 (385)
M20X1.5	325 (440)	465 (630)	538 (730)	277 (375)	391 (530)
M22X1.5	435 (590)	620 (840)	723 (980)	369 (500)	524 (710)
M24X2.0	546 (740)	789 (1070)	922 (1250)	465 (630)	664 (900)
M27X2.0	811 (1100)	1143 (1550)	1328 (1800)	679 (920)	959 (1300)
M30X2.0	1106 (1500)	1586 (2150)	1844 (2500)	959 (1300)	1364 (1850)

REFERENCE

SAE BOLT TORQUE GUIDE

Use these torque values when tightening hardware—excluding: lock nuts, thread-forming, self-tapping, and metal screws—unless otherwise specified.

NOTE: All torque values are in foot-pounds (lb.-ft.), except those marked with asterisks (*), which are in inch-pounds (lb.-in.). To convert lb.-ft. to Newton Meter (Nm)—metric—torque values, multiply the lb.-ft. value by 1.355, or for inch pounds, multiply the lb.-in. value by 0.113.

Unified National Thread	Grade 2 		Grade 5 		Grade 8 	
	Dry	Oiled	Dry	Oiled	Dry	Oiled
8-32	19*	14*	30*	22*	41*	31*
8-36	20*	15*	31*	23*	43*	32*
10-24	27*	21*	43*	32*	60*	45*
10-32	31*	23*	49*	36*	68*	51*
1/4-20	66*	50*	9	75*	12	9
1/4-28	76*	56*	10	86*	14	10
5/16-18	11	9	17	13	25	18
5/16/24	12	9	19	14	25	20
3/8-16	20	15	30	23	45	35
3/8-24	23	17	35	25	50	35
7/16-14	32	24	50	35	70	55
7/16-20	36	27	55	40	80	60
1/2-13	35	35	75	55	110	80
1/2-20	40	40	90	65	120	90
9/16-12	55	55	110	80	150	110
9/16-18	60	60	120	90	170	130
5/8-11	75	75	150	110	220	170
5/8-18	85	85	180	130	240	180
3/4-10	130	130	260	200	380	280
3/4-16	150	150	300	220	420	320
7/8-9	125	125	430	320	600	460
7/8-14	140	140	470	630	660	500
1-8	190	190	640	480	900	680
1-14	210	210	710	530	1000	740

* Value shown is in pound-force inch (lb.-in.)—inch pounds.

Manitou Americas, Inc.
One Gehl Way
P. O. Box 179
West Bend, WI 53095-0179 U.S.A