

MINI EXCAVATOR

ViO17U

PREFACE

(1). This parts catalog is for Yanmar crawler excavator VIO17 for Europe.

(2). This parts catalog does not contain the technical data needed for service.

The illustrations used in this parts catalog have been simplified for clarification.

The content of this parts catalog is subject to change without prior notice.

Be sure to use only Yanmar genuine spare-parts. If imitation parts are used, it may cause machine defects.

(3). How to read this parts catalog: Parts change may be made without prior notice.

- Pos | Position number. The position number is in accordance with the position number on the illustration.

- Parts Number | The Parts Number is the identification number of the parts.

- ~|> | The first serial number of machine using this parts.

- >|~ | The last serial number of machine using this parts.

- Description | The name of the parts. Some parts can have a wrong translation.

- I. | Interchangeability. In the case where a part change took place, one of the following interchangeability marks is indicated for that part.

N: Old --> New, New part is interchangeable for Old Part but not interchangeable conversely

Q: Old <-- New, New part is not interchangeable for Old Part but not interchangeable conversely

R: Old <--> New, New Part is interchangeable for Old and vice versa.

S: Old <-X-> New, New Part is not interchangeable for Old and vice versa.

F: Interchangeable only by set.

K: Change only in quantity used.

- Q. | Quantity.

- R. | Remarques

- S. | If the box is empty, the part is not saleable.

- P. | The page where you can find the details for this modules.

(4). You will find some abbreviation.

AC	Accumulator
BC	Boom Cylinder
CV	Control valve
DB	Drain Bloc
FM	Flange Manifold
HP	Hydraulic Pump
HT	Hydraulic Tank
LR	Left Remote Control Valve
LPT	Low Pressure Te
LPB	Low Pressure Bloc
OC	Oil Cooler
O	Option
PB	Pressure Bloc
RR	Right Remote Control Valve
SC	Swing Cylinder
SJ	Swivel Joint
3W-T	Three way Te
TM	Turning Motor

	VIO17	
1	EQUIPMENTS	6
1.1	ANTI-THEFT DEVICE	
1.1.1	KEYBOARD ANTI-THEFT	7
1.1.2	KEY IGNITION	8
1.1.3	GPS LOCALISER	9
1.2	SEAT	
1.2.1	PVC SEAT	10
1.3	QUICK COUPLING	
1.3.1	AYR	11
1.3.2	FASTER	12
1.4	UNDER CARRIAGE	
1.4.1	CRAWLER	13
1.5	CABIN / CANOPY	
1.5.1	CANOPY(ROPS)	14
2	VEHICLE	15
2.1	LABEL	16
2.2	SAFETY LABEL	17
2.3	SILENSER	18
2.4	AIR CLEANER	19
2.5	ACCELERATOR LEVER	20
2.6	ENGINE MOUNT	21
2.7	RADIATOR & MOUNT	22
2.8	FUEL TANK	23
2.9	FUEL LINE	24
2.9.1	SEPARATOR, WATER	26
2.10	BATTERY	27
2.11	ELECTRIC PART(ENGINE)	28
2.12	ELECTRIC PART(SEAT MOUNT)	29
2.13	ELECTRIC PART(START SWITCH)	30
2.14	WORK LAMP	31
2.15	SPROCKET & ROLLER	32
2.16	IDLER & ADJUST	33
2.17	CONTROL EQUIPMENT(LOCK LEVER & STAND)(RIGHT)	34
2.18	CONTROL EQUIPMENT(LOCK LEVER & STAND)(LEFT)	35
2.19	CONTROL EQUIPMENT(TRAVEL LEVER)	36
2.20	CONTROL EQUIPMENT(BLADE LEVER)	37
2.21	CONTROL EQUIPMENT(VARIABLE LEG LEVER)	38
2.22	CONTROL EQUIPMENT(SWING PEDAL)	39
2.23	CONTROL EQUIPMENT(LOW-HIGH PEDAL)	40
2.24	CONTROL EQUIPMENT(P.T.O. PEDAL)	41
2.25	ARM REST	42
2.26	CONTROL VALVE PLATE	43
2.27	TRACK FRAME	44
2.28	TURNING FRAME & TURNING BEARING	45


2.29	COVER(LOWER)	46
2.30	COVER(TURNING FRAME UNDER)	47
2.31	COVER(HOSE)	48
2.32	COVER(SEAT MOUNT)	49
2.33	COVER(SIDE)	50
2.34	STEP	51
2.35	INSTRUMENT PANEL	52
2.35.1	PANEL	53
2.36	SEAT PLATE	54
2.37	SEAT MOUNT	55
2.38	BONNET	56
2.39	HYD.OIL PUMP & JOINT	57
2.40	BOOM CYLINDER	59
2.41	ARM CYLINDER	61
2.42	BUCKET CYLINDER	62
2.43	SWING CYLINDER	63
2.44	BLADE CYLINDER	64
2.45	VARIABLE LEG WIDEN / SHORTEN CYLINDER	65
2.46	TRAVEL MOTOR	66
2.47	TURNIG MOTOR	67
2.48	ACCUMULATOR	68
2.49	SWIVEL JOINT	69
2.50	CONTROL VALVE(1/7)	70
2.51	CONTROL VALVE(2/7)	71
2.52	CONTROL VALVE(3/7)	72
2.53	CONTROL VALVE(4/7)	73
2.54	CONTROL VALVE(5/7)	74
2.55	CONTROL VALVE(6/7)	75
2.56	CONTROL VALVE(7/7)	76
2.57	REMOTE CONTROL VALVE	77
2.58	STOP VALVE	78
2.59	HYD.OIL TANK	79
2.60	HYD.OIL PIPING(PUMP)	80
2.61	HYD.OIL PIPING(LOWER)	81
2.62	HYD.OIL PIPING(SWIVEL JOINT)	82
2.63	HYD.OIL PIPING(IMP)	83
2.64	HYD.OIL PIPING(TURNING MOTOR)	84
2.65	HYD.OIL PIPING(SWING CYLINDER)	85
2.66	HYD.OIL PIPING(RESERVOIR)	86
2.67	HYD.OIL PIPING(RETURN)	87
2.68	HYD.OIL PIPING(CONTROL VALVE)	88
2.69	HYD.OIL PIPING(P.T.O.)	89
2.70	CONTROL PIPING(1)	90
2.71	CONTROL PIPING(2)	91
2.72	GREASING	92

2.73	BOOM BRACKET	93
2.74	BOOM	94
2.75	ARM	95
2.76	BUCKET ARM & LINK	96
2.77	BUCKET PIN	97
2.78	BLADE	98
2.79	S-J EXCHANGE KIT	99
2.80	S-J HOSE CHANGE KIT	100
2.81	WEIGHT ASSY	101
3	ENGINE 3TNV70-XBV	102
3.1	CYLINDER BLOCK	103
3.2	GEAR HOUSING	104
3.3	FLYWHEEL HOUSING & L.O. SUMP	105
3.4	CYLINDER HEAD & BONNET	106
3.5	EXHAUST MANIFOLD	108
3.6	CAMSHAFT & DRIVING GEAR	109
3.7	CRANKSHAFT & PISTON	110
3.8	LUB.OIL SYSTEM	111
3.9	COOLING WATER SYSTEM	112
3.10	FUEL INJECTION PUMP	113
3.11	GOVERNOR	115
3.12	FUEL INJECTION VALVE	117
3.13	STARTING MOTOR	118
3.14	GENERATOR	119
3.15	GASKET SET & TOOLS	120
3.16		121
4	MAINTENANCE KIT	122
4.1	SERVICE KIT 50H VIO17	122
4.2	SERVICE KIT 250H/750H VIO17	122
4.3	SERVICE KIT 500H VIO17	122
4.5	SERVICE KIT 1000H+ VIO17	122

I EQUIPMENT


1.1.1

EQUIPMENTS > ANTI-THEFT DEVICE > KEYBOARD
ANTI-THEFT



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	222170-40000			SPRING WASHER 4	2		✓
2	264500-40102			BOLT 4* 10	2		✓
3	172AYA-17720			G'TEL MODCOD50	1		✓
4	172AYA-17770			GTEL, SEAL	1		✓
5	17AA64-17750			G'TEL BRACKET ASSY	1		✓
7	222170-40000			SPRING WASHER 4	2		✓
9	172AYA-17700			G'TEL REL 9000	1		✓
10	172AYA-17710			G'TEL, BRACKET	1		✓
11	172AYA-17790			BRACKET MED & G'TEL	1		✓

EQUIPMENTS > ANTI-THEFT DEVICE > KEY IGNITION





Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	221371-40000			WASHER M14	1		✓
2	267161-40002			NUT H M14	1		✓
3	172AYV-16680			MED, LED HARNESS	1		✓
4	172AYV-16750			MED, KEY SWICTH	1		✓
5	172AYV-16770			COVER, SWITCH	1		✓
6	172AYV-16780			SPACER	1		✓
7	17AA64-17740			BRACKET MED	1		✓
8	172451-65610			SCREW CBL M6X20	2		✓
9	222170-40000			SPRING WASHER 4	2		✓
10	264500-40102			BOLT 4* 10	2		✓
11	172AYA-17780			MODCOD50 FILM	1		✓
12	172AYV-16850			ANTI-THEFT DEVICE	1		✓

EQUIPMENTS > ANTI-THEFT DEVICE > GPS LOCALISER



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
	172AYV-80000			BRACKET BAUMACO	1		✓
	172AYV-17310			Kit BAUMACO D	1		✓
	172AYV-17410			BAUMACO ANTI-THEFT	1		✓
	172AYV-17430			KEY	2		✓
	172AYV-17440			KEY HARNESS	1		✓
	172AYV-17450			ANTENNA GSM	1		✓
	172AYV-17460			ANTENNA GPS	1		✓
	172AYV-17490			FUSE 3A	1		✓
	172AYV-17520			BUZZER	1		✓
	172AYV-17580			RELAY	1		✓


EQUIPMENTS > SEAT > PVC SEAT



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A59-64000			SEAT ASSY	1		✓
2	172A59-64110			BASE ASSY, SEAT	1		✓
3	222171-00000			SPRING WASHER 10	5		✓
4	261160-80202			BOLT H M	4		✓
5	261161-00202			BOLT H M	5		✓
6	263660-80002			FLANGE NUT H M8	4		✓
10	172A59-64950			BACK REST	1		✓
11	172A59-64960			CUSHION	1		✓
12	172A59-64970			RAIL SET	1		✓
13	172A59-64980			SEAT BELT	1		✓
14	172A59-64990			WEIGHT ADJ KNOB KIT	1		✓


EQUIPMENTS > QUICK COUPLING > AYR

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
27	172AYA-76240			SEAL RING BS1/2	2			☒
28	900122-			COUPLING M1/2	1			☒
29	900123-			COUPLING 1/2	1			☒




EQUIPMENTS > QUICK COUPLING > FASTER


Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
27	172AYA-76240			SEAL RING BS1/2	2		☒	
28	172AYA-76580			COUPLING M1/2	1		☒	
28	172AYA-76590			COUPLING F1/2	1		☒	



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-38600			CRAWLER, RUBBER	2		☒
1	17AA64-38600			CRAWLER ASSY, RUBBER	2	AFTER SALES TRACK	☒



EQUIPMENTS > CABIN / CANOPY > CANOPY(ROPS)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-54150			STOPPER, BOOM BRACKET	1		✓
2	172A64-66280			CANOPY ASSY	1		✓
6	172A64-68250			STUD 21-M20X28	2		✓
7	222171-20000			SPRING WASHER 12	2		✓
8	222172-00000			SPRING WASHER 20	2		✓
9	260141-00302			BOLT W/WASHER M10X30	2		✓
10	260761-20352			BOLT H 10,9 M	2		✓
11	261161-20252			BOLT H M	2		✓
12	260762-00502			BOLT, 20 X 50	2		✓

II

VEHICLE





VIO17 > VEHICLE > LABEL

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	17AA64-03801	M00697		DRIVE SET	Z	1		☒
2	17AA64-03811	M00697		DECORATION SET	Z	1		☒
3	172A59-03820	M00697		LABEL PICTOGRAMME	Z	1		☒




VIO17 > VEHICLE > SAFETY LABEL

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172171-03420	M00697		CAUTION PLATE ASSY	Z	1	




VIO17 > VEHICLE > SILENSER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172A64-11310			PIPE, AIR	1			✓
3	172183-11400			INSULANT,THERMAL	1			✓
4	172A64-11330			SILENCER ASSY	1			✓
5	172A64-11340			CLUMP	1			✓
6	124701-11911			GASKET	1			✓
7	260130-80552			BOLT W/WASHER M 8X55	1			✓
8	260131-00162			BOLT W/WASHER M10X16	3			✓
9	260510-80002			NUT W/WASHER H M	4			✓
10	263660-80002			FLANGE NUT H M8	1			✓

VIO17 > VEHICLE > AIR CLEANER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172448-11500			AIR CLEANER ASSY	1		✓
2	172448-11510			AIR CLEANER, ASSY	1		✓
3	119258-12530			PAN, DUST	1		✓
4	119808-12540			VALVE, UNLOADER	1		✓
5	119655-12560			ELEMENT	1		✓
6	105027-12580			RING	1		✓
7	172A64-11520			HOSE A, AIR CLEANER	1		✓
8	172A64-11530			HOSE B, AIR CLEANER	1		✓
9	230000-60000			CLAMP 60	3		✓
10	260130-80162			BOLT W/WASHER M 8X16	2		✓

VIO17 > VEHICLE > ACCELERATOR LEVER



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-12100			BRACKET,WIRE	1		✓
2	172A64-12140			LEVER ASSY,ACCEL	1		✓
3	172A64-12180			ARM ASSY,ACCEL	1		✓
4	172A64-12200			THROTTLE WIRE	1		✓
5	172498-12250			THROTTLE GRIP	1		✓
6	172113-12522			PIN	1		✓
7	1C6281-52310			PIN 6,COME-OFF SNAP	2		✓
8	221370-60000			WASHER M6	2		✓
9	221371-20000			WASHER M12	1		✓
10	260130-80162			BOLT W/WASHER M 8X16	2		✓
11	261160-80252			BOLT H M	1		✓
12	267160-80002			NUT H M 8	1		✓
13	267561-20002			NUT H M	2		✓
14	933170-01490			SPRING 12	2		✓


VIO17 > VEHICLE > ENGINE MOUNT



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	105425-01690			PLUG M16	1		✓
2	172A64-13100			MOUNT FL,ENGINE	1		✓
3	172A64-13110			MOUNT FR,ENGINE	1		✓
4	172A64-13120			MOUNT ASSY,ENGINE	1		✓
5	172A64-13150			STOPPER F	1		✓
6	172A64-13160			STOPPER R	1		✓
7	172179-13211			ABSORBER, SHOCK	2		✓
8	172447-13260			ABSOBER,SHOCK 290K	1		✓
9	172A55-13700			BLOCK ASSY, DRAIN	1		✓
10	221901-60002			SEAL WASHER 16S	1		✓
11	222171-00000			SPRING WASHER 10	4		✓
12	222171-40000			SPRING WASHER 14	2		✓
13	260131-00202			BOLT	2		✓
14	260131-00252			BOLT W/WASHER M10X25	4		✓
15	260131-00252			BOLT W/WASHER M10X25	3		✓
16	260141-00252			BOLT	8		✓
17	267161-00002			NUT H M10	4		✓
18	267361-40002			NUT H M14	2		✓

VIO17 > VEHICLE > RADIATOR & MOUNT


page 22/142



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-13190			COOLER	1		✓
2A	172A64-13210	MXXXXX		RADIATOR ASSY	W 1		✓
2B	172446-13450	MXXXXX		PLUG, COOLER	W 1		✓
2C	172A64-13220	MXXXXX		COOLER ASSY, OIL	W 1		✓
2D	172A64-13230	MXXXXX		SUPPORT ASSY	W 1		✓
2E	260140-60122	MXXXXX		BOLT W/WASHER M 6X12	W 5		✓
3	172A64-13310			SEAL A	2		✓
4	172A64-13320			SEAL B	1		✓
5	172444-13210			DRAIN PLUG, WATER	1		✓
6	172444-13220			BODY	1		✓
7	121250-49121			PLUG	1		✓
8	243110-00160			O-RING	1		✓
9	172446-13330			ABSOBER,SHOCK	4		✓
10	172A64-13360			SHROUD ASSY(OC	1		✓
12	172456-13480			RUBBER 315	1		✓
13	172A64-13400			BRACKET ASSY,UP	1		✓
14	172A64-13510			PIPE A, WATER	1		✓
15	172A64-13520			PIPE B, WATER	1		✓
16	172A64-13700			DUCT ASSY,OC(GRAY49)	1		✓
17	172638-06710			RUBBER, CUSHION 300	1		✓
18	172A64-13680			SEAL C	1		✓
20	172A64-13760			SEAL A,OC	1		✓
21	172A64-13770			SEAL B,OC	1		✓
22	172A64-13780			SEAL C,OC	1		✓
23	172A64-13790			SEAL D,OC	1		✓
24	172186-13810			PIPE, FUEL	2		✓
25	172186-13820			TUBE	2		✓
27	933168-55770			BAND 146	4		✓
28	119813-44510			TANK ASSY.SUB	1		✓
29	124450-44550			CLAMP, SUB-TANK	1		✓
30	121256-44600			BRACKET, SUB-TANK	1		✓
31	124766-59050			CLAMP 12	4		✓
32	222170-80000			WASHER GROWER 8	2		✓
33	230010-25000			CLAMP 25	2		✓
34	230010-41000			CLAMP 41	2		✓
35	260130-80162			BOLT W/WASHER M 8X16	2		✓
36	260130-80162			BOLT W/WASHER M 8X16	2		✓
37	260140-60122			BOLT W/WASHER M 6X12	5		✓
38	261160-80452			BOLT H M	2		✓

VIO17 > VEHICLE > FUEL TANK


page 23/142



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-14110			FUEL TANK, ASSY	1		✓
2	194151-04141			STRAINER, FUEL	1		✓
3	194151-04150			GASKET	1		✓
4	194250-04301			CAP, TANK	1		✓
6	194250-04321			VALVE, VENT	1		✓
8	172A29-62900			RUBBER PLATE A	3		✓
9	172456-14151			FUEL GAUGE	1		✓
10	172A64-14200			CLAMP ASSY, FUEL	1		✓
12	172A64-14230			PLATE, RUBBER	1		✓
13	172162-14200			GASKET	1		✓
14	172458-14370			SOUCER,FUEL	1		✓
15	172A64-14410			MOUNT ASSY,FUEL OEL	1		✓
16	172455-14470			HOSE (9.5X600	1		✓
17	172171-14610			FUEL PIPE L=260	1		✓
18	124766-59050			CLAMP 12	2		✓
19	224870-80160			PIN 8X16	1		✓
20	230800-13000			CLAMP HOSE 12	1		✓
21	260131-00202			BOLT	3		✓
22	263671-00002			FLANGE NUT H M10	2		✓
23	265570-50122			PAN HEAD SCREW M	5		✓
23	260220-50122	MZZZZZ		PAN HEAD SCREW W/WASHER	N 5		✓
24	172126-16540			CLAMP 10X70	1		✓


VIO17 > VEHICLE > FUEL LINE

page 24/142




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	172186-13810			PIPE, FUEL	1			✓	
2	172186-13820			TUBE	1			✓	
4	933168-55770			BAND 146	2			✓	
5	172A64-14250			HOSE ASSY,FO 260	1			✓	
6	172A64-14260			PIPE,CORRUGATED L180	1			✓	
8	933168-55770			BAND 146	2			✓	
9	172456-14610			FUEL PIPE	1			✓	
10	172456-14620			PIPE,CORRUGATED 1410	1			✓	
12	933168-55770			BAND 146	2			✓	
13	172137-16560			CLAMP	1			✓	
14	172137-16560			CLAMP	2			✓	
15	129612-52100			FUEL PUMP	1			✓	
16	119833-55620			STRAINER ASSY, FUEL	1			✓	
17	104200-55330			SPRING, TAPER VALVE	1			✓	
18	119810-55340			LEVER	1			✓	
19	121254-55510			CUP, STRAINER	1			✓	
20	102103-55520			O-RING	1			✓	
21	110250-55610			RING, RETAINING	1			✓	
22	121250-55620			SPRING	1			✓	
23	119810-55650			ELEMENT	1			✓	
24	104200-55750			SCREW M4	1			✓	
25	243112-40100			O-RING	1			✓	
26	129335-55700			SEPARATOR, WATER	1			✓	26
27	104200-55321			VALVE, TAPER	1			✓	
28	104200-55330			SPRING, TAPER VALVE	1			✓	
29	104200-55341			HANDLE, COCK	1			✓	
30	124064-55510			BOWL, FUEL STRAINER	1			✓	
31	102103-55520			O-RING	1			✓	
32	110250-55610			RING, RETAINING	1			✓	
33	121257-55720			SPRING, SCREEN	1			✓	
34	121257-55731			FLOAT	1			✓	
36	101720-55750			PLUG 6	2			✓	
37	104200-55750			SCREW M4	1			✓	
38	171081-55910			SCREEN	1			✓	
39	234180-60000			GASKET 6	2			✓	
40	243112-40100			O-RING	1			✓	
41	124766-59050			CLAMP 12	12			✓	
42	184015-59130			HOSE	1			✓	
44	184015-59140			TUBE	1			✓	
45	933168-55770			BAND 146	2			✓	
46	184015-59250			HOSE 850	1			✓	
48	184015-59260			PIPE,CORRUGATE L770	1			✓	

VIO17 > VEHICLE > FUEL LINE



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
49	933168-55770			BAND 146	2		✓
50	184014-59650			HOSE 340	1		✓
51	184014-59510			TUBE	1		✓
53	933168-55770			BAND 146	2		✓
54	261160-80652			BOLT H M	1		✓
55	222170-80000			WASHER GROWER 8	1		✓
56	222170-80000			WASHER GROWER 8	1		✓
57	260140-60162			BOLT W/WASHER M 6X16	2		✓
58	261160-80652			BOLT H M	1		✓


VEHICLE > FUEL LINE > SEPARATOR, WATER




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
18	129335-55700			SEPARATOR, WATER	1			☒	
19	104200-55321			VALVE, TAPER	1			☒	
20	104200-55330			SPRING, TAPER VALVE	1			☒	
21	104200-55341			HANDLE, COCK	1			☒	
22	124064-55510			BOWL, FUEL STRAINER	1			☒	
23	102103-55520			O-RING	1			☒	
24	110250-55610			RING, RETAINING	1			☒	
25	121257-55720			SPRING, SCREEN	1			☒	
26	121257-55731			FLOAT	1			☒	
28	101720-55750			PLUG 6	2			☒	
29	104200-55750			SCREW M4	1			☒	
30	171081-55910			SCREEN	1			☒	
31	234180-60000			GASKET 6	2			☒	
32	243112-40100			O-RING	1			☒	

VIO17 > VEHICLE > BATTERY


Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172458-16110			BATTERY	1			✓
2	172725-16160			ROD	2			✓
3	194940-64750			CLAMP,BATTERY	1			✓
4	221570-60000			WASHER LL 6	2			✓
5	267160-60002			NUT H M 6	4			✓



VIO17 > VEHICLE > ELECTRIC PART(ENGINE)




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	172A64-16101			CORD ASSY,BATTERY (+	1			✓	
3	172458-16140			HARNESS C	1			✓	
3	172A64-16120	M/#01843	-	HARNESS, F	N	1		✓	
4	172A64-16501			HARNESS (A), WIRE	1			✓	
4-1	172A64-16502	M02841	-	HARNESS ASSY, A	N	1		✓	
4A	1A7130-51130	MZZZZZ	-	DIODE, 1.5A	W	1		✓	
5	172112-16650			CLAMP(B)	2			✓	
6	172460-16700			STAY A	1			✓	
7	221370-80000			WASHER	1			✓	
8	224172-00250			COTTER PIN 2.0X25	1			✓	
9	260131-00162			BOLT W/WASHER M10X16	1			✓	
10	260131-00162			BOLT W/WASHER M10X16	2			✓	
11	260131-00162			BOLT W/WASHER M10X16	2			✓	
12	267160-80002			NUT H M 8	1			✓	
13	933168-55770			BAND 146	3			✓	
14	933171-15801			WIRE, EARTH	1			✓	
15	172A64-16131			HARNESS, BAT. MINUS	1			✓	
16	260131-00202			BOLT	1			✓	
17	1A7347-51200	M02841	-	METAL CLIP	W	2		✓	
18	221371-00000	M02841	-	WASHER M10	W	3		✓	
19	260140-80202	M02841	-	BOLT	W	1		✓	




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-16551			HARNESS (B), WIRE	1		✓
1-1	172A64-16552	M01797		HARNESS ASSY, B	S 1	CHANGE REF.NO.1-1 WITH REF.NO.32,33 & FIG.36 REF.NO.23.	✓
3	172183-16580			BODY,FUSER	1		✓
4	172183-16590			COVER	1		✓
6	172447-17140			HOUSING	1		✓
7	172447-17150			FUSE 40A	1		✓
8	294201-50000			FUSE	4		✓
9	172183-16550			BRACKET,FUSE	1		✓
10	172A64-17120			BRACKET ASSY,ELC	1		✓
10	172A64-17121	M/# 01435		BRACKET ASSY,ELC	N 1		✓
11	172446-14250			RUBBER PLATE	1		✓
13	119247-77100			RELAY, SAFETY	3		✓
14	119653-77710			LIMITER,CURRENT	1		✓
15	119650-77910			RELAY, GROW	2		✓
18	129211-77920			TIMER	1		✓
19	221370-60000			WASHER M6	2		✓
20	260130-60122			BOLT W/WASHER M 6X12	4		✓
21	260130-80162			BOLT W/WASHER M 8X16	3		✓
22	260140-60122			BOLT W/WASHER M 6X12	3		✓
23	260140-60162			BOLT W/WASHER M 6X16	1		✓
24	260140-60252			BOLT W/WASHER M 6X25	2		✓
25	261160-60162			BOLT H M6x16	2		✓
26	194464-52190			SWITCH	1		✓
27	194151-57100			HORN	1		✓
28	260140-60162			BOLT W/WASHER M 6X16	2		✓
29	267761-80002			NUT H M18	1		✓
30	194464-52190			SWITCH	2		✓
31	267761-80002			NUT H M18	2		✓
32	124970-77920	M01797		TIMER, GLOW PLUG	W 1	CHANGE REF.NO.1-1 WITH REF.NO.32,33 & FIG.36 REF.NO.23.	✓
33	260140-60202	M01797		BOLT W/WASHER M 6X20	W 1	CHANGE REF.NO.1-1 WITH REF.NO.32,33 & FIG.36 REF.NO.23.	✓

VIO17 > VEHICLE > ELECTRIC PART(START SWITCH)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172187-17100			SWITCH,STARTER	1		✓
2	172187-17070			HARNEES, KEY SWITCH	1		✓
3	172187-17080			COVER	3		✓
4	172187-17090			COVER	2		✓
6	933110-00301			KEY ASSY	1		✓
7	172A64-17250			SOCKET ASSY	1		✓

VIO17 > VEHICLE > WORK LAMP




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172448-16550			HARNESS,BOOM LAMP	1			✓
2	172A64-172101			BRACKET, WORKING LAMP	1			✓
2	172A64-17210-Y M07001			BRACKET,WORK LAMP	S 1			✓
3	172156-17401			WORKING LAMP, ASSY	1			✓
4	172156-17420			BULB 12V-27W	1			✓
5	221170-80000			WASHER Z8	1			✓
6	260130-80162			BOLT W/WASHER M 8X16	1			✓
7	260140-80162			BOLT W/WASHER M 8X 16	4			✓
8	267160-80002			NUT H M 8	1			✓
9	933168-55770			BAND 146	1			✓

VIO17 > VEHICLE > SPROCKET & ROLLER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172A64-29100			SPROCKET	2			✓
2	264501-00252			SOCKET CAP SCREW 10,9 M	16			✓
3	772A64-37300-2			TRACK ROLLER,RUBBER	6			✓
5	172448-37310			SHAFT, ROLLER	6			✓
6	1E6140-73420			SEAL QLF255218, OIL	12			✓
7	222520-00520			CIRCLIP 52	12			✓
8	241010-62054			BALL BEARING	12			✓
9	260131-20252			BOLT W/WASHER M12X25	12			✓
10	933152-03700			WASHER, SIDE CLUTCH	12			✓
11	172A64-37500			SLIDE PLATE ASSY	2			✓
12	260131-00252			BOLT W/WASHER M10X25	4			✓

VIO17 > VEHICLE > IDLER & ADJUST




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-37200			FORK ASSY,IDLER	2		✓
2	172A64-37210			IDLER, ASSY	2		✓
3	172A64-37100			IDLER	2		✓
4	172A64-37120			SHAFT,IDLER	2		✓
5	172A64-37130			FORK L,IDLER	2		✓
6	172A64-37140			FORK R,IDLER	2		✓
7	1A1060-48300			SEAL QLN306213.2,OIL	4		✓
10	222420-00250			SNAP RING 25	2		✓
11	222420-00300			SNAP RING 30	2		✓
12	222520-00620			CIRCLIP 62	4		✓
13	241010-62064			BALL BEARING	4		✓
14	172448-37712			SPRING, ADJUST	2		✓
15	172448-37800			TUBE, ADJUSTER	2		✓
16	172122-37844			VALVE ASSY, NIPPLE	2		✓
21	243150-00140			O-RING	2		✓
22	247610-20000			GREASE NIPPLE	2		✓
23	172137-37850			RING, BACK UP	2		✓
24	243150-00300			O-RING	2		✓
25	260131-00352			BOLT W/WASHER M10X35	8		✓
26	933126-38600			SEAL, DUST	2		✓
27	933171-13691			PLUG PT1/8	2		✓

VIO17 > VEHICLE > CONTROL EQUIPMENT(LOCK
LEVER & STAND)(RIGHT)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	1D4070-23580			KNOB RED M10	1		✓
1-1	172A77-46050	MZZZZZ		GRIP,RED	S 1		✓
2	172165-45970			SPRING	1		✓
3	172A64-46450			LOCK LEVER ASSY,R(49	1	REF.NO.3 = M10 SCREW	✓
3-1	172A64-46451	MZZZZZ		LOCK LEVER ASSY,R(49	F 1	REF.NO.3-1 NO SCREW. TO BE CHANGED WITH REF.NO.17-1.	✓
4	172A64-46470			SHAFT ASSY,R LEVER	1		✓
5	223510-50032			SPRING PIN 5x32	1		✓
6	243110-00210			O-RING	3		✓

VIO17 > VEHICLE > CONTROL EQUIPMENT(LOCK LEVER & STAND)(LEFT)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-46100			LEVER STAND,L (73)	1	W = 41MM.	✓
1-1	172A64-46101	M03318		LEVER STAND ASSY,L	S 1	W = 45MM.	✓
2	172141-41370			BUSH	4		✓
3	172124-46200			O-RING 27X5.7	4		✓
4	172A64-46210			BASE ASSY,LEVER L(73	1		✓
5	172A47-46230			PLATE ASSY,BASE L	1		✓
6	172A47-46310			ROD ASSY,SPRING	1		✓
7	172162-46690			SPRING	1		✓
7	172A69-46270	M02357		SPRING 2.3X15X60	N 1		✓
8	172455-46890			SPRING,GAS	1		✓
9	172165-47550			BUSH	1		✓
10	221370-80000			WASHER	2		✓
11	222720-00070			SNAP RING E 7	1		✓
12	224172-00200			COTTER PIN 2.0X20	2		✓
13	247610-20000			GREASE NIPPLE	1		✓
14	247610-50000			GREASE NIPPLE	1		✓
15	260131-00202			BOLT	3		✓
16	260141-00252			BOLT	2		✓
17	1D4070-23580			KNOB RED M10	1		✓
17-1	172A77-46050	MZZZZZ		GRIP,RED	S 1		✓
18	172A47-46343			LOCK LEVER,L(GRAY:49	1	REF.NO.18 M10 SCREW.	✓
18-1	172A47-46344	MZZZZZ		LOCK LEVER,L(GRAY:49	F 1	REF.NO.18-1 NO SCREW. TO BE CHANGED WITH REF.NO.17-1	✓
19	223510-35040			SPRING PIN 3.5x40	1		✓
20	223510-60040			SPRING PIN 6x40	1		✓


VIO17 > VEHICLE > CONTROL EQUIPMENT(TRAVEL LEVER)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A47-44200			PEDAL (R), TRACK	1		✓
2	172A47-44230			PEDAL (L), TRACK	1		✓
3	261060-80302			FLANGE BOLT H M 8X30	4		✓
4	172141-41340			BOOTS	2		✓
5	172A64-45100			LEVER L,TRACK (49)	1		✓
5-1	172A64-45101	MZZZZZ		LEVER L ASSY,TRACK	S 1		✓
6	172141-41370			BUSH	2		✓
8	172A64-45130			LEVER (R), TRACK	1		✓
8-1	172A64-45131	MZZZZZ		LEVER R ASSY,TRACK	S 1		✓
9	172141-41370			BUSH	2		✓
11	172A64-45200			SHAFT ASSY	1		✓
12	172458-45510-1			BRACKET,BOOT(GRAY:49	1		✓
13	172164-45951			GRIP (L)	1		✓
14	172164-45961			GRIP (R)	1		✓
15	172124-46200			O-RING 27X5.7	3		✓
16	172124-46340			ROD (A), SPOOL	2		✓
17	172122-46590			ROD END 8	2		✓
18	1C6281-52310			PIN 6,COME-OFF SNAP	2		✓
19	221170-80000			WASHER Z8	2		✓
20	221370-80000			WASHER	2		✓
21	247610-20000			GREASE NIPPLE	2		✓
22	260130-80162			BOLT W/WASHER M 8X16	1		✓
23	260130-80162			BOLT W/WASHER M 8X16	2		✓
24	260510-80002			NUT W/WASHER H M	4		✓
25	261160-80404			BOLT H M	4		✓
26	267560-80002			NUT H M	4		✓
27	267561-00002			NUT H M	2		✓
28	933110-54100			PIN 4.75X14	2		✓

2.20


VIO17 > VEHICLE > CONTROL EQUIPMENT(BLADE
LEVER)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-45690			CABLE, BLADE	1		✓
2	172A64-45700			BLADE LEVER ASSY(49)	1		✓
3	172141-41360			BUSH	2		✓
5	172164-45970			GRIP, BLADE	1		✓
6	1C6281-52310			PIN 6,COME-OFF SNAP	2		✓
7	221370-50000			WASHER M5	1		✓
8	261160-80254			BOLT H M	2		✓
9	267560-80002			NUT H M	2		✓
10	933110-54100			PIN 4.75X14	2		✓

2.21

VIO17 > VEHICLE > CONTROL EQUIPMENT(VARIABLE
LEG LEVER)




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	194150-01190			KNOB, THROTTLE LEVER	1				✓
2	172A64-45800			LEVER ASSY, W-N	1				✓
3	172A64-45840			PLATE, LINK	1				✓
4	172A64-45850			LINK ARM ASSY,W-N	1				✓
5	1C6281-52310			PIN 6,COME-OFF SNAP	1				✓
6	221370-80000			WASHER	1				✓
7	223721-00000			SNAP PIN 10	1				✓
8	223721-40000			SNAP PIN 14	1				✓
9	26347-080002			NUT	1				✓
10	933110-54100			PIN 4.75X14	1				✓

2.22


VIO17 > VEHICLE > CONTROL EQUIPMENT(SWING
PEDAL)

page 39/142




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-45280			CABLE,SWING	1		✓
2	172458-45521-1			PEDAL,SWING(GRAY:49)	1		✓
3	172187-45530			SHAFT	1		✓
4	172458-45540-1			COVER,PEDAL(GRAY:49)	1		✓
5	172A64-45650			LINK, ASSY	1		✓
6	172141-41360			BUSH	2		✓
8	172187-45651			SHAFT	1		✓
9	172187-45760			COVER PAD	1		✓
10	172157-45990			BOOTS, PEDAL	1		✓
11	172165-46340			BOLT	2		✓
12	1C6281-52310			PIN 6,COME-OFF SNAP	1		✓
13	221370-80000			WASHER	1		✓
14	221371-00000			WASHER M10	1		✓
15	224172-50200			COTTER PIN 2.5X20	1		✓
16	243110-00210			O-RING	2		✓
17	247610-40000			GREASE NIPPLE	1		✓
18	260510-80002			NUT W/WASHER H M	1		✓
19	260510-80002			NUT W/WASHER H M	1		✓
20	261160-80254			BOLT H M	2		✓
21	267160-80002			NUT H M 8	2		✓
22	933110-54100			PIN 4.75X14	1		✓
23	172614-16520	M/#XXXXX	-	BAND 100	W 1		✓

VIO17 > VEHICLE > CONTROL EQUIPMENT(LOW-HIGH PEDAL)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	1A1040-43900			SPRING WASHER	1		✓
2	172A64-45900			PEDAL ASSY (GRAY:49)	1		✓
3	172141-41360			BUSH	2		✓
5	172458-45950			PAD,PEDAL	1		✓
6	172162-46690			SPRING	1		✓
7	243110-00210			O-RING	2		✓
8	260130-80162			BOLT W/WASHER M 8X16	1		✓


VIO17 > VEHICLE > CONTROL EQUIPMENT(P.T.O. PEDAL)





Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172458-03240			LABEL PEDAL LOCK	1		✓
2	172068-28490			SPRING 8	2		✓
3	172A64-45290			CABLE, PTO	1		✓
4	172448-453801			BRACKET PTO	1		✓
5	172458-45521-1			PEDAL,SWING(GRAY:49)	1		✓
6	172187-45530			SHAFT	1		✓
7	172458-45540-1			COVER,PEDAL(GRAY:49)	1		✓
8	172A64-45650			LINK, ASSY	1		✓
9	172141-41360			BUSH	2		✓
11	172187-45651			SHAFT	1		✓
12	172187-45760			COVER PAD	1		✓
13	172448-45800-3			PLATE,LOCK(PTO (10)	1		✓
14	172157-45990			BOOTS, PEDAL	1		✓
15	172165-46340			BOLT	2		✓
16	1C6281-52310			PIN 6,COME-OFF SNAP	1		✓
17	221370-80000			WASHER	1		✓
18	221370-80000			WASHER	3		✓
19	221371-00000			WASHER M10	1		✓
20	224172-50200			COTTER PIN 2.5X20	1		✓
21	243110-00210			O-RING	2		✓
22	247610-40000			GREASE NIPPLE	1		✓
23	260131-00202			BOLT	2		✓
24	260510-80002			NUT W/WASHER H M	1		✓
25	260510-80002			NUT W/WASHER H M	1		✓
26	261160-80254			BOLT H M	2		✓
27	261160-80604			BOLT H M	1		✓
28	263660-80002			FLANGE NUT H M8	1		✓
29	267160-80002			NUT H M 8	2		✓
30	267570-80002			NUT H M	2		✓
31	933110-54100			PIN 4.75X14	1		✓

VIO17 > VEHICLE > ARM REST

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A59-46510			PLATE, GUIDE (L)	1		✓
2	172A59-46520			PLATE, GUIDE (R)	1		✓
3	172519-63240			BOLT 8X 16	4		✓
4	172441-44320			ARM REST (CUSHION)	2		✓
5	172441-44350			SCREW M8X12	4		✓




VIO17 > VEHICLE > CONTROL VALVE PLATE



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172730-05250			WASHER 13.2X30X3.2	2		✓
2	172A64-45420			VALVE STAND ASSY(49)	1		✓
2	172A64-45421	M/#00977	-	VALVE STAND ASSY(49)	N 1		✓
3	172A64-45580			COLLAR, 17.3X2.3X4	2		✓
4	260131-20252			BOLT W/WASHER M12X25	6		✓

VIO17 > VEHICLE > TRACK FRAME




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	172A64-50200			FRAME,L-CENTER (49)	1		D = 340MM		✓
1	172A64-50201	M/#XXXXX	-	FRAME ASSY,L-CENTER	S	1	D = 330MM		✓
2	172A64-50400			FRAME,CRAWLER L(49)	1				✓
3	172A64-50410			FRAME, CRAWLER (R)	1				✓
4	172A64-50700			BOLT ASSY, STOPPER	4				✓
4	172A64-50701	M/#01272	-	BOLT ASSY, STOPPER	R	4			✓
5	222121-60000			SPRING WAHER 16	4				✓
6	267161-60002			NUT H M16	8				✓

2.28


VIO17 > VEHICLE > TURNING FRAME & TURNING BEARING

page 45/142




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-53300			WEIGHT (GRAY:49)	1		✓
2	172A64-54100			FRAME,TURNING (49)	1		✓
4	172448-54120			SEAL 50X60X4, DUST	2		✓
5	172171-54750			BUSH 50X65	2		✓
6	172A64-54230			SUPPORT, STAND 185	4		✓
7	172176-68210			CLIP, TREE	2		✓
8	221571-40000			WASHER LL14	3		✓
9	222121-60000			SPRING WAHER 16	3		✓
10	247610-50000			GREASE NIPPLE	1		✓
11	261161-60602			BOLT H M	3		✓
12	194940-24350			PIN 10X28, STRAIGHT	3		✓
13	172447-57600			BEARING, REVOLVE	1		✓
15	172149-57610			SEAL SET	1		✓
16	172149-57620			SEAL, UPPER	1		✓
17	172149-17630			TUBE, CORRUGAT	1		✓
18	260761-20252			BOLT H 10,9 M	3		✓
19	260761-20402			BOLT H 10,9 M	14		✓
20	260761-20452			BOLT H 10,9 M	18		✓
21	172444-54920			SEAL,WEIGHT C	2		✓

VIO17 > VEHICLE > COVER(LOWER)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172458-504802			COVER,FRAME(GRAY:49)	2		✓
2	172A64-61500			COVER,MOTOR(GRAY:49)	1		✓
3	172A64-61510			COVER R,MOTOR (49)	1		✓
4	172A64-61520			COVER ASSY,SJ (49)	1		✓
5	260131-00202			BOLT	4		✓
6	260141-00202			BOLT	6		✓
7	261061-00122			BOLT M10X 12 PLATED	4		✓

VIO17 > VEHICLE > COVER(TURNING FRAME UNDER)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-61310			COVER ASSY,C/V (49)	1		✓
2	172A64-61340			UNDER COVER,EX (49)	1		✓
3	172A64-61350			COVER,PUMP (GRAY:49)	1		✓
4	172A64-61360			COLLAR	1		✓
5	221571-00000			WASHER	1		✓
6	261061-00162			FLANGE BOLT H M10X16	2		✓
7	261061-00162			FLANGE BOLT H M10X16	3		✓
8	261061-00162			FLANGE BOLT H M10X16	3		✓
9	261061-00202			FLANGE BOLT H M10X20	1		✓

VIO17 > VEHICLE > COVER(HOSE)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-615501			COVER ASSY,HOSE	1		✓
1	172A64-61550-Y M07001			COVER ASSY, HOSE	S 1		✓
3	172156-78510			SUPPORT, HOSE (A	2		✓
4	172156-78520			SUPPORT, HOSE (B)	1		✓
5	172446-78750-2			CLAMP,HOSE(YELLOW:2J	1		✓
5	172446-78750-Y M07001			CLAMP,HOSE	S 1		✓
6	172446-78760			RUBBER PLATE (A)	2		✓
7	172446-78770			RUBBER PLATE (B)	1		✓
8	221170-80000			WASHER Z8	4		✓
9	221570-80000			WASHER LL 8	4		✓
10	222170-80000			WASHER GROWER 8	4		✓
11	222170-80000			WASHER GROWER 8	1		✓
12	261160-80162			BOLT H M	4		✓
13	261160-80162			BOLT H M	1		✓

VIO17 > VEHICLE > COVER(SEAT MOUNT)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172187-61421			HANDLE,LOCK	1		✓
2	172A64-61610			COVER ASSY,BATTERY	1		✓
3	172A64-61630			PLATE ASSY,COVER(73)	1		✓
4	172A64-61660			COVER ASSY,FO	1		✓
6	172478-65220			RUBBER,20	1		✓
7	172176-67790			PLUG	1		✓
8	172A64-61700			COVER,RES CAP	1		✓
9	172A64-61710			COVER,RADIATOR CAP	1		✓
10	172A64-61820			LOCK PLATE,FO	1		✓
11	172A64-61850			PLATE ASSY,COVER(73)	1		✓
12	260140-80162			BOLT W/WASHER M 8X 16	2		✓
13	260140-80162			BOLT W/WASHER M 8X 16	2		✓
14	172164-66170			KEY ASSY, CYLINDER	1		✓
19	260140-80162			BOLT W/WASHER M 8X 16	2		✓
20	260140-80162			BOLT W/WASHER M 8X 16	4		✓
21	260140-80162			BOLT W/WASHER M 8X 16	2		✓
22	260140-80202			BOLT	4		✓
23	263471-00002			U-NUT M	1		✓


VIO17 > VEHICLE > COVER(SIDE)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-614001			COVER (L) ASSY	1		✓
1	172A64-61400-Y	M07001		COVER L ASSY	S 1		✓
3	172A64-61450			EV A,COVER L	1		✓
4	172A64-61460			EV B,COVER L	1		✓
5	221571-00000			WASHER	2		✓
6	260131-00202			BOLT	2		✓
7	260141-00202			BOLT	2		✓
8	172A64-61260			COVER (R) ASSY	1		✓
8	172A64-61260-Y	M07001		COVER ASSY	S 1		✓
10	172A64-61470			EV A,COVER R	1		✓
11	172445-62010			RUBBER 45, EDGE	1		✓
12	221571-00000			WASHER	2		✓
13	260131-00202			BOLT	2		✓
14	260141-00202			BOLT	2		✓

VIO17 > VEHICLE > STEP

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-62100			STEP ASSY	1		✓
3	172A64-62120			SEAL,STEP	1		✓
4	172A64-62130			EV,STEP	1		✓
5	172448-62400			BOLT 8X35	4		✓
6	172A64-62270			FLOORMAT	1		✓




VIO17 > VEHICLE > INSTRUMENT PANEL



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172187-17280			SWITCH,LIGHT	1		✓
2	172472-17501	M01797		PANEL, INSTRUMENT	Z 1	ANALOGIC TYPE	✓
5	172187-17320			PACKING	1		✓
7	172187-17341			GAUGE ASSY	1		✓
8	172187-17350			METER ASSY, HOUR	1		✓
9	172187-17360			PRINT CIRCUIT	1		✓
10	172187-17371			CIRCUIT, ASSY	1		✓
11	172187-17380			BULB	4		✓
15	172187-17470			PLATE	1		✓
16	172187-17480			BULB	2		✓
17	172187-17560			PLUG	2		✓
18	172187-17570			GASKET	2		✓
19	172A47-63110			IN-PANEL (G)	1		✓
20	172A47-63121			IN-PANEL (R)	1		✓
21	172519-63240			BOLT 8X 16	6		✓
22	228575-00121			SCREW 5X12	4		✓
23	172A77-17250	M01797		PANEL	W 1	LCD TYPE	✓ 53


VEHICLE > INSTRUMENT PANEL > PANEL




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
8	172472-17351			INDICATOR PANEL	1			☒	
11	172187-17280			SWITCH,LIGHT	1			☒	
12	172187-17290			SWITCH, HEATER	1			☒	
13	172472-17300			SWITCH ASSY,WASHER	1			☒	
15	172187-17320			PACKING	1			☒	
17	172187-17341			GAUGE ASSY	1			☒	
19	172187-17360			PRINT CIRCUIT	1			☒	
20	172187-17371			CIRCUIT, ASSY	1			☒	
21	172187-17380			BULB	4			☒	
25	172187-17470			PLATE	1			☒	
26	172187-17480			BULB	2			☒	

VIO17 > VEHICLE > SEAT PLATE

Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	172444-17660			CLIP		2			☒
2	172A64-64100			PLATE ASSY (GRAY:73)		1			☒
4	172A64-64120			EV,SEAT BASE		1			☒
5	172A64-64170			STOPPER,RAIL		1			☒
6	260141-00202			BOLT		3			☒
7	260141-00252			BOLT		1			☒




VIO17 > VEHICLE > SEAT MOUNT




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-64200			MOUNT ASSY,SEAT (73)	1	REF.NO.1 H=260MM	✓
1-1	172A64-64201	M03318		MOUNT ASSY,SEAT	S 1	REF.NO.1-1 H=263MM.	✓
2	172122-17190			CLIP	2		✓
3	172141-41360			BUSH	2		✓
5	172A64-64910			SEAL,600	1		✓
6	172A64-64920			SEAL,480	1		✓
7	172A64-64930			SEAL,240	1		✓
8	172A64-64940			SEAL,560	1		✓
9	172A64-64950			SEAL,1500	1		✓
10	172A64-64960			EV,SEAT MOUNT	1		✓
11	172A64-64710			PIPE,HAND HOLD	1		✓
12	172A64-64730			PIPE,HAND HOLD	1		✓
13	172448-65680			ROLLER CATCH,F	1		✓
14	260131-20302			BOLT W/WASHER M12X30	4		✓
15	260141-00202			BOLT	5		✓
16	265570-40082			PAN HEAD SCREW M	2		✓

VIO17 > VEHICLE > BONNET




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172187-61421			HANDLE,LOCK	1		✓
2	1A1380-62160			WASHER	1		✓
3	172444-64730			ROD STOPPER	1		✓
4	172A64-651001	-		HOOD, ASSY (YELLOW:2J)	1	REF. No.4 = NO HOLES FOR EMBLEM	✓
4-1	172A64-65600-Y M07001			BONNET ASSY Y	S 1	REF. No.4-1 = HOLES FOR EMBLEM	✓
6	172A64-65160			SEAL,1170	1		✓
7	172A64-65170			EV BONNET	1		✓
8	172649-65770			SEAL C, RUBBER	1		✓
9	172A64-65180			PLATE,LOCK	1		✓
10	172A64-65200			MOUNT ASSY,BONNET(73	1		✓
11	172A64-65250			ROCK ASSY	1		✓
12	172164-66170			KEY ASSY, CYLINDER	1		✓
17	221370-80000			WASHER	1		✓
18	224172-00200			COTTER PIN 2.0X20	2		✓
19	260141-00202			BOLT	4		✓
20	260141-00202			BOLT	2		✓
21	263471-00002			U-NUT M	1		✓
22	172A64-03050 30/01/2011			EMBLEM ASSY Y	1		✓

VIO17 > VEHICLE > HYD.OIL PUMP & JOINT




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-71100			MOUNT ASSY,PUMP	1		✓
2	172A64-71210			GUIDE ASSY,HOSE	1		✓
2-1	172A64-71211	M02841		GUIDE ASSY,HOSE	S 1		✓
3	223120-80200			PARALLEL PIN 8x20	2		✓
4	260131-00252			BOLT W/WASHER M10X25	8		✓
5	172448-71200			COUPLING	1		✓
6	264501-00352			SOCKET CAP SCREW 10,9 M	3		✓
7	172A64-73100			PUMP ASSY, PISTON	1		✓
8	178076-12400			PLUG, G1/4	2		✓
9	1E1271-27620			ROTOR SET 13	1		✓
12	168PA0-29010			POWER PISTON SET	1		✓
16	168PA0-29020			COUPLING SET	1		✓
19	1A6750-29850			PLUG	1		✓
20	158802-85040			PIN,PARALLEL(4X14	1		✓
21	168PA0-86010			PORT BLOCK	1		✓
22	168PA0-86020			HOUSING	1		✓
23	168PA0-86030			PACKING	1		✓
24	168PA0-86050			KEY	1		✓
25	168PA0-86060			SHAFT	1		✓
26	168PA0-86140			PLUNGER BLOCK CMP	1		✓
35	168PA0-86210			VALVE PLATE	1		✓
36	168PA0-86290			CRADLE HOLDER CMP	1		✓
42	168PA0-86330			THRUST PLATE	1		✓
43	168PA0-86340			CRADLE (MD-9CA)	1		✓
44	158842-86360			RETAINER	1		✓
45	158842-86610			RETAINER	1		✓
46	158842-86620			RETAINER	1		✓
47	168PA0-86650			SPRING(CRADLE)	1		✓
48	168PA0-86720			BUSHING(17X8)	1		✓
49	168PA0-86730			CONTROL BLOCK	1		✓
50	168PA0-86740			RELIEF VALVE	1		✓
51	168PA0-86750			PLUG (RELIEF VALVE)	1		✓
52	168PA0-86760			SPRING(RELIEF VALVE)	1		✓
53	168PA0-86830			COLLAR (GEAR PUMP)	1		✓
54	168PA0-87010			PUMP COMP.,GEAR	1		✓
55	168PA0-87020			SOLENOID VALVE ASSY	1		✓
56	222520-00420			SNAP RING 42	1		✓
57	222920-00250			CIRCLIP 25	2		✓
58	223120-60120			PARALLEL PIN 6x12	3		✓
59	223120-80160			PARALLEL PIN 8X 16	2		✓
60	241010-60054			BALL BEARING	1		✓

VIO17 > VEHICLE > HYD.OIL PUMP & JOINT




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
61	241622-02620			NEEDLE BEARING	1		✓
62	243110-00110			O-RING	2		✓
62	243150-00110	M/#00977		O-RING 1B P-11.0	N 2		✓
63	243110-00140			O-RING	2		✓
63	243150-00140	M/#00977		O-RING	N 2		✓
64	243110-00220			O-RING	1		✓
64	243150-00220	M/#00977		O-RING	N 1		✓
65	243410-00140			O-RING	4		✓
65	194327-45640	M/#00977		O-RING 1A S-14.0	N 4		✓
66	243410-00630			O-RING	1		✓
67	243410-00670			O-RING	1		✓
68	244212-54208			SEAL TC25 42 08, OIL	1		✓
69	261060-80202			FLANGE BOLT H M 8X20	2		✓
70	264500-80252			SOCKET CAP SCREW 10,9 M	4		✓
71	264500-80352			SOCKET CAP SCREW 10,9 M	3		✓
72	264501-00452			BOLT M10X 45	4		✓
73	267161-00002			NUT H M10	1		✓
74	26979-100452			SCREW, 10 X 45	1		✓
75	260131-20352			BOLT W/WASHER M12X35	2		✓

VIO17 > VEHICLE > BOOM CYLINDER




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	172010-01640			COLLAR		2			✓
2	172137-46042			SPRING WASHER 8		2			✓
3	172A23-72043			SHAFT,14X54		1			✓
4	172A23-72052			GROMMET		1			✓
5	172A64-720501			COVER, BOOM CYLINDER		2			✓
5	172A64-72051-1	M/# 0176		COVER,CYLINDER (2J)	N	2			✓
5	172A64-72051-Y	M07001		COVER,CYLINDER	S	2			✓
6	172A46-72070			SPACER		1			✓
7	172A23-72081			GUIDE		2			✓
8	172A64-721001			BOOM CYLINDER ASS		1			✓
8	172A64-72100-Y	M07001		CYLINDER,BOOM CMP	S	1			✓
9	172A64-72030			SEAL SET,HEAD 60 35		1			✓
16	172A64-72110-1			TUBE ASSY,BOOM (2J)		1			✓
16	172A64-72110-Y	M07001		TUBE ASSY, BOOM	S	1			✓
18	172A64-72190			BUSH,35-45-30		1			✓
19	172448-81610			SEAL 35X45X4		2			✓
20	172A64-72150			ROD, BOOM CYLINDER		1			✓
22	172A64-72190			BUSH,35-45-30		1			✓
23	172448-81610			SEAL 35X45X4		2			✓
24	172A64-722001			ARM CYLINDER ASSY		1			✓
24	172A64-72200-Y	M07001		TUBE ASSY, BOOM	S	1			✓
25	172638-72200			SEAL KIT		1			✓
28	172A64-72230			U-NUT M24X1.5		1			✓
29	172149-72241			HEAD 6035 COMPL.		1			✓
31	245500-35300			BUSH 35X30		1			✓
32	172448-72270			ABSORBER, SHOCK		1			✓
33	172449-72350			COLLAR		1			✓
34	172A20-72430			PISTON 55(24-28)		1			✓
35	172141-76180			FITTING		2			✓
36	243150-00110			O-RING 1B P-11.0		2			✓
37	221371-00000			WASHER M10		1			✓
38	247610-20000			GREASE NIPPLE		1			✓
39	247610-40000			GREASE NIPPLE		1			✓
40	260131-00202			BOLT		1			✓
41	933125-59600			WASHER 60 B, LOCK		1			✓
42	172A64-722501			GUIDE ASSY, 545 (2J)		1			✓
42	172A64-72251	M/# 0176		GUIDE ASSY,545 (2J)	N	1			✓
42	172A64-72251-Y	M07001		GUIDE ASSY,545	S	1			✓
43	172A23-729511			PLATE,SLIDE 585 (2J)		1			✓
43	172A23-72951-Y	M07001		PLATE,SLIDE 585	S	1			✓
44	172A64-82620			PIN 35X110		1			✓
45	172A64-82760			PIN 35X127		1			✓

VIO17 > VEHICLE > BOOM CYLINDER




Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
46	172141-84601			SHIM 35		2			✓
50	221571-00000			WASHER		2			✓
51	222171-00000	M/# 01109		SPRING WASHER 10	Z	1			✓
52	260131-00162			BOLT W/WASHER M10X16		4			✓
53	260131-00252			BOLT W/WASHER M10X25		2			✓
54	260761-00202			BOLT H 10,9 M		2			✓
55	261161-00202			BOLT H M		1			✓
55	260131-00202	M/# 01109		BOLT	N	1			✓
56	264500-60162			SOCKET CAP SCREW 10,9 M		1			✓
56	172A47-72840	M/# 01435		BOLT	N	1			✓
57	933147-03400			WASHER, BRAKE ARM		1			✓
58	933168-14170			SPRING 16		2			✓

VIO17 > VEHICLE > ARM CYLINDER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172137-46042			SPRING WASHER 8	4		✓
2	172A23-72043			SHAFT,14X54	1		✓
3	172A23-72052			GROMMET	1		✓
4	172A46-72070			SPACER	1		✓
5	172A23-72081			GUIDE	2		✓
6	172A64-723001			ARM CYLINDER ASSY	1		✓
6	172A64-72300-Y M07001			CYLINDER ASSY,ARM	S 1		✓
7	172449-72020			SEAL SET HEAD	1		✓
12	172141-72250			U-NUT M27	1		✓
13	172A64-72310-1			TUBE ASSY,ARM (2J)	1		✓
13	172A64-72310-Y M07001			TUBE ASSY, ARM	S 1		✓
15	172149-72440			BUSH A 30X30	1		✓
16	172448-81600			SEAL, DUST	2		✓
17	172449-72321			GASKET RGU55	1		✓
20	172A64-72350			ROD, ARM CYLINDER	1		✓
22	172149-72440			BUSH A 30X30	1		✓
23	172448-81600			SEAL, DUST	2		✓
24	172A64-72390			PISTON,55X27X28	1		✓
25	172449-72410			HEAD ASSY, CYLINDER	1		✓
27	245500-35300			BUSH 35X30	1		✓
28	172173-72550			ROCK WASHER 55	1		✓
29	172141-76180			FITTING	2		✓
30	243150-00110			O-RING 1B P-11.0	2		✓
31	247610-40000			GREASE NIPPLE	1		✓
32	247610-50000			GREASE NIPPLE	1		✓
33	172A64-729001			GUID ASSY,500 (2J)	1		✓
33	172A64-72901-1 MZZZZZ			GUIDE ASSY,500	R 1		✓
33	172A64-72901-Y M07001			GUIDE ASSY,500	S 1		✓
34	172A64-729801			PLATE,SLIDE 520 (2J)	1		✓
34	172A64-72980-Y M07001			PLATE,SLIDE 520	S 1		✓
35	260761-00202			BOLT H 10,9 M	4		✓
36	264500-60162			SOCKET CAP SCREW 10,9 M	1		✓
36	172A47-72840 M/# 01435			BOLT	N 1		✓

VIO17 > VEHICLE > BUCKET CYLINDER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172137-46042			SPRING WASHER 8	2		✓
2	172A23-72043			SHAFT,14X54	1		✓
3	172A23-72052			GROMMET	1		✓
4	172A46-72070			SPACER	1		✓
5	172A23-72081			GUIDE	2		✓
6	172A64-724001			BUCKET CYLINDER ASSY	1		✓
6	172A64-72400-Y	M07001		CYLINDER ,BUCKET	S 1		✓
7	172A64-72040			SEAL SET,HEAD55 30	1		✓
12	172449-72321			GASKET RGU55	1		✓
15	172A64-72410-1			TUBE ASSY,BUCKET(2J)	1		✓
15	172A64-72410-Y	M07001		TUBE ASSY, BUCKET	S 1		✓
17	172149-72440			BUSH A 30X30	1		✓
18	172448-81600			SEAL, DUST	2		✓
19	172A64-72440			PISTON,55X22X28	1		✓
20	172A64-72450			ROD, BUCKET CYLINDER	1		✓
22	172149-72680			BUSH (B) 30X30	1		✓
23	172448-81600			SEAL, DUST	2		✓
24	172A64-72490			U-NUT M22X1.5	1		✓
25	172173-72550			ROCK WASHER 55	1		✓
26	172449-72560			HEAD ASSY, CYLINDER	1		✓
28	245500-30300			BUSH 30X30	1		✓
29	172141-76180			FITTING	1		✓
30	243150-00110			O-RING 1B P-11.0	1		✓
31	233910-20000			FITTING AA04C04Y	1		✓
32	247610-50000			GREASE NIPPLE	1		✓
33	172A64-729501			GUID ASSY,445 (2J)	1		✓
33	172A64-72951-1	MZZZZZ		GUIDE ASSY,445	R 1		✓
33	172A64-72951-Y	M07001		GUIDE ASSY,445	S 1		✓
34	172A64-729801			PLATE,SLIDE 520 (2J)	1		✓
34	172A64-72980-Y	M07001		PLATE,SLIDE 520	S 1		✓
35	222171-00000	M/# 01109		SPRING WASHER 10	Z 1		✓
36	260761-00202			BOLT H 10,9 M	2		✓
37	261161-00202			BOLT H M	1		✓
37	260131-00202	M/# 01109		BOLT	N 1		✓
38	264500-60162			SOCKET CAP SCREW 10,9 M	1		✓
38	172A47-72840	M/# 01435		BOLT	N 1		✓
39	933147-03400			WASHER, BRAKE ARM	1		✓
40	933168-14170			SPRING 16	2		✓

VIO17 > VEHICLE > SWING CYLINDER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-72500			SWING CYLINDER, ASSY	1		✓
2	172449-72040			SEAL SET,HEAD (65-35)	1		✓
7	172141-72250			U-NUT M27	1		✓
8	172A64-72510			TUBE ASSY,SWING (49)	1		✓
10	172448-72650			SEAL 40X50X4	2		✓
11	172458-72740			BUSH	1		✓
12	172A64-72540			PISTON,65X27X31	1		✓
13	172A64-72550			ROD ASSY,SWING	1		✓
14	172168-72410			BUSH 40X50X40	1		✓
16	172448-72650			SEAL 40X50X4	2		✓
17	172142-72560			WASHER 65, LOCK	1		✓
18	172449-72810			ROD END, CMP	1		✓
20	245500-35300			BUSH 35X30	1		✓
21	172449-72960			GASKET RGU65	1		✓
24	233910-20000			FITTING AA04C04Y	2		✓
25	247610-50000			GREASE NIPPLE	1		✓
26	172165-82580			SHIM 40X75X0.5	2		✓
27	172165-82590			SHIM 40X75X1.2	2		✓
28	172165-82600			SHIM 40X75X1.6	2		✓
29	172A64-82650			PIN 40X96	1		✓
30	172A64-82670			PIN ,40X120	1		✓
31	172146-82910			SPACER	1		✓
32	172117-83970-7			PLATE(C),LOCK(GRAY49	1		✓
33	260131-00202			BOLT	2		✓
34	260131-20252			BOLT W/WASHER M12X25	1		✓

VIO17 > VEHICLE > BLADE CYLINDER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-72601			BLADE CYLINDER, ASSY	1		✓
2	172A64-72020			SEAL SET, HEAD 60 30	1		✓
7	172638-72201	M/#01404	-	SEAL KIT	1		✓
7	172638-72200			SEAL KIT	1		✓
10	172A64-72490			U-NUT M22X1.5	1		✓
11	172A64-72610			TUBE ASSY,BLADE (49)	1		✓
12	172149-72440			BUSH A 30X30	1		✓
14	172448-81600			SEAL, DUST	2		✓
15	172A64-72640			PISTON,60X22X28	1		✓
16	172A64-72651			ROD ASSY,BLADE	1		✓
17	172149-72440			BUSH A 30X30	1		✓
19	172448-81600			SEAL, DUST	2		✓
20	172447-72860			HEAD 60 30	1		✓
22	245500-30300			BUSH 30X30	1		✓
23	233910-20000			FITTING AA04C04Y	2		✓
24	933125-59600			WASHER 60 B, LOCK	1		✓
25	172A64-72690			PROTECTOR (GRAY:49)	1		✓
26	260141-00252			BOLT	2		✓

VIO17 > VEHICLE > VARIABLE LEG WIDEN / SHORTEN
CYLINDER




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-50720			PIN,30X95	1		✓
2	172A64-50730			PIN 30X65	1		✓
3	172A64-50770			PLATE,LOCK (GRAY:49)	2		✓
4	172A64-72700			EXTENSION CYLINDER ASSY	1		✓
5	172A64-72040			SEAL SET,HEAD55 30	1		✓
10	172449-72321			GASKET RGU55	1		✓
13	172A64-72490			U-NUT M22X1.5	1		✓
14	172173-72550			ROCK WASHER 55	1		✓
15	172A64-72710			TUBE ASSY,VARIABLE	1		✓
16	172A64-72750			ROD,ASSY,VARIABLE	1		✓
17	172A64-72810			HEAD ASSY, 55 30	1		✓
19	245500-30300			BUSH 30X30	1		✓
20	172A64-72860			PISTON,55	1		✓
21	233910-20000			FITTING AA04C04Y	2		✓
22	260131-00252			BOLT W/WASHER M10X25	4		✓

VIO17 > VEHICLE > TRAVEL MOTOR




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-73300			MOTOR ASSY, TRAVELING	2		✓
2	172A64-73350			GEROLLER ASSY	2		✓
3	172A64-73360			SPINDLE WHEEL ASSY	2		✓
4	172A64-73440			PLUG	2		✓
5	172168-73370			BOLT	8		✓
6	172A64-73380			PLATE,VALVE	2		✓
7	172A64-73390			COVER,ROLLER	2		✓
8	172A64-73400			BOLT,10X80	14		✓
9	172A64-73410			BOLT,8X73	14		✓
10	172A64-73420			COVER,END ASSY	2		✓
11	172A64-73430			VALVE ASSY	2		✓
12	172A64-73450			DRIVE	2		✓
13	172A64-73460			SPACER	4		✓
14	264501-00252			SOCKET CAP SCREW 10,9 M	16		✓
15	172A64-73510			SEAL KIT,TRAVEL M	2		✓
16	172A64-73520			SEAL KIT,END COVER	2		✓

VIO17 > VEHICLE > TURNIG MOTOR




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-73310			MOTOR ASSY, TURNING	1		✓
2	172137-70490			PLUG	2		✓
3	172137-70570			PIN	2		✓
4	172137-70580			SPRING	2		✓
5	172137-70590			PLATE	1		✓
6	172137-70600			VALVE	1		✓
7	172148-73350			PLATE, VALVE	1		✓
8	172173-73520			COLLAR	1		✓
9	172A64-73600			BOLT,8X20	8		✓
10	172A64-73610			DRIVE	1		✓
11	172A64-73620			BOLT	4		✓
12	172A64-73630			ROLLER	1		✓
13	172A64-73640			HOUSING, VALVE ASSY	1		✓
14	172168-73590			PLUG	2		✓
15	238710-10000			PLUG PT 1/8	3		✓
16	172173-73690			SNAP RING	1		✓
17	172173-73700			SNAP RING	1		✓
18	172456-77150			HOUSING, BEARING	1		✓
19	172456-77160			FLANGE, MOUTING	1		✓
20	172456-77170			GEAR	1		✓
21	172456-77180			PISTON ,HYDRAULIC	1		✓
22	172456-77190			RING	1		✓
23	172456-77200			CIRCLIP	1		✓
24	172456-77210			PLATE,FRICTION	6		✓
25	172456-77220			PLATE	7		✓
26	172456-77230			SPRING	8		✓
27	172456-77240			FRONT BEARING	1		✓
28	172456-77250			NEEDLE BEARING	1		✓
29	172141-77260			VALVE DRIVE	1		✓
30	172A64-73660			KIT,SEAL SWING MOTOR	1		✓
45	260131-20402			BOLT W/WASHER M12X40	4		✓

VIO17 > VEHICLE > ACCUMULATOR




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172478-73600			ACCUMULATOR	1		✓
2	172478-73630			CLAMP	1		✓
3	172141-76180			FITTING	1		✓
4	243150-00110			O-RING 1B P-11.0	1		✓
5	172478-76200			FITTING	1		✓
6	172A64-79250			HOSE G504BC030S	1		✓
7	221170-80000			WASHER Z8	2		✓
8	260130-80202			BOLT W/WASHER M8X20	2		✓
9	267160-80002			NUT H M 8	2		✓

VIO17 > VEHICLE > SWIVEL JOINT





Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172448-73840			SWIVEL JOINT ASSY	1		✓
2	172448-73851			SWIVEL,ASSY	1		✓
3	172446-73900			SEAL SET ,SWIVEL	1		✓
4	172142-73800			O-RING 55.76X5.7	2		✓
5	172447-73840			SEAL, SWIVEL	9		✓
6	172148-73870			RING EL, BUCK UP	1		✓
7	243210-00700			O-RING	1		✓
8	172448-73860			HUB,SWIVEL	1		✓
9	172446-73872			SHAFT, SWIVEL	1		✓
12	172446-73890			FLANGE,SWIVEL	1		✓
13	172157-73910			SPACER, SWIVEL	1		✓
14	222420-00401			SNAP RING 40	1		✓
15	238710-10000			PLUG PT 1/8	8		✓
16	260130-80352			BOLT W/WASHER M 8X35	3		✓
17	172448-73900			DUST COVER	1		✓
18	260131-00302			BOLT	3		✓

VIO17 > VEHICLE > CONTROL VALVE(1/7)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-74100			VALVE ASSY,CONTROL	1		✓
2	172A64-74430			SECTION, BOOM LOCK	1		✓
3	172A64-74440			BOOM LOCK SEC ASSY	1		✓
4	172456-74440			OVERLOAD 300/5	1		✓
5	172A64-74450			SECTION, BUCKET	1		✓
6	172456-74280			OVERLOAD 250	1		✓
7	172A64-74460			BUCKET SEC ASSY	1		✓
8	172458-74150			CHECK VALVE	1		✓
9	172458-74160			SPRING,CHECK VALVE	1		✓
10	172458-74230			PACKING S 22	2		✓
11	172458-74240			COVER (B1), PILOT	1		✓
12	172458-74250			COVER (A1), PILOT	1		✓
13	172458-74260			SWP HEX.BOLT 5X20	4		✓
14	172A64-74470			SPOOL ASSY,BUCKET	1		✓
15	172458-74630			PLUG	1		✓
16	243150-00110			O-RING 1B P-11.0	1		✓
17	172A64-74550			BOLT L=412	4		✓
18	172458-74720			PACKING G4	1		✓
19	243110-00180			O-RING	1		✓
20	267160-80002			NUT H M 8	4		✓
21	260131-00162			BOLT W/WASHER M10X16	3		✓



VIO17 > VEHICLE > CONTROL VALVE(2/7)



Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	172A64-74390			SECTION, TRAV. (R)	1				✓
2	172458-74130			SEAL	1				✓
3	172458-74140			BRACKET, OIL SEAL	1				✓
4	172458-74170			CAP,SPRING	1				✓
5	172458-74290			CHECK VALVE	1				✓
6	172A64-74360			SPOOL ASSY,TRAVEL	1				✓
7	172458-74360			SPRING, CHECK VALVE	1				✓
8	172458-74460			PLUG GPM1/32	2				✓
9	172458-74640			STAY, CHECK VALVE	1				✓
10	243110-00120			O-RING	1				✓
11	243150-00110			O-RING 1B P-11.0	1				✓
12	264500-50102			SOCKET CAP SCREW 10,9 M	2				✓
13	264500-50182			BOLT 5* 18	2				✓
14	172A64-74400			SECTION, BOOM	1				✓
15	172462-74340			VALVE ASSY, OVERLOAD	1				✓
16	172A64-74410			BOOM SEC ASSY	1				✓
17	172458-74150			CHECK VALVE	1				✓
18	172458-74160			SPRING,CHECK VALVE	1				✓
19	172458-74230			PACKING S 22	2				✓
20	172458-74240			COVER (B1), PILOT	1				✓
21	172458-74250			COVER (A1), PILOT	1				✓
22	172458-74260			SWP HEX.BOLT 5X20	4				✓
23	172A64-74420			SPOOL ASSY,BOOM	1				✓
24	172458-74630			PLUG	1				✓
25	243150-00110			O-RING 1B P-11.0	1				✓
26	172458-74720			PACKING G4	3				✓
27	243110-00060			O-RING	1				✓
28	243110-00180			O-RING	2				✓
29	243150-00090			O-RING	1				✓
30	243150-00100			O-RING	1				✓



VIO17 > VEHICLE > CONTROL VALVE(3/7)

page 72/142




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-74350			SECTION TRAV. (L)	1		✓
2	172458-74130			SEAL	1		✓
3	172458-74140			BRACKET, OIL SEAL	1		✓
4	172458-74170			CAP,SPRING	1		✓
5	172458-74290			CHECK VALVE	1		✓
6	172A64-74360			SPOOL ASSY,TRAVEL	1		✓
7	172458-74360			SPRING, CHECK VALVE	1		✓
8	172458-74460			PLUG GPM1/32	2		✓
9	172458-74640			STAY, CHECK VALVE	1		✓
10	243110-00120			O-RING	1		✓
11	243150-00110			O-RING 1B P-11.0	1		✓
12	264500-50102			SOCKET CAP SCREW 10,9 M	2		✓
13	264500-50182			BOLT 5* 18	2		✓
14	172A64-74370			SECTION, INLET	1		✓
15	172A64-74380			SUPPLY SEC ASSY	1		✓
16	172458-74230			PACKING S 22	2		✓
17	172458-74240			COVER (B1), PILOT	1		✓
18	172458-74260			SWP HEX.BOLT 5X20	4		✓
19	172458-74530			SEAT, SPRING	1		✓
20	172458-74540			SPRING,RETURN	1		✓
21	172458-74550			COVER (A2), PILOT	1		✓
22	172A64-74480			RELIEF VALVE 210	2		✓
23	172458-74720			PACKING G4	2		✓
24	243110-00060			O-RING	1		✓
25	243110-00180			O-RING	1		✓

VIO17 > VEHICLE > CONTROL VALVE(4/7)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-74260			SECTION, OPTION	1		✓
2	172458-74130			SEAL	1		✓
3	172458-74140			BRACKET, OIL SEAL	1		✓
4	172458-74150			CHECK VALVE	1		✓
5	172458-74160			SPRING,CHECK VALVE	1		✓
6	172458-74170			CAP,SPRING	1		✓
7	172A64-74270			SPOOL ASSY,OPTION	1		✓
8	172458-74630			PLUG	1		✓
9	243110-00120			O-RING	1		✓
10	243150-00110			O-RING 1B P-11.0	2		✓
11	264500-50102			SOCKET CAP SCREW 10,9 M	2		✓
12	264500-50182			BOLT 5* 18	2		✓
13	172A64-74280			SECTION, SWING	1		✓
14	172447-74230			ANTICAVITAION VALVE	1		✓
15	172A64-74290			SWING SEC ASSY	1		✓
16	172458-74130			SEAL	1		✓
17	172458-74140			BRACKET, OIL SEAL	1		✓
18	172458-74150			CHECK VALVE	1		✓
19	172458-74160			SPRING,CHECK VALVE	1		✓
20	172458-74170			CAP,SPRING	1		✓
21	172A64-74300			SPOOL ASSY,SWING	1		✓
22	172458-74630			PLUG	1		✓
23	243110-00120			O-RING	1		✓
24	243150-00110			O-RING 1B P-11.0	1		✓
25	264500-50102			SOCKET CAP SCREW 10,9 M	2		✓
26	264500-50182			BOLT 5* 18	2		✓
27	172458-74720			PACKING G4	2		✓
28	243110-00180			O-RING	2		✓



VIO17 > VEHICLE > CONTROL VALVE(5/7)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-74200			SECTION, PTO	1		✓
2	172A64-74210			PTO SEC ASSY	1		✓
3	172458-74130			SEAL	1		✓
4	172458-74140			BRACKET, OIL SEAL	1		✓
5	172458-74170			CAP, SPRING	1		✓
6	172A64-74220			SPOOL ASSY, PTO	1		✓
7	172490-74310			CHECK VALVE	1		✓
8	172490-74320			SPRING, CHECK VALVE	1		✓
9	172490-74330			STAY, CHECK VALVE	1		✓
10	172458-74650			STAY, CHECK VALVE	2		✓
11	243110-00120			O-RING	1		✓
12	243150-00110			O-RING 1B P-11.0	1		✓
13	243150-00140			O-RING	2		✓
14	264500-50102			SOCKET CAP SCREW 10,9 M	2		✓
15	264500-50182			BOLT 5* 18	2		✓
16	172456-74290			RELIEF VALVE	2		✓
17	172A64-74230			SECTION, ARM	1		✓
18	172447-74230			ANTICAVITAION VALVE	1		✓
19	172A64-74240			ARM SEC ASSY	1		✓
20	172458-74150			CHECK VALVE	1		✓
21	172458-74160			SPRING, CHECK VALVE	1		✓
22	172458-74230			PACKING S 22	2		✓
23	172458-74240			COVER (B1), PILOT	1		✓
24	172A64-74250			SPOOL ASSY, ARM	1		✓
25	172458-74250			COVER (A1), PILOT	1		✓
26	172458-74260			SWP HEX. BOLT 5X20	4		✓
27	172458-74630			PLUG	1		✓
28	243150-00110			O-RING 1B P-11.0	1		✓
29	172462-74340			VALVE ASSY, OVERLOAD	1		✓
30	172458-74720			PACKING G4	2		✓
31	243110-00060			O-RING	1		✓
32	243110-00180			O-RING	1		✓




VIO17 > VEHICLE > CONTROL VALVE(6/7)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-74150			SECTION, CONFLUENCE	1		✓
2	172A64-74160			SECTION, CONFLUENCE	1		✓
3	172A64-74170			CASE,FILTER	1		✓
4	172A64-74180			FILTER	1		✓
5	172A64-74190			RING, 8	1		✓
6	172458-74230			PACKING S 22	2		✓
7	172458-74240			COVER (B1), PILOT	1		✓
8	172458-74260			SWP HEX.BOLT 5X20	4		✓
9	172458-74290			CHECK VALVE	2		✓
10	172458-74360			SPRING, CHECK VALVE	2		✓
11	172458-74530			SEAT, SPRING	1		✓
12	172458-74540			SPRING,RETURN	1		✓
13	172458-74550			COVER (A2), PILOT	1		✓
14	172458-74640			STAY, CHECK VALVE	2		✓
15	172458-74670			PLUG,PF1/8	2		✓
16	243150-00080			O-RING	2		✓
17	243150-00110			O-RING 1B P-11.0	2		✓
18	243152-40100			O-RING 1B P-10A	1		✓
19	172A64-74490			RELIEF VALVE 170	1		✓


VIO17 > VEHICLE > CONTROL VALVE(7/7)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-74110			SECTION, BLADE	1		✓
2	172A64-74120			SPOOL ASSY,BLADE	1		✓
3	172458-74130			SEAL	1		✓
4	172458-74140			BRACKET, OIL SEAL	1		✓
5	172458-74150			CHECK VALVE	1		✓
6	172458-74160			SPRING,CHECK VALVE	1		✓
7	172458-74170			CAP,SPRING	1		✓
8	172458-74630			PLUG	1		✓
9	243110-00120			O-RING	1		✓
10	243150-00110			O-RING 1B P-11.0	1		✓
11	264500-50102			SOCKET CAP SCREW 10,9 M	2		✓
12	264500-50182			BOLT 5* 18	2		✓
13	172A64-74130			SECTION, TURNING	1		✓
14	172A64-74140			SPOOL ASSY,TURNING	1		✓
15	172458-74150			CHECK VALVE	1		✓
16	172458-74160			SPRING,CHECK VALVE	1		✓
17	172458-74230			PACKING S 22	2		✓
18	172458-74240			COVER (B1), PILOT	1		✓
19	172458-74250			COVER (A1), PILOT	1		✓
20	172458-74260			SWP HEX.BOLT 5X20	4		✓
21	172458-74630			PLUG	1		✓
22	243150-00110			O-RING 1B P-11.0	1		✓
23	172458-74720			PACKING G4	2		✓




VIO17 > VEHICLE > REMOTE CONTROL VALVE




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172458-46730			BOLT M6X30	6		✓
2	172A64-74310			REMOTE CONTROL VALVE (L)	1		✓
3	172151-73400			PLUG	4		✓
4	172151-73420			SEAL	4		✓
5	172151-73450			WASHER	4		✓
6	172A64-74590			PLATE	1		✓
7	172A64-74600			ROD,PUSH	4		✓
8	172A64-74610			SEAT,SPRING	4		✓
9	172A64-74620			SPRING	4		✓
10	172A64-74630			SPRING	4		✓
11	172A64-74640			JOINT	1		✓
12	172A64-74650			PLATE,CIRCULAR	1		✓
13	172A64-74660			NUT,ADJUSTING	1		✓
14	172A64-74680			BELLOWS	1		✓
15	172A64-74900			NUT,LOCK	1		✓
16	172A64-74910			LEVER	1		✓
17	172A64-74920			KNOB	1		✓
18	172A64-74930			PIN,SPRING	1		✓
19	243150-00200			O-RING	4		✓
20	172A64-74320			REMOTE CONTROL VALVE (D)	1		✓
21	172151-73400			PLUG	4		✓
22	172151-73420			SEAL	4		✓
23	172151-73450			WASHER	4		✓
24	172151-73610			TERMINAL	2		✓
25	172A64-74590			PLATE	1		✓
26	172A64-74600			ROD,PUSH	4		✓
27	172A64-74610			SEAT,SPRING	4		✓
28	172A64-74620			SPRING	4		✓
29	172A64-74630			SPRING	4		✓
30	172A64-74640			JOINT	1		✓
31	172A64-74650			PLATE,CIRCULAR	1		✓
32	172A64-74660			NUT,ADJUSTING	1		✓
33	172A64-74670			BUSH	1		✓
34	172A64-74680			BELLOWS	1		✓
35	172A64-74900			NUT,LOCK	1		✓
36	172A64-74910			LEVER	1		✓
37	172A64-74920			KNOB	1		✓
38	172A64-74930			PIN,SPRING	1		✓
39	172A64-74940			SLEEVE,INSULATION	2		✓
40	243150-00200			O-RING	4		✓
41	172A78-74650	M/#01400	-	PLATE CMP	1		✓

VIO17 > VEHICLE > STOP VALVE

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-45600			STAY ASSY,VALVE	1		✓
2	172A64-74800			STOP VALVE	1		✓
3	222170-50000			SPRING WASHER 5	2		✓
4	260131-00202			BOLT	2		✓
5	264500-50452			SOCKET CAP SCREW 10,9 M	2		✓




VIO17 > VEHICLE > HYD.OIL TANK




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	772A64-75100			RESERVOIR TANK ASSY	1		✓
2	172A64-73700			FILTER,SUCTION	1		✓
3	172A64-73770			FILTER ASSY,RETURN	1		✓
4	172A64-73780			HYDRAULIC FILTER	1		✓
5	243150-00440			O-RING	1		✓
7	172446-75250			CAP, HYD.OIL TANK	1		✓
8	172447-75600			GAUGE	1		✓
9	172455-75290			BOLT M10	2		✓
10	172455-75300			O-RING	4		✓
13	172116-75850B			PLUG, OIL FEED	1		✓
14	234911-40002			PLUG M8,DRAIN	1		✓
15	243110-00160			O-RING	1		✓
16	243110-00380			O-RING	1		✓
17	260131-20252			BOLT W/WASHER M12X25	3		✓

VIO17 > VEHICLE > HYD.OIL PIPING(PUMP)



Pos.	Parts Number	~ ~>	-> ~	Description	I. Q.	R.	S. P.
1	172730-75141			FITTING	1		✓
2	172124-76100			FLANGE, PUMP INLET	1		✓
3	172141-76180			FITTING	2		✓
4	243150-00110			O-RING 1B P-11.0	2		✓
5	172112-77361			CONNECTOR	2		✓
6	221171-00000			WASHER Z10	4		✓
7	243150-00140			O-RING	1		✓
8	243150-00180			O-RING	2		✓
9	260131-00252			BOLT W/WASHER M10X25	4		✓
10	172A64-78101			HOSE NA, SUCTION	1		✓
11	172A64-78120			HOSE H208BZ059S	1		✓
12	172A64-78130			HOSE H208BZ050S	1		✓
13	172A64-78140			HOSE H206BZ062S	1		✓
14	172A64-78620			HOSE H504CC103S	1		✓
15	230010-41000			CLAMP 41	4		✓
16	243210-00350			O-RING	1		✓
16	243110-00350	M/#XXXXX		O-RING	N 1		✓


VIO17 > VEHICLE > HYD.OIL PIPING(LOWER)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172730-75141			FITTING	4		✓
2	172A64-76101			JOINT G1/8-G1/8	2		✓
4	243150-00080			O-RING	4		✓
5	243150-00140			O-RING	4		✓
6	172A64-78441			HOSE F205BB085W	2		✓
7	172A64-78451			HOSE F205BB089W	2		✓
8	172A64-78470			HOSE F204BX032W	2		✓
9	172A64-78481			HOSE F204BE094W	2		✓
9-1	172A6478482	M/#01435	-	HOSE F204BE094W	1		✓
9A	172A6478460	M/#01435	-	HOSE F204BE082W	1		✓
10	172A64-78492			HOSE P202BB085W	2		✓
11	172A64-78501			HOSE F204BB043W	1		✓
12	172A64-78511			HOSE F204BB059W	1		✓
13	172A64-78520			HOSE P204BC050W	1		✓
14	172A64-78530			HOSE P204BC068W	1		✓


VIO17 > VEHICLE > HYD.OIL PIPING(SWIVEL JOINT)

page 82/142



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172147-76180			ELBOW 90ç 1/4X3/8	4		✓
2	172147-76180			ELBOW 90ç 1/4X3/8	4		✓
3	172162-76320			FITTING T 1/4	1		✓
4	172186-76390			NIPPLE	1		✓
5	233910-20000			FITTING AA04C04Y	3		✓
6	233930-20000			FITTING CA04C04Y	2		✓
7	233930-20000			FITTING CA04C04Y	2		✓
8	233940-20000			FITTING BA04C04Y	4		✓
9	172A64-78211			HOSE G804YY055	1		✓
9	172464-78212	M/#00865	-	HOSE G804YY055	1		✓
10	172A64-78250			HOSE F204BC059	1		✓
11	172A64-78260			HOSE F204BC069	1		✓
11	172A64-78261	M/#01435	-	HOSE F204BC069	1		✓
12	172A64-78310			HOSE F204BC063	2		✓
13	172A64-78350			HOSE F206BC035	1		✓
14	172A64-78360			HOSE F206BC045	1		✓
15	172A64-78371			HOSE F206BC030	1		✓
16	172A64-78380			HOSE F206BC041	1		✓
17	172A64-78612	M/#01435	-	HOSE H504CE052	1		✓
17	172A64-78611	EXXX	-	HOSE H504CE052	1		✓
17	172A64-78610			HOSE H504BC056S	1		✓
18	230000-13000			CLAMP 13	2		✓


VIO17 > VEHICLE > HYD.OIL PIPING(IMP)



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-76200			GUIDE L,HOSE ASSY	1		✓
2	172A64-76240			GUIDE R,HOSE ASSY	1		✓
3	260131-20302			BOLT W/WASHER M12X30	2		✓
4	172A64-78291			HOSE F204BC248R	1		✓
5	172A64-78301			HOSE F204BC198R	1		✓
6	172A64-78391			HOSE F204BC137K	1		✓
7	172A64-78401			HOSE F204BC147K	1		✓
8	172A64-78411			HOSE F204BC303R	1		✓
9	172A64-78421			HOSE F204BC330R	1		✓
10	172A64-78910			COVER, HOSE	1		✓
11	172122-79920			CLAMP	1		✓
12	194202-56460			BAND	2		✓
13	172126-11510			BAND 300	1		✓


VIO17 > VEHICLE > HYD.OIL PIPING(TURNING MOTOR)

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172131-76130			ELBOW,NIPPLE	1			✓
2	172124-76160			FITTING	2			✓
3	172141-76180			FITTING	1			✓
4	243150-00110			O-RING 1B P-11.0	1			✓
5	172487-76200			ELBOW	1			✓
6	243150-00140			O-RING	1			✓
7	243150-00140			O-RING	2			✓
8	172A64-78270			HOSE F204BC059S	2			✓
9	172A64-78651			HOSE F403BC026	1			✓




VIO17 > VEHICLE > HYD.OIL PIPING(SWING CYLINDER)

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172A64-78330			HOSE F204BB090	1		☒	
2	172A64-78340			HOSE F204BC111	1		☒	




VIO17 > VEHICLE > HYD.OIL PIPING(RESERVOIR)

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-76120			JOINT, DRAIN	1		✓
2	172A64-76140			BLOCK, DRAIN	1		✓
3	260130-80202			BOLT W/WASHER M8X20	2		✓
4	233930-30000			FITTING CA06C06Y	1		✓
5	172A64-78231			HOSE G806YY021	1		✓
6	230010-16000			CLAMP 16	2		✓




VIO17 > VEHICLE > HYD.OIL PIPING(RETURN)

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-78161			HOSE G808CY082S	1		✓
2	172A64-78170			HOSE G808BY075	1		✓
3	172A64-78191			HOSE G808YY032S	1		✓
4	172A64-78200			HOSE G808YY138	1		✓
5	230010-16000			CLAMP 16	6		✓
5-1	230010-16000	M/#XXXXX		CLAMP 16	K 8		✓




VIO17 > VEHICLE > HYD.OIL PIPING(CONTROL VALVE)

page 88/142




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172123-76121			FITTING PF1/4	7		✓
2	172162-76131			ADAPTER	2		✓
3	172422-76130			FITTING	4		✓
4	172A64-76160			ELBOW 1/2X3/8 ASSY	1		✓
5	243150-00140			O-RING	1		✓
6	172124-76160			FITTING	6		✓
7	172187-76170			FITTING	1		✓
8	243150-00110			O-RING 1B P-11.0	1		✓
9	172141-76180			FITTING	2		✓
10	243150-00110			O-RING 1B P-11.0	2		✓
11	172142-76181			FITTING 90-3/8	1		✓
12	243150-00140			O-RING	1		✓
13	172183-76200			FITTING 1/4	1		✓
14	172A47-76230			NIPPLE G1/4	1		✓
15	243150-00110			O-RING 1B P-11.0	1		✓
16	172147-76260			FITTING	3		✓
17	172116-76381			FITTING G3/8	2		✓
18	172645-76570			FITTING PF3/8	1		✓
19	243150-00140			O-RING	1		✓
20	172141-76900			CONNECTOR ASSY	2		✓
21	243150-00180			O-RING	2		✓
22	172141-76920			FITTING 3/8-1/4L	1		✓
23	243150-00140			O-RING	1		✓
24	243150-00110			O-RING 1B P-11.0	8		✓
25	243150-00140			O-RING	17		✓
26	172116-76381			FITTING G3/8	1		✓
27	243150-00140			O-RING	1		✓
28	172480-76120			ADJUSTABLE TEE 3/8	1		✓
29	243150-00140			O-RING	1		✓

VIO17 > VEHICLE > HYD.OIL PIPING(P.T.O.)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-76250			GUIDE PL,HOSE ASSY	1		✓
2	172183-76250-2			PLATE, SPACER	4		✓
2	172183-76250-Y M07001			PLATE, SPACER	S 4		✓
3	172A64-76260			GUIDE PR,HOSE ASSY	1		✓
4	172A64-766001			PIPE (L), PTO	1		✓
4	172A64-76600-Y M07001			TUBE ASSY, PTO	S 1		✓
5	172A64-766301			PIPE (R), PTO	1		✓
5	172A64-76630-Y M07001			TUBE ASSY, PTO	S 1		✓
6	172142-76950-6			CLAMP	6		✓
6	172142-76950-Y M07001			CLAMP	S 6		✓
7	260131-20502			BOLT W/WASHER M12X50	6		✓
8	172A64-78551			HOSE F206BC115R	2		✓
9	172A64-78570			HOSE H206CC	1		✓
10	172A64-78580			HOSE H506BC	1		✓
11	172137-75570			FITTING PF1/2	2		✓

VIO17 > VEHICLE > CONTROL PIPING(1)




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172123-76121			FITTING PF1/4	2		✓
2	172455-76220			FITTING G1/4	2		✓
3	243150-00110			O-RING 1B P-11.0	4		✓
4	172A47-76310			PILOT BLOCK	1		✓
5	238710-10000			PLUG PT 1/8	1		✓
6	238710-20000			PLUG PT 1/4	2		✓
7	260131-00162			BOLT W/WASHER M10X16	2		✓
8	172A64-78221			HOSE G804YY077	1		✓
9	172A64-78630			HOSE F403CC066	1		✓
10	172A64-78640			HOSE F403CC042	1		✓
11	172A64-78700			HOSE F403CC038	1		✓
12	230000-13000			CLAMP 13	2		✓
13	172614-16520			BAND 100	1		✓
14	194202-56460			BAND	1		✓
15	172A64-78671			HOSE F403BE115	1		✓
16	172A64-78681			HOSE F403BC117	1		✓
17	172A64-78721			HOSE G804BY120	1		✓
18	172A64-78730			HOSE G804BY173	1		✓
19	172122-79930			CLAMP	3		✓
20	172137-79950			COVER	1		✓
21	230000-13000			CLAMP 13	2		✓
22	172A46-78500	M/#00797	-	HOSE	1		✓
23	933168-55770	M/#00797	-	BAND 146	2		✓




Pos.	Parts Number	~ ~>	> ~	Description	I. Q.	R.	S. P.
1	172123-76121			FITTING PF1/4	8		☑
2	243150-00110			O-RING 1B P-11.0	8		☑
3	172A64-78790			HOSE F403BB120	1		☑
4	172A64-78800			HOSE F403BC117	1		☑
5	172A64-78810			HOSE F403BC125	1		☑
6	172A64-78821			HOSE F403BC150S	1		☑
7	172A64-79130			HOSE F403BC132	1		☑
8	172A64-79140			HOSE F403BB095	1		☑
9	172A64-79220			HOSE F403BC138	1		☑
10	172A64-79230			HOSE F403BB095	1		☑

VIO17 > VEHICLE > GREASING

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A47-77800			HOSE P602YY100	1		✓
2	172A64-77800			HOSE P602YY090	1		✓
3	172A47-77820			JOINT,GREASE	4		✓
7	172312-77820			FITTING, GREASE	1		✓
8	247610-20000			GREASE NIPPLE	2		✓




VIO17 > VEHICLE > BOOM BRACKET




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172448-82302-1			BRACKET,BOOM (2J)	1			✓
1	172448-82302-Y	M07001		BRACKET,BOOM	S 1			✓
2	172165-82520			SHIM 50X90X0.5	1			✓
3	172165-82530			SHIM 50X85X1.2	1			✓
4	172A64-82641			PIN, 50X312	1			✓
5	222420-00500			SNAP RING 50	1			✓
6	261161-21302			BOLT H M	1			✓
7	267561-20002			NUT H M	2			✓

VIO17 > VEHICLE > BOOM




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172010-01640			COLLAR	2		✓
2	172A64-811001			BOOM ASSY (YELLOW)	1		✓
2	172A64-81100-Y M07001			BOOM ASSY	S 1		✓
4	172448-81610			SEAL 35X45X4	2		✓
5	172141-82270			BUSH 35X45	2		✓
6	172A64-82601			PIN 35X237	1		✓
7	172A64-82730			PIN 35X155	1		✓
8	172A64-82790			PIN 30X121	1		✓
9	172141-84601			SHIM 35	2		✓
13	221571-00000			WASHER	3		✓
14	247610-50000			GREASE NIPPLE	1		✓
15	260131-00252			BOLT W/WASHER M10X25	3		✓
16	933160-06711			SHIM 30, PIN ADJUST	1		✓

VIO17 > VEHICLE > ARM




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172010-01640			COLLAR	2		✓
2	172A64-81600			ARM 950 ASSY	1		✓
2	172A64-81600-Y M07001			ARM ASSY	S 1		✓
3	172137-81300			BUSH 30X45	4		✓
4	172448-81600			SEAL, DUST	4		✓
6	172448-81610			SEAL 35X45X4	2		✓
7	172141-82270			BUSH 35X45	2		✓
8	172A64-82820			PIN 30X87	2		✓
9	221571-00000			WASHER	2		✓
10	247610-40000			GREASE NIPPLE	1		✓
11	260131-00252			BOLT W/WASHER M10X25	2		✓
12	933160-06711			SHIM 30, PIN ADJUST	2		✓
16	172183-81160			TREE CLIP	4		✓

VIO17 > VEHICLE > BUCKET ARM & LINK




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-813801			LINK, BUCKET	1		✓
1	172A64-81380-Y	M07001		LINK ASSY,BUCKET	S 1		✓
2	172137-81300			BUSH 30X45	2		✓
4	172448-81600			SEAL, DUST	6		✓
5	172137-84451			BUSH 30X21	2		✓
6	172A64-814101			LINK (L), BUCKET	1		✓
6	172A64-81411-1	M/#XXXXX		ARM L,BUCKET ASSY	N 1		✓
6	172A64-81411-Y	M07001		ARM L,BUCKET ASSY	S 1		✓
7	172A64-814401			LINK (R), BUCHET	1		✓
7	172A64-81441-1	M/#XXXXX		ARM R,BUCKET ASSY	N 1		✓
7	172A64-81441-Y	M07001		ARM R,BUCKET ASSY	S 1		✓
8	172A64-82850			PIN 30X159	2		✓
9	172A64-82880			COLLAR	2		✓
10	247610-20000			GREASE NIPPLE	4		✓
11	261161-00552			BOLT H M	2		✓
12	267161-00002			NUT H M10	4		✓
13	933160-06711			SHIM 30, PIN ADJUST	2		✓

VIO17 > VEHICLE > BUCKET PIN



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	172A55-99451			PIN ASSY	2			✓
2	172A64-82850			PIN 30X159	2			✓
3	172A64-82880			COLLAR	2			✓
4	247610-20000			GREASE NIPPLE	2			✓
5	261161-00552			BOLT H M	2			✓
6	267161-00002			NUT H M10	4			✓
7	933160-06711			SHIM 30, PIN ADJUST	2			✓




VIO17 > VEHICLE > BLADE



Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1	172010-01640			COLLAR		4			✓
2	172110-36010			WASHER		4			✓
3	172A64-94100			BRAD,ASSY (GRAY:49)		1			✓
4	172A64-94250			EXTEND BLADE (L)		1			✓
5	172A64-94260			EXTEND BLADE (R)		1			✓
6	172A64-94350			PIN 30X76 A		2			✓
7	172A64-94370			PIN 30X76 B		2			✓
8	172448-94700			PIN 25X143		2			✓
9	172448-94710			PIN 25		2			✓
10	224174-00400			COTTER PIN 4.0X40		2			✓
11	247610-20000			GREASE NIPPLE		2			✓
12	247610-40000			GREASE NIPPLE		2			✓
13	260131-00252			BOLT W/WASHER M10X25		4			✓
14	933160-06711			SHIM 30, PIN ADJUST		4			✓

VIO17 > VEHICLE > S-J EXCHANGE KIT




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1		FROMFIRST	-		1			☒



172A64-08400
SWIVEL JOINT EXCHANGE KIT


VIO17 > VEHICLE > S-J HOSE CHANGE KIT

Pos.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.	S.	P.
1		FROMFIRST	-			1			☒



172A64-08450
SWIVEL JOINT HOSE EXCHANGE KIT

VIO17 > VEHICLE > WEIGHT ASSY




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	172A64-08600	M/#01769	-	WEIGHT KIT(2P	1		✓
2	172730-05250			WASHER 13.2X30X3.2	2		✓
3	172A64-53400			WEIGHT ASSY,OP	1		✓
6	172A64-53450			SPACER,R	2		✓
7	1A1380-62160			WASHER	1		✓
8	172A64-65300			ROD ASSY,STOPPER	1		✓
11	172176-68210			CLIP, TREE	2		✓
12	172A64-68290			JOINT21-M20X48	2		✓
13	221370-80000			WASHER	1		✓
14	222171-20000			SPRING WASHER 12	2		✓
15	222172-00000			SPRING WASHER 20	2		✓
16	224172-00200			COTTER PIN 2.0X20	2		✓
17	260761-20552			BOLT, 12 X 55	2		✓
18	260762-00702			BOLT, 20 X 70	2		✓
19	172A64-08610	M/#01769	-	WEIGHT KIT(4P	1		✓
20	172A64-53400			WEIGHT ASSY,OP	1		✓
23	172A64-53460			SPECER,F	2		✓
24	172176-68210			CLIP, TREE	2		✓
25	172A64-68290			JOINT21-M20X48	2		✓
26	222172-00000			SPRING WASHER 20	2		✓
27	260761-20552			BOLT, 12 X 55	2		✓
28	260762-00702			BOLT, 20 X 70	2		✓


III

ENGINE

VIO17 > ENGINE 3TNV70-XBV > CYLINDER BLOCK




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	719515-01560			BLOCK ASSY, CYLINDER	1		✓
4	124060-01050			PLUG PT1/8	1		✓
5	105311-01090			PLUG 30 (SUS)	4		✓
6	119623-01250			PLUG 45	1		✓
7	124160-01910			PLUG PT1/4	1		✓
8	119285-01990			PLUG 25	3		✓
9	119620-02020			BOLT	8		✓
12	119717-02411			BUSH, CAMSHAFT	1		✓
13	272411-20000			SEALING CAP	1		✓
14	719717-02901			MAIN BEARING SET	4	REPAIR PART.	✓
26	119810-02931			BEARING, THRUST	2	REPAIR PART.	✓
29	119515-01200			BOLT CYLINDER HEAD	14		✓
30	119515-01330			GASKET, CYL. HEAD	1		✓
31	119810-02941			BEARING,THRUST .25OS	2	OVER SIZED(O.S.=0.25) PART.	✓
34	719717-02911			MAIN METAL US=0.25	4	UNDER SIZED(U.S.=0.25)P ART.	✓



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119717-01501			HOUSING ASSY, GEAR	1		✓
2	119717-01570			BOLT, STUD M8	3		✓
3	119734-01590			COVER ASSY,GEAR CASE	1		✓
4	719734-01500			COVER ASSY,GEAR CASE	1		✓
5	119717-01521			COVER, GEAR CASE	1		✓
6	238760-30000			PLUG PT3/8	2		✓
7	119717-01800			SEAL, OIL	1		✓
8	119717-32100			COVER ASSY,F.I.PUMP	1		✓
9	119717-32080			COVER, LUB.OIL PUMP	1		✓
10	129900-32130			SAFETY VALVE	1		✓
11	129001-32320			SPRING	1		✓
12	129001-32330			PLUG	1		✓
13	119717-32110			ROTOR INNER	1		✓
14	119717-32120			ROTOR ASSY, LUB. OIL	1		✓
15	119802-32130			SCREW M6X16	8		✓
16	119660-01911			PIPE, KNOCK	4		✓
17	119624-32040			O-RING P 12.0	1		✓
18	119717-32050			O-RING, P17.0	3		✓
19	121850-51960			O-RING, F.I.PUMP	1		✓
20	261060-60122			FLANGE BOLT H M 6X12	1		✓
21	261060-60162			FLANGE BOLT H M 6X16	4		✓
22	261060-60402			FLANGE BOLT H M 6X40	4		✓
23	261060-60402			FLANGE BOLT H M 6X40	3		✓
24	261060-60602			FLANGE BOLT H M 6X60	7		✓
25	261060-60652			FLANGE BOLT H M 6X65	2		✓
26	263060-80002			FLANGE NUT H M8	3		✓
27	124160-01751			CAP, LUB.OIL SUPPLY	1		✓
28	243110-00320			O-RING	1		✓
29	119717-01750			COVER, PUMP TIMING	1		✓


3.3

VIO17 > ENGINE 3TNV70-XBV > FLYWHEEL HOUSING
& L.O. SUMP




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	129100-01580			PARALLEL PIN 8X16	2		✓
2	119515-01601			HOUSING, FLYWHEEL	1		✓
3	119620-01750			CAP, FLYWHEEL COVER	1		✓
4	261060-60452			FLANGE BOLT H M 6X45	17		✓
5	262061-00252			BOLT H M10X25	7		✓
6	121120-01620			BOLT M 10X28	3		✓
7	119515-01720			SPACER, OIL SUMP	1		✓
8	261060-60122			FLANGE BOLT H M 6X12	1		✓
9	261060-60252			FLANGE BOLT H M 6X25	1		✓
10	124085-02220			SEAL, OIL	1		✓
11	119540-01780			SUMP ASSY, LUB.OIL	1		✓
13	119540-39910			HOSE, OIL DRAIN CMP	1		✓
14	119540-39930			HOSE, OIL DRAIN	1		✓
15	119656-39930			PLUG, DRAIN	1		✓
16	230010-22000			CLAMP HOSE 22	1		✓
17	230010-22000			CLAMP HOSE 22	1		✓

VIO17 > ENGINE 3TNV70-XBV > CYLINDER HEAD & BONNET



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119718-07910			LIFTER, ENGINE	1		✓
2	261060-80162			FLANGE BOLT H M 8X16	2		✓
3	129901-11450			PROTECTOR NOZZLE	3		✓
4	119600-11460			GASKET, NOZZLE	6		✓
5	105010-11490			CAP, VALVE	6		✓
6	119515-11740			HEAD ASSY, CYLINDER	1		✓
10	119515-11800			GUIDE, VALVE	6	REPAIR PART.	✓
12	119285-11990			PLUG 35	2		✓
13	23876-005000			PLUG PT 1/16,SCREW	1		✓
14	119717-11340			SEAL, VALVE STEM	3		✓
15	119717-11350			SEAL, VALVE STEM	3		✓
16	119515-11101			VALVE, SUCTION	3		✓
17	119515-11110			VALVE, EXHAUST	3		✓
18	119717-11131			SPRING, VALVE	6		✓
19	129508-11180			RETAINER, SPRING	6		✓
20	119717-11190			KEY	12		✓
21	119717-77800			PLUG, GLOW	3		✓
22	119717-77820			CONNECTOR, GLOW PLUG	1		✓
23	223510-60012			SPRING PIN 6x12	2		✓
24	119515-11200			SUPPORT ASSY, ARM	1		✓
25	119515-11240			SHAFT ASSY, ROCKER	1		✓
28	119717-11260			SUPPORT, ROCKER ARM	3		✓
29	119515-11280			SPRING, SHAFT	2		✓
30	119717-11650			ARM ASSY, ROCKER	6		✓
31	129150-11230			SCREW, VALVE	6		✓
33	129150-11750			NUT M8XP1.0	6		✓
34	222420-00120			SNAP RING 12	2		✓
35	269790-50162			SLOTTED SET SCREW M	1		✓
36	261060-80402			FLANGE BOLT H M 8X40	3		✓
37	124160-01751			CAP, LUB.OIL SUPPLY	1		✓
38	119515-11380			BONNET ASSY, HEAD	1		✓
39	119717-03031			PLATE, BAFFLE	1		✓
40	119717-03070			BAFFLE, BREATHER	1		✓
41	119717-03070			BAFFLE, BREATHER	2		✓
42	119802-03100			DIAPHRAGM ASSY	1		✓
43	119802-03110			PLATE,DIAPHRAGM	1		✓
44	119802-03121			COVER,DIAPHRAGM	1		✓
45	119802-03131			DIAPHRAGM	1		✓
46	119802-03141			SPRING,DIAPHRAGM	1		✓
48	119515-11310			GASKET, BONNET	1		✓
49	119515-11320			PLATE, BAFFLE	1		✓
50	119515-11330			GASKET, BONNET	1		✓


VIO17 > ENGINE 3TNV70-XBV > CYLINDER HEAD & BONNET




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
51	228575-00100			SCREW M5X10	4		✓
52	228575-00100			SCREW M5X10	4		✓
53	228575-00160			SCREW 5X16	2		✓
54	243110-00320			O-RING	1		✓
55	261060-60202			FLANGE BOLT H M 6X20	3		✓
56	261060-60752			BOLT M 6X 75 PLATED	6		✓

VIO17 > ENGINE 3TNV70-XBV > EXHAUST MANIFOLD

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119540-13100			MANIFOLD, EXHAUST	1		✓
2	119717-13110			GASKET,MANIFOLD	1		✓
3	263060-80002			FLANGE NUT H M8	2		✓
4	119717-13600			STUD M8X50	2		✓
5	119802-13620			BOLT M 8X 50 PLATED	4		✓
6	119131-18320			BOLT M 8X22	4		✓




VIO17 > ENGINE 3TNV70-XBV > CAMSHAFT & DRIVING GEAR




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119620-14200			TAPPET	6		✓
2	119515-14400			ROD, PUSH	6		✓
3	119515-14581			CAMSHAFT ASSY	1		✓
8	261060-60122			FLANGE BOLT H M 6X12	2		✓
9	119717-25050			SHAFT, IDLE GEAR	1		✓
10	119717-25101			GEAR ASSY, IDLE	1		✓
12	119717-25911			BUSH,IDLE GEAR	1	REPAIR PART.	✓
13	261060-60352			FLANGE BOLT H M 6X35	3		✓
14	129150-25301			BOLT FI-P	4		✓
15	119717-25930			GEAR,PUMP	1		✓
16	119717-51150			FLANGE	1		✓
17	222171-20000			SPRING WASHER 12	1		✓
18	267161-20002			NUT H M12	1		✓

VIO17 > ENGINE 3TNV70-XBV > CRANKSHAFT & PISTON




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119515-21700			CRANKSHAFT ASSY	1		✓
2	129100-01580			PARALLEL PIN 8X16	1		✓
4	225120-40120			KEY 4X12	1		✓
7	119620-21500			BOLT, FLYWHEEL	5		✓
8	119515-21590			FLYWHEEL ASSY	1		✓
10	124950-21600			GEAR, RING	1		✓
11	119717-21650			V-PULLEY, CRANKSHAFT	1		✓
12	119621-21680			BOLT M12X1.25,FLANGE	1		✓
13	119620-21941			WASHER	1		✓
14	119515-22080			PISTON W/RINGS	3		✓
16	119515-22500			RING SET	3		✓
20	119515-22300			PIN, PISTON	3		✓
21	222520-00220			SNAP RING 22	6		✓
22	119515-23000			ROD ASSY, CONNECTING	3		✓
25	119717-23910			BUSH, PISTON PIN	3	REPAIR PART.	✓
26	119717-23200			BOLT CONNECTING ROD	6		✓
27	119515-23601			METAL ASSY, CRANK PIN	3	REPAIR PART.	✓
29	119515-22900			PISTON ASSY (0S=0.25)	3	OVER SIZED(O.S.=0.25) PART.	✓
31	119515-22550			RING SET (0S=0.25)	3	OVER SIZED(O.S.=0.25) PART.	✓
35	119515-23611			BEARING,PIN US=0.25	3	UNDER SIZED(U.S.=0.25)P ART.	✓




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119515-34801			DIPSTICK, LUB OIL	1		✓
2	129100-35140			STUD	1		✓
3	119305-35151			FILTER, LUB. OIL	1	REPAIR PART.	✓
4	119717-32060			O-RING, P15.0	1		✓
5	119515-35080			PIPE ASSY, LUB,OIL	1		✓
9	261060-60102			FLANGE BOLT H M 6X10	2		✓
10	114250-39450			SWITCH,(0.5KG)L.O.	1		✓
11	119717-39210			PIPE ASSY, HYDRAULIC	1		✓
12	129005-59830			BOLT ASSY, JOINT	2		✓
13	221900-80002			SEAL WASHER 8S	2		✓
14	238570-30000			BANJO BOLT M8	2		✓
15	221900-80002			SEAL WASHER 8S	2		✓
16	121520-34810			GUIDE, DIPSTICK	1		✓

VIO17 > ENGINE 3TNV70-XBV > COOLING WATER SYSTEM




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119515-42001			PUMP ASSY, C.W.	1		✓
2	119515-42041			COVER	1		✓
3	119717-42031			GASKET	1		✓
8	265770-60122			CUNTERSUNK HEAD SCREW M	4		✓
9	272412-50000			SEALING CAP	1		✓
10	119717-42320			O-RING	1		✓
11	129916-49740			PLUG, DRAIN R03	1		✓
12	119515-42020			GASKET, C.W. PUMP	1		✓
13	234140-80000			GASKET 8	1		✓
14	261060-80122			FLANGE BOLT H M 8X12	1		✓
15	261060-80502			FLANGE BOLT H M 8X50	3		✓
16	171056-49120			PLUG, DRAIN	1		✓
17	119717-42350			V-PULLEY, C.W.PUMP	1		✓
18	251320-03500			V-BELT	1		✓
19	119233-44740			FAN (D=290)	1		✓
20	124465-44950			GASKET 16	1		✓
21	261060-60302			FLANGE BOLT H M 6X30	4		✓
22	129350-49530			COVER, THERMOSTAT	1		✓
23	119717-49800			THERMOSTAT	1		✓
24	261060-80202			FLANGE BOLT H M 8X20	2		✓
25	171056-49351			SENSOR	1		✓
26	121250-44901			SWITCH, THERMO 110°C	1		✓
27	121267-44760			SPACER	1		✓
28	129150-49360			GASKET 10	1		✓

VIO17 > ENGINE 3TNV70-XBV > FUEL INJECTION PUMP




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	719540-51450			FIE ASY(3TNV70-XBV	1	GOVERNOR ASSY(FIG.11) IS INCORPORATED IN THIS FOP CMP (REF NO.1).	☒
4	129155-51020			STUD, FEED PUMP	2		☒
5	119717-51030			CAMSHAFT	1		☒
6	119717-51060			SUPPORT, BEARING	1		☒
7	119717-51070			PARALLEL PIN	1		☒
8	122710-51090			KEY	1		☒
9	119515-51100			PLUNGER ASSY	3		☒
12	129155-51140			PIN, BARREL LOCKING	3		☒
13	158600-51170			RETAINING SPRING	3		☒
14	119717-51570			RECEIVER,SPRING	3		☒
15	119717-51190			SPRING PLUNGER	3		☒
16	119717-51200			TAPPET ASSY	3		☒
21	129155-51600			SHIM PACK	3		☒
40	158600-51270			RETAINER	3		☒
41	129155-51280			O-RING S6	3		☒
42	129155-51280			O-RING S6	1		☒
43	119717-51300			FUEL INJECTOR	3		☒
46	119717-51330			PLATE	3		☒
47	124550-51350			GASKET, DELIVERY	3		☒
48	158600-51442			VALVE ASSY, DELIVERY	3		☒
54	118400-51370			LOCKING	3		☒
55	243160-00150			O-RING	3		☒
56	129155-51400			DEFLECTOR	1		☒
57	158600-51410			PLUG	1		☒
58	158600-51420			PLUG	1		☒
59	129155-51450			SHIM SET, ADJUSTING	1		☒
64	119717-51500			RACK, CONTROL	1		☒
65	129155-51521			BUSH, RACK	1		☒
66	129155-51530			SPACER, AUX. SPRING	1		☒
67	129155-51540			SNAP RING	1		☒
68	129155-51550			PINION, CONTROL	3		☒
70	129100-51570			SCREW	3		☒
71	158600-51570			PLUG	1		☒
72	129155-51580			O-RING	1		☒
73	129155-51591			SPRING, RACK	1		☒
74	129155-51701			COVER	1		☒
75	119717-51711			GASKET SIDE COVER	1		☒
76	119717-51750			COVER, BODY SIDE	1		☒
77	119717-51761			GASKET SIDE COVER	1		☒

VIO17 > ENGINE 3TNV70-XBV > FUEL INJECTION PUMP




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
78	158600-51790			GUIDE, RACK	1		✓
79	267161-20002			NUT H M12	1		✓
80	221901-60002			SEAL WASHER 16S	1		✓
81	222170-60000			WASHER GROWER 6	2		✓
82	223510-50010			SPRING PIN 5x10	2		✓
83	241010-60034			BALL BEARING	1		✓
84	241010-63034			BALL BEARING	1		✓
85	119717-51420			O-RING	1		✓
86	260220-50122			PAN HEAD SCREW W/WASHER	8		✓
87	260220-60162			PAN HEAD SCREW W/WASHER	4		✓
88	261060-50102			BOLT H M 5X10	3		✓
89	267160-60002			NUT H M 6	2		✓
90	119717-51150			FLANGE	1		✓
91	222171-20000			SPRING WASHER 12	1		✓
92	119717-51490			BOLT, FIXATION	1		✓
93	119717-51480			COLLAR. FIC FIX	1		✓
96	129155-52051			GASKET	1		✓
97	129100-52200			COVER, BLIND	1		✓

VIO17 > ENGINE 3TNV70-XBV > GOVERNOR



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
2	119717-61050			GASKET LOWER COVER	1		✓
3	119717-61060			CASE, GOVERNOR	1		✓
4	119717-61070			GASKET	1		✓
5	119540-61100			CASE ASSY, GOVERNOR	1		✓
6	129155-51280			O-RING S6	1		✓
8	119717-61120			LINK, L=29.3 :3	1	REFER TO THE MARK STAMPED ON THE PART	✓
9	119717-61130			LINK, L=29.8 :98	1	REFER TO THE MARK STAMPED ON THE PART	✓
10	119717-61140			LINK, L=28.8 :88	1	REFER TO THE MARK STAMPED ON THE PART	✓
11	119717-61150			LINK, L=30.3 :03	1	REFER TO THE MARK STAMPED ON THE PART	✓
12	129209-61370			NUT M6	1		✓
13	129052-61390			SHAFT, GOV. LEVER	1		✓
14	119717-61400			SHAFT ASSY, CONTROL	1		✓
20	119534-61430			RETAINER	1		✓
21	129155-61450			BOLT, REVOL. LIMIT	1		✓
22	129156-61460			SHIM T=0.6	1		✓
23	129155-61480			SPACER ASSY	1		✓
24	119515-61440			LEVER, CONTROL	1		✓
30	119534-61420			SPRING	1		✓
31	119761-61500			LEVER ASSY, GOVERNOR	2		✓
32	174307-51700			SHIM SET	2		✓
50	129486-61540			SPRING, SET	1		✓
60	129486-61650			SPRING	1		✓
61	158552-61700			SHIM ASSY	1		✓
65	158552-61710			SHIM T=1.0	1		✓
66	119660-61901			RETAINER, SHAFT	1		✓
67	129255-61410			NUT	1		✓
68	222720-00030			CIRCLIP E- 3	1		✓
69	261060-60102			FLANGE BOLT H M 6X10	1		✓
70	243410-00070			O-RING 1A S-7.0	1		✓
71	261060-60102			FLANGE BOLT H M 6X10	1		✓
72	221901-00002			SEAL WASHER 10S	1		✓
73	238871-00002			PLUG M10	1		✓
74	119717-61200			WEIGHT ASSY	1		✓
77	119660-61300			NUT, GOVERNOR WEIGHT	1		✓
78	129155-61341			SLEEVE	1		✓
79	129155-61460			BOLT, IDLE LIMIT	1		✓

VIO17 > ENGINE 3TNV70-XBV > GOVERNOR




Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
80	221901-20002			SEAL WASHER 12S	2		✓
81	223720-40000			SNAP PIN 4	1		✓
82	158552-61900			O-RING	1		✓
83	261060-60102			FLANGE BOLT H M 6X10	4		✓
84	261060-60142			FLANGE BOLT H M 6X14	2		✓
85	261060-60202			FLANGE BOLT H M 6X20	4		✓
86	261060-60452			FLANGE BOLT H M 6X45	3		✓
87	26736-120002			NUT, 12	1		✓
88	267560-60002			NUT H M	1		✓
89	158601-61790			LIMITER ASSY, FUEL	1		✓
97	119761-61560			ANGLEICH ASSY	1		✓
130	129489-61700			SPRING, GOVERNOR	1		✓
131	129209-61930			CAP NUT	1		✓
132	129209-61970			PLATE	1		✓
133	119233-77932			SOLENOID, STOP	1		✓
134	234141-20016			GASKET 12	1		✓
137	129209-61961			CASE	1	INCLUDED IN REF.NO.1 FIG.10	☐
138	243110-00160			O-RING	1		✓
140	119285-66650			CAP HIGH IDLE	1	INCLUDED IN REF.NO.1 FIG.10	☐

3.12


VIO17 > ENGINE 3TNV70-XBV > FUEL INJECTION VALVE

page 117/142





Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119517-53001			NOZZLE ASSY	3		✓
2	118200-53010			HOLDER, NOZZLE	3		✓
3	119517-53010			NOZZLE ASSY	3		✓
4	129901-53800			SHIM SET	3		✓
5	129150-59120			RETAINER, INJ. PIPE	1		✓
8	129150-59131			BOLT M4X14,HEX.SCKT.	2		✓
9	119546-59810			PIPE ASSY ,INJECTION	1		✓
10	119546-59820			PIPE ASSY ,INJECTION	1		✓
11	119546-59830			PIPE ASSY ,INJECTION	1		✓
12	119840-59570			FITTING	1		✓
13	119515-59540			PIPE ASSY,F.O.RETURN	1		✓
19	129901-59560			GASKET, RETURN	3		✓
20	119540-59570			PIPE, FUEL RETURN	1		✓
21	124066-59100			CLAMP 8	2		✓
22	119540-59560			PIPE,FUEL RETURN	1		✓
23	119620-59700			NUT	3		✓
24	119813-59950			VALVE ASSY, CHECK	1		✓
30	221901-20002			SEAL WASHER 12S	2		✓
31	103854-39140			BOLT, PIPE JOINT	1		✓
32	101304-59020			JOINT 12, PIPE	1		✓
33	221901-20002			SEAL WASHER 12S	2		✓

VIO17 > ENGINE 3TNV70-XBV > STARTING MOTOR





Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	261061-00252			FLANGE BOLT H M10X25	2		✓
2	119540-77010			STARTER RA1 4	1		✓
3	129407-77210			YOKE	1		✓
4	129407-77220			ARMATURE ASSY	1		✓
5	129129-77230			BEARING	1		✓
6	129129-77240			BEARING	1		✓
7	X02830-60061			ROLLER	5		✓
8	129129-77260			RETAINER	1		✓
9	129129-77270			PINION	1		✓
10	129407-77300			HOLDER ASSY	1		✓
11	X94917-30461			SPRING	4		✓
12	129129-77460			SCREW	2		✓
13	129129-77320			BOLT	2		✓
14	129407-77330			BOLT,W/WASHER	2		✓
15	X9491200240			BALL	1		✓
16	129129-77340			SPRING	1		✓
17	129129-77350			O-RING	2		✓
18	129129-77362			COVER	1		✓
19	X9490561370			NUT	1		✓
20	129129-77380			CAP	1		✓
21	X1280996600			STARTER KIT	1		✓
22	129129-77390			CLUTCH ASSY, STARTER	1		✓
23	129129-77440			BEARING	1		✓
24	129129-77450			BEARING	1		✓
25	129129-77400			SHAFT	1		✓
26	129129-77410			SPRING, COIL	1		✓
27	X0283270140			RETAINER	1		✓
28	129407-77410			SPRING	1		✓
29	X02837-12350			PINION, STARTER	1		✓
30	X02802-10230			NUT	1		✓
31	129129-77430			RING	1		✓

VIO17 > ENGINE 3TNV70-XBV > GENERATOR



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	119910-77200			GENERATOR ASSY	1		✓
2	X2A10592KA			PLATE ASSY	1		✓
3	X2A07075KB			PLATE,COIL	1		✓
4	X3A02982KC			STETA ASSY	1		✓
5	24104-062010			BALL BEARING	3		✓
6	X4A10092KA			COLER	1		✓
7	XM0690-00000			CLAMP	1		✓
8	XM771860000			COUPLER	1		✓
9	119259-77250			SCREW	2		✓
10	XYSPS400800			SCREW	1		✓
11	X3A08863KA			FLYWHEEL ASSY (12P)	1		✓
12	XM860250000			WASHER 10	1		✓
13	XM219230000			WASHER, SPRING	1		✓
14	XM8637-20000			NUT	1		✓
15	XM771870000			CAP	1		✓
16	261060-80202			FLANGE BOLT H M 8X20	1		✓
17	119740-77250			BOLT, M10X76	1		✓
18	129972-77341			BOLT, ADJUSTING	1		✓
19	263061-00002			FLANGE NUT H M10	1		✓
20	119940-77270			ADJUSTER, BELT	1		✓
21	119540-77300			ADJUSTER, BELT	1		✓

VIO17 > ENGINE 3TNV70-XBV > GASKET SET & TOOLS



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	719544-92600			JEU DE JOINTS	1	OPTIONAL	✓
2	121850-51960			O-RING, F.I.PUMP	1		✓
3	119717-11340			SEAL, VALVE STEM	3		✓
4	129901-11450			PROTECTOR NOZZLE	3		✓
5	119515-11310			GASKET, BONNET	1		✓
6	119717-13110			GASKET,MANIFOLD	1		✓
7	243410-00240			O-RING	1		✓
8	119717-11350			SEAL, VALVE STEM	3		✓
9	221900-80002			SEAL WASHER 8S	4		✓
10	243110-00320			O-RING	2		✓
11	119717-32060			O-RING, P15.0	1		✓
12	119624-32040			O-RING P 12.0	1		✓
13	119717-32050			O-RING, P17.0	3		✓
14	119600-11460			GASKET, NOZZLE	6		✓
15	119515-11330			GASKET, BONNET	1		✓
16	221901-60002			SEAL WASHER 16S	1		✓
17	221901-20002			SEAL WASHER 12S	4		✓
18	129901-59560			GASKET, RETURN	3		✓
19	119515-42020			GASKET, C.W. PUMP	1		✓
20	234140-80000			GASKET 8	1		✓
21	124465-44950			GASKET 16	2		✓
22	119515-01330			GASKET, CYL. HEAD	1		✓
23	129400-92410			FLEX HORN	1	OPTIONAL	✓
24	977770-1207F			LIQUID,SEAL	1	OPTIONAL	✓

VIO17 > ENGINE 3TNV70-XBV >

Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S. P.
1	719534-01000			SHORT BLOCK ASSY	1		
2	119534-01560			BLOCK ASSY, CYLINDER	1		
3	119620-14200			TAPPET	6		
4	119515-14581			CAMSHAFT ASSY	1		
5	119515-21700			CRANKSHAFT ASSY	1		
6	119515-22080			PISTON W/RINGS	3		
7	119515-22300			PIN, PISTON	3		
8	119515-23000			ROD ASSY, CONNECTING	3		
9	119515-23601			METAL ASSY, CRANK PIN	3		
10	119717-25101			GEAR ASSY, IDLE	1		
11	222520-00220			SNAP RING 22	6		
12	261060-60122			FLANGE BOLT H M 6X12	2		

NOT ILLUSTRATED

> VIO17 > MAINTENANCE KIT

- 1: 50H
- 2: 250H / 750H
- 3: 500H
- 4: 1000H
- 5: 1000H+



Pos.	Parts Number	~ ->	-> ~	Description	I. Q.	R.	S.	P.
1	ABA006-00A			SERVICE KIT 50H VIO17			☒	122
2	ABB006-00			SERVICE KIT 250H/750H VIO17			☒	122
3	ABC006-00			SERVICE KIT 500H VIO17			☒	122
4	ABC006-00			SERVICE KIT 500H VIO17			☒	122
5	ABE006-00			SERVICE KIT 1000H+ VIO17			☒	122

Description	Parts Number	P.
.....		99
.....		100
ABSOBER,SHOCK	172446-13330	22
ABSOBER,SHOCK 290K	172447-13260	21
ABSORBER, SHOCK	172179-13211	21
ABSORBER, SHOCK	172448-72270	59
ACCUMULATOR	172478-73600	68
ADAPTER	172162-76131	88
ADJUSTABLE TEE 3/8	172480-76120	88
ADJUSTER, BELT	119540-77300	119
ADJUSTER, BELT	119940-77270	119
AIR CLEANER ASSY	172448-11500	19
AIR CLEANER, ASSY	172448-11510	19
ANGLEICH ASSY	119761-61560	116
ANTENNA GPS	172AYV-17460	9
ANTENNA GSM	172AYV-17450	9
ANTI-THEFT DEVICE	172AYV-16850	8
ANTICAVITAION VALVE	172447-74230	73, 74
ARM 950 ASSY	172A64-81600	95
ARM ASSY	172A64-81600-Y	95
ARM ASSY, ROCKER	119717-11650	106
ARM ASSY,ACCEL	172A64-12180	20
ARM CYLINDER ASSY	172A64-722001	59
ARM CYLINDER ASSY	172A64-723001	61
ARM L,BUCKET ASSY	172A64-81411-1	96
ARM L,BUCKET ASSY	172A64-81411-Y	96
ARM R,BUCKET ASSY	172A64-81441-1	96
ARM R,BUCKET ASSY	172A64-81441-Y	96
ARM REST (CUSHION)	172441-44320	42
ARM SEC ASSY	172A64-74240	74
ARMATURE ASSY	129407-77220	118
BACK REST	172A59-64950	10
BAFFLE, BREATHER	119717-03070	106
BALL	X9491200240	118
BALL BEARING	24104-062010	119
BALL BEARING	241010-60034	114
BALL BEARING	241010-60054	57
BALL BEARING	241010-62054	32
BALL BEARING	241010-62064	33
BALL BEARING	241010-63034	114
BAND	194202-56460	83, 90
BAND 100	172614-16520	39, 90
BAND 146	933168-55770	22, 24, 25, 28, 31, 90
BAND 300	172126-11510	83
BANJO BOLT M8	238570-30000	111
BASE ASSY, SEAT	172A59-64110	10
BASE ASSY,LEVER L(73	172A64-46210	35
BATTERY	172458-16110	27
BAUMACO ANTI-THEFT	172AYV-17410	9
BEARING	129129-77230	118
BEARING	129129-77240	118
BEARING	129129-77440	118
BEARING	129129-77450	118
BEARING, REVOLVE	172447-57600	45
BEARING, THRUST	119810-02931	103
BEARING,PIN US=0.25	119515-23611	110
BEARING,THRUST .25OS	119810-02941	103
BELLOWS	172A64-74680	77
BLADE CYLINDER, ASSY	172A64-72601	64
BLADE LEVER ASSY(49)	172A64-45700	37
BLOCK ASSY, CYLINDER	119534-01560	121
BLOCK ASSY, CYLINDER	719515-01560	103
BLOCK ASSY, DRAIN	172A55-13700	21
BLOCK, DRAIN	172A64-76140	86
BODY	172444-13220	22
BODY,FUSER	172183-16580	29
BOLT	172A47-72840	60, 61, 62
BOLT	172A64-73620	67
BOLT	119620-02020	103
BOLT	129129-77320	118
BOLT	172165-46340	39, 41
BOLT	172168-73370	66
BOLT	260131-00202	21, 23, 28, 35, 41, 46, 50, 59, 60, 62, 63, 78
BOLT	260131-00302	69

Description	Parts Number	P.
BOLT	260140-80202	28, 49
BOLT	260141-00202	46, 50, 54, 55, 56
BOLT	260141-00252	21, 35, 54, 64
BOLT 4* 10	264500-40102	7, 8
BOLT 8X 16	172519-63240	42, 52
BOLT 5* 18	264500-50182	71, 72, 73, 74, 76
BOLT 8X35	172448-62400	51
BOLT ASSY, JOINT	129005-59830	111
BOLT ASSY, STOPPER	172A64-50700	44
BOLT ASSY, STOPPER	172A64-50701	44
BOLT CONNECTING ROD	119717-23200	110
BOLT CYLINDER HEAD	119515-01200	103
BOLT FI-P	129150-25301	109
BOLT H 10,9 M	260761-00202	60, 61, 62
BOLT H 10,9 M	260761-20252	45
BOLT H 10,9 M	260761-20352	14
BOLT H 10,9 M	260761-20402	45
BOLT H 10,9 M	260761-20452	45
BOLT H M	261160-80162	48
BOLT H M	261160-80202	10
BOLT H M	261160-80252	20
BOLT H M	261160-80254	37, 39, 41
BOLT H M	261160-80404	36
BOLT H M	261160-80452	22
BOLT H M	261160-80604	41
BOLT H M	261160-80652	25
BOLT H M	261161-00202	10, 60, 62
BOLT H M	261161-00552	96, 97
BOLT H M	261161-20252	14
BOLT H M	261161-21302	93
BOLT H M	261161-60602	45
BOLT H M 5X10	261060-50102	114
BOLT H M6x16	261160-60162	29
BOLT H M10X25	262061-00252	105
BOLT L=412	172A64-74550	70
BOLT M 6X 75 PLATED	261060-60752	107
BOLT M 8X 50 PLATED	119802-13620	108
BOLT M 8X22	119131-18320	108
BOLT M 10X28	121120-01620	105
BOLT M4X14,HEX.SCKT.	129150-59131	117
BOLT M6X30	172458-46730	77
BOLT M10	172455-75290	79
BOLT M10X 12 PLATED	261061-00122	46
BOLT M10X 45	264501-00452	58
BOLT M12X1.25,FLANGE	119621-21680	110
BOLT W/WASHER M 6X12	260130-60122	29
BOLT W/WASHER M 6X12	260140-60122	22, 29
BOLT W/WASHER M 6X16	260140-60162	25, 29
BOLT W/WASHER M 6X20	260140-60202	29
BOLT W/WASHER M 6X25	260140-60252	29
BOLT W/WASHER M 8X 16	260140-80162	31, 49
BOLT W/WASHER M 8X16	260130-80162	19, 20, 22, 29, 31, 36, 40
BOLT W/WASHER M 8X35	260130-80352	69
BOLT W/WASHER M 8X55	260130-80552	18
BOLT W/WASHER M8X20	260130-80202	68, 86
BOLT W/WASHER M10X16	260131-00162	18, 28, 60, 70, 90
BOLT W/WASHER M10X25	260131-00252	21, 32, 57, 60, 65, 80, 94, 95, 98
BOLT W/WASHER M10X30	260141-00302	14
BOLT W/WASHER M10X35	260131-00352	33
BOLT W/WASHER M12X25	260131-20252	32, 43, 63, 79
BOLT W/WASHER M12X30	260131-20302	55, 83
BOLT W/WASHER M12X35	260131-20352	58
BOLT W/WASHER M12X40	260131-20402	67
BOLT W/WASHER M12X50	260131-20502	89
BOLT, 12 X 55	260761-20552	101
BOLT, 20 X 50	260762-00502	14
BOLT, 20 X 70	260762-00702	101
BOLT, ADJUSTING	129972-77341	119
BOLT, FIXATION	119717-51490	114
BOLT, FLYWHEEL	119620-21500	110
BOLT, IDLE LIMIT	129155-61460	115
BOLT, M10X76	119740-77250	119
BOLT, PIPE JOINT	103854-39140	117
BOLT, REVOL. LIMIT	129155-61450	115

Description	Parts Number	P.
BOLT, STUD M8	119717-01570	104
BOLT,8X20	172A64-73600	67
BOLT,8X73	172A64-73410	66
BOLT,10X80	172A64-73400	66
BOLT,W/WASHER	129407-77330	118
BONNET ASSY Y	172A64-65600-Y	56
BONNET ASSY, HEAD	119515-11380	106
BOOM ASSY	172A64-81100-Y	94
BOOM ASSY (YELLOW)	172A64-811001	94
BOOM CYLINDER ASS	172A64-721001	59
BOOM LOCK SEC ASSY	172A64-74440	70
BOOM SEC ASSY	172A64-74410	71
BOOTS	172141-41340	36
BOOTS, PEDAL	172157-45990	39, 41
BOWL, FUEL STRAINER	124064-55510	24, 26
BRACKET ASSY,ELC	172A64-17120	29
BRACKET ASSY,ELC	172A64-17121	29
BRACKET ASSY,UP	172A64-13400	22
BRACKET BAUMACO	172AYV-80000	9
BRACKET MED	17AA64-17740	8
BRACKET MED & G'TEL	172AYA-17790	7
BRACKET PTO	172448-453801	41
BRACKET, OIL SEAL	172458-74140	71, 72, 73, 74, 76
BRACKET, SUB-TANK	121256-44600	22
BRACKET, WORKING LAMP	172A64-172101	31
BRACKET,BOOM	172448-82302-Y	93
BRACKET,BOOM (2J)	172448-82302-1	93
BRACKET,BOOT(GRAY:49)	172458-45510-1	36
BRACKET,FUSE	172183-16550	29
BRACKET,WIRE	172A64-12100	20
BRACKET,WORK LAMP	172A64-17210-Y	31
BRIDE,ASSY (GRAY:49)	172A64-94100	98
BUCKET CYLINDER ASSY	172A64-724001	62
BUCKET SEC ASSY	172A64-74460	70
BULB	172187-17380	52, 53
BULB	172187-17480	52, 53
BULB 12V-27W	172156-17420	31
BUSH	172A64-74670	77
BUSH	172141-41360	37, 39, 40, 41, 55
BUSH	172141-41370	35, 36
BUSH	172165-47550	35
BUSH	172458-72740	63
BUSH (B) 30X30	172149-72680	62
BUSH 30X21	172137-84451	96
BUSH 30X30	245500-30300	62, 64, 65
BUSH 30X45	172137-81300	95, 96
BUSH 35X30	245500-35300	59, 61, 63
BUSH 35X45	172141-82270	94, 95
BUSH 40X50X40	172168-72410	63
BUSH 50X65	172171-54750	45
BUSH A 30X30	172149-72440	61, 62, 64
BUSH, CAMSHAFT	119717-02411	103
BUSH, PISTON PIN	119717-23910	110
BUSH, RACK	129155-51521	113
BUSH,35-45-30	172A64-72190	59
BUSH,IDLE GEAR	119717-25911	109
BUSHING(17X8)	168PA0-86720	57
BUZZER	172AYV-17520	9
CABLE, BLADE	172A64-45690	37
CABLE, PTO	172A64-45290	41
CABLE,SWING	172A64-45280	39
CAMSHAFT	119717-51030	113
CAMSHAFT ASSY	119515-14581	109, 121
CANOPY ASSY	172A64-66280	14
CAP	129129-77380	118
CAP	XM771870000	119
CAP HIGH IDLE	119285-66650	116
CAP NUT	129209-61930	116
CAP, FLYWHEEL COVER	119620-01750	105
CAP, HYD.OIL TANK	172446-75250	79
CAP, LUB.OIL SUPPLY	124160-01751	104, 106
CAP, TANK	194250-04301	23
CAP, VALVE	105010-11490	106
CAP,SPRING	172458-74170	71, 72, 73, 74, 76

Description	Parts Number	P.
CASE	129209-61961	116
CASE ASSY, GOVERNOR	119540-61100	115
CASE, GOVERNOR	119717-61060	115
CASE, FILTER	172A64-74170	75
CAUTION PLATE ASSY	172171-03420	17
CHECK VALVE	172458-74150	70, 71, 73, 74, 76
CHECK VALVE	172458-74290	71, 72, 75
CHECK VALVE	172490-74310	74
CIRCLIP	172456-77200	67
CIRCLIP 52	222520-00520	32
CIRCLIP 62	222520-00620	33
CIRCLIP 25	222920-00250	57
CIRCLIP E- 3	222720-00030	115
CIRCUIT, ASSY	172187-17371	52, 53
CLAMP	172122-79920	83
CLAMP	172122-79930	90
CLAMP	172137-16560	24
CLAMP	172142-76950-6	89
CLAMP	172142-76950-Y	89
CLAMP	172478-73630	68
CLAMP	XM0690-00000	119
CLAMP 8	124066-59100	117
CLAMP 25	230010-25000	22
CLAMP 10X70	172126-16540	23
CLAMP 12	124766-59050	22, 23, 24
CLAMP 13	230000-13000	82, 90
CLAMP 16	230010-16000	86, 87
CLAMP 41	230010-41000	22, 80
CLAMP 60	230000-60000	19
CLAMP ASSY, FUEL	172A64-14200	23
CLAMP HOSE 12	230800-13000	23
CLAMP HOSE 22	230010-22000	105
CLAMP(B)	172112-16650	28
CLAMP, SUB-TANK	124450-44550	22
CLAMP, BATTERY	194940-64750	27
CLAMP, HOSE	172446-78750-Y	48
CLAMP, HOSE (YELLOW:2)	172446-78750-2	48
CLIP	172122-17190	55
CLIP	172444-17660	54
CLIP, TREE	172176-68210	45, 101
CLUMP	172A64-11340	18
CLUTCH ASSY, STARTER	129129-77390	118
COLER	X4A10092KA	119
COLLAR	172A64-61360	47
COLLAR	172A64-82880	96, 97
COLLAR	172010-01640	59, 94, 95, 98
COLLAR	172173-73520	67
COLLAR	172449-72350	59
COLLAR (GEAR PUMP)	168PA0-86830	57
COLLAR, 17.3X2.3X4	172A64-45580	43
COLLAR. FIC FIX	119717-51480	114
CONNECTOR	172112-77361	80
CONNECTOR ASSY	172141-76900	88
CONNECTOR, GLOW PLUG	119717-77820	106
CONTROL BLOCK	168PA0-86730	57
COOLER	172A64-13190	22
COOLER ASSY, OIL	172A64-13220	22
CORD ASSY, BATTERY (+)	172A64-16101	28
COTTER PIN 2.0X20	224172-00200	35, 56, 101
COTTER PIN 2.0X25	224172-00250	28
COTTER PIN 2.5X20	224172-50200	39, 41
COTTER PIN 4.0X40	224174-00400	98
COUPLER	XM771860000	119
COUPLING	172448-71200	57
COUPLING 1/2	900123-	11
COUPLING F1/2	172AYA-76590	12
COUPLING M1/2	172AYA-76580	12
COUPLING M1/2	900122-	11
COUPLING SET	168PA0-29020	57
COVER	119515-42041	112
COVER	129129-77362	118
COVER	129155-51701	113
COVER	172137-79950	90
COVER	172183-16590	29

Description	Parts Number	P.
COVER	172187-17080	30
COVER	172187-17090	30
COVER ASSY,BATTERY	172A64-61610	49
COVER ASSY,HOSE	172A64-615501	48
COVER (A1), PILOT	172458-74250	70, 71, 74, 76
COVER (A2), PILOT	172458-74550	72, 75
COVER (B1), PILOT	172458-74240	70, 71, 72, 74, 75, 76
COVER (L) ASSY	172A64-614001	50
COVER (R) ASSY	172A64-61260	50
COVER ASSY	172A64-61260-Y	50
COVER ASSY, HOSE	172A64-61550-Y	48
COVER ASSY,C/V (49)	172A64-61310	47
COVER ASSY,F.I.PUMP	119717-32100	104
COVER ASSY,FO	172A64-61660	49
COVER ASSY,GEAR CASE	119734-01590	104
COVER ASSY,GEAR CASE	719734-01500	104
COVER ASSY,SJ (49)	172A64-61520	46
COVER L ASSY	172A64-61400-Y	50
COVER PAD	172187-45760	39, 41
COVER R,MOTOR (49)	172A64-61510	46
COVER, BLIND	129100-52200	114
COVER, BODY SIDE	119717-51750	113
COVER, BOOM CYLINDER	172A64-720501	59
COVER, GEAR CASE	119717-01521	104
COVER, HOSE	172A64-78910	83
COVER, LUB.OIL PUMP	119717-32080	104
COVER, PUMP TIMING	119717-01750	104
COVER, SWITCH	172AYV-16770	8
COVER, THERMOSTAT	129350-49530	112
COVER,CYLINDER	172A64-72051-Y	59
COVER,CYLINDER (2J)	172A64-72051-1	59
COVER,DIAPHRAGM	119802-03121	106
COVER,END ASSY	172A64-73420	66
COVER,FRAME(GRAY:49)	172458-504802	46
COVER,MOTOR(GRAY:49)	172A64-61500	46
COVER,PEDAL(GRAY:49)	172458-45540-1	39, 41
COVER,PUMP (GRAY:49)	172A64-61350	47
COVER,RADIATOR CAP	172A64-61710	49
COVER,RES CAP	172A64-61700	49
COVER,ROLLER	172A64-73390	66
CRADLE (MD-9CA)	168PA0-86340	57
CRADLE HOLDER CMP	168PA0-86290	57
CRANKSHAFT ASSY	119515-21700	110, 121
CRAWLER ASSY, RUBBER	17AA64-38600	13
CRAWLER, RUBBER	172A64-38600	13
CUNTERSUNK HEAD SCREW M	265770-60122	112
CUP, STRAINER	121254-55510	24
CUSHION	172A59-64960	10
CYLINDER ,BUCKET	172A64-72400-Y	62
CYLINDER ASSY,ARM	172A64-72300-Y	61
CYLINDER,BOOM CMP	172A64-72100-Y	59
DECORATION SET	17AA64-03811	16
DEFLECTOR	129155-51400	113
DIAPHRAGM	119802-03131	106
DIAPHRAGM ASSY	119802-03100	106
DIODE, 1.5A	1A7130-51130	28
DIPSTICK, LUB OIL	119515-34801	111
DRAIN PLUG, WATER	172444-13210	22
DRIVE	172A64-73450	66
DRIVE	172A64-73610	67
DRIVE SET	17AA64-03801	16
DUCT ASSY,OC(GRAY49)	172A64-13700	22
DUST COVER	172448-73900	69
ELBOW	172487-76200	84
ELBOW 1/2X3/8 ASSY	172A64-76160	88
ELBOW 90ç 1/4X3/8	172147-76180	82
ELBOW,NIPPLE	172131-76130	84
ELEMENT	119655-12560	19
ELEMENT	119810-55650	24
EMBLEM ASSY Y	172A64-03050	56
EV A,COVER L	172A64-61450	50
EV A,COVER R	172A64-61470	50
EV B,COVER L	172A64-61460	50
EV BONNET	172A64-65170	56

Description	Parts Number	P.
EV,SEAT BASE	172A64-64120	54
EV,SEAT MOUNT	172A64-64960	55
EV,STEP	172A64-62130	51
EXTEND BLADE (L)	172A64-94250	98
EXTEND BLADE (R)	172A64-94260	98
EXTENSION CYLINDER ASSY	172A64-72700	65
FAN (D=290)	119233-44740	112
FIE ASY(3TNV70-XBV	719540-51450	113
FILTER	172A64-74180	75
FILTER ASSY,RETURN	172A64-73770	79
FILTER, LUB. OIL	119305-35151	111
FILTER,SUCTION	172A64-73700	79
FITTING	119840-59570	117
FITTING	172124-76160	84, 88
FITTING	172141-76180	59, 61, 62, 68, 80, 84, 88
FITTING	172147-76260	88
FITTING	172187-76170	88
FITTING	172422-76130	88
FITTING	172478-76200	68
FITTING	172730-75141	80, 81
FITTING AA04C04Y	233910-20000	62, 63, 64, 65, 82
FITTING BA04C04Y	233940-20000	82
FITTING CA04C04Y	233930-20000	82
FITTING CA06C06Y	233930-30000	86
FITTING 1/4	172183-76200	88
FITTING 3/8-1/4L	172141-76920	88
FITTING 90-3/8	172142-76181	88
FITTING G1/4	172455-76220	90
FITTING G3/8	172116-76381	88
FITTING PF1/2	172137-75570	89
FITTING PF1/4	172123-76121	88, 90, 91
FITTING PF3/8	172645-76570	88
FITTING T 1/4	172162-76320	82
FITTING, GREASE	172312-77820	92
FLANGE	119717-51150	109, 114
FLANGE BOLT H M 6X10	261060-60102	111, 115, 116
FLANGE BOLT H M 6X12	261060-60122	104, 105, 109, 121
FLANGE BOLT H M 6X14	261060-60142	116
FLANGE BOLT H M 6X16	261060-60162	104
FLANGE BOLT H M 6X20	261060-60202	107, 116
FLANGE BOLT H M 6X25	261060-60252	105
FLANGE BOLT H M 6X30	261060-60302	112
FLANGE BOLT H M 6X35	261060-60352	109
FLANGE BOLT H M 6X40	261060-60402	104
FLANGE BOLT H M 6X45	261060-60452	105, 116
FLANGE BOLT H M 6X60	261060-60602	104
FLANGE BOLT H M 6X65	261060-60652	104
FLANGE BOLT H M 8X12	261060-80122	112
FLANGE BOLT H M 8X16	261060-80162	106
FLANGE BOLT H M 8X20	261060-80202	58, 112, 119
FLANGE BOLT H M 8X30	261060-80302	36
FLANGE BOLT H M 8X40	261060-80402	106
FLANGE BOLT H M 8X50	261060-80502	112
FLANGE BOLT H M10X16	261061-00162	47
FLANGE BOLT H M10X20	261061-00202	47
FLANGE BOLT H M10X25	261061-00252	118
FLANGE NUT H M8	263060-80002	104, 108
FLANGE NUT H M8	263660-80002	10, 18, 41
FLANGE NUT H M10	263061-00002	119
FLANGE NUT H M10	263671-00002	23
FLANGE, MOUTING	172456-77160	67
FLANGE, PUMP INLET	172124-76100	80
FLANGE,SWIVEL	172446-73890	69
FLEX HORN	129400-92410	120
FLOAT	121257-55731	24, 26
FLOORMAT	172A64-62270	51
FLYWHEEL ASSY	119515-21590	110
FLYWHEEL ASSY (12P)	X3A08863KA	119
FORK ASSY,IDLER	172A64-37200	33
FORK L,IDLER	172A64-37130	33
FORK R,IDLER	172A64-37140	33
FRAME ASSY,L-CENTER	172A64-50201	44
FRAME, CRAWLER (R)	172A64-50410	44
FRAME,CRAWLER L(49)	172A64-50400	44

Description	Parts Number	P.
FRAME,L-CENTER (49)	172A64-50200	44
FRAME,TURNING (49)	172A64-54100	45
FRONT BEARING	172456-77240	67
FUEL GAUGE	172456-14151	23
FUEL INJECTOR	119717-51300	113
FUEL PIPE	172456-14610	24
FUEL PIPE L=260	172171-14610	23
FUEL PUMP	129612-52100	24
FUEL TANK, ASSY	172A64-14110	23
FUSE	294201-50000	29
FUSE 3A	172AYV-17490	9
FUSE 40A	172447-17150	29
G'TEL BRACKET ASSY	17AA64-17750	7
G'TEL MODCOD50	172AYA-17720	7
G'TEL REL 9000	172AYA-17700	7
G'TEL, BRACKET	172AYA-17710	7
GASKET	119717-42031	112
GASKET	119717-61070	115
GASKET	124701-11911	18
GASKET	129155-52051	114
GASKET	172162-14200	23
GASKET	172187-17570	52
GASKET	194151-04150	23
GASKET 6	234180-60000	24, 26
GASKET 8	234140-80000	112, 120
GASKET 10	129150-49360	112
GASKET 12	234141-20016	116
GASKET 16	124465-44950	112, 120
GASKET LOWER COVER	119717-61050	115
GASKET RGU55	172449-72321	61, 62, 65
GASKET RGU65	172449-72960	63
GASKET SIDE COVER	119717-51711	113
GASKET SIDE COVER	119717-51761	113
GASKET, BONNET	119515-11310	106, 120
GASKET, BONNET	119515-11330	106, 120
GASKET, C.W. PUMP	119515-42020	112, 120
GASKET, CYL. HEAD	119515-01330	103, 120
GASKET, DELIVERY	124550-51350	113
GASKET, NOZZLE	119600-11460	106, 120
GASKET, RETURN	129901-59560	117, 120
GASKET,MANIFOLD	119717-13110	108, 120
GAUGE	172447-75600	79
GAUGE ASSY	172187-17341	52, 53
GEAR	172456-77170	67
GEAR ASSY, IDLE	119717-25101	109, 121
GEAR, RING	124950-21600	110
GEAR,PUMP	119717-25930	109
GENERATOR ASSY	119910-77200	119
GEROLLER ASSY	172A64-73350	66
GREASE NIPPLE	247610-20000	33, 35, 36, 59, 92, 96, 97, 98
GREASE NIPPLE	247610-40000	39, 41, 59, 61, 95, 98
GREASE NIPPLE	247610-50000	35, 45, 61, 62, 63, 94
GRIP (L)	172164-45951	36
GRIP (R)	172164-45961	36
GRIP, BLADE	172164-45970	37
GRIP,RED	172A77-46050	34, 35
GROMMET	172A23-72052	59, 61, 62
GTEL, SEAL	172AYA-17770	7
GUID ASSY,445 (2J)	172A64-729501	62
GUID ASSY,500 (2J)	172A64-729001	61
GUIDE	172A23-72081	59, 61, 62
GUIDE ASSY, 545 (2J)	172A64-722501	59
GUIDE ASSY,445	172A64-72951-1	62
GUIDE ASSY,445	172A64-72951-Y	62
GUIDE ASSY,500	172A64-72901-1	61
GUIDE ASSY,500	172A64-72901-Y	61
GUIDE ASSY,545	172A64-72251-Y	59
GUIDE ASSY,545 (2J)	172A64-72251	59
GUIDE ASSY,HOSE	172A64-71210	57
GUIDE ASSY,HOSE	172A64-71211	57
GUIDE L,HOSE ASSY	172A64-76200	83
GUIDE PL,HOSE ASSY	172A64-76250	89
GUIDE PR,HOSE ASSY	172A64-76260	89
GUIDE R,HOSE ASSY	172A64-76240	83

Description	Parts Number	P.
GUIDE, DIPSTICK	121520-34810	111
GUIDE, RACK	158600-51790	114
GUIDE, VALVE	119515-11800	106
HANDLE, COCK	104200-55341	24, 26
HANDLE, LOCK	172187-61421	49, 56
HARNEES, KEY SWITCH	172187-17070	30
HARNESS (A), WIRE	172A64-16501	28
HARNESS (B), WIRE	172A64-16551	29
HARNESS ASSY, A	172A64-16502	28
HARNESS ASSY, B	172A64-16552	29
HARNESS C	172458-16140	28
HARNESS, BAT. MINUS	172A64-16131	28
HARNESS, F	172A64-16120	28
HARNESS, BOOM LAMP	172448-16550	31
HEAD 60 30	172447-72860	64
HEAD 6035 COMPL.	172149-72241	59
HEAD ASSY, 55 30	172A64-72810	65
HEAD ASSY, CYLINDER	119515-11740	106
HEAD ASSY, CYLINDER	172449-72410	61
HEAD ASSY, CYLINDER	172449-72560	62
HOLDER ASSY	129407-77300	118
HOLDER, NOZZLE	118200-53010	117
HOOD, ASSY (YELLOW:2J)	172A64-651001	56
HORN	194151-57100	29
HOSE	172A46-78500	90
HOSE	184015-59130	24
HOSE (9.5X600)	172455-14470	23
HOSE 340	184014-59650	25
HOSE 850	184015-59250	24
HOSE A, AIR CLEANER	172A64-11520	19
HOSE ASSY, FO 260	172A64-14250	24
HOSE B, AIR CLEANER	172A64-11530	19
HOSE F204BB043W	172A64-78501	81
HOSE F204BB059W	172A64-78511	81
HOSE F204BB090	172A64-78330	85
HOSE F204BC059	172A64-78250	82
HOSE F204BC059S	172A64-78270	84
HOSE F204BC063	172A64-78310	82
HOSE F204BC069	172A64-78260	82
HOSE F204BC069	172A64-78261	82
HOSE F204BC111	172A64-78340	85
HOSE F204BC137K	172A64-78391	83
HOSE F204BC147K	172A64-78401	83
HOSE F204BC198R	172A64-78301	83
HOSE F204BC248R	172A64-78291	83
HOSE F204BC303R	172A64-78411	83
HOSE F204BC330R	172A64-78421	83
HOSE F204BE082W	172A6478460	81
HOSE F204BE094W	172A64-78481	81
HOSE F204BE094W	172A6478482	81
HOSE F204BX032W	172A64-78470	81
HOSE F205BB085W	172A64-78441	81
HOSE F205BB089W	172A64-78451	81
HOSE F206BC030	172A64-78371	82
HOSE F206BC035	172A64-78350	82
HOSE F206BC041	172A64-78380	82
HOSE F206BC045	172A64-78360	82
HOSE F206BC115R	172A64-78551	89
HOSE F403BB095	172A64-79140	91
HOSE F403BB095	172A64-79230	91
HOSE F403BB120	172A64-78790	91
HOSE F403BC026	172A64-78651	84
HOSE F403BC117	172A64-78681	90
HOSE F403BC117	172A64-78800	91
HOSE F403BC125	172A64-78810	91
HOSE F403BC132	172A64-79130	91
HOSE F403BC138	172A64-79220	91
HOSE F403BC150S	172A64-78821	91
HOSE F403BE115	172A64-78671	90
HOSE F403CC038	172A64-78700	90
HOSE F403CC042	172A64-78640	90
HOSE F403CC066	172A64-78630	90
HOSE G504BC030S	172A64-79250	68
HOSE G804BY120	172A64-78721	90

Description	Parts Number	P.
HOSE G804BY173	172A64-78730	90
HOSE G804YY055	172A64-78211	82
HOSE G804YY055	172A64-78212	82
HOSE G804YY077	172A64-78221	90
HOSE G806YY021	172A64-78231	86
HOSE G808BY075	172A64-78170	87
HOSE G808CY082S	172A64-78161	87
HOSE G808YY032S	172A64-78191	87
HOSE G808YY138	172A64-78200	87
HOSE H206BZ062S	172A64-78140	80
HOSE H206CC	172A64-78570	89
HOSE H208BZ050S	172A64-78130	80
HOSE H208BZ059S	172A64-78120	80
HOSE H504BC056S	172A64-78610	82
HOSE H504CC103S	172A64-78620	80
HOSE H504CE052	172A64-78611	82
HOSE H504CE052	172A64-78612	82
HOSE H506BC	172A64-78580	89
HOSE NA, SUCTION	172A64-78101	80
HOSE P202BB085W	172A64-78492	81
HOSE P204BC050W	172A64-78520	81
HOSE P204BC068W	172A64-78530	81
HOSE P602YY090	172A64-77800	92
HOSE P602YY100	172A47-77800	92
HOSE, OIL DRAIN	119540-39930	105
HOSE, OIL DRAIN CMP	119540-39910	105
HOUSING	168PA0-86020	57
HOUSING	172447-17140	29
HOUSING ASSY, GEAR	119717-01501	104
HOUSING, BEARING	172456-77150	67
HOUSING, FLYWHEEL	119515-01601	105
HOUSING, VALVE ASSY	172A64-73640	67
HUB,SWIVEL	172448-73860	69
HYDRAULIC FILTER	172A64-73780	79
IDLER	172A64-37100	33
IDLER, ASSY	172A64-37210	33
IN-PANEL (G)	172A47-63110	52
IN-PANEL (R)	172A47-63121	52
INDICATOR PANEL	172472-17351	53
INSULANT,THERMAL	172183-11400	18
JEU DE JOINTS	719544-92600	120
JOINT	172A64-74640	77
JOINT 12, PIPE	101304-59020	117
JOINT G1/8-G1/8	172A64-76101	81
JOINT, DRAIN	172A64-76120	86
JOINT,GREASE	172A47-77820	92
JOINT21-M20X48	172A64-68290	101
KEY	168PA0-86050	57
KEY	172AYV-17430	9
KEY	119717-11190	106
KEY	122710-51090	113
KEY 4X12	225120-40120	110
KEY ASSY	933110-00301	30
KEY ASSY, CYLINDER	172164-66170	49, 56
KEY HARNESS	172AYV-17440	9
Kit BAUMACO D	172AYV-17310	9
KIT,SEAL SWING MOTOR	172A64-73660	67
KNOB	172A64-74920	77
KNOB RED M10	1D4070-23580	34, 35
KNOB, THROTTLE LEVER	194150-01190	38
LABEL PEDAL LOCK	172458-03240	41
LABEL PICTOGRAMME	172A59-03820	16
LEVER	172A64-74910	77
LEVER	119810-55340	24
LEVER (R), TRACK	172A64-45130	36
LEVER ASSY, GOVERNOR	119761-61500	115
LEVER ASSY, W-N	172A64-45800	38
LEVER ASSY,ACCEL	172A64-12140	20
LEVER L ASSY,TRACK	172A64-45101	36
LEVER L,TRACK (49)	172A64-45100	36
LEVER R ASSY,TRACK	172A64-45131	36
LEVER STAND ASSY,L	172A64-46101	35
LEVER STAND,L (73)	172A64-46100	35
LEVER, CONTROL	119515-61440	115

Description	Parts Number	P.
LIFTER, ENGINE	119718-07910	106
LIMITER ASSY, FUEL	158601-61790	116
LIMITER,CURRENT	119653-77710	29
LINK (L), BUCKET	172A64-814101	96
LINK (R), BUCHET	172A64-814401	96
LINK ARM ASSY,W-N	172A64-45850	38
LINK ASSY,BUCKET	172A64-81380-Y	96
LINK, ASSY	172A64-45650	39, 41
LINK, BUCKET	172A64-813801	96
LINK, L=28.8 :88	119717-61140	115
LINK, L=29.3 :3	119717-61120	115
LINK, L=29.8 :98	119717-61130	115
LINK, L=30.3 :03	119717-61150	115
LIQUID,SEAL	977770-1207F	120
LOCK LEVER ASSY,R(49	172A64-46450	34
LOCK LEVER ASSY,R(49	172A64-46451	34
LOCK LEVER,L(GRAY:49	172A47-46343	35
LOCK LEVER,L(GRAY:49	172A47-46344	35
LOCK PLATE,FO	172A64-61820	49
LOCKING	118400-51370	113
MAIN BEARING SET	719717-02901	103
MAIN METAL US=0.25	719717-02911	103
MANIFOLD, EXHAUST	119540-13100	108
MED, KEY SWICTH	172AYV-16750	8
MED, LED HARNESS	172AYV-16680	8
METAL ASSY, CRANK PIN	119515-23601	110, 121
METAL CLIP	1A7347-51200	28
METER ASSY, HOUR	172187-17350	52
MODCOD50 FILM	172AYA-17780	8
MOTOR ASSY, TRAVELING	172A64-73300	66
MOTOR ASSY, TURNING	172A64-73310	67
MOUNT ASSY,BONNET(73	172A64-65200	56
MOUNT ASSY,ENGINE	172A64-13120	21
MOUNT ASSY,FUEL OEL	172A64-14410	23
MOUNT ASSY,PUMP	172A64-71100	57
MOUNT ASSY,SEAT	172A64-64201	55
MOUNT ASSY,SEAT (73)	172A64-64200	55
MOUNT FL,ENGINE	172A64-13100	21
MOUNT FR,ENGINE	172A64-13110	21
NEEDLE BEARING	172456-77250	67
NEEDLE BEARING	241622-02620	58
NIPPLE	172186-76390	82
NIPPLE G1/4	172A47-76230	88
NOZZLE ASSY	119517-53001	117
NOZZLE ASSY	119517-53010	117
NUT	26347-080002	38
NUT	119620-59700	117
NUT	129255-61410	115
NUT	X02802-10230	118
NUT	X9490561370	118
NUT	XM8637-20000	119
NUT H M	267560-60002	116
NUT H M	267560-80002	36, 37
NUT H M	267561-00002	36
NUT H M	267561-20002	20, 93
NUT H M	267570-80002	41
NUT H M 6	267160-60002	27, 114
NUT H M 8	267160-80002	20, 28, 31, 39, 41, 68, 70
NUT H M10	267161-00002	21, 58, 96, 97
NUT H M12	267161-20002	109, 114
NUT H M14	267161-40002	8
NUT H M14	267361-40002	21
NUT H M16	267161-60002	44
NUT H M18	267761-80002	29
NUT M6	129209-61370	115
NUT M8XP1.0	129150-11750	106
NUT W/WASHER H M	260510-80002	18, 36, 39, 41
NUT, 12	26736-120002	116
NUT, GOVERNOR WEIGHT	119660-61300	115
NUT,ADJUSTING	172A64-74660	77
NUT,LOCK	172A64-74900	77
O-RING	102103-55520	24, 26
O-RING	119717-42320	112
O-RING	119717-51420	114

Description	Parts Number	P.
O-RING	129129-77350	118
O-RING	129155-51580	113
O-RING	158552-61900	116
O-RING	172455-75300	79
O-RING	243110-00060	71, 72, 74
O-RING	243110-00110	58
O-RING	243110-00120	71, 72, 73, 74, 76
O-RING	243110-00140	58
O-RING	243110-00160	22, 79, 116
O-RING	243110-00180	70, 71, 72, 73, 74
O-RING	243110-00210	34, 39, 40, 41
O-RING	243110-00220	58
O-RING	243110-00320	104, 107, 120
O-RING	243110-00350	80
O-RING	243110-00380	79
O-RING	243112-40100	24, 26
O-RING	243150-00080	75, 81
O-RING	243150-00090	71
O-RING	243150-00100	71
O-RING	243150-00140	33, 58, 74, 80, 81, 84, 88
O-RING	243150-00180	80, 88
O-RING	243150-00200	77
O-RING	243150-00220	58
O-RING	243150-00300	33
O-RING	243150-00440	79
O-RING	243160-00150	113
O-RING	243210-00350	80
O-RING	243210-00700	69
O-RING	243410-00140	58
O-RING	243410-00240	120
O-RING	243410-00630	58
O-RING	243410-00670	58
O-RING 1A S-7.0	243410-00070	115
O-RING 1A S-14.0	194327-45640	58
O-RING 1B P-10A	243152-40100	75
O-RING 1B P-11.0	243150-00110	58, 59, 61, 62, 68, 70, 71, 72, 73, 74, 75, 76, 80, 84, 88, 90, 91
O-RING 27X5.7	172124-46200	35, 36
O-RING 55.76X5.7	172142-73800	69
O-RING P 12.0	119624-32040	104, 120
O-RING S6	129155-51280	113, 115
O-RING, F.I.PUMP	121850-51960	104, 120
O-RING, P15.0	119717-32060	111, 120
O-RING, P17.0	119717-32050	104, 120
OVERLOAD 250	172456-74280	70
OVERLOAD 300/5	172456-74440	70
PACKING	168PA0-86030	57
PACKING	172187-17320	52, 53
PACKING S 22	172458-74230	70, 71, 72, 74, 75, 76
PACKING G4	172458-74720	70, 71, 72, 73, 74, 76
PAD,PEDAL	172458-45950	40
PAN HEAD SCREW M	265570-40082	55
PAN HEAD SCREW M	265570-50122	23
PAN HEAD SCREW W/WASHER	260220-50122	23, 114
PAN HEAD SCREW W/WASHER	260220-60162	114
PAN, DUST	119258-12530	19
PANEL	172A77-17250	52
PANEL, INSTRUMENT	172472-17501	52
PARALLEL PIN	119717-51070	113
PARALLEL PIN 6x12	223120-60120	57
PARALLEL PIN 8X 16	223120-80160	57
PARALLEL PIN 8X16	129100-01580	105, 110
PARALLEL PIN 8x20	223120-80200	57
PEDAL (L), TRACK	172A47-44230	36
PEDAL (R), TRACK	172A47-44200	36
PEDAL ASSY (GRAY:49)	172A64-45900	40
PEDAL,SWING(GRAY:49)	172458-45521-1	39, 41
PILOT BLOCK	172A47-76310	90
PIN	172113-12522	20
PIN	172137-70570	67
PIN 8X16	224870-80160	23
PIN ,40X120	172A64-82670	63
PIN 4.75X14	933110-54100	36, 37, 38, 39, 41
PIN 6,COME-OFF SNAP	1C6281-52310	20, 36, 37, 38, 39, 41

Description	Parts Number	P.
PIN 10X28, STRAIGHT	194940-24350	45
PIN 25	172448-94710	98
PIN 25X143	172448-94700	98
PIN 30X65	172A64-50730	65
PIN 30X76 A	172A64-94350	98
PIN 30X76 B	172A64-94370	98
PIN 30X87	172A64-82820	95
PIN 30X121	172A64-82790	94
PIN 30X159	172A64-82850	96, 97
PIN 35X110	172A64-82620	59
PIN 35X127	172A64-82760	59
PIN 35X155	172A64-82730	94
PIN 35X237	172A64-82601	94
PIN 40X96	172A64-82650	63
PIN ASSY	172A55-99451	97
PIN, 50X312	172A64-82641	93
PIN, BARREL LOCKING	129155-51140	113
PIN, PISTON	119515-22300	110, 121
PIN,30X95	172A64-50720	65
PIN,PARALLEL(4X14	158802-85040	57
PIN,SPRING	172A64-74930	77
PINION	129129-77270	118
PINION, CONTROL	129155-51550	113
PINION, STARTER	X02837-12350	118
PIPE (L), PTO	172A64-766001	89
PIPE (R), PTO	172A64-766301	89
PIPE A, WATER	172A64-13510	22
PIPE ASSY ,INJECTION	119546-59810	117
PIPE ASSY ,INJECTION	119546-59820	117
PIPE ASSY ,INJECTION	119546-59830	117
PIPE ASSY, HYDRAULIC	119717-39210	111
PIPE ASSY, LUB,OIL	119515-35080	111
PIPE ASSY,F.O.RETURN	119515-59540	117
PIPE B, WATER	172A64-13520	22
PIPE, AIR	172A64-11310	18
PIPE, FUEL	172186-13810	22, 24
PIPE, FUEL RETURN	119540-59570	117
PIPE, KNOCK	119660-01911	104
PIPE,CORRUGATE L770	184015-59260	24
PIPE,CORRUGATED 1410	172456-14620	24
PIPE,CORRUGATED L180	172A64-14260	24
PIPE,FUEL RETURN	119540-59560	117
PIPE,HAND HOLD	172A64-64710	55
PIPE,HAND HOLD	172A64-64730	55
PISTON ,HYDRAULIC	172456-77180	67
PISTON 55(24-28)	172A20-72430	59
PISTON ASSY (OS=0.25)	119515-22900	110
PISTON W/RINGS	119515-22080	110, 121
PISTON,55	172A64-72860	65
PISTON,55X22X28	172A64-72440	62
PISTON,55X27X28	172A64-72390	61
PISTON,60X22X28	172A64-72640	64
PISTON,65X27X31	172A64-72540	63
PLATE	172A64-74590	77
PLATE	119717-51330	113
PLATE	129209-61970	116
PLATE	172137-70590	67
PLATE	172187-17470	52, 53
PLATE	172456-77220	67
PLATE ASSY	X2A10592KA	119
PLATE ASSY (GRAY:73)	172A64-64100	54
PLATE ASSY,BASE L	172A47-46230	35
PLATE ASSY,COVER(73)	172A64-61630	49
PLATE ASSY,COVER(73)	172A64-61850	49
PLATE CMP	172A78-74650	77
PLATE(C),LOCK(GRAY49	172117-83970-7	63
PLATE, BAFFLE	119515-11320	106
PLATE, BAFFLE	119717-03031	106
PLATE, GUIDE (L)	172A59-46510	42
PLATE, GUIDE (R)	172A59-46520	42
PLATE, LINK	172A64-45840	38
PLATE, RUBBER	172A64-14230	23
PLATE, SPACER	172183-76250-2	89
PLATE, SPACER	172183-76250-Y	89

Description	Parts Number	P.
PLATE, VALVE	172148-73350	67
PLATE,CIRCULAR	172A64-74650	77
PLATE,COIL	X2A07075KB	119
PLATE,DIAPHRAGM	119802-03110	106
PLATE,FRICTION	172456-77210	67
PLATE,LOCK	172A64-65180	56
PLATE,LOCK (GRAY:49)	172A64-50770	65
PLATE,LOCK(PTO (10)	172448-45800-3	41
PLATE,SLIDE 520	172A64-72980-Y	61, 62
PLATE,SLIDE 520 (2J)	172A64-729801	61, 62
PLATE,SLIDE 585	172A23-72951-Y	59
PLATE,SLIDE 585 (2J)	172A23-729511	59
PLATE,VALVE	172A64-73380	66
PLUG	1A6750-29850	57
PLUG	172A64-73440	66
PLUG	121250-49121	22
PLUG	129001-32330	104
PLUG	158600-51410	113
PLUG	158600-51420	113
PLUG	158600-51570	113
PLUG	172137-70490	67
PLUG	172151-73400	77
PLUG	172168-73590	67
PLUG	172176-67790	49
PLUG	172187-17560	52
PLUG	172458-74630	70, 71, 73, 74, 76
PLUG (RELIEF VALVE)	168PA0-86750	57
PLUG 6	101720-55750	24, 26
PLUG 25	119285-01990	103
PLUG 30 (SUS)	105311-01090	103
PLUG 35	119285-11990	106
PLUG 45	119623-01250	103
PLUG GPM1/32	172458-74460	71, 72
PLUG M8,DRAIN	234911-40002	79
PLUG M10	238871-00002	115
PLUG M16	105425-01690	21
PLUG PT 1/4	238710-20000	90
PLUG PT 1/8	238710-10000	67, 69, 90
PLUG PT 1/16,SCREW	23876-005000	106
PLUG PT1/4	124160-01910	103
PLUG PT1/8	124060-01050	103
PLUG PT1/8	933171-13691	33
PLUG PT3/8	238760-30000	104
PLUG, COOLER	172446-13450	22
PLUG, DRAIN	119656-39930	105
PLUG, DRAIN	171056-49120	112
PLUG, DRAIN R03	129916-49740	112
PLUG, G1/4	178076-12400	57
PLUG, GLOW	119717-77800	106
PLUG, OIL FEED	172116-75850B	79
PLUG,PF1/8	172458-74670	75
PLUNGER ASSY	119515-51100	113
PLUNGER BLOCK CMP	168PA0-86140	57
PORT BLOCK	168PA0-86010	57
POWER PISTON SET	168PA0-29010	57
PRINT CIRCUIT	172187-17360	52, 53
PROTECTOR (GRAY:49)	172A64-72690	64
PROTECTOR NOZZLE	129901-11450	106, 120
PTO SEC ASSY	172A64-74210	74
PUMP ASSY, C.W.	119515-42001	112
PUMP ASSY, PISTON	172A64-73100	57
PUMP COMP.,GEAR	168PA0-87010	57
RACK, CONTROL	119717-51500	113
RADIATOR ASSY	172A64-13210	22
RAIL SET	172A59-64970	10
RECEIVER,SPRING	119717-51570	113
RELAY	172AYV-17580	9
RELAY, GROW	119650-77910	29
RELAY, SAFETY	119247-77100	29
RELIEF VALVE	168PA0-86740	57
RELIEF VALVE	172456-74290	74
RELIEF VALVE 170	172A64-74490	75
RELIEF VALVE 210	172A64-74480	72
REMOTE CONTROL VALVE (D)	172A64-74320	77

Description	Parts Number	P.
REMOTE CONTROL VALVE (L)	172A64-74310	77
RESERVOIR TANK ASSY	772A64-75100	79
RETAINER	119534-61430	115
RETAINER	129129-77260	118
RETAINER	158600-51270	113
RETAINER	158842-86360	57
RETAINER	158842-86610	57
RETAINER	158842-86620	57
RETAINER	X0283270140	118
RETAINER, INJ. PIPE	129150-59120	117
RETAINER, SHAFT	119660-61901	115
RETAINER, SPRING	129508-11180	106
RETAINING SPRING	158600-51170	113
RING	105027-12580	19
RING	129129-77430	118
RING	172456-77190	67
RING EL, BUCK UP	172148-73870	69
RING SET	119515-22500	110
RING SET (OS=0.25)	119515-22550	110
RING, 8	172A64-74190	75
RING, BACK UP	172137-37850	33
RING, RETAINING	110250-55610	24, 26
ROCK ASSY	172A64-65250	56
ROCK WASHER 55	172173-72550	61, 62, 65
ROD	172725-16160	27
ROD (A), SPOOL	172124-46340	36
ROD ASSY, CONNECTING	119515-23000	110, 121
ROD ASSY, BLADE	172A64-72651	64
ROD ASSY, SPRING	172A47-46310	35
ROD ASSY, STOPPER	172A64-65300	101
ROD ASSY, SWING	172A64-72550	63
ROD END 8	172122-46590	36
ROD END, CMP	172449-72810	63
ROD STOPPER	172444-64730	56
ROD, ARM CYLINDER	172A64-72350	61
ROD, BOOM CYLINDER	172A64-72150	59
ROD, BUCKET CYLINDER	172A64-72450	62
ROD, PUSH	119515-14400	109
ROD, ASSY, VARIABLE	172A64-72750	65
ROD, PUSH	172A64-74600	77
ROLLER	172A64-73630	67
ROLLER	X02830-60061	118
ROLLER CATCH, F	172448-65680	55
ROTOR ASSY, LUB. OIL	119717-32120	104
ROTOR INNER	119717-32110	104
ROTOR SET 13	1E1271-27620	57
RUBBER 45, EDGE	172445-62010	50
RUBBER 315	172456-13480	22
RUBBER PLATE	172446-14250	29
RUBBER PLATE (A)	172446-78760	48
RUBBER PLATE (B)	172446-78770	48
RUBBER PLATE A	172A29-62900	23
RUBBER, CUSHION 300	172638-06710	22
RUBBER, 20	172478-65220	49
SAFETY VALVE	129900-32130	104
SCREEN	171081-55910	24, 26
SCREW	119259-77250	119
SCREW	129100-51570	113
SCREW	129129-77460	118
SCREW	XYSPS400800	119
SCREW 5X12	228575-00121	52
SCREW 5X16	228575-00160	107
SCREW CBL M6X20	172451-65610	8
SCREW M4	104200-55750	24, 26
SCREW M5X10	228575-00100	107
SCREW M6X16	119802-32130	104
SCREW M8X12	172441-44350	42
SCREW, 10 X 45	26979-100452	58
SCREW, VALVE	129150-11230	106
SEAL	172151-73420	77
SEAL	172458-74130	71, 72, 73, 74, 76
SEAL 35X45X4	172448-81610	59, 94, 95
SEAL 40X50X4	172448-72650	63
SEAL 50X60X4, DUST	172448-54120	45


Description	Parts Number	P.
SEAL A	172A64-13310	22
SEAL A,OC	172A64-13760	22
SEAL B	172A64-13320	22
SEAL B,OC	172A64-13770	22
SEAL C	172A64-13680	22
SEAL C, RUBBER	172649-65770	56
SEAL C,OC	172A64-13780	22
SEAL D,OC	172A64-13790	22
SEAL KIT	172638-72200	59, 64
SEAL KIT	172638-72201	64
SEAL KIT,END COVER	172A64-73520	66
SEAL KIT,TRAVEL M	172A64-73510	66
SEAL QLF255218, OIL	1E6140-73420	32
SEAL QLN306213.2,OIL	1A1060-48300	33
SEAL RING BS1/2	172AYA-76240	11, 12
SEAL SET	172149-57610	45
SEAL SET ,SWIVEL	172446-73900	69
SEAL SET HEAD	172449-72020	61
SEAL SET, HEAD 60 30	172A64-72020	64
SEAL SET,HEAD (65-35)	172449-72040	63
SEAL SET,HEAD 60 35	172A64-72030	59
SEAL SET,HEAD55 30	172A64-72040	62, 65
SEAL TC25 42 08, OIL	244212-54208	58
SEAL WASHER 8S	221900-80002	111, 120
SEAL WASHER 10S	221901-00002	115
SEAL WASHER 12S	221901-20002	116, 117, 120
SEAL WASHER 16S	221901-60002	21, 114, 120
SEAL, DUST	172448-81600	61, 62, 64, 95, 96
SEAL, DUST	933126-38600	33
SEAL, OIL	119717-01800	104
SEAL, OIL	124085-02220	105
SEAL, SWIVEL	172447-73840	69
SEAL, UPPER	172149-57620	45
SEAL, VALVE STEM	119717-11340	106, 120
SEAL, VALVE STEM	119717-11350	106, 120
SEAL,240	172A64-64930	55
SEAL,480	172A64-64920	55
SEAL,560	172A64-64940	55
SEAL,600	172A64-64910	55
SEAL,1170	172A64-65160	56
SEAL,1500	172A64-64950	55
SEAL,STEP	172A64-62120	51
SEAL,WEIGHT C	172444-54920	45
SEALING CAP	272411-20000	103
SEALING CAP	272412-50000	112
SEAT ASSY	172A59-64000	10
SEAT BELT	172A59-64980	10
SEAT, SPRING	172458-74530	72, 75
SEAT,SPRING	172A64-74610	77
SECTION TRAV. (L)	172A64-74350	72
SECTION, ARM	172A64-74230	74
SECTION, BLADE	172A64-74110	76
SECTION, BOOM	172A64-74400	71
SECTION, BOOM LOCK	172A64-74430	70
SECTION, BUCKET	172A64-74450	70
SECTION, CONFLUENCE	172A64-74150	75
SECTION, CONFLUENCE	172A64-74160	75
SECTION, INLET	172A64-74370	72
SECTION, OPTION	172A64-74260	73
SECTION, PTO	172A64-74200	74
SECTION, SWING	172A64-74280	73
SECTION, TRAV. (R)	172A64-74390	71
SECTION, TURNING	172A64-74130	76
SENER	171056-49351	112
SEPARATOR, WATER	129335-55700	24, 26
SERVICE KIT 50H VIO17	ABA006-00A	122
SERVICE KIT 250H/750H VIO17	ABB006-00	122
SERVICE KIT 500H VIO17	ABC006-00	122
SERVICE KIT 1000H+ VIO17	ABE006-00	122
SHAFT	168PA0-86060	57
SHAFT	129129-77400	118
SHAFT	172187-45530	39, 41
SHAFT	172187-45651	39, 41
SHAFT ASSY	172A64-45200	36

Description	Parts Number	P.
SHAFT ASSY, CONTROL	119717-61400	115
SHAFT ASSY, ROCKER	119515-11240	106
SHAFT ASSY,R LEVER	172A64-46470	34
SHAFT, GOV. LEVER	129052-61390	115
SHAFT, IDLE GEAR	119717-25050	109
SHAFT, ROLLER	172448-37310	32
SHAFT, SWIVEL	172446-73872	69
SHAFT,14X54	172A23-72043	59, 61, 62
SHAFT,IDLER	172A64-37120	33
SHIM 30, PIN ADJUST	933160-06711	94, 95, 96, 97, 98
SHIM 35	172141-84601	60, 94
SHIM 40X75X0.5	172165-82580	63
SHIM 40X75X1.2	172165-82590	63
SHIM 40X75X1.6	172165-82600	63
SHIM 50X85X1.2	172165-82530	93
SHIM 50X90X0.5	172165-82520	93
SHIM ASSY	158552-61700	115
SHIM PACK	129155-51600	113
SHIM SET	129901-53800	117
SHIM SET	174307-51700	115
SHIM SET, ADJUSTING	129155-51450	113
SHIM T=0.6	129156-61460	115
SHIM T=1.0	158552-61710	115
SHORT BLOCK ASSY	719534-01000	121
SHROUD ASSY(OC	172A64-13360	22
SILENCER ASSY	172A64-11330	18
SLEEVE	129155-61341	115
SLEEVE,INSULATION	172A64-74940	77
SLIDE PLATE ASSY	172A64-37500	32
SLOTTED SET SCREW M	269790-50162	106
SNAP PIN 4	223720-40000	116
SNAP PIN 10	223721-00000	38
SNAP PIN 14	223721-40000	38
SNAP RING	129155-51540	113
SNAP RING	172173-73690	67
SNAP RING	172173-73700	67
SNAP RING 12	222420-00120	106
SNAP RING 22	222520-00220	110, 121
SNAP RING 25	222420-00250	33
SNAP RING 30	222420-00300	33
SNAP RING 40	222420-00401	69
SNAP RING 42	222520-00420	57
SNAP RING 50	222420-00500	93
SNAP RING E 7	222720-00070	35
SOCKET ASSY	172A64-17250	30
SOCKET CAP SCREW 10,9 M	264500-50102	71, 72, 73, 74, 76
SOCKET CAP SCREW 10,9 M	264500-50452	78
SOCKET CAP SCREW 10,9 M	264500-60162	60, 61, 62
SOCKET CAP SCREW 10,9 M	264500-80252	58
SOCKET CAP SCREW 10,9 M	264500-80352	58
SOCKET CAP SCREW 10,9 M	264501-00252	32, 66
SOCKET CAP SCREW 10,9 M	264501-00352	57
SOLENOID VALVE ASSY	168PA0-87020	57
SOLENOID, STOP	119233-77932	116
SOUCER,FUEL	172458-14370	23
SPACER	172A46-72070	59, 61, 62
SPACER	172A64-73460	66
SPACER	172AYV-16780	8
SPACER	121267-44760	112
SPACER	172146-82910	63
SPACER ASSY	129155-61480	115
SPACER, AUX. SPRING	129155-51530	113
SPACER, OIL SUMP	119515-01720	105
SPACER, SWIVEL	172157-73910	69
SPACER,R	172A64-53450	101
SPECER,F	172A64-53460	101
SPINDLE WHEEL ASSY	172A64-73360	66
SPOOL ASSY,ARM	172A64-74250	74
SPOOL ASSY,BLADE	172A64-74120	76
SPOOL ASSY,BOOM	172A64-74420	71
SPOOL ASSY,BUCKET	172A64-74470	70
SPOOL ASSY,OPTION	172A64-74270	73
SPOOL ASSY,PTO	172A64-74220	74
SPOOL ASSY,SWING	172A64-74300	73

Description	Parts Number	P.
SPOOL ASSY,TRAVEL	172A64-74360	71, 72
SPOOL ASSY,TURNING	172A64-74140	76
SPRING	172A64-74620	77
SPRING	172A64-74630	77
SPRING	119534-61420	115
SPRING	121250-55620	24
SPRING	129001-32320	104
SPRING	129129-77340	118
SPRING	129407-77410	118
SPRING	129486-61650	115
SPRING	172137-70580	67
SPRING	172162-46690	35, 40
SPRING	172165-45970	34
SPRING	172456-77230	67
SPRING	X94917-30461	118
SPRING 8	172068-28490	41
SPRING 2.3X15X60	172A69-46270	35
SPRING 12	933170-01490	20
SPRING 16	933168-14170	60, 62
SPRING PIN 3.5x40	223510-35040	35
SPRING PIN 5x10	223510-50010	114
SPRING PIN 5x32	223510-50032	34
SPRING PIN 6x12	223510-60012	106
SPRING PIN 6x40	223510-60040	35
SPRING PLUNGER	119717-51190	113
SPRING WAHER 16	222121-60000	44, 45
SPRING WASHER	1A1040-43900	40
SPRING WASHER 4	222170-40000	7, 8
SPRING WASHER 5	222170-50000	78
SPRING WASHER 8	172137-46042	59, 61, 62
SPRING WASHER 10	222171-00000	10, 21, 60, 62
SPRING WASHER 12	222171-20000	14, 101, 109, 114
SPRING WASHER 14	222171-40000	21
SPRING WASHER 20	222172-00000	14, 101
SPRING(CRADLE)	168PA0-86650	57
SPRING(RELIEF VALVE)	168PA0-86760	57
SPRING, ADJUST	172448-37712	33
SPRING, CHECK VALVE	172458-74360	71, 72, 75
SPRING, CHECK VALVE	172490-74320	74
SPRING, COIL	129129-77410	118
SPRING, GOVERNOR	129489-61700	116
SPRING, RACK	129155-51591	113
SPRING, SCREEN	121257-55720	24, 26
SPRING, SET	129486-61540	115
SPRING, SHAFT	119515-11280	106
SPRING, TAPER VALVE	104200-55330	24, 26
SPRING, VALVE	119717-11131	106
SPRING,CHECK VALVE	172458-74160	70, 71, 73, 74, 76
SPRING,DIAPHRAGM	119802-03141	106
SPRING,GAS	172455-46890	35
SPRING,RETURN	172458-74540	72, 75
SPROCKET	172A64-29100	32
STOPPER,RAIL	172A64-64170	54
STARTER KIT	X1280996600	118
STARTER RA1 4	119540-77010	118
STAY A	172460-16700	28
STAY ASSY,VALVE	172A64-45600	78
STAY, CHECK VALVE	172458-74640	71, 72, 75
STAY, CHECK VALVE	172458-74650	74
STAY, CHECK VALVE	172490-74330	74
STEP ASSY	172A64-62100	51
STETA ASSY	X3A02982KC	119
STOP VALVE	172A64-74800	78
STOPPER F	172A64-13150	21
STOPPER R	172A64-13160	21
STOPPER, BOOM BRACKET	172A64-54150	14
STRAINER ASSY, FUEL	119833-55620	24
STRAINER, FUEL	194151-04141	23
STUD	129100-35140	111
STUD 21-M20X28	172A64-68250	14
STUD M8X50	119717-13600	108
STUD, FEED PUMP	129155-51020	113
SUMP ASSY, LUB.OIL	119540-01780	105
SUPPLY SEC ASSY	172A64-74380	72

Description	Parts Number	P.
SUPPORT ASSY	172A64-13230	22
SUPPORT ASSY, ARM	119515-11200	106
SUPPORT, BEARING	119717-51060	113
SUPPORT, HOSE (A)	172156-78510	48
SUPPORT, HOSE (B)	172156-78520	48
SUPPORT, ROCKER ARM	119717-11260	106
SUPPORT, STAND 185	172A64-54230	45
SWING CYLINDER, ASSY	172A64-72500	63
SWING SEC ASSY	172A64-74290	73
SWITCH	194464-52190	29
SWITCH ASSY,WASHER	172472-17300	53
SWITCH, HEATER	172187-17290	53
SWITCH, THERMO 110°C	121250-44901	112
SWITCH,(0.5KG)L.O.	114250-39450	111
SWITCH,LIGHT	172187-17280	52, 53
SWITCH,STARTER	172187-17100	30
SWIVEL JOINT ASSY	172448-73840	69
SWIVEL,ASSY	172448-73851	69
SWP HEX.BOLT 5X20	172458-74260	70, 71, 72, 74, 75, 76
TANK ASSY.SUB	119813-44510	22
TAPPET	119620-14200	109, 121
TAPPET ASSY	119717-51200	113
TERMINAL	172151-73610	77
THERMOSTAT	119717-49800	112
THROTTLE GRIP	172498-12250	20
THROTTLE WIRE	172A64-12200	20
THRUST PLATE	168PA0-86330	57
TIMER	129211-77920	29
TIMER, GLOW PLUG	124970-77920	29
TRACK ROLLER,RUBBER	772A64-37300-2	32
TREE CLIP	172183-81160	95
TUBE	172186-13820	22, 24
TUBE	184014-59510	25
TUBE	184015-59140	24
TUBE ASSY, ARM	172A64-72310-Y	61
TUBE ASSY, BOOM	172A64-72110-Y	59
TUBE ASSY, BOOM	172A64-72200-Y	59
TUBE ASSY, BUCKET	172A64-72410-Y	62
TUBE ASSY, PTO	172A64-76600-Y	89
TUBE ASSY, PTO	172A64-76630-Y	89
TUBE ASSY,ARM (2J)	172A64-72310-1	61
TUBE ASSY,BLADE (49)	172A64-72610	64
TUBE ASSY,BOOM (2J)	172A64-72110-1	59
TUBE ASSY,BUCKET(2J)	172A64-72410-1	62
TUBE ASSY,SWING (49)	172A64-72510	63
TUBE ASSY,VARIABLE	172A64-72710	65
TUBE, ADJUSTER	172448-37800	33
TUBE, CORRUGAT	172149-17630	45
U-NUT M	263471-00002	49, 56
U-NUT M22X1.5	172A64-72490	62, 64, 65
U-NUT M24X1.5	172A64-72230	59
U-NUT M27	172141-72250	61, 63
UNDER COVER,EX (49)	172A64-61340	47
V-BELT	251320-03500	112
V-PULLEY, C.W.PUMP	119717-42350	112
V-PULLEY, CRANKSHAFT	119717-21650	110
VALVE	172137-70600	67
VALVE ASSY	172A64-73430	66
VALVE ASSY, CHECK	119813-59950	117
VALVE ASSY, DELIVERY	158600-51442	113
VALVE ASSY, NIPPLE	172122-37844	33
VALVE ASSY, OVERLOAD	172462-74340	71, 74
VALVE ASSY,CONTROL	172A64-74100	70
VALVE DRIVE	172141-77260	67
VALVE PLATE	168PA0-86210	57
VALVE STAND ASSY(49)	172A64-45420	43
VALVE STAND ASSY(49)	172A64-45421	43
VALVE, EXHAUST	119515-11110	106
VALVE, SUCTION	119515-11101	106
VALVE, TAPER	104200-55321	24, 26
VALVE, UNLOADER	119808-12540	19
VALVE, VENT	194250-04321	23
WASHER	1A1380-62160	56, 101
WASHER	119620-21941	110

Description	Parts Number	P.
WASHER	172110-36010	98
WASHER	172151-73450	77
WASHER	221370-80000	28, 35, 36, 38, 39, 41, 56, 101
WASHER	221571-00000	47, 50, 60, 94, 95
WASHER 10	XM860250000	119
WASHER 13.2X30X3.2	172730-05250	43, 101
WASHER 60 B, LOCK	933125-59600	59, 64
WASHER 65, LOCK	172142-72560	63
WASHER GROWER 6	222170-60000	114
WASHER GROWER 8	222170-80000	22, 25, 48
WASHER LL 6	221570-60000	27
WASHER LL 8	221570-80000	48
WASHER LL14	221571-40000	45
WASHER M5	221370-50000	37
WASHER M6	221370-60000	20, 29
WASHER M10	221371-00000	28, 39, 41, 59
WASHER M12	221371-20000	20
WASHER M14	221371-40000	8
WASHER Z8	221170-80000	31, 36, 48, 68
WASHER Z10	221171-00000	80
WASHER, BRAKE ARM	933147-03400	60, 62
WASHER, SIDE CLUTCH	933152-03700	32
WASHER, SPRING	XM219230000	119
WEIGHT (GRAY:49)	172A64-53300	45
WEIGHT ADJ KNOB KIT	172A59-64990	10
WEIGHT ASSY	119717-61200	115
WEIGHT ASSY,OP	172A64-53400	101
WEIGHT KIT(2P	172A64-08600	101
WEIGHT KIT(4P	172A64-08610	101
WIRE, EARTH	933171-15801	28
WORKING LAMP, ASSY	172156-17401	31
YOKE	129407-77210	118




MINI EXCAVATOR

YANMAR

YANMAR CONSTRUCTION EUROPE EQUIPMENT S.A.S

<http://www.yanmar.eu>



PARTS CATALOG

MINI EXCAVATOR

V17U