


Y00B5902,Industrial,"Vertical multi cyl, diesel(T-series)",
[Info]
PcNo=Y00B5902
PcName=3TNE88-(E)B1(B37-2B)
JpnUse=1
JpnSec1=fGf"fwf"
JpnSec2=-§ -
JpnSec3=TNE
JpnPreface=0
EngUse=1
EngSec1=ENGINE (US)
EngSec2=SMALL VERTICAL (B)
EngSec3=TNE
EngPreface=0


1,1,,729001-01560,, "BLOCK ASSY, CYLINDER",1,1,,,,,,,,,,,,,
4,2,,124160-01910,, "PLUG PT1/4",3,3,,,,,,,,,,,,,
5,2,,171051-01921,, PLUG,1,1,,,,,,,,,,,,,
6,2,,23871-010000,, "PLUG PT1/8, SCREW",1,,,,,,,,,,,,,
6-1,2,,23876-010000,, "PLUG PT1/8, SCREW",1,1,,,,,N,,GZ-99001,"E/# 21695",,,,,,
7,2,,27231-500000,, "PLUG 50",1,1,,,,,,,,,,,,,
8,2,,27241-120000,, "PLUG 12",2,2,,,,,,,,,,,,,
9,2,,27241-300000,, "PLUG 30",6,6,,,,,,,,,,,,,
10,2,,129150-02020,, "BOLT, METAL CAP",8,8,,,,,,,,,,,,,
13,2,,129001-02800,, "MAIN BEARING",4,4,,,,,,,,,,,,,
16,2,,129150-02930,, "METAL, THRUST",2,2,,,,,,,,,,,,,
19,2,,129795-02411,, "BUSH, CAMSHAFT",1,1,,,,,,,,,,,,,
20,1,,129150-01200,, "STUD, CYL. HEAD",14,14,,,,,,,,,,,,,
21,1,,129001-01340,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,,,,
22,1,,129150-02870,, "MAIN METAL US=0.25",4,,,,,1,,,,,,,,,
25,1,,129150-02940,, "METAL, THRUST OS=0.25",2,2,,,,,2,,,,,,,,,

Fig. 1 シリンダブロック
CYLINDER BLOCK




1,1,,719810-01500,, "HOUSING ASSY, GEAR",1,1,,,,,,,,,,,,,
3,2,,129795-01800,, "SEAL, OIL",1,1,,,,,,,,,,,,,
4,1,,129400-01520,, "FLANGE,GEARS HOUSING",1,1,,,,,,,,,,,,,
5,1,,121450-01560,, "STUD M 8X 22",3,3,,,,,,,,,,,,,
6,1,,124160-01751,, "CAP, LUB.OIL SUPPLY",1,1,,,,,,,,,,,,,
7,1,,124240-01871,, "COVER, HO-P",1,1,,,,,,,,,,,,,
8,1,,124240-01883,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,,,,
9,1,,129795-01950,, "PIPE, KNOCK L=18",2,2,,,,,,,,,,,,,
10,1,,129150-03100,, "RETAINER,1,1,,,,,,,,,,,,,
11,1,,121850-51960,, "O-RING, F.I.PUMP",1,1,,,,,A,,,,,,,,,
12,1,,24311-000160,, "O-RING 1A P-16.0",2,2,,,,,,,,,,,,,
13,1,,24311-000320,, "O-RING 1A P-32.0",1,1,,,,,A,,,,,,,,,
14,1,,26106-080122,, "BOLT M 8X 12 PLATED",4,4,,,,,,,,,,,,,
15,1,,26106-080162,, "BOLT M 8X 16 PLATED",1,1,,,,,,,,,,,,,
16,1,,26106-080162,, "BOLT M 8X 16 PLATED",3,3,,,,,,,,,,,,,
17,1,,26106-080202,, "BOLT M 8X 20 PLATED",2,2,,,,,,,,,,,,,
18,1,,26106-080452,, "BOLT M 8X 45 PLATED",6,6,,,,,,,,,,,,,
19,1,,26106-080552,, "BOLT M 8X 55 PLATED",3,3,,,,,,,,,,,,,
20,1,,26106-080852,, "BOLT M 8X 85 PLATED",4,,,,,,,,,,,,,
20-1,1,,129001-91840,, "BOLT M 8X 85 PLATED",4,4,,,,,N,,TE-97594,E/#06523,,,,,,,,,
21,1,,26366-080002,, "NUT M 8",3,3,,,,,,,,,,,,,
22,1,,22190-080002,, "SEAL WASHER 8S",4,4,,,,,,,,,,,,,
23,1,,22190-080002,, "SEAL WASHER 8S",1,1,,,,,,,,,,,,,
24,1,,121023-01550,, "COVER, BLIND",1,1,,,,,W,,*,EXXX,,,,,,,,,
25,1,,24341-000240,, "O-RING 1A S-24.0",1,1,,,,,W,,*,EXXX,,,,,,,,,
26,1,,26106-060162,, "BOLT M 6X 16 PLATED",2,2,,,,,W,,*,EXXX,,,,,,,,,

Fig. 2 ギヤケース
GEAR HOUSING



1,1,,129100-01580,, "PARALLEL PIN 8X16",2,2,,,,,,,,,,,,,
2,1,,171301-01600,, "HOUSING, FLYWHEEL",1,,,,,,,,,,,,,
2-1,1,,129612-01600,, "HOUSING, FLYWHEEL",1,1,,,,,N,, TN-96317, "FROM 1ST",,,,,,
3,1,,119620-01750,, "CAP, FLYWHEEL COVER",1,1,,,,,,,,,,,,,
4,1,,26206-100252,, "BOLT M10X25",6,6,,,,,,,,,,,,,
5,1,,26206-100302,, "BOLT M10X30",4,4,,,,,,,,,,,,,
6,1,,129129-01550,, "SUMPASSY, LUB. OIL",1,1,,,,,,,,,,,,,
7,2,,129129-01540,, "LUB.OIL CMP",1,1,,,,,W,, TE-99071, "E/# 21695",,,,,,
9,3,,105425-01690,, "PLUG M16",1,1,,,,,,,,,,,,,
10,2,,22190-160002,, "SEAL WASHER 16S",1,1,,,,,,,,,,,,,
11,2,,26106-080122,, "BOLT M 8X 12 PLATED",8,8,,,,,,,,,,,,,
12,1,,26106-080252,, "BOLT M 8X 25 PLATED",6,6,,,,,,,,,,,,,
13,1,,26106-080852,, "BOLT M 8X 85 PLATED",8,,,,,,,,,,,,,
13-1,1,,129001-91840,, "BOLT M 8X 85 PLATED",8,8,,,,,N,, TE-97594, E/#06523,,,,,
14,1,,26106-080502,, "BOLT M 8X 50 PLATED",4,4,,,,,,,,,,,,,
15,1,,26106-081202,, "BOLT M 8X120 PLATED",4,,,,,,,,,,,,,
15-1,1,,129001-91910,, "BOLT M 8X120",4,4,,,,,N,, TE-97594, E/#06523,,,,,
16,1,,129100-01640,, "CASE ASSY, OIL SEAL",1,1,,,,,,,,,,,,,
18,2,,129795-01780,, "SEAL, OIL",1,1,,,,,,,,,,,,,
19,1,,129100-01580,, "PARALLEL PIN 8X16",2,2,,,,,,,,,,,,,
20,1,,129486-01670,, "BOLT M8X30, COLLAR HD",9,9,,,,,,,,,,,,,


Fig. 3 フライホイールハウジング&オイルパン
FLYWHEEL HOUSING & LUB.OIL SUMP



1,1,,119856-03090,,HOSE,1,1,,,,,,,,,,,,,
2,1,,124736-07900,, "LIFTER, ENGINE",2,2,,,,,,,,,,,,,
3,1,,26106-080142,, "BOLT M 8X 14 PLATED",4,4,,,,,,,,,,,,,
4,1,,729001-11700,, "HEAD ASSY, CYLINDER",1,1,,,,,,,,,,,,,
8,2,,120130-11860,, "GUIDE, VALVE",3,3,,,,,1,,,,,,,,,
10,2,,129150-11810,, "GUIDE, VALVE",3,3,,,,,1,,,,,,,,,
11,2,,26216-060202,, "STUD M 6X 20 PLATED",6,6,,,,,,,,,,,,,
12,2,,27241-400000,, "PLUG 40",2,2,,,,,,,,,,,,,
13,2,,129100-11100,, "VALVE, INTAKE",3,3,,,,,,,,,,,,,
14,2,,129100-11110,, "VALVE, EXHAUST",3,3,,,,,,,,,,,,,
15,2,,129795-11120,, "SPRING, VALVE",6,6,,,,,,,,,,,,,
16,2,,129795-11180,, "RETAINER, SPRING",6,6,,,,,,,,,,,,,
17,2,,27310-080000,, "COTTER 8",6,6,,,,,,,,,,,,,
18,2,,121400-11340,, "SEAL, VALVE STEM",3,3,,,,,,,,,,,,,
19,2,,124460-11340,, "SEAL, VALVE STEM",3,3,,,,,,,,,,,,,
20,2,,129150-11370,, "CAP, VALVE",6,6,,,,,,,,,,,,,
21,2,,22351-060012,, "SPRING PIN 6X12",2,2,,,,,,,,,,,,,
22,2,,26366-060002,, "NUT M 6",6,6,,,,,,,,,,,,,
23,1,,129100-11240,, "SHAFT ASSY, ROCKER",1,1,,,,,,,,,,,,,
24,2,,129155-11260,, "SUPPORT, ROCKER ARM",2,2,,,,,,,,,,,,,
25,2,,129155-11270,, "SUPPORT, ROCKER ARM",2,2,,,,,,,,,,,,,
26,2,,129150-11280,, "SPRING",3,3,,,,,,,,,,,,,
27,2,,129150-11290,, "SHAFT, ROCKER ARM",1,1,,,,,,,,,,,,,
30,2,,129100-11650,, "ARM ASSY, ROCKER",6,6,,,,,,,,,,,,,
31,3,,129150-11230,, "SCREW, VALVE",6,6,,,,,,,,,,,,,
33,3,,129150-11750,, "NUT M8XP1.0",6,6,,,,,,,,,,,,,
34,2,,26226-080182,, "STUD M 8X 18 PLATED",3,3,,,,,,,,,,,,,
35,1,,119625-11871,, "PROTECTOR, NOZZLE",3,3,,,,,,,,,,,,,
35-1,1,,119625-11870,, "PROTECTOR, NOZZLE",3,3,,,,,N,,TE-97605,E/#06523,,,,,,
36,1,,119625-11880,, "SEAT, NOZZLE",3,3,,,,,,,,,,,,,
37,1,,119625-11900,, "RETAINER",3,3,,,,,,,,,,,,,
38,1,,26106-080252,, "BOLT M 8X 25 PLATED",2,2,,,,,,,,,,,,,
39,1,,26106-080502,, "BOLT M 8X 50 PLATED",6,6,,,,,,,,,,,,,
40,1,,129100-11350,, "BONNET ASSY",1,1,,,,,,,,,,,,,
41,2,,124160-01751,, "CAP, LUB.OIL SUPPLY",1,1,,,,,,,,,,,,,
42,2,,129150-03020,, "COVER, BREATHER",1,1,,,,,,,,,,,,,
43,2,,129150-03070,, "BAFFLE, BREATHER",1,1,,,,,,,,,,,,,
44,2,,129150-03080,, "PLATE, SHELTER",1,1,,,,,,,,,,,,,
47,2,,129150-11310,, "GASKET, BONNET",1,1,,,,,A,,,,,,,,,
48,2,,24311-000320,, "O-RING 1A P-32.0",1,1,,,,,A,,,,,,,,,
49,2,,24341-000500,, "O-RING 1A S-50.0",1,1,,,,,A,,,,,,,,,
50,2,,26106-080162,, "BOLT M 8X 16 PLATED",2,2,,,,,,,,,,,,,
51,1,,124160-11360,, "KNOB",3,3,,,,,,,,,,,,,
52,1,,24311-000120,, "O-RING 1A P 12.0",3,3,,,,,A,,,,,,,,,


Fig. 4 シリンダヘッド&ボンネット
CYLINDER HEAD & BONNET

見出しNo. 23は、見出しNo. 24
から34を含みます。
23 inc. 24 ~ 34




1,1,,129122-12100,, "MANIFOLD, SUCTION",1,1,,,,,,,,,,,,,
2,1,,129150-12111,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,,,,
3,1,,26106-080252,, "BOLT M 8X 25 PLATED",4,4,,,,,,,,,,,,,
4,1,,119812-12200,, "SILENCER, SUCTION",1,1,,,,,,,,,,,,,
5,1,,129132-12581,, "SUPPORT ASSY,CLEANER",1,1,,,,,,,,,,,,,
7,2,,129132-12570,, "SEAT, SUPPORT",2,2,,,,,,,,,,,,,
8,1,,129132-12800,, BAND,1,1,,,,,,,,,,,,,
10,2,,129132-12860,, "SHEET, RUBBER",1,1,,,,,,,,,,,,,
11,1,,129132-12810,, SUPPORT,1,1,,,,,,,,,,,,,
13,2,,129132-12890,, "SHEET, RUBBER",1,1,,,,,,,,,,,,,
14,2,,129132-12900,, DAMPER,1,1,,,,,,,,,,,,,
15,1,,23000-060000,, "CLAMP 60",2,2,,,,,,,,,,,,,
16,1,,26106-060142,, "BOLT M 6X 14 PLATED",2,2,,,,,,,,,,,,,
17,1,,26106-080142,, "BOLT M 8X 14 PLATED",4,4,,,,,,,,,,,,,
18,1,,26106-080252,, "BOLT M 8X 25 PLATED",2,2,,,,,,,,,,,,,
19,1,,129030-12500,, "AIR CLEANER ASSY",1,1,,,,,,,,,,,,,
20,2,,121120-12531,, "PAN ASSY, DUST",1,1,,,,,,,,,,,,,
21,2,,121120-12541,, "RETAINER, ELEMENT",1,1,,,,,,,,,,,,,
22,2,,129150-12510,, "ELEMENT, AIR CLEANER",1,1,,,,,,,,,,,,,
23,2,,121120-12561,, "BOLT, WING",1,1,,,,,,,,,,,,,
24,2,,121120-12571,, "SEAL WASHER",1,1,,,,,,,,,,,,,
25,1,,129120-77501,, "HEATER, AIR",1,1,,,,,,,,,,,,,
26,1,,129150-77511,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,,,,
27,1,,26106-080352,, "BOLT M 8X 35 PLATED",4,4,,,,,,,,,,,,,

Fig. 5 吸気マニホールド&エアクリーナ
SUC. MANIFOLD & AIR CLEANER



1,1,,129001-13100,, "MANIFOLD, EXHAUST",1,1,,,,,,,,,,,,,
2,1,,129001-13110,, "GASKET, EXH.MANIFOLD",1,1,,,,,A,,,,,,,,,
3,1,,194990-22050,, "NUT W/WASHER 8",2,,,,,,,,,,,,,
3-1,1,,26366-080002,, "NUT M 8",2,2,,,,,R,, TE-98187,E/#17638,,,,,,
4,1,,26106-080402,, "BOLT M 8X 40 PLATED",4,4,,,,,,,,,,,,,
5,1,,26216-080222,, "STUD M 8X 22 PLATED",4,,,,,,,,,,,,,
5-1,1,,119131-18320,, "BOLT M 8X 22",4,4,,,,,N,, TE-97467,E/#06523,,,,,,
6,1,,26216-080402,, "STUD M 8X 40 PLATED",2,2,,,,,,,,,,,,,
7,1,,124701-11911,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,,,,
8,1,,129030-13500,, SILENCER,1,1,,,,,,,,,,,,,
9,1,,171350-13650,, "STAY, SILENCER",1,,,,,,,,,,,,,
9-1,1,,171350-13651,, "STAY, SILENCER",1,1,,,,,N,, TE-97423,E/#06523,,,,,,
10,1,,194990-22050,, "NUT W/WASHER 8",4,,,,,,,,,,,,,
10-1,1,,26366-080002,, "NUT M 8",4,4,,,,,R,, TE-98187,E/#17638,,,,,,
11,1,,26014-080202,, "BOLT M 8X 20",4,4,,,,,,,,,,,,,


Fig. 6 排気マニホールド&サイレンサ
EXH. MANIFOLD & SILENCER



1,1,,129150-14200,,TAPPET,6,6,,,,,,,,,,,,,
2,1,,129150-14400,, "ROD, PUSH",6,6,,,,,,,,,,,,,
3,1,,129129-14580,, "CAMSHAFT ASSY",1,1,,,,,,,,,,,,,
4,2,,129150-02450,, "METAL, THRUST",1,1,,,,,,,,,,,,,
6,2,,129150-14101,, "GEAR, CAMSHAFT",1,1,,,,,,,,,,,,,
7,2,,22512-070140,, "KEY 7X 14",1,1,,,,,,,,,,,,,
8,1,,26106-080142,, "BOLT M 8X 14 PLATED",2,2,,,,,,,,,,,,,
9,1,,129100-25061,, "SHAFT, IDLE GEAR",1,1,,,,,,,,,,,,,
10,1,,129150-25101,, "GEAR W/BUSH",1,1,,,,,,,,,,,,,
12,2,,129150-25061,, "BUSH, IDLE GEAR",1,1,,,,,,,,,,,,,
13,1,,26106-080452,, "BOLT M 8X 45 PLATED",2,2,,,,,,,,,,,,,


Silverhorn.co.uk

Fig. 7 カムシャフト & 駆動ギヤ
CAMSHAFT & DRIVING GEAR




1,1,,129001-21000,, "CRANKSHAFT ASSY",1,1,,,,,,,,,,,,,
2,2,,129100-01580,, "PARALLEL PIN 8X16",1,1,,,,,,,,,,,,,
4,2,,129150-21200,, "GEAR, CRANKSHAFT",1,1,,,,,,,,,,,,,
5,2,,22512-070140,, "KEY 7X 14",1,1,,,,,,,,,,,,,
7,1,,22351-040010,, "SPRING PIN 4X10",1,1,,,,,,,,,,,,,
8,1,,171340-21650,, "V-PULLEY, CRANKSHAFT",1,1,,,,,,,,,,,,,
9,1,,129795-21661,, WASHER,1,1,,,,,,,,,,,,,
10,1,,121850-21680,, "BOLT, V-PULLEY",1,1,,,,,,,,,,,,,
11,1,,121111-21501,, "BOLT, FLYWHEEL",6,6,,,,,,,,,,,,,
12,1,,129128-21590,, "FLYWHEEL W/RING GEAR",1,1,,,,,,,,,,,,,
14,2,,119865-21600,, "GEAR, RING",1,1,,,,,,,,,,,,,
15,1,,129001-22081,, "PISTON W/RINGS",3,3,,,,,,,,,,,,,
17,2,,129001-22500,, "RING SET, PISTON",3,3,,,,,,,,,,,,,
21,1,,129202-22300,, "PIN,PISTON",3,3,,,,,,,,,,,,,
22,1,,22252-000260,, "CIRCLIP 26",6,6,,,,,,,,,,,,,
23,1,,729402-23100,, "ROD ASSY, CONNECTING",3,3,,,,,,,,,,,,,
26,2,,121550-23200,, "BOLT, CONNECTING ROD",6,6,,,,,,,,,,,,,
27,2,,129150-23600,, "BEARING, CRANKPIN",3,3,,,,,,,,,,,,,
29,1,,129001-22900,, "PISTON W/RING OS=.25",3,,,,,1,,,,,,,,,
29-1,1,,129001-22901,, "PISTON W/RING OS=.25",3,3,,,,,N,1,TE-93049, "FROM
1ST",,,,,,,,,
31,2,,129001-22950,, "RING SET O.S=0.25",3,3,,,,,1,,,,,,,,,
35,1,,129150-23610,, "METAL.PIN US=0.25",3,3,,,,,2,,,,,,,,,
37,1,,129100-23910,, "BUSH, PISTON PIN",3,3,,,,,3,,,,,,,,,

Fig. 8 クランクシャフト&ピストン
CRANKSHAFT & PISTON




1,1,,129001-32001,, "PUMP ASSY, LUB. OIL",1,1,,,,,,,,,,,,,
14,1,,129150-32020,, "GASKET, L.O. PUMP",1,1,,,,,A,,,,,,,,,
15,1,,26450-060252,, "BOLT M 6X 25",4,4,,,,,,,,,,,,,
16,1,,129132-34800,, DIPSTICK,1,1,,,,,,,,,,,,,
17,1,,121520-34810,, "GUIDE, DIPSTICK",1,1,,,,,,,,,,,,,
18,1,,129150-35041,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,,,,
19,1,,129150-35091,, "PIPE ASSY, OIL INLET",1,1,,,,,,,,,,,,,
20,1,,26106-080352,, "BOLT M 8X 35 PLATED",2,2,,,,,,,,,,,,,
21,1,,129150-35101,, "BRACKET, STRAINER",1,1,,,,,,,,,,,,,
22,1,,129150-35111,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,,,,
23,1,,129150-35151,, "FILTER 80X80L",1,1,,,,,,,,,,,,,
24,1,,129001-35300,, "BOLT,LUB.O. STRAINER",1,1,,,,,,,,,,,,,
25,1,,129150-35350,, NUT,1,1,,,,,,,,,,,,,
26,1,,24311-000160,, "O-RING 1A P-16.0",1,1,,,,,,,,,,,,,
27,1,,26106-080202,, "BOLT M 8X 20 PLATED",3,3,,,,,,,,,,,,,
28,1,,124160-39140,, "BOLT 10, PIPE JOINT",1,1,,,,,,,,,,,,,
29,1,,129211-39450,, "PIPE, LUB.OIL ASSY",1,1,,,,,W,,TE-97278,E/#06523,,,,,
29A,2,,129150-39450,, "PIPE ASSY, LUB. OIL",1,1,,,,,,,,,,,,,
32A,2,,123658-39320,, "PIPE,STEADY RST.RBBR",1,1,,,,,W,,TE-97278,E/#06523,,,,,
32B,2,,23297-080081,, "RETAINER 8X 8",1,1,,,,,W,,TE-97278,E/#06523,,,,,
33,1,,124550-59830,, "BOLT W/ SEAL WASHER",1,1,,,,,W,,TE-98875,E/#21694,,,,,
33B,2,,22190-080003,, "SEAL WASER 8",1,1,,,,,W,,TE-98875,E/#21694,,,,,
34,1,,23414-080000,, "GASKET 8, ROUND",2,,,,,,,,,,,,,
34-1,1,,22190-080003,, "SEAL WASER 8",1,1,,,,,N,,TE-98875,E/#21694,,,,,
35,1,,23414-100000,, "GASKET 10, ROUND",2,2,,,,,,,,,,,,,
36,1,,124160-39450,, "SWITCH, OIL PRESSURE",1,1,,,,,,,,,,,,,

Fig. 9 潤滑油システム
LUB. OIL SYSTEM



1,1,,129001-42002,, "PUMP ASSY, C.WATER",1,,,,,,,,,,,,,
1-1,1,,129001-42003,, "PUMP ASSY,COOLANT",1,1,,,,,N,,TE-99506,"E/# 21695",,,,,,,
11,2,,23871-020000,, "PLUG PT1/4,SCREW",1,,,,,,,,,,,,,
11-1,2,,23876-020000,, "PLUG 1/4",1,1,,,,,N,,GZ-99001,"E/# 21695",,,,,,,
12,2,,23871-030000,, "PLUG PT3/8,SCREW",2,,,,,,,,,,,,,
12-1,2,,23876-030000,, "PLUG PT3/8,SCREW",2,2,,,,,N,,GZ-99001,"E/# 21695",,,,,,,
13,1,,121850-11860,, "PLUG PT1/4",1,,,,,,Z,*EXXX,,,,,,
14,1,,129100-42020,, "GASKET, C.W. PUMP",1,1,,,,,A,,,,,,
15,1,,26106-080602,, "BOLT M 8X 60 PLATED",3,3,,,,,,
16,1,,25132-003800,, "V-BELT (A-38)",1,1,,,,,,
16A,1,,25132-003700,, "V-BELT A37",1,1,,,,,1,,,,,,
17,1,,129403-42380,, "V-PULLEY(D=110)",1,1,,,,,,
17A,1,,129155-42350,, "V-PULLEY, C.W. PUMP",1,1,,,,,1,,,,,,
18,1,,171340-44740,, "FAN, COOLING",1,1,,,,,,
19,1,,129030-44760,, "SPACER",1,1,,,,,,
20,1,,26106-060502,, "BOLT M 6X 50 PLATED",4,4,,,,,,
21,1,,121550-49111,, "JOINT PT1/4",1,1,,,,,,
22,1,,121450-42450,, "PLUG M16",1,1,,,,,,
23,1,,121250-44901,, "SWITCH, THERMO(110⁰C)",1,1,,,,,,
24,1,,124465-44950,, "GASKET 16",1,1,,,,,A,,,,,,
25,1,,124465-44950,, "GASKET 16",1,1,,,,,A,,,,,,
26,1,,129350-49560,, "COVER, THERMOSTAT",1,1,,,,,,
27,1,,129795-49551,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,
28,1,,129001-42040,, "JOINT",1,1,,,,,,
29,1,,24321-000300,, "O-RING G30",1,,,,,,
29-1,1,,129486-42140,, "O-RING,CW-P",1,1,,,,,N,,TE-99412,"E/# 21695",,,,,,,
30,1,,26106-080162,, "BOLT M 8X 16 PLATED",3,3,,,,,,
31,1,,129155-49800,, "THERMOSTAT",1,1,,,,,,
32,1,,129150-49811,, "GASKET, (NON-ASB.)",1,1,,,,,A,,,,,,
33,1,,129100-49840,, "GASKET, THERMO. CASE",1,1,,,,,A,,,,,,
34,1,,26106-080202,, "BOLT M 8X 20 PLATED",2,2,,,,,,

Fig. 10 冷却水システム
COOLING WATER SYSTEM




1,1,,729030-51380,, "PUMP ASSY, F.I.PUMP",1,,,,,1,,,,,
1A,1,,729030-51450,, "PUMP ASSY, F.INJECT",,1,,,,,1,,,,,
2,2,,129155-52050,, GASKET,1,1,,,,,
3,2,,129100-52100,, "PUMP ASSY, FUEL FEED",1,1,,,,,
20,2,,129155-51020,, "STUD, FEED PUMP",2,2,,,,,
21,2,,119810-51040,, CAMSHAFT,1,1,,,,,
22,2,,129155-51050,, "BALL BEARING, THRUST",1,1,,,,,
23,2,,129155-51060,, "CAM SHAFT SUPPORT",1,,,,,
23A,2,,129208-51060,, SUPPORT,,1,,,,,
24,2,,122710-51090,, KEY,1,1,,,,,
25,2,,129506-51100,, "PLUNGER W/BARREL",3,3,,,,,
28,2,,129155-51140,, "PIN, BARREL LOCKING",3,3,,,,,
29,2,,174307-51170,, "RETAINER A",3,3,,,,,
30,2,,129155-51180,, "SPRING SHOE, PLUNGER",3,3,,,,,
31,2,,124950-51190,, "SPRING, PLUNGER",3,3,,,,,
32,2,,129155-51200,, "TAPPET ASSY",3,3,,,,,
39,2,,129155-51270,, "LOCKING, TAPPET",3,3,,,,,
40,2,,129155-51280,, "O-RING S6",3,3,,,,,
41,2,,129505-51300,, "VALVE W/SEAT, DELIV.",3,3,,,,,
44,2,,129155-51320,, "SPRING, DELIV. VALVE",3,3,,,,,
45,2,,129155-51340,, "GUARD, DELIVERY VALVE",3,3,,,,,
46,2,,124550-51350,, "GASKET, DELIVERY",3,3,,,,,
47,2,,124550-51370,, "O-RING, DELIVERY",3,3,,,,,
48,2,,129155-51370,, "STOPPER, VALVE",3,3,,,,,
49,2,,129155-51380,, "LOCKING (A)",2,2,,,,,
50,2,,129155-51390,, "LOCKING (B)",2,2,,,,,
51,2,,129155-51400,, DEFLECTOR,1,1,,,,,
52,2,,129155-51410,, "CHECK BOLT, DEFLECTOR",1,1,,,,,
53,2,,129155-51420,, "PLUG (M16)",1,1,,,,,
54,2,,129155-51450,, "SHIM SET, ADJUSTING",1,1,,,,,
59,2,,129155-51500,, "RACK, CONTROL",1,1,,,,,
60,2,,129155-51521,, "BUSH, RACK",1,1,,,,,
61,2,,129155-51550,, "PINION, CONTROL",3,3,,,,,
62,2,,122117-51560,, "SCREW, PINION",3,3,,,,,
63,2,,174307-51560,, PINION,3,3,,,,,
64,2,,129155-51570,, "PLUG (M12)",1,1,,,,,
65,2,,129155-51580,, O-RING,1,1,,,,,
66,2,,129155-51600,, "SHIM PACK",3,3,,,,,
85,2,,129155-51700,, "COVER, LOWER",1,1,,,,,
86,2,,129155-51710,, "GASKET, LOWER COVER",1,1,,,,,
87,2,,129155-51750,, "COVER, SIDE",1,1,,,,,
88,2,,129155-51760,, "GASKET, SIDE COVER",1,1,,,,,
89,2,,129155-51790,, "LOCKING, RACK",1,1,,,,,
90,2,,129156-51910,, "LABEL, CAUTION",1,1,,,,,
91,2,,129155-51930,, "SPACER T=3.25",1,1,,,,,
92,2,,129155-51940,, "SPACER T=1.5",1,1,,,,,
93,2,,22217-060000,, "SPRING WASHER 6",2,2,,,,,
94,2,,22351-050010,, "SPRING PIN 5X10",2,2,,,,,
95,2,,24101-063034,, "BALL BEARING",1,1,,,,,
96,2,,24341-000160,, "O-RING 1A S-16.0",1,1,,,,,
97,2,,26022-050102,, "SCREW M 5X 10",8,8,,,,,
98,2,,26022-060162,, "SCREW M 6X 16",4,4,,,,,
99,2,,26116-050302,, "BOLT M 5X 30 PLATED",2,2,,,,,
100,2,,22217-050000,, "SPRING WASHER 5",2,2,,,,,
101,2,,129155-51530,, "SPACER, AUX. SPRING",1,1,,,,,
102,2,,129155-51540,, CIRCLIP,1,1,,,,,
103,2,,129155-51591,, "SPRING, RACK",1,1,,,,,
104,2,,26716-060002,, "NUT 6",2,2,,,,,
105,2,,22190-160002,, "SEAL WASHER 16S",1,1,,,,,
106,2,,129208-54500,, "FLANGE ASSY",,1,,,,,
108,3,,22217-120000,, "SPRING WASHER",,1,,,,,
109,3,,26716-120002,, "NUT 12",,1,,,,,
110,1,,129150-25931,, GEAR,,1,,,,,

111,1,,129150-25301,, "BOLT, FI-P" ,,,4,,,,,,,,,,,,,
112,1,,129150-25900,, "GEAR, FUEL INJ. PUMP",1,,,,,,,,,,,,,
113,1,,22217-120000,, "SPRING WASHER",1,,,,,,,,,,,,,
114,1,,26716-120002,, "NUT 12",1,,,,,,,,,,,,,


Silverhorn.co.uk

Fig. 11 燃料噴射ポンプ
FUEL INJECTION PUMP



1,2,,129155-51280,, "O-RING S6",1,1,,,,,,,,,,,,,
2,2,,129052-61010,, "CASE, GOVERNOR",1,1,,,,,,,,,,,,,
3,2,,129052-61050,, PACKING,1,1,,,,,,,,,,,,,
4,2,,129052-61060,, COVER,1,1,,,,,,,,,,,,,
5,2,,129052-61070,, PACKING,1,1,,,,,,,,,,,,,
6,2,,129155-61120,, "LINK L=30(MARK 0",1,1,,,,,1,,,,,
7,2,,129155-61130,, "LINK L=31(MARK 1",1,1,,,,,1,,,,,
8,2,,129155-61140,, "LINK L=30.5(MARK 05)",1,1,,,,,1,,,,,
9,2,,129155-61201,, "WEIGHT ASSY, GOV.",1,1,,,,,,,,,,,,,
13,2,,129155-61341,, SLEEVE,1,1,,,,,2,,,,,
14,2,,129155-61350,, SLEEVE,1,1,,,,,2,,,,,
15,2,,129155-61360,, SLEEVE,1,1,,,,,2,,,,,
16,2,,129100-61400,, "SHAFT ASSY, CONTROL",1,1,,,,,,,,,,,,,
19,2,,129155-61430,, "SPACER, SHAFT",1,1,,,,,,,,,,,,,
20,2,,129155-61450,, "BOLT, REVOL. LIMIT",1,1,,,,,,,,,,,,,
21,2,,129155-61460,, "BOLT, IDLE LIMIT",1,1,,,,,,,,,,,,,
22,2,,129155-61480,, "SPACER ASSY",2,2,,,,,,,,,,,,,
23,2,,129052-61390,, "SHAFT, GOV. LEVER",1,1,,,,,,,,,,,,,
24,2,,129052-61500,, "LEVER ASSY, GOVERNOR",1,1,,,,,,,,,,,,,
25,3,,174307-51700,, "SHIM SET",2,2,,,,,,,,,,,,,
29,3,,129052-61540,, SPRING,1,1,,,,,,,,,,,,,
30,3,,129155-61540,, SHIFTER,1,1,,,,,,,,,,,,,
35,3,,22272-000040,, "CIRCLIP E- 4",1,1,,,,,,,,,,,,,
38,2,,129155-61830,, "O-RING S10",1,1,,,,,,,,,,,,,
39,2,,119660-61901,, "RETAINER, SHAFT",1,1,,,,,,,,,,,,,
40,2,,129155-61950,, "BOLT, WASHER BASED",1,1,,,,,,,,,,,,,
41,2,,124550-66370,, "LOCK NUT M 6",1,1,,,,,,,,,,,,,
42,2,,22117-040000,, "WASHER 4",1,1,,,,,,,,,,,,,
43,2,,22190-060002,, "SEAL WASHER 6S",1,,,,,,,,,,,,,
43-1,2,,22190-060003,, "SEAL WASHER 6S",1,1,,,,,R,,M1-98108,"E/# 21695",,,,,,
44,2,,22190-100002,, "SEAL WASHER 10S",1,1,,,,,,,,,,,,,
45,2,,22190-120002,, "SEAL WASHER 12",2,2,,,,,,,,,,,,,
46,2,,22287-120000,, "WASHER 12",1,1,,,,,,,,,,,,,
47,2,,22372-040000,, "SNAP PIN 4",2,2,,,,,,,,,,,,,
48,2,,23887-100002,, "PLUG 10",1,1,,,,,,,,,,,,,
49,2,,24341-000280,, "O-RING 1A S-28.0",1,1,,,,,,,,,,,,,
50,2,,26106-060102,, "BOLT M 6X 10 PLATED",1,1,,,,,,,,,,,,,
51,2,,26106-060102,, "BOLT M 6X 10 PLATED",1,1,,,,,,,,,,,,,
52,2,,26106-060102,, "BOLT M 6X 10 PLATED",4,4,,,,,,,,,,,,,
53,2,,26106-060142,, "BOLT M 6X 14 PLATED",2,2,,,,,,,,,,,,,
54,2,,26106-060202,, "BOLT M 6X 20 PLATED",6,6,,,,,,,,,,,,,
55,2,,26756-060002,, "LOCK NUT 6",1,1,,,,,,,,,,,,,
56,2,,26776-120002,, "LOCK NUT M12 PLATED",2,2,,,,,,,,,,,,,
57,1,,129100-61440,, "LEVER, CONTROL",1,1,,,,,,,,,,,,,
58,1,,129155-61470,, "BOLT, FUEL CONTROL",1,1,,,,,,,,,,,,,
59,1,,129132-61550,, "ANGLEICH ASSY",1,1,,,,,,,,,,,,,
63,2,,129155-61590,, NUT,1,1,,,,,,,,,,,,,
67,1,,129100-61650,, "SPRING, FUEL CONTROL",1,1,,,,,,,,,,,,,
68,1,,129489-61700,, "SPRING, GOVERNOR",1,1,,,,,,,,,,,,,
69,1,,119233-77951,, SOLENOID,1,1,,,,,,,,,,,,,
70,1,,26366-080002,, "NUT M 8",1,1,,,,,,,,,,,,,
71,1,,26687-120002,, "CAP NUT M12",1,,,,,,,,,,,,,
71A,1,,129100-61930,, "NUT, CAP",1,,,,,,,,,,,,,
72,1,,135210-61090,, LEAD,,1,,,,,,,,,,,,,
73,1,,22451-060000,, "WIRE 0.6",1,,,,,,,,,,,,,


Fig. 12 ガバナ GOVERNOR



1,1,,729102-53100,, "VALVE ASSY, F.INJECT",1,1,,,,,,,,,,,,,
2,2,,129102-53000,, "NOZZLE ASSY,F.INJECT",3,3,,,,,,,,,,,,,
5,2,,114250-53080,, "NUT, NOZZLE CASE",3,3,,,,,,,,,,,,,
6,2,,129100-53100,, "HOLDER ASSY, NOZZLE",3,3,,,,,,,,,,,,,
9,2,,114250-53120,, "SPRING, NOZZLE",3,3,,,,,,,,,,,,,
10,2,,114250-53130,, "SEAT, NOZZLE SPRING",3,3,,,,,,,,,,,,,
11,2,,114250-53140,, "PLATE, STOP",3,3,,,,,,,,,,,,,
12,2,,114250-53210,, PIN,6,6,,,,,,,,,,,,,
13,2,,114250-53400,, "SHIM PACK",3,3,,,,,,,,,,,,,
20,1,,129150-59120,, "RETAINER, INJ. PIPE",1,1,,,,,,,,,,,,,
23,2,,129150-59131,, "BOLT M4X14,HEX.SCKT.",2,2,,,,,,,,,,,,,
24,1,,129211-59910,, "PIPE, FUEL INJECTION",1,1,,,,,,,,,,,,,
28,1,,129211-59920,, "PIPE, FUEL INJECTION",1,1,,,,,,,,,,,,,
32,1,,129211-59930,, "PIPE, FUEL INJECTION",1,1,,,,,,,,,,,,,
36,1,,129210-59130,, "PIPE ASSY, FUEL OIL",1,1,,,,,W,,TE-98382,E/#17866,,,,,,
37,2,,124766-59050,, "CLAMP 12",2,2,,,,,,,,,,,,,
38,1,,124066-59100,, "CLAMP 8",7,7,,,,,,,,,,,,,
39,1,,121250-59550,, "PIPE, FUEL",2,2,,,,,,,,,,,,,
40,1,,119840-59560,, "PIPE, FUEL RETURN",1,1,,,,,,,,,,,,,
41,1,,119840-59570,, JOINT,1,1,,,,,,,,,,,,,
42,1,,129150-59580,, CAP,1,1,,,,,,,,,,,,,
43,1,,129100-59951,, "VALVE ASSY, CHECK",1,1,,,,,,,,,,,,,
51,1,,23414-120000,, "GASKET 12, ROUND",2,,,,,,,,,,,,,
51-1,1,,22190-120002,, "SEAL WASHER 12",2,2,,,,,N,,TN-99116,"E/# 21695",,,,,,,


Fig. 13 燃料噴射パイプ
FUEL INJECTION PIPE

REFER TO Fig. 14



1,1,,129052-55620,, "STRAINER ASSY, FUEL",1,1,,,,,,,,,,,,,
2,2,,104200-55321,, "VALVE, TAPER",1,1,,,,,,,,,,,,,
3,2,,104200-55330,, "SPRING, TAPER VALVE",1,1,,,,,,,,,,,,,
4,2,,129100-55650,, "ELEMENT, FUEL",1,1,,,,,,,,,,,,,
6,2,,129100-55670,, LEVER,1,1,,,,,,,,,,,,,
7,2,,129100-55680,, "CUP, STRAINER",1,1,,,,,,,,,,,,,
8,2,,129100-55690,, "RING, RETAINING",1,1,,,,,,,,,,,,,
9,2,,129100-55700,, SPRING,1,1,,,,,,,,,,,,,
10,2,,104200-55750,, "SCREW M 4",1,1,,,,,,,,,,,,,
11,2,,24311-000160,, "O-RING 1A P-16.0",1,1,,,,,,,,,,,,,
12,2,,24311-240100,, "O-RING 1A P-10A",1,1,,,,,,,,,,,,,
13,2,,24321-000650,, "O-RING 1A G-65.0",1,1,,,,,A,,,,,,,,,
14,1,,26014-080702,, "BOLT W/WASHER M8X 70",1,1,,,,,,,,,,,,,
15,1,,103854-39140,, "BOLT, PIPE JOINT",1,1,,,,,,,,,,,,,
16,1,,101304-59020,, "JOINT 12, PIPE",1,1,,,,,,,,,,,,,
17,1,,129210-59040,, "PIPE ASSY, FUEL OIL",1,1,,,,,W,,TE-98382,E/#17866,,,,,,
18,2,,124766-59050,, "CLAMP 12",4,,,,,,,,,,,,,
18-1,2,,124766-59050,, "CLAMP 12",2,2,,,,,K,,TE-98382,E/#17866,,,,,,
19,1,,22190-120002,, "SEAL WASHER 12",2,2,,,,,,,,,,,,,
20,1,,129210-59150,, "PIPE ASSY, FUEL OIL",1,1,,,,,W,,TE-98382,E/#17866,,,,,,
21,2,,124766-59050,, "CLAMP 12",2,2,,,,,W,,TE-98382,E/#17866,,,,,,


Fig. 14 燃料パイプ
FUEL PIPE



1,1,,171008-77010,,STARTER,1,1,,,,,,,,,,,,,
2,2,,171008-77400,, "ARMATURE ASSY",1,1,,,,,,,,,,,,,
3,3,,171008-77410,, BEARING(1),1,1,,,,,,,,,,,,,
4,3,,171008-77420,, BEARING(2),1,1,,,,,,,,,,,,,
6,2,,171008-77440,, "COIL ASSY, FIELD",1,1,,,,,,,,,,,,,
7,3,,171008-77450,, "SCREW, POLE CORE SET",4,4,,,,,,,,,,,,,
8,3,,171008-77460,, "BRUSH (+)",2,2,,,,,,,,,,,,,
9,2,,171008-77470,, "HOLDER ASSY, BRUSH",1,1,,,,,,,,,,,,,
10,3,,171008-77480,, "BRUSH (-)",2,2,,,,,,,,,,,,,
11,3,,171008-77490,, "SPRING, BRUSH",4,4,,,,,,,,,,,,,
12,2,,171008-77500,, "COVER, REAR",1,1,,,,,,,,,,,,,
13,2,,171008-77510,, "HOUSING ASSY, GEAR",1,1,,,,,,,,,,,,,
14,2,,171008-77520,, "HOUSING, CENTER",1,1,,,,,,,,,,,,,
15,2,,171008-77530,, "SWITCH, MAGNETIC",1,,,,,,,,,,,,,
15-1,2,,171008-77531,, "MAGNETIC SWITCH ASSY",1,1,,,,,R,,TE-
98079,E/#06523,,,,,,,,,,,,,
16,2,,171008-77540,, "LEVER SET, SHIFT",1,1,,,,,,,,,,,,,
19,2,,171008-77571,, "DUST COVER,(NON-ASB.)",1,1,,,,,,,,,,,,,
26,2,,171008-77640,, "BOLT, THROUGH",2,2,,,,,,,,,,,,,
27,2,,171008-77650,, "PINION ASSY",1,1,,,,,,,,,,,,,
28,3,,171008-77660,, "SHAFT, PINION",1,1,,,,,,,,,,,,,
29,3,,171008-77670,, "STOPPER SET, PINION",1,1,,,,,,,,,,,,,
33,3,,171008-77720,, "CLUTCH ASSY",1,1,,,,,,,,,,,,,
34,4,,171008-77730,, "BALL BEARING (3)",1,1,,,,,,,,,,,,,
35,4,,171008-77740,, "BALL BEARING (4)",1,1,,,,,,,,,,,,,
36,2,,171008-77750,, "COVER, M TERMINAL",1,1,,,,,,,,,,,,,
37,2,,26106-060322,, "BOLT M 6X 32 PLATED",2,2,,,,,,,,,,,,,
38,2,,26106-060402,, "BOLT M 6X 40 PLATED",3,3,,,,,,,,,,,,,
39,1,,26116-120252,, "BOLT M12X 25 PLATED",2,2,,,,,,,,,,,,,

15

スターティングモータ
STARTING MOTOR




1,1,,26106-100652,, "BOLT M10X 65 PLATED",1,,,,,,,,,,,,,
1-1,1,,129795-01900,, STUD,1,1,,,,,N,, TN-97118,E/#06380,,,,,
2,1,,129150-77202,, GENERATOR,1,1,,,,,,,,,,,,,
3,2,,XM219230000,, "WASHER, SPRING",1,1,,,,,,,,,,,,,
4,2,,XM329830000,, COLLAR,1,1,,,,,,,,,,,,,
5,2,,XM860250000,, "WASHER 10",1,1,,,,,,,,,,,,,
6,2,,XM863720000,, NUT,1,1,,,,,,,,,,,,,
7,2,,129150-77210,, "PLATE ASSY",1,1,,,,,,,,,,,,,
8,3,,XM069000000,, CLAMP,1,1,,,,,,,,,,,,,
9,3,,XM081780000,, STATOR,1,1,,,,,,,,,,,,,
10,3,,XM178780000,, COUPLER,1,1,,,,,,,,,,,,,
11,3,,XYSPS400800,, SCREW,1,1,,,,,,,,,,,,,
12,3,,XYSPS402400,, SCREW,2,2,,,,,,,,,,,,,
15,2,,129150-77230,, "FLYWHEEL ASSY",1,1,,,,,,,,,,,,,
16,1,,26366-100002,, "NUT M10",1,1,,,,,,,,,,,,,
17,1,,129100-77320,, "ADJUSTER, V-BELT",1,1,,,,,,,,,,,,,
18,1,,26014-080252,, "BOLT M 8X 25",1,,,,,,,,,,,,,
18-1,1,,119810-77340,, BOLT,1,1,,,,,N,, TE-97613,E/#06523,,,,,
19,1,,26106-080502,, "BOLT M 8X 50 PLATED",1,1,,,,,,,,,,,,,

16



ジェネレータ GENERATOR

Exploded view diagram of a vehicle headlight assembly. The diagram shows the main headlight housing (2) and its mounting bracket (17). A new screw (1-1) is shown being installed into the bracket (17) to secure it to the housing (2). A previous screw (19) is shown being removed from the bracket (17). A callout box labeled "旧形 PREVIOUS" (Old Form PREVIOUS) shows the previous screw (19) and its position on the bracket (17). Other components shown include a washer (18), a nut (16), and a connector (2).



1,1,,729030-92610,, "GASKET SET(NON-ASB.)",1,1,,,,,1,,,,,,,,,
2,2,,129001-01340,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
3,2,,124240-01883,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
4,2,,121850-51960,, "O-RING, F.I.PUMP",1,1,,,,,,,,,,,,,
5,2,,24311-000320,, "O-RING 1A P-32.0",1,1,,,,,,,,,,,,,
6,2,,24341-000500,, "O-RING 1A S-50.0",1,1,,,,,,,,,,,,,
7,2,,24311-000320,, "O-RING 1A P-32.0",1,1,,,,,,,,,,,,,
8,2,,129150-11310,, "GASKET, BONNET",1,1,,,,,,,,,,,,,
9,2,,24311-000120,, "O-RING 1A P 12.0",3,3,,,,,,,,,,,,,
10,2,,129150-12111,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
11,2,,124701-11911,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
12,2,,129001-13110,, "GASKET, EXH.MANIFOLD",1,1,,,,,,,,,,,,,
13,2,,129150-32020,, "GASKET, L.O. PUMP",1,1,,,,,,,,,,,,,
14,2,,129150-35041,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
15,2,,129150-35111,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
16,2,,129100-42020,, "GASKET, C.W. PUMP",1,1,,,,,,,,,,,,,
17,2,,129795-49551,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
18,2,,129150-49811,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
19,2,,129100-49840,, "GASKET, THERMO. CASE",1,1,,,,,,,,,,,,,
20,2,,124465-44950,, "GASKET 16",2,2,,,,,,,,,,,,,
21,2,,24321-000650,, "O-RING 1A G-65.0",1,1,,,,,,,,,,,,,
22,2,,129150-77511,, "GASKET, (NON-ASB.)",1,1,,,,,,,,,,,,,
23,1,,977770-01212,, "GASKET, LIQUID",1,1,,,,,1,,,,,,,,,
24,1,,129400-92420,, "FLEX HORN",1,1,,,,,1,,,,,,,,,

Fig. 17 パッキンセット (オプション) & 工具
GASKET SET (OPTIONAL) & TOOL



0,Y00B5902

1,001,, "ENGINE SECTION 3TNE88-(E)B1"

2,1,, "CYLINDER BLOCK", 3TNE88-B1, 3TNE88-EB1,,

2,2,, "GEAR HOUSING", 3TNE88-B1, 3TNE88-EB1,,

2,3,, "FLYWHEEL HOUSING & OIL SUMP", 3TNE88-B1, 3TNE88-EB1,,

2,4,, "CYLINDER HEAD & BONNET", 3TNE88-B1, 3TNE88-EB1,,

2,5,, "SUCTION MANIFOLD & AIR CLEANER", 3TNE88-B1, 3TNE88-EB1,,

2,6,, "EXHAUST MANIFOLD & SILENCER", 3TNE88-B1, 3TNE88-EB1,,

2,7,, "CAMSHAFT & DRIVE GEAR", 3TNE88-B1, 3TNE88-EB1,,

2,8,, "CRANKSHAFT & PISTON", 3TNE88-B1, 3TNE88-EB1,,

2,9,, "LUB. OIL SYSTEM", 3TNE88-B1, 3TNE88-EB1,,

2,10,, "COOLING WATER SYSTEM", 3TNE88-B1, 3TNE88-EB1,,

2,11,, "FUEL INJECTION PUMP", 3TNE88-B1, 3TNE88-EB1,,

2,12,, GOVERNOR, 3TNE88-B1, 3TNE88-EB1,,

2,13,, "FUEL INJECTION PIPE", 3TNE88-B1, 3TNE88-EB1,,

2,14,, "FUEL PIPE", 3TNE88-B1, 3TNE88-EB1,,

2,15,, "STARTING MOTOR", 3TNE88-B1, 3TNE88-EB1,,

2,16,, GENERATOR, 3TNE88-B1, 3TNE88-EB1,,

2,17,, "GASKET SET(OPTIONAL) & TOOL", 3TNE88-B1, 3TNE88-EB1,,