

[Info]

PcNo=Y00B4401

PcName=4TN84L-RBB(B6)

JpnUse=1

JpnSec1=fGf"fwf"

JpnSec2=--§ ¯

JpnSec3=TN

JpnPreface=0

EngUse=1

EngSec1=ENGINE

EngSec2=SMALL VERTICAL (B)


EngSec3=TN

EngPreface=0

Silverhorn.co.uk


1,1,,729405-01560,, "BLOCK ASSY, CYLINDER",1,,,,,,,,,,,,,
2,3,,124160-01910,, "PLUG PT1/4",2,,,,,,,,,,,,,
3,3,,124160-01910,, "PLUG PT1/4",1,,,,,,,,,,,,,
4,3,,171051-01921,, PLUG,1,,,,,,,,,,,,,
5,3,,23871-010000,, "PLUG PT1/8, SCREW",1,,,,,,,,,,,,,
6,3,,27231-500000,, "PLUG 50",1,,,,,,,,,,,,,
7,3,,27241-120000,, "PLUG 12",2,,,,,,,,,,,,,
8,3,,27241-300000,, "PLUG 30",8,,,,,,,,,,,,,
9,2,,23414-080000,, "GASKET 8, ROUND",4,,,,,,,,,,,,,
10,2,,23871-030000,, "PLUG PT3/8, SCREW",1,,,,,,,,,,,,,
11,2,,26106-080122,, "BOLT M 8X 12 PLATED",4,,,,,,,,,,,,,
12,2,,129150-02020,, "BOLT, BEARING CAP",10,,,,,,,,,,,,,
13,2,,129150-02800,, "MAIN BEARING",5,,,,,,,,,,,,,
14,2,,129150-02930,, "BEARING, THRUST",2,,,,,,,,,,,,,
15,2,,129795-02411,, "BUSH, CAMSHAFT",1,,,,,,,,,,,,,
16,1,,129150-01200,, "STUD, CYL. HEAD",18,,,,,,,,,,,,,
17,1,,129405-01330,, "GASKET, CYL. HEAD",1,,,,,,,,,,,,,
17-1,1,,129405-01331,, "GASKET, (NON-ASB.)",1,,,,,R,A,, "E/# 12496",,,,,,
18,1,,129150-02870,, "MAIN BEARING US=0.25",5,,,,,1,,,,,
19,1,,129150-02940,, "BEARING, THRUST .250S",1,,,,,2,,,,,

Fig. 1 シリンダブロック
CYLINDER BLOCK




1,1,,719810-01500,, "HOUSING ASSY, GEAR",1,,,,,W,,,"E/# 02046",,,,,,
2,2,,129795-01800,, "SEAL, OIL",1,,,,,
3,1,,121450-01560,, "STUD M 8X 22",3,,,,,
4,1,,124160-01751,, "CAP, LUB.OIL SUPPLY",1,,,,,
5,1,,129400-01520,, "FLANGE,GEARS HOUSING",1,,,,,
6,1,,124240-01871,, "COVER, HO-P",1,,,,,
7,1,,124240-01882,, "GASKET, HYD.OIL PUMP",1,,,,,
7-1,1,,124240-01883,, "GASKET, (NON-ASB.)",1,,,,,N,A,, "E/# 02309",,,,,,
8,1,,129795-01950,, "PIPE, KNOCK L=18",2,,,,,
9,1,,121850-51960,, "O-RING, F.I.PUMP",1,,,,,A,,,,,
10,1,,24311-000160,, "O-RING 1A P-16.0",2,,,,,
11,1,,24311-000320,, "O-RING 1A P-32.0",1,,,,,A,,,,,
12,1,,26106-080122,, "BOLT M 8X 12 PLATED",4,,,,,
13,1,,26106-080162,, "BOLT M 8X 16 PLATED",1,,,,,
14,1,,26106-080162,, "BOLT M 8X 16 PLATED",3,,,,,
15,1,,26106-080202,, "BOLT M 8X 20 PLATED",2,,,,,
16,1,,26106-080452,, "BOLT M 8X 45 PLATED",6,,,,,
17,1,,26106-080552,, "BOLT M 8X 55 PLATED",3,,,,,
18,1,,26106-080852,, "BOLT M 8X 85 PLATED",4,,,,,
19,1,,26366-080002,, "NUT M 8",3,,,,,
20,1,,43400-500410,, "SEAL WASHER 8S",4,,,,,
20-1,1,,22190-080002,, "SEAL WASHER 8S",4,,,,,R,,,"E/# 12496",,,,,,
21,1,,43400-500410,, "SEAL WASHER 8S",1,,,,,
21-1,1,,22190-080002,, "SEAL WASHER 8S",1,,,,,R,,,"E/# 12496",,,,,,
22,1,,121023-01550,, "COVER, BLIND",1,,,,,
23,1,,24341-000240,, "O-RING 1A S-24.0",1,,,,,
24,1,,26106-060122,, "BOLT M 6X 12 PLATED",2,,,,,
25,1,,121420-01760,, "O-RING",1,,,,,
25-1,1,,24311-000320,, "O-RING 1A P-32.0",1,,,,,N,A,, "E/# 02815",,,,,,
26,1,,171031-11741,, "PIPE",1,,,,,

Fig. 2 ギヤケース
GEAR HOUSING




1,1,,129100-01580,, "PARALLEL PIN 8X16",2,,,,,,,,,,,,,
2,1,,171440-01600,, "HOUSING, FLYWHEEL",1,,,,,,,,,,,,,
3,1,,119620-01750,, "CAP, FLYWHEEL COVER",1,,,,,,,,,,,,,
4,1,,26206-100252,, "BOLT M10X25",8,,,,,,,,,,,,,
5,1,,729550-01541,, "SUMP ASSY, LUB.OIL",1,,,,,,,,,,,,,
6,2,,729403-01540,, "COVER, LUB.OIL SUMP",1,,,,,W,, EXXX,,,,,
6A,3,,121400-01640,, "PLUG M16",2,,,,,,,,,,,,,
7,3,,24311-000180,, "O-RING 1A P-18.0",2,,,,,A,,,,,
8,2,,26106-080252,, "BOLT M 8X 25 PLATED",20,,,,,,,,,,,,,
9,1,,26106-080502,, "BOLT M 8X 50 PLATED",8,,,,,,,,,,,,,
10,1,,26106-081002,, "BOLT M 8X100 PLATED",14,,,,,,,,,,,,,
11,1,,26106-081202,, "BOLT M 8X120 PLATED",4,,,,,,,,,,,,,
12,1,,129555-01750,, "PIPE, KNOCK",1,,,,,,,,,,,,,
13,1,,129100-01580,, "PARALLEL PIN 8X16",2,,,,,,,,,,,,,
14,1,,129100-01640,, "CASE ASSY, OIL SEAL",1,,,,,W,, "E/# 03508",,,,,,
15,2,,129150-01650,, "CASE, OIL SEAL",1,,,,,,,,,,,,,
16,2,,129795-01780,, "SEAL, OIL",1,,,,,,,,,,,,,
17,1,,26106-080302,, "BOLT M 8X 30 PLATED",9,,,,,,,,,,,,,

Fig. 3 フライホイールハウジング&オイルパン
FLYWHEEL HOUSING & LUB. OIL SUMP



1,1,,729402-11700,, "HEAD ASSY, CYLINDER",1,,,,,,,,,,,,,
2,2,,120130-11860,, "GUIDE, VALVE",4,,,,,,,,,1,,,,,,,,,
3,2,,129150-11810,, "GUIDE, VALVE",4,,,,,,,,,1,,,,,,,,,
4,3,,121850-11860,, "PLUG PT1/4",3,,,,,,,,,,,,,,,,,,,,,
4-1,3,,23871-020000,, "PLUG PT1/4, SCREW",3,,,,,,,,,R,, "E/# 12496",,,,,,,,,,
5,3,,23871-030000,, "PLUG PT3/8, SCREW",4,,,,,,,,,,,,,,,,,,,,,
6,3,,27241-220000,, "PLUG 22",4,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
7,3,,27241-400000,, "PLUG 40",2,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
8,3,,26216-060202,, "STUD M 6X 20 PLATED",8,,,,,,,,,,,,,,,,,,,,,
9,2,,129100-11100,, "VALVE, INTAKE",4,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
10,2,,129100-11110,, "VALVE, EXHAUST",4,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
11,2,,129795-11120,, "SPRING, VALVE",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
12,2,,129795-11180,, "RETAINER, SPRING",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
13,2,,103338-11190,, "COTTER 8",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
13-1,2,,27310-080000,, "COTTER 8",8,,,,,,,,,R,, "E/# 12496",,,,,,,,,,
14,2,,121400-11340,, "SEAL, VALVE STEM",4,,,,,,,,,A,,,,,,,,,,,,,
15,2,,124460-11340,, "SEAL, VALVE STEM",4,,,,,,,,,A,,,,,,,,,,,,,
16,2,,26366-060002,, "NUT M 6",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
17,2,,129150-11370,, "CAP, VALVE",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
18,2,,119625-11900,, "RETAINER",4,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
19,2,,119625-11870,, "PROTECTOR, NOZZLE",4,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
19-1,2,,119625-11871,, "PROTECTOR, NOZZLE",4,,,,,,,,,R,A,, "E/# 12496",,,,,,,,,,
20,2,,119625-11880,, "SEAT, NOZZLE",4,,,,,,,,,A,,,,,,,,,,,,,,,,,,,,,
21,1,,22351-060012,, "SPRING PIN 6X12",2,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
22,1,,129555-11241,, "SHAFT ASSY, ROCKER",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
23,2,,129550-11290,, "SHAFT, ROCKER ARM",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
24,3,,27241-100000,, "PLUG 10",2,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
25,2,,129155-11260,, "SUPPORT, ROCKER ARM",2,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
26,2,,129155-11270,, "SUPPORT, ROCKER ARM",3,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
27,2,,129150-11280,, "SPRING",4,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
28,2,,729150-11650,, "ARM ASSY, ROCKER",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
28-1,2,,729402-11650,, "ARM ASSY, ROCKER",8,,,,,,,,,N,, EXXX,,,,,,,,,
29,3,,129150-11750,, "NUT M8XP1.0",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
30,3,,129150-11230,, "SCREW, VALVE",8,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
31,2,,26226-080182,, "STUD M 8X 18 PLATED",3,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
32,2,,26756-080002,, "LOCK NUT M 8 PLATED",3,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
33,1,,26106-080252,, "BOLT M 8X 25 PLATED",3,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
34,1,,26106-080502,, "BOLT M 8X 50 PLATED",7,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
35,1,,124736-07900,, "LIFTER, ENGINE",2,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
36,1,,26106-080142,, "BOLT M 8X 14 PLATED",4,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
37,1,,729403-11520,, "BONNET ASSY",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
38,2,,129150-03070,, "BAFFLE, BREATHER",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
39,2,,129150-03080,, "PLATE, SHELTER",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
40,2,,24341-000500,, "O-RING 1A S-50.0",1,,,,,,,,,A,,,,,,,,,,,,,
41,2,,26106-080162,, "BOLT M 8X 16 PLATED",2,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
42,2,,129550-11310,, "GASKET, BONNET",1,,,,,,,,,A,,,,,,,,,,,,,,,,,,,,,
43,2,,129150-03020,, "COVER, BREATHER",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
44,2,,24311-000320,, "O-RING 1A P-32.0",1,,,,,,,,,A,,,,,,,,,,,,,
45,2,,124160-01751,, "CAP, LUB.OIL SUPPLY",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
46,1,,129150-03100,, "RETAINER",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
47,1,,171350-03090,, "PIPE, BREATHER",1,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
48,1,,124160-11360,, "KNOB",3,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
49,1,,24311-000120,, "O-RING 1A P 12.0",3,,,,,,,,,,,,,,,,,,,,,,,,,,,,,

Fig. 4 シリンダヘッド&ボンネット
CYLINDER HEAD & BONNET




1,1,,171351-12210,,HOSE,1,,,,,,,,,,,,,
2,1,,129432-12500,, "CLEANER ASSY, AIR",1,,,,,,,,,,,,,
3,2,,121252-12521,, "BODY, AIR CLEANER",1,,,,,,,,,,,,,
4,2,,121120-12531,, "PAN ASSY, DUST",1,,,,,,,,,,,,,
5,2,,121120-12541,, "RETAINER, ELEMENT",1,,,,,,,,,,,,,
6,2,,121120-12561,, "BOLT, WING",1,,,,,,,,,,,,,
7,2,,121120-12571,, "SEAL WASHER",1,,,,,,,,,,,,,
8,2,,121120-12901,, ELEMENT,1,,,,,,,,,,,,,
9,1,,121400-12540,, "BRACE (B) ASSY",1,,,,,,,,,,,,,
10,2,,121400-12560,, "BRACE (B)",1,,,,,,,,,,,,,
11,2,,121400-12570,, "SEAT (B), RUBBER",1,,,,,,,,,,,,,
12,1,,171351-12580,, "SUPPORT ASSY,CLEANER",1,,,,,,,,,,,,,
13,2,,171351-12560,, "SUPPORT, AIR CLEANER",1,,,,,,,,,,,,,
14,2,,171351-12570,, "SEAT(B), RUBBER",1,,,,,,,,,,,,,
15,1,,23000-060000,, "CLAMP 60",2,,,,,,,,,,,,,
16,1,,26106-080142,, "BOLT M 8X 14 PLATED",4,,,,,,,,,,,,,
17,1,,26366-060002,, "NUT M 6",4,,,,,,,,,,,,,
18,1,,129488-12100,, "MANIFOLD, AIR INTAKE",1,,,,,,,,,,,,,
19,1,,129550-12110,, "GASKET, SUC.MANIFOLD",1,,,,,,,,,,,,,
19-1,1,,129550-12111,, "GASKET, (NON-ASB.)",1,,,,,N,A,, "E/# 02309",,,,,,
20,1,,26106-080352,, "BOLT M 8X 35 PLATED",5,,,,,,,,,,,,,
21,1,,129402-13100,, "MANIFOLD, EXHAUST",1,,,,,,,,,,,,,
22,1,,129550-13110,, "GASKET, EXH.MANIFOLD",1,,,,,A,,,,,
23,1,,194990-22050,, "NUT W/WASHER 8",2,,,,,,,,,,,,,
24,1,,26106-080802,, "BOLT M 8X 80 PLATED",6,,,,,,,,,,,,,
25,1,,26216-080222,, "STUD M 8X 22 PLATED",4,,,,,,,,,,,,,
26,1,,26216-080802,, "STUD M 8X 80 PLATED",2,,,,,,,,,,,,,
27,1,,129120-77501,, "HEATER, AIR",1,,,,,,,,,,,,,
28,1,,129150-77510,, "GASKET, AIR HEATER",1,,,,,,,,,,,,,
28-1,1,,129150-77511,, "GASKET, (NON-ASB.)",1,,,,,N,A,, "E/# 02309",,,,,,
29,1,,26106-080352,, "BOLT M 8X 35 PLATED",4,,,,,,,,,,,,,

1,1,,729402-14580,, "CAMSHAFT ASSY",1,,,,,W,,,EXXX,,,,,
2,2,,129150-14101,, "GEAR, CAMSHAFT",1,,,,,,,,,,,,,
3,2,,22512-070140,, "KEY 7X 14",1,,,,,,,,,,,,,
4,2,,129150-02450,, "BEARING, THRUST",1,,,,,,,,,,,,,
5,1,,129150-14200,, TAPPET,8,,,,,,,,,,,,,
6,1,,129150-14400,, "ROD, PUSH",8,,,,,,,,,,,,,
7,1,,129100-25061,, "SHAFT, IDLE GEAR",1,,,,,,,,,,,,,
8,1,,129150-25101,, "GEAR W/BUSH",1,,,,,,,,,,,,,
9,2,,129150-25061,, "BUSH, IDLE GEAR",1,,,,,,,,,,,,,
10,1,,26106-080452,, "BOLT M 8X 45 PLATED",2,,,,,,,,,,,,,
11,1,,26106-080162,, "BOLT M 8X 16 PLATED",2,,,,,,,,,,,,,


Silverhorn.co.uk

Fig. **6** カムシャフト&駆動ギヤ
CAMSHAFT & DRIVING GEAR




1,1,,729400-21700,, "CRANKSHAFT ASSY",1,,,,,,,,,,,,,
2,2,,129150-21200,, "GEAR, CRANKSHAFT",1,,,,,,,,,,,,,
3,2,,22351-040010,, "SPRING PIN 4X10",1,,,,,,,,,,,,,
4,2,,22512-070140,, "KEY 7X 14",1,,,,,,,,,,,,,
5,1,,171301-21650,, "V-PULLEY, CRANKSHAFT",1,,,,,,,,,,,,,
6,1,,129795-21661,, WASHER,1,,,,,,,,,,,,,
7,1,,121850-21680,, "BOLT, V-PULLEY",1,,,,,,,,,,,,,
8,1,,129100-01580,, "PARALLEL PIN 8X16",1,,,,,,,,,,,,,
9,1,,121111-21501,, "BOLT, FLYWHEEL",6,,,,,,,,,,,,,
10,1,,129403-21590,, "FLYWHEEL ASSY",1,,,,,,,,,,,,,
11,2,,124550-21600,, "RING GEAR",1,,,,,,,,,,,,,
12,1,,129105-22080,, "PISTON W/RING",4,,,,,,,,,,,,,
13,2,,129105-22500,, "RING SET, PISTON",4,,,,,,,,,,,,,
14,1,,129150-22300,, "PIN, PISTON",4,,,,,,,,,,,,,
15,1,,121100-22400,, CIRCLIP,8,,,,,,,,,,,,,
16,1,,729105-22900,, "PISTON W/RING OS=.25",4,,,,,,,,1,,,,,
17,2,,729157-22951,, "RING SET O.S=0.25",4,,,,,,,,1,,,,,
18,1,,729150-23700,, "ROD ASSY, CONNECTING",4,,,,,,,,,,,,,
18-1,1,,729402-23100,, "ROD ASSY, CONNECTING",4,,,,,N,,EXXX,,,,,
19,2,,121550-23200,, "BOLT, CONNECTING ROD",8,,,,,,,,,,,,,
20,2,,129150-23600,, "BEARING, CRANKPIN",4,,,,,,,,,,,,,
21,1,,129100-23910,, "BUSH, PISTON PIN",4,,,,,,,,2,,,,,
22,1,,129150-23610,, "BEARING, PIN U.S=0.25",4,,,,,,,,3,,,,,

Fig. 7 クランクシャフト&ピストン
CRANKSHAFT & PISTON




1,1,,129150-32000,, "PUMP ASSY, LUB. OIL",1,,,,,,,,,,,,,
1-1,1,,129407-32000,, "PUMP ASSY, LUB. OIL",1,,,,,,N,,,"E/# 12496",,,,,,,
1A-1,2,,129407-32010,, BODY,1,,,,,,,,,,,,,
2,1,,129150-32020,, "GASKET, L.O. PUMP",1,,,,,,A,,,,,,,,,
3,1,,26450-060252,, "BOLT M 6X 25",4,,,,,,,,,,,,,
4,1,,121520-34810,, "GUIDE, DIPSTICK",1,,,,,,,,,,,,,
5,1,,129403-34800,, "DIPSTICK, LUB. OIL",1,,,,,,,,,,,,,
6,1,,129150-35040,, "GASKET, OIL STRAINER",1,,,,,,,,,,,,,
6-1,1,,129150-35041,, "GASKET, (NON-ASB.)",1,,,,,,N,A,,,"E/# 02309",,,,,,,
7,1,,129403-35090,, "PIPE, OIL INLET",1,,,,,,,,,,,,,
8,1,,26106-080122,, "BOLT M 8X 12 PLATED",2,,,,,,,,,,,,,
9,1,,26106-080352,, "BOLT M 8X 35 PLATED",2,,,,,,,,,,,,,
10,1,,129150-35101,, "BRACKET, STRAINER",1,,,,,,,,,,,,,
11,1,,129150-35110,, "GASKET, BRACKET",1,,,,,,,,,,,,,
11-1,1,,129150-35111,, "GASKET, (NON-ASB.)",1,,,,,,N,A,,,"E/# 02309",,,,,,,
12,1,,129150-35150,, "FILTER 90X80L",1,,,,,,,,,,,,,
13,1,,119865-35300,, "VALVE ASSY,OIL PRESS",1,,,,,,,,,,,,,
13-1,1,,129001-35300,, "BOLT,LUB.O. STRAINER",1,,,,,,S,,,"E/# 12496",,,,,,,
14,1,,129150-35350,, NUT,1,,,,,,,,,,,,,
15,1,,24311-000160,, "O-RING 1A P-16.0",1,,,,,,A,,,,,,,,,
16,1,,26106-080202,, "BOLT M 8X 20 PLATED",3,,,,,,,,,,,,,
17,1,,124160-39450,, "SWITCH, OIL PRESSURE",1,,,,,,,,,,,,,
18,1,,129550-39450,, "PIPE ASSY, LUB. OIL",1,,,,,,,,,,,,,
19,1,,124160-39140,, "BOLT 10, PIPE JOINT",1,,,,,,,,,,,,,
20,1,,124550-59820,, "BOLT 8, PIPE JOINT",1,,,,,,,,,,,,,
21,1,,43400-500410,, "SEAL WASHER 8S",2,,,,,,,,,,,,,
21-1,1,,22190-080002,, "SEAL WASHER 8S",2,,,,,,N,,,"E/# 12496",,,,,,,
22,1,,23414-100000,, "GASKET 10, ROUND",2,,,,,,,,,,,,,

Fig. 8 潤滑油システム
LUB. OIL SYSTEM



1,1,,121850-11860,, "PLUG PT1/4",1,,,,,,,,,,,,,
2,1,,129100-42001,, "PUMP ASSY, C.WATER",1,,,,,,,,,,,,,
2-1,1,,129100-42002,, "PUMP, C.W. (NON-ASB.)",1,,,,,N,, "E/# 02309",,,,,,
3,2,,23871-030000,, "PLUG PT3/8, SCREW",1,,,,,,,,,,,,,
4,1,,129100-42020,, "GASKET, C.W. PUMP",1,,,,,A,,,,,,,,,
5,1,,26106-080602,, "BOLT M 8X 60 PLATED",3,,,,,,,,,,,,,
6,1,,121492-42290,, "V-BELT (A-38)",1,,,,,,,,,,,,,
6-1,1,,25132-003800,, "V-BELT (A-38)",1,,,,,N,, "E/# 12496",,,,,,
7,1,,129550-42350,, V-PULLEY(D=120),1,,,,,,,,,,,,,
8,1,,129432-44740,, "FAN, COOLING (D370*EF)",1,,,,,,,,,,,,,
9,1,,121267-44760,, SPACER,1,,,,,,,,,,,,,
10,1,,26014-060302,, "BOLT W/WASHER 6X 30",4,,,,,,,,,,,,,
11,1,,121550-49111,, "JOINT PT1/4",1,,,,,,,,,,,,,
12,1,,129100-49050,, "PIPE, C.W. (BY-PASS)",1,,,,,,,,,,,,,
12-1,1,,129132-49050,, "PIPE, COOLING WATER",1,,,,,N,, "E/# 12496",,,,,,
13,1,,23000-016000,, "CLAMP 16",2,,,,,,,,,,,,,
14,1,,121450-42450,, "PLUG M16",1,,,,,,,,,,,,,
15,1,,121250-44901,, "SWITCH, THERMO(110 β C)",1,,,,,,,,,,,,,
16,1,,124465-44950,, "GASKET 16",1,,,,,A,,,,,,,,,
17,1,,124465-44950,, "GASKET 16",1,,,,,A,,,,,,,,,
18,1,,129350-49530,, "COVER, THERMOSTAT",1,,,,,,,,,,,,,
19,1,,129795-49550,, "GASKET, THERMO.COVER",1,,,,,,,,,,,,,
19-1,1,,129795-49551,, "GASKET, (NON-ASB.)",1,,,,,N,A, "E/# 02309",,,,,,
20,1,,129100-49800,, "CASE ASSY, THERMOSTAT",1,,,,,,,,,,,,,
21,2,,124770-11770,, "JOINT PT1/8",1,,,,,,,,,,,,,
22,2,,129100-49820,, "GASKET, COVER",1,,,,,,,,,,,,,
23,2,,129100-49830,, "COVER, THERMOST.CASE",1,,,,,,,,,,,,,
24,2,,23871-030000,, "PLUG PT3/8, SCREW",1,,,,,,,,,,,,,
25,2,,26116-060162,, "BOLT M 6X 16 PLATED",2,,,,,,,,,,,,,
26,1,,129155-49800,, THERMOSTAT,1,,,,,,,,,,,,,
27,1,,129150-49810,, "GASKET, THERMOSTAT",1,,,,,,,,,,,,,
27-1,1,,129150-49811,, "GASKET, (NON-ASB.)",1,,,,,N,A, "E/# 02309",,,,,,
28,1,,129100-49840,, "GASKET, THERMO. CASE",1,,,,,A,,,,,,,,,
29,1,,26106-080202,, "BOLT M 8X 20 PLATED",2,,,,,,,,,,,,,
30,1,,26106-080252,, "BOLT M 8X 25 PLATED",1,,,,,,,,,,,,,
31,1,,26106-080502,, "BOLT M 8X 50 PLATED",1,,,,,,,,,,,,,
32,1,,26106-080602,, "BOLT M 8X 60 PLATED",1,,,,,,,,,,,,,


Fig. 9 冷却水システム
COOLING WATER SYSTEM



1,1,,729432-51370,, "PUMP W/GOV.& F.PUMP",1,,,,,1,,,,,
2,2,,129470-51040,, CAMSHAFT,1,,,,,
3,2,,129155-51050,, "BALL BEARING, THRUST",1,,,,,
4,2,,129155-51060,, "CAM SHAFT SUPPORT",1,,,,,
5,2,,122710-51090,, KEY,1,,,,,
6,2,,129400-51100,, "PLUNGER W/BARREL",4,,,,,
7,2,,129155-51140,, "PIN, BARREL LOCKING",4,,,,,
8,2,,174307-51170,, "RETAINER A",4,,,,,
9,2,,129155-51180,, "SPRING SHOE, PLUNGER",4,,,,,
10,2,,124950-51190,, "SPRING, PLUNGER",4,,,,,
11,2,,129155-51200,, "TAPPET ASSY",4,,,,,
13,3,,129155-51250,, "BOLT, ADJUSTING",4,,,,,
14,3,,174100-54120,, "PIN, ROLLER",4,,,,,
15,2,,129155-51270,, "LOCKING, TAPPET",4,,,,,
16,2,,129155-51280,, "O-RING S6",5,,,,,
17,2,,128170-51300,, "VALVE W/SEAT, DELIV.",4,,,,,
18,2,,129155-51320,, "SPRING, DELIV. VALVE",4,,,,,
19,2,,129155-51340,, "GUARD, DELIVERY VALVE",4,,,,,
20,2,,124550-51350,, "GASKET, DELIVERY",4,,,,,
21,2,,124550-51370,, "O-RING, DELIVERY",4,,,,,
22,2,,129155-51370,, "STOPPER, VALVE",4,,,,,
23,2,,129155-51380,, "LOCKING (A)",2,,,,,
24,2,,129155-51390,, "LOCKING (B)",2,,,,,
25,2,,129555-51400,, DEFLECTER,1,,,,,
26,2,,129155-51410,, "CHECK BOLT, DEFLECTOR",1,,,,,
27,2,,129155-51450,, "SHIM SET, ADJUSTING",1,,,,,
28,2,,129555-51500,, "RACK, CONTROL",1,,,,,
29,2,,26716-060002,, "NUT M 6",2,,,,,
30,2,,129155-51521,, "BUSH, RACK",1,,,,,
31,2,,129155-51530,, "SPACER, AUX. SPRING",1,,,,,
32,2,,129155-51540,, CIRCLIP,1,,,,,
33,2,,129155-51550,, "PINION, CONTROL",4,,,,,
34,2,,122117-51560,, "SCREW, PINION",4,,,,,
35,2,,174307-51560,, PINION,4,,,,,
36,2,,129155-51570,, "PLUG (M12)",1,,,,,
37,2,,129155-51580,, O-RING,1,,,,,
38,2,,129155-51591,, "SPRING, RACK",1,,,,,
39,2,,129155-51600,, "SHIM PACK",4,,,,,
40,2,,129555-51700,, COVER,1,,,,,
41,2,,129555-51710,, GASKET,1,,,,,
42,2,,129555-51750,, "COVER, SIDE",1,,,,,
43,2,,129555-51760,, GASKET,1,,,,,
44,2,,129155-51790,, "LOCKING, RACK",1,,,,,
45,2,,129156-51910,, "LABEL, CAUTION",1,,,,,
46,2,,129155-51930,, "SPACER T=3.25",1,,,,,
47,2,,129155-51940,, "SPACER T=1.5",1,,,,,
48,2,,22217-060000,, "SPRING WASHER 6",2,,,,,
49,2,,22351-050010,, "SPRING PIN 5X10",2,,,,,
50,2,,24101-063034,, "BALL BEARING",1,,,,,
51,2,,24341-000160,, "O-RING 1A S-16.0",1,,,,,
52,2,,26116-050302,, "BOLT M 5X 30 PLATED",2,,,,,
53,2,,129155-51020,, "STUD, FEED PUMP",2,,,,,
54,2,,26022-050102,, "SCREW M 5X 10",11,,,,,
55,2,,26022-060162,, "SCREW M 6X 16",4,,,,,
56,2,,129100-52100,, "PUMP ASSY, FUEL FEED",1,,,,,
56B,3,,129158-52020,, DIAPHRAGM,1,,,,,
56D,3,,129158-52060,, COVER,1,,,,,
56E,3,,129158-52070,, GASKET,1,,,,,
56F,3,,129158-52080,, "SCREW, CROSS",6,,,,,
56G,3,,129158-52090,, CAP,2,,,,,
56H,3,,129158-52160,, SPRING,1,,,,,
56I,3,,129158-52250,, TAPPET,1,,,,,
56J,3,,129158-52260,, SPRING,1,,,,,


56K,3,,129158-52270,, "PIN, TAPPET",1,,,,,,,,,,,,,
56L,3,,129158-52350,, "LEVER, PRIMING",1,,,,,,,,,,,,,
56M,3,,129158-52360,, "SPRING, RETURN",1,,,,,,,,,,,,,
56N,3,,129158-52370,, "PIN, PRIMING LEVER",1,,,,,,,,,,,,,
56P,3,,129158-52380,, "O-RING,PRIMING LEVER",1,,,,,,,,,,,,,
57,2,,129155-52050,, GASKET,1,,,,,,,,,,,,,
58,2,,129155-51420,, "PLUG (M16)",1,,,,,,,,,,,,,
59,2,,43400-500490,, "SEAL WASHER 16S",1,,,,,,,,,,,,,
59-1,2,,22190-160002,, "SEAL WASHER 16S",1,,,,,R,, "E/# 12496",,,,,,
59A,2,,22217-050000,, "SPRING WASHER 5",2,,,,,W,, EXXX,,,,,
60,1,,129150-25900,, "GEAR, FUEL INJ. PUMP",1,,,,,,,,,,,,,
61,1,,22217-120000,, "WASHER 12,SPRING",1,,,,,,,,,,,,,
62,1,,26716-120002,, "NUT M12",1,,,,,,,,,,,,,

Fig. 10 燃料噴射ポンプ FUEL INJECTION PUMP




1,1,,729506-53100,, "VALVE ASSY,F.INJECT",4,,,,,,,,,,,,,
2,2,,129506-53000,, "NOZZLE ASSY,F.INJECT",4,,,,,,,,,,,,,
3,2,,114250-53080,, "NUT, NOZZLE CASE",4,,,,,,,,,,,,,
4,2,,129100-53100,, "HOLDER ASSY, NOZZLE",4,,,,,,,,,,,,,
5,2,,114250-53120,, "SPRING, NOZZLE",4,,,,,,,,,,,,,
6,2,,114250-53130,, "SEAT, NOZZLE SPRING",4,,,,,,,,,,,,,
7,2,,114250-53140,, "PLATE, STOP",4,,,,,,,,,,,,,
8,2,,114250-53210,, PIN,8,,,,,,,,,,,,,
9,2,,114250-53400,, "SHIM PACK",4,,,,,,,,,,,,,
10,1,,129550-59120,, RETAINER,1,,,,,,,,,,,,,
10-1,1,,129150-59120,, "RETAINER, INJ. PIPE",2,,,,,,N,,,"E/# 12496",,,,,,
11,2,,129150-59130,, "BOLT M 4X 12",2,,,,,,,,,,,,,
11-1,2,,129150-59131,, "BOLT M4X14,HEX.SCKT.",4,,,,,,N,,,"E/# 12496",,,,,,
12,1,,129400-59910,, "PIPE, FUEL INJECTION",1,,,,,,,,,,,,,
13,1,,129400-59920,, "PIPE, FUEL INJECTION",1,,,,,,,,,,,,,
14,1,,129400-59930,, "PIPE, FUEL INJECTION",1,,,,,,,,,,,,,
15,1,,129400-59940,, "PIPE, FUEL INJECTION",1,,,,,,,,,,,,,

Fig. 11 燃料噴射パイプ
FUEL INJECTION PIPE




1,1,,129100-55621,, "STRAINER ASSY, FUEL",1,,,,,,,,,,,,,
2,2,,104200-55321,, "VALVE, TAPER",1,,,,,,,,,,,,,
3,2,,104200-55330,, "SPRING, TAPER VALVE",1,,,,,,,,,,,,,
4,2,,129100-55650,, "ELEMENT, FUEL",1,,,,,,,,,,,,,
5,2,,129100-55670,, LEVER,1,,,,,,,,,,,,,
6,2,,129100-55680,, "CUP, STRAINER",1,,,,,,,,,,,,,
7,2,,129100-55690,, "RING, RETAINING",1,,,,,,,,,,,,,
8,2,,129100-55700,, SPRING,1,,,,,,,,,,,,,
9,2,,104200-55750,, "SCREW M 4",1,,,,,,,,,,,,,
10,2,,24311-000160,, "O-RING 1A P-16.0",1,,,,,,,,,,,,,
11,2,,24311-240100,, "O-RING 1A P-10A",1,,,,,,,,,,,,,
12,2,,24321-000650,, "O-RING 1A G-65.0",1,,,,,,,,,,,,,
13,1,,124066-59100,, "CLAMP 8",1,,,,,,,,,,,,,
14,1,,129150-59580,, CAP,1,,,,,,,,,,,,,
15,1,,26014-080702,, "BOLT W/WASHER M8X 70",1,,,,,,,,,,,,,
16,1,,103854-39140,, "BOLT, PIPE JOINT",1,,,,,,,,,,,,,
17,1,,101304-59020,, "JOINT 12, PIPE",1,,,,,,,,,,,,,
18,1,,124766-59050,, "CLAMP 12",2,,,,,Z,, "E/# 08202",,,,,,
19,1,,104200-59170,, "GASKET 12",2,,,,,,,,,,,,,
20,1,,129555-59510,, "PIPE, FUEL",1,,,,,,,,,,,,,
21,1,,105025-59530,, "FUEL OIL PIPE",1,,,,,,,,,,,,,
22,1,,23000-013000,, "CLAMP 13",2,,,,,,,,,,,,,
23,1,,124766-59050,, "CLAMP 12",2,,,,,,,,,,,,,
23-1,1,,124766-59050,, "CLAMP 12",4,,,,,K,, "E/# 08202",,,,,,
24,1,,124066-59100,, "CLAMP 8",9,,,,,,,,,,,,,
25,1,,105025-59530,, "FUEL OIL PIPE",1,,,,,,,,,,,,,
26,1,,121250-59550,, "PIPE, FUEL",3,,,,,,,,,,,,,
27,1,,119840-59560,, "PIPE, FUEL RETURN",1,,,,,,,,,,,,,
28,1,,119840-59570,, JOINT,1,,,,,,,,,,,,,
29,1,,129150-59580,, CAP,1,,,,,,,,,,,,,
30,1,,129100-59951,, "VALVE ASSY, CHECK",1,,,,,,,,,,,,,
31,1,,23414-120000,, "GASKET 12, ROUND",2,,,,,,,,,,,,,

12 燃料パイプ FUEL PIPE



1,1,,129155-51280,, "O-RING S6",2,,,,,,,,,,,,,
2,1,,129155-61011,, "CASE, GOVERNOR",1,,,,,,,,,,,,,
2-1,1,,129155-61012,, "CASE, GOVERNOR",1,,,,,N,,,"E/# 12068",,,,,,
3,1,,129155-61050,, "GASKET, GOV. CASE",1,,,,,,,,,,,,,
4,1,,129155-61060,, "COVER, GOVERNOR CASE",1,,,,,,,,,,,,,
5,1,,129155-61070,, "GASKET, CASE COVER",1,,,,,,,,,,,,,
6,1,,26776-120002,, "LOCK NUT M12 PLATED",2,,,,,,,,,,,,,
7,1,,129155-61120,, "LINK L=30(MARK 0)",1,,,,,1,,,,,
8,1,,129155-61130,, "LINK L=31(MARK 1)",1,,,,,1,,,,,
9,1,,129155-61140,, "LINK L=30.5(MARK 05)",1,,,,,1,,,,,
10,1,,129155-61201,, "WEIGHT ASSY, GOV.",1,,,,,,,,,,,,,
11,1,,129155-61341,, "SLEEVE",1,,,,,,,,,,,,,
12,1,,129100-61400,, "SHAFT ASSY, CONTROL",1,,,,,,,,,,,,,
13,1,,129255-61410,, "NUT",1,,,,,,,,,,,,,
14,1,,129255-61420,, "SPRING",1,,,,,,,,,,,,,
15,1,,129155-61430,, "SPACER, SHAFT",1,,,,,,,,,,,,,
16,1,,129100-61440,, "LEVER, CONTROL",1,,,,,,,,,,,,,
17,1,,129155-61450,, "BOLT, REVOL. LIMIT",1,,,,,,,,,,,,,
18,1,,129155-61470,, "BOLT, FUEL CONTROL",1,,,,,,,,,,,,,
19,1,,129155-61480,, "SPACER ASSY",2,,,,,,,,,,,,,
20,1,,129155-61490,, "SHAFT, GOV. LEVER",1,,,,,,,,,,,,,
21,1,,129500-61500,, "LEVER ASSY, GOVERNOR",1,,,,,,,,,,,,,
21-1,1,,129500-61501,, "LEVER ASSY, GOVERNOR",1,,,,,N,,,"E/# 12068",,,,,,
22,2,,174307-51700,, "SHIM SET",2,,,,,,,,,,,,,
23,2,,129155-61530,, "BUSH",2,,,,,,,,,,,,,
23-1,2,,119843-61550,, "BUSH",2,,,,,R,,,"E/# 12068",,,,,,
24,2,,26022-060122,, "SCREW M 6X 12",1,,,,,,,,,,,,,
25,1,,129155-61540,, "SHIFTER",1,,,,,,,,,,,,,
26,1,,129100-61650,, "SPRING, FUEL CONTROL",1,,,,,,,,,,,,,
27,1,,171353-61710,, "SPRING, GOVERNOR",1,,,,,,,,,,,,,
28,1,,129155-61810,, "PIN, STOP LEVER",1,,,,,,,,,,,,,
29,1,,129155-61830,, "O-RING S10",1,,,,,,,,,,,,,
30,1,,129100-61851,, "PLUG (15)",1,,,,,,,,,,,,,
31,1,,26687-120002,, "CAP NUT M12",1,,,,,,,,,,,,,
32,1,,129155-61950,, "BOLT, WASHER BASED",1,,,,,,,,,,,,,
33,1,,124550-66370,, "LOCK NUT M 6",1,,,,,,,,,,,,,
34,1,,22117-040000,, "WASHER 4",1,,,,,,,,,,,,,
35,1,,43400-500430,, "SEAL WASHER 10S",1,,,,,,,,,,,,,
35-1,1,,22190-100002,, "SEAL WASHER 10S",1,,,,,N,,,"E/# 12496",,,,,,
36,1,,43400-500450,, "SEAL WASHER 12S",1,,,,,,,,,,,,,
36-1,1,,22190-120002,, "SEAL WASHER 12S",1,,,,,N,,,"E/# 12496",,,,,,
37,1,,22272-000040,, "CIRCLIP E- 4",1,,,,,,,,,,,,,
38,1,,22272-000060,, "CIRCLIP E- 6",2,,,,,,,,,,,,,
39,1,,22287-120000,, "WASHER 12",1,,,,,,,,,,,,,
40,1,,22351-030016,, "SPRING PIN 3X16",1,,,,,,,,,,,,,
41,1,,22360-040000,, "SNAP PIN 4",2,,,,,,,,,,,,,
41-1,1,,22372-040000,, "SNAP PIN 4",2,,,,,R,,,"E/# 04978",,,,,,
42,1,,43400-500390,, "SEAL WASHER 6S",1,,,,,,,,,,,,,
42-1,1,,22190-060002,, "SEAL WASHER 6S",1,,,,,N,,,"E/# 12496",,,,,,
43,1,,23887-100002,, "PLUG 10",1,,,,,,,,,,,,,
44,1,,26022-050102,, "SCREW M 5X 10",4,,,,,,,,,,,,,
44-1,1,,26022-050102,, "SCREW M 5X 10",2,,,,,K,,,"E/# 12068",,,,,,
44A,1,,26023-050102,, "SCREW M 5X 10",2,,,,,W,,,"E/# 12068",,,,,,
45,1,,26106-060202,, "BOLT M 6X 20 PLATED",6,,,,,,,,,,,,,
46,1,,129432-61550,, "UNGLEICH ASSY",1,,,,,,,,,,,,,
47,2,,129155-61540,, "SHIFTER",1,,,,,M,,,,,
47-1,2,,129155-61590,, "NUT",1,,,,,,,,,,,,,



Fig. 13 ガバナ
GOVERNOR



1,1,,124250-77012,, "STARTER (S12-77A)",1,,,,,Z,1,, "E/# 08683",,,,,,
2,2,,124250-77070,, "STOPPER SET, PINION",1,,,,,,,,,,,,,
6,2,,124250-77110,, "COIL ASSY, FIELD",1,,,,,,,,,,,,,
7,3,,124250-77120,, "SCREW SET, PORE CORE",4,,,,,,,,,,,,,
8,3,,124250-77130,, "BRUSH (+)",2,,,,,,,,,,,,,
9,2,,124250-77140,, "COVER ASSY, REAR",1,,,,,,,,,,,,,
10,3,,124250-77150,, "METAL, REAR COVER",1,,,,,,,,,,,,,
11,2,,124250-77160,, "HOLDER ASSY, BRUSH",1,,,,,,,,,,,,,
12,3,,124250-77170,, "BRUSH (-)",2,,,,,,,,,,,,,
13,3,,124250-77180,, "SPRING, BRUSH",4,,,,,,,,,,,,,
14,2,,124250-77190,, "BEARING ASSY, CENTER",1,,,,,,,,,,,,,
15,3,,124250-77520,, BEARING,1,,,,,,,,,,,,,
16,2,,124250-77210,, "PINION ASSY",1,,,,,,,,,,,,,
17,2,,124250-77220,, "CASE ASSY, GEAR",1,,,,,,,,,,,,,
18,3,,124250-77230,, "METAL, GEAR CASE",1,,,,,,,,,,,,,
19,2,,124250-77240,, "COVER SET, DUST",1,,,,,,,,,,,,,
22,2,,124250-77270,, "LEVER SET, SHIFT",1,,,,,,,,,,,,,
26,2,,124250-77310,, "SWITCH, MAGNETIC",1,,,,,,,,,,,,,
27,2,,124250-77320,, "BOLT, THROUGH",2,,,,,,,,,,,,,
28,2,,124250-77500,, "ARMATURE ASSY",1,,,,,,,,,,,,,
29,2,,124250-77510,, "WASHER KIT",1,,,,,,,,,,,,,
33,2,,26557-040122,, "SCREW M 4X 12, PAN HD",2,,,,,,,,,,,,,
34,2,,26106-060322,, "BOLT M 6X 32 PLATED",2,,,,,,,,,,,,,
35,1,,26116-120252,, "BOLT M12X 25 PLATED",2,,,,,Z,1,, "E/# 08683",,,,,,

Fig. 14 スタートイングモータ (旧型)
STARTING MOTOR (PREVIOUS)


UP TO E/#08683



1,1,,129400-77011,,STARTER,1,,,,,W,1,, "E/# 08684",,,,,,
2,2,,129400-77400,, "ARMATURE ASSY",1,,,,,
3,3,,171008-77410,,BEARING(1),1,,,,,
4,3,,171008-77420,,BEARING(2),1,,,,,
5,2,,129400-77440,, "COIL ASSY, FIELD",1,,,,,
6,3,,171008-77450,, "SCREW, POLE CORE SET",4,,,,,
7,3,,129400-77460,, "BRUSH (+)",2,,,,,
8,2,,129400-77470,, "HOLDER ASSY, BRUSH",1,,,,,
9,3,,129400-77480,, "BRUSH (-)",2,,,,,
10,3,,129400-77490,, "SPRING, BRUSH",4,,,,,
11,2,,129400-77510,, "COVER, REAR",1,,,,,
12,2,,171008-77510,, "HOUSING ASSY, GEAR",1,,,,,
13,2,,129400-77520,, "HOUSING, CENTER",1,,,,,
14,2,,129400-77530,, "SWITCH ASSY, MAGNETIC",1,,,,,
15,2,,171008-77540,, "LEVER SET, SHIFT",1,,,,,
18,2,,129400-77570,, "COVER KIT, DUST",1,,,,,
19,2,,129400-77640,, "BOLT, THROUGH",2,,,,,
20,2,,171008-77650,, "PINION ASSY",1,,,,,
21,3,,171008-77660,, "SHAFT, PINION",1,,,,,
22,3,,171008-77670,, "STOPPER SET, PINION",1,,,,,
26,3,,171008-77720,, "CLUTCH ASSY",1,,,,,
27,4,,171008-77730,, "BALL BEARING (3)",1,,,,,
28,4,,171008-77740,, "BALL BEARING (4)",1,,,,,
29,2,,26106-060322,, "BOLT M 6X 32 PLATED",2,,,,,
30,2,,26106-060402,, "BOLT M 6X 40 PLATED",3,,,,,
31,1,,26116-120252,, "BOLT M12X 25 PLATED",2,,,,,W,1,, "E/# 08684",,,,,,


Fig. **15** スターティングモータ (新型)
STARTING MOTOR (NEW)

FROM E/#08684





1,1,,121450-01570,,STUD,1,,,,,,,,,,,,,
1-1,1,,26106-100652,, "BOLT M10X 65 PLATED",1,,,,,S,,,EXXX,,,,,
2,1,,129150-77202,,GENERATOR,1,,,,,,,,,,,,,
3,2,,XM219230000,, "WASHER, SPRING",1,,,,,,,,,,,,,
4,2,,XM329830000,,COLLAR,1,,,,,,,,,,,,,
5,2,,XM860250000,, "WASHER 10",1,,,,,,,,,,,,,
6,2,,XM863720000,,NUT,1,,,,,,,,,,,,,
7,2,,129150-77210,, "PLATE ASSY",1,,,,,,,,,,,,,
7-1,2,,119259-77220,,PLATE,1,,,,,N,,, "E/# 03508",,,,,,
8,3,,XM069000000,,CLAMP,1,,,,,,,,,,,,,
9,3,,XM081780000,,STATOR,1,,,,,,,,,,,,,
10,3,,XM178780000,,COUPLER,1,,,,,,,,,,,,,
11,3,,XYSPS400800,,SCREW,1,,,,,,,,,,,,,
12,3,,XYSPS402400,,SCREW,6,,,,,,,,,,,,,
13,3,,24107-062010,, "BALL BEARING",1,,,,,,,,,,,,,
14,2,,129150-77230,, "FLYWHEEL ASSY",1,,,,,,,,,,,,,
15,1,,26366-100002,, "NUT M10",1,,,,,,,,,,,,,
16,1,,129410-77330,, "ADJUSTER, V-BELT",1,,,,,,,,,,,,,
17,1,,26014-080252,, "BOLT M 8X 25",1,,,,,,,,,,,,,

Fig. **16** ジェネレータ
GENERATOR



1,1,,729432-92600,, "GASKET SET(NON-ASB.)",1,,,,,,,,,,,,,
1-1,1,,729432-92601,, "GASKET SET(NON-ASB.)",1,,,,,,N,1,, "E/# 02309",,,,,,,
2,2,,129405-01330,, "GASKET, CYL.HEAD",1,,,,,,,,,,,,,
2-1,2,,129405-01331,, "GASKET, (NON-ASB.)",1,,,,,,R,, "E/# 12496",,,,,,,
3,2,,124240-01882,, "GASKET, HYD.OIL PUMP",1,,,,,,Z,, EXXX,,,,,,
4,2,,121850-51960,, "O-RING, F.I.PUMP",1,,,,,,,,,,,,,
5,2,,129150-01660,, "GASKET,OIL SEAL CASE",1,,,,,,,,,,,,,
6,2,,124460-11340,, "SEAL, VALVE STEM",4,,,,,,,,,,,,,
7,2,,119625-11870,, "PROTECTOR, NOZZLE",4,,,,,,,,,,,,,
7-1,2,,119625-11871,, "PROTECTOR, NOZZLE",4,,,,,,R,, "E/# 12496",,,,,,,
8,2,,119625-11880,, "SEAT, NOZZLE",4,,,,,,,,,,,,,
9,2,,121420-01760,, "O-RING",1,,,,,,,,,,,,,
10,2,,129550-11310,, "GASKET, BONNET",1,,,,,,,,,,,,,
11,2,,129150-77510,, "GASKET, AIR HEATER",1,,,,,,,,,,,,,
11-1,2,,124150-77511,, "GASKET",1,,,,,,N,, "E/# 02309",,,,,,,
12,2,,129550-12110,, "GASKET, SUC.MANIFOLD",1,,,,,,,,,,,,,
12-1,2,,129550-12111,, "GASKET, (NON-ASB.)",1,,,,,,N,, "E/# 02309",,,,,,,
13,2,,129550-13110,, "GASKET, EXH.MANIFOLD",1,,,,,,,,,,,,,
14,2,,121400-11340,, "SEAL, VALVE STEM",4,,,,,,,,,,,,,
15,2,,129150-32020,, "GASKET, L.O. PUMP",1,,,,,,,,,,,,,
16,2,,129150-35040,, "GASKET, OIL STRAINER",1,,,,,,,,,,,,,
16-1,2,,129150-35041,, "GASKET, (NON-ASB.)",1,,,,,,N,, "E/# 02309",,,,,,,
17,2,,129150-35110,, "GASKET, BRACKET",1,,,,,,,,,,,,,
17-1,2,,129150-35111,, "GASKET, (NON-ASB.)",1,,,,,,N,, "E/# 02309",,,,,,,
18,2,,129100-42020,, "GASKET, C.W. PUMP",1,,,,,,,,,,,,,
19,2,,129795-49550,, "GASKET, THERMO.COVER",1,,,,,,,,,,,,,
19-1,2,,129795-49551,, "GASKET, (NON-ASB.)",1,,,,,,N,, "E/# 02309",,,,,,,
20,2,,129150-49810,, "GASKET, THERMOSTAT",1,,,,,,,,,,,,,
20-1,2,,129150-49811,, "GASKET, (NON-ASB.)",1,,,,,,N,, "E/# 02309",,,,,,,
21,2,,129100-49840,, "GASKET, THERMO. CASE",1,,,,,,,,,,,,,
22,2,,124465-44950,, "GASKET 16",2,,,,,,,,,,,,,
23,2,,24341-000500,, "O-RING 1A S-50.0",1,,,,,,,,,,,,,
24,2,,24311-000160,, "O-RING 1A P-16.0",1,,,,,,,,,,,,,
25,2,,24311-000180,, "O-RING 1A P-18.0",2,,,,,,,,,,,,,
26,2,,24311-000320,, "O-RING 1A P-32.0",2,,,,,,,,,,,,,
27,1,,129400-92420,, "FLEX HORN",1,,,,,,1,,,,,,,,,
28,1,,977770-01212,, "GASKET, LIQUID",1,,,,,,1,,,,,,,,

Fig. **17** パッキンセット (オプション) & 工具
GASKET SET (OPTIONAL) & TOOL



0,Y00B4401
1,001,, "ENGINE 4TN84L-RBB"
2,1,, "CYLINDER BLOCK",4TN84L-RBB,,,
2,2,, "GEAR HOUSING",4TN84L-RBB,,,
2,3,, "FLYWHEEL HOUSING & OIL SUMP",4TN84L-RBB,,,
2,4,, "CYLINDER HEAD & BONNET",4TN84L-RBB,,,
2,5,, "SUC./ EXH.MANIFOLD & CLEANER",4TN84L-RBB,,,
2,6,, "CAMSHAFT & DRIVING GEAR",4TN84L-RBB,,,
2,7,, "CRANKSHAFT & PISTON",4TN84L-RBB,,,
2,8,, "LUB. OIL SYSTEM",4TN84L-RBB,,,
2,9,, "COOLING WATER SYSTEM",4TN84L-RBB,,,
2,10,, "FUEL INJECTION PUMP",4TN84L-RBB,,,
2,11,, "FUEL INJECTION PIPE",4TN84L-RBB,,,
2,12,, "FUEL PIPE",4TN84L-RBB,,,
2,13,, GOVERNOR,4TN84L-RBB,,,
2,14,, "STARTING MOTOR(PREVIOUS)",4TN84L-RBB,,,
2,15,, "STARTING MOTOR(NEW)",4TN84L-RBB,,,
2,16,, GENERATOR,4TN84L-RBB,,,
2,17,, "GASKET SET(OPTIONAL) & TOOL",4TN84L-RBB,,,